

Innovating Energy Technology

Efficient for Ecology



FRENIC-eHVAC

User's Manual

Thank you for purchasing our multifunction FRENIC-eHVAC series of inverters.

- This product is designed to drive a three-phase motor under variable speed control. Read through this user's manual and become familiar with the handling procedure for correct use.
- Improper handling might result in incorrect operation, a short life, or even a failure of this product as well as the motor.
- Deliver this manual to the end user of this product. Keep this manual in a safe place until this product is discarded.
- For how to use an optional device, refer to the instruction and installation manuals for that optional device.

Copyright © 2015 Fuji Electric Co., Ltd.

All rights reserved.

No part of this publication may be reproduced or copied without prior written permission from Fuji Electric Co., Ltd.

All products and company names mentioned in this manual are trademarks or registered trademarks of their respective holders.

The information contained herein is subject to change without prior notice for improvement.

The purpose of this user's manual is to provide accurate information in handling, setting up and operating of the FRENIC-eHVAC series of inverters. Please feel free to send your comments regarding any errors or omissions you may have found, or any suggestions you may have for generally improving the manual.

In no event will Fuji Electric Co., Ltd. be liable for any direct or indirect damages resulting from the application of the information in this manual.

Preface

Thank you for purchasing our multifunction FRENIC-eHVAC series of inverters. This product is designed to drive a three-phase induction motor or a three-phase permanent magnet synchronous motor under variable speed control.

This manual provides all the information on the FRENIC-eHVAC series of inverters including its operating procedure and selection of peripheral equipment. Before use, carefully read this manual for proper use. Improper handling might result in incorrect operation, a short life, or even a failure of this product as well as the motor.

The table below lists the other materials related to the use of the FRENIC-eHVAC. Read them in conjunction with this manual if necessary.

Name	Material No.	Description
Catalog	24A1-E-0097	Product scope, features, specifications, external drawings, and options of the product Described in Chinese
RS-485 User's Manual Supplement version	24A1-E-0099	Overview of functions implemented by using FRENIC-eHVAC RS-485 communications facility, its communications specifications, Modbus RTU/Fuji general-purpose inverter protocol, function codes and related data formats

The materials are subject to change without notice. Be sure to obtain the latest editions for use.

How this manual is organized

This manual contains Chapters 1 through 13 and Appendices.

Chapter 1 BEFORE USE

This chapter describes the items to checked before the use of the inverter.

Chapter 2 INSTALLATION AND WIRING

This chapter describes the important points in installing and wiring inverters.

Chapter 3 OPERATION USING THE KEYPAD

This chapter describes keypad operation of the inverter.

Chapter 4 TEST RUN PROCEDURE

This chapter describes basic settings required for making a test run.

Chapter 5 FUNCTION CODE

This chapter explains the table of function codes used in FRENIC-eHVAC, and the detail of each function code.

Chapter 6 TROUBLESHOOTING

This chapter describes troubleshooting procedures to be followed when the inverter malfunctions or detects an alarm or a light alarm condition. In this chapter, first check whether any alarm code or the "light alarm" indication $(L - \overline{D}_{L})$ is displayed or not, and then proceed to the troubleshooting items.

Chapter 7 MAINTENANCE AND INSPECTION

This chapter describes the maintenance and inspection items of the inverter.

Chapter 8 BLOCK DIAGRAMS FOR CONTROL LOGIC

This chapter describes the main block diagrams of the control section.

Chapter 9 COMMUNICATION FUNCTIONS

This chapter describes an overview of inverter operation through the RS-485 and CANopen communications. For details of RS-485 communication, refer to the RS-485 Communication User's Manual (24A7-E-0021).

Chapter 10 SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES

This chapter provides you with information about the inverter output torque characteristics, selection procedure, and equations for calculating capacities to help you select optimal motor and inverter models. It also helps you select braking resistors, and motor drive control.

Chapter 11 SELECTING Peripheral EQUIPMENT

This chapter describes how to use a range of peripheral equipment and options, FRENIC-eHVAC's configuration with them, and requirements and precautions for selecting wires and crimp terminals.

Chapter 12 SPECIFICATIONS

This chapter describes the output ratings, input power, basic functions and other specifications of the FRENIC-eHVAC standard model.

Chapter 13 EXTERNAL DIMENSIONS

This chapter gives external dimensions of the inverter.

APPENDICES

CONTENTS

Chapter 1 BEFORE USE	
1.1 Acceptance Inspection (Nameplates and Inverter Type)	1-1
1.2 External View and Terminal Blocks	1-3
1.3 Precautions for Using Inverters	1-5
1.3.1 Usage environment	1-5
1.3.2 Storage environment	1-7
[1] Temporary storage	1-7
[2] Long-term storage	1-7
1.3.3 Precautions for connection of peripheral equipment	1-8
[1] Phase-advancing capacitors for power factor correction	1-8
[2] Power supply lines (Application of a DC/AC reactor)	1-8
[3] DC reactor (DCR) for correcting the inverter input power factor (for suppressing harmonics)	1-8
[4] PWM converter for correcting the inverter input power factor	1-8
[5] Molded case circuit breaker (MCCB) / residual-current-operated protective device (R earth leakage circuit breaker (ELCB)	.CD) / 1-9
[6] Magnetic contactor (MC) in the inverter input (primary) circuit	
[7] Magnetic contactor (MC) in the inverter output (secondary) circuit	
[8] Surge absorber/surge killer	
1.3.4 Noise reduction	1-10
1.3.5 Leakage current	1-10
1.3.6 Precautions in driving a permanent magnet synchronous motor (PMSM)	1-10
Chapter 2 INSTALLATION AND WIRING	
2.1 Installation	2-1
2.2 Wiring	2-3
2.2.1 Basic connection diagram	2-3
2.2.7 Basic connection diagram	2-5
223 Precautions for wiring	2-8
2.2.4 Precautions for long wiring (between inverter and motor)	2-10
2.2.5 Main circuit terminals	
[1] Screw specifications	
[2] Terminal lavout diagram (main circuit terminal)	
[3] Recommended wire size (main circuit terminals)	
[4] Description of terminal functions (main circuit terminal)	
2.2.6 Control circuit terminals (common to all models)	2-26
[1] Screw specifications and recommended wire size (control circuit terminals)	
[2] Terminal lavout diagram (control circuit terminal)	
[3] Description of terminal functions (control circuit terminal)	2-27
2.2.7 Switching connector (types FRN0176F2F-4G or above)	2-35
2.2.8 Operating slide switches	
2.1 Names and European of Keynad Components	2.1
3.1 Names and Functions of Reypad Components	۱-د د د
3.2 Overview of Operation Modes	
3.3 Ruilling Mode	
3.3.1 Monitoring light clormo	
3.3.2 NUTITUTITY TYTE diditions	/-ى ە د
2.2.4 Sotting up reference frequency from the keynod	۵- د
3.3.4 Setting up reference frequency from the keypad	
5.5.5 Setting up FID control Intercess control	

[2] Settings under external PID control	3-12
3.3.6	Remote and local modes	3-13
3.4 P	rogramming Mode	3-14
3.4.1	Setting up function codes "Data Setting: $/$ through $/$ "	3-15
3.4.2	Checking changed function codes "Data Checking: 2,-EP" "	3-16
3.4.3	Monitoring the running status "Drive Monitoring:	3-17
3.4.4	Checking I/O signal status "I/O Checking: 4 "".	3-21
3.4.5	Reading maintenance information "Maintenance Information: 5,5,5,6,5,7,5,7,5,7,5,7,5,7,7,7,7,7,7,7,	3-25
3.4.6	Reading alarm information "Alarm Information: 5,92"	3-29
3.4.7	Copying data "Data Copying: """"	3-32
3.4.8	Setting up basic function codes quickly "Quick Setup: 2,57,2"	3-36
3.5 A	larm Mode	3-38
3.5.1	Releasing the alarm and switching to Running mode	3-38
3.5.2	Displaying the alarm history	3-38
3.5.3	Displaying the status of inverter at the time of alarm	3-38
3.5.4	Switching to Programming mode	3-38
Chapter 4 11		
4.1 16	est Run Procedure Flowchart	
4.2 C		
4.3 P	owering ON and Checking	
4.4 5		
4.4.1	V/r control with slip compensation inactive for IM	
4.4.2	Vector Control without speed sensor and magnetic pole position sensor for PMSM	
4.5 C	onfiguring Function Codes for Drive Controls	
4.5.1	Driving an induction Motor (IM)	
[1	Driving a non-Fuji motor or Fuji non-standard IM under the V/f control	
[2	J Driving a Fuji general-purpose IM under the V/t control	
[3] Tuning (For IM)	4-8
4.5.2	and magnetic note position sensor	1-11
1 1	1 Driving a non-Euli PMSM	۲۱-4-11 1_1_4
[2	 Driving a Fuji dedicated PMSM (GNB2 series) 	4-16
[3	 Driving a Fuji pon-dedicated PMSM (pon-GNB2 series) 	4-16
46 R	unning the Inverter for Motor Operation Check	4-17
4.0 1		
462	Check points during a test run	4-17
463	Modification of motor control function code data	4-18
4.7 S	electing a Frequency Command Source	4-19
4.7.1	Setting up a frequency command from the keypad	
472	Setting up a frequency command with an external potentiometer	4-19
473	Setting up a frequency command with multistep frequency selection	4-20
4.8 S	electing a Run Command Source	
481	Setting up a run command from the keypad	4-21
482	Setting up a run command with digital input signals (terminals [FWD] and [REV])	4-21
4.0.2		
Chapter 5 Fl	JNCTION CODES	
5.1 F	unction Codes Overview	5-1
5.2 F	unction Codes Table	5-2
5.2.1	Supplementary note	5-2
5.2.2	Function codes table	
5.2.3	Factory default value per applicable electric motor capacitance	5-31

[1] When Fuji standard motor 8-series, or other motors are selected by motor selection	5 00
(Function code P99 = 0 or 4)	5-32
[2] When HP failing motor is selected by motor selection (Function code P99/A39 = 1)	5-33
5.3 1 E codes (Basic functions)	5-34
[1] Frequency setting by keynad (F01 = 0 (Factory default state) 8)	5-36
[2] Setting up a reference frequency using analog input (F01 = 1 to 3.5)	5-37
[3] Frequency setting by digital input signal "UP"/"DOWN" (F01=7)	5-43
[4] Frequency setting using pulse train input (F01=12)	5-44
5.3.2 E codes (Extension terminal functions)	5-80
5.3.3 C codes (Control functions)	5-116
5.3.4 P codes (Motor 1 parameters)	5-125
5.3.5 H codes (High performance functions)	5-130
[1] Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment	5-142
[2] Measuring the capacitance of DC link bus capacitor under ordinary operating conditions at power shutdown	5-143
5.3.6 A codes (Motor 2 parameters)	5-160
5.3.7 J codes (Applied functions)	. 5-161
[1] PID command with the \bigcirc / \bigcirc keys on the keypad (J02 = 0, factory default)	. 5-162
[2] PID command by analog inputs (J02 = 1)	5-162
[3] PID command with UP/DOWN control (J02 = 3)	5-165
[4] PID command via communications link (J02 = 4)	5-165
[5] Pump control	. 5-176
5.3.8 d codes (Applied functions 2)	. 5-228
[1] Speed control (Vector control without speed sensor nor pole position sensor for PMSM)	. 5-228
5.3.9 U codes (Customizable logic operation)	5-232
5.3.10 U1 codes (Customizable logic operation)	. 5-257
5.3.11 y codes (Link functions)	. 5-261
Chapter 6 TROUBLESHOOTING	
6.1 Protective Function	6-1
6.2 Before Proceeding with Troubleshooting	6-2
6.3 If an Alarm Code Appears on the LED Monitor	6-3
6.3.1 Alarm code list	6-3
6.3.2 Causes, checks and measures of alarms	6-6
[1] Lor PID feedback wire break	6-6
[2] $d = R$ Braking transistor broken	6-6
[3]	6-6
[4] ELL Customizable logic failure	6-7
[5] <i>EF</i> Ground fault	6-7
[6] <i>E</i> / Memory error	6-7
[7] $\mathcal{E}_{\mathcal{T}}\mathcal{L}$ Keypad communications error	6-8
[8] <i>Er-3</i> CPU error	6-8
[9] <i>Er-</i> ^レ Option communications error	6-8
[10] \mathcal{E} -S Option error	6-8
[11] $E - S$ Operation error	6-9
[12] <i>Er-</i> 7 Tuning error	6-9
[13] $E_{\Gamma}B$ RS-485 communications error (Communications port 1)/	
とーーー RS-485 communications error (Communications port 2)	6-10
[14] <i>Erd</i> Step-out detection/detection failure of magnetic pole position at startup	6-11
[15] End Speed inconsistency / Excessive speed deviation	6-12
[16] <i>と</i> ーケ Data saving error during undervoltage	6-13
1171 たこと Hardware error	6-13

[18] <i>Err</i> -	Simulated failure	6-13
[19] <i>FLI</i> 5	DC fuse-blowing	6-13
[20] <u>/</u> "¬	Input phase loss	6-14
[21] <i>Lor^L</i>	Password Protection	6-14
[22] ///	Undervoltage	6-15
[23] [[[Instantaneous overcurrent	6-16
[24] []H /	Cooling fin overheat	6-17
[25] <i>[] - - </i>	External alarm	6-17
[26] <i>[]H]</i>	Inverter internal overheat	6-17
[27] []	Motor protection (PTC thermistor)	6-18
[28] <i>[]H5</i>	Charging resistor overheat	6-18
[29] []L /	Motor overloads 1	6-19
[30] <i>[]LL</i> /	Inverter overload	6-20
[31] <i>[][</i> []	Output phase-failure detection	6-20
[32] [35]	Overspeed protection	6-21
[33] [][[]	Overvoltage	6-21
[34] <i>FbF</i>	Charge circuit fault	6-22
6.4 If the "Light	Alarm" Indication $(L - AL)$ Appears on the LED Monitor	6-23
6.5 When Code	es Other Than Alarm Codes and Light Alarm Indication $(\angle -P \angle)$ are Displayed	6-24
6.5.1 Abnorma	al motor operation	
[1] The n	notor does not rotate	6-24
[2] The n	notor rotates, but the speed does not increase	6-26
[3] Then	notor runs in the opposite direction to the command	
[4] Spee	d fluctuation or current oscillation (e.g., hunting) occurs during running	
at cor	istant speed	6-28
[5] Unple	asant noises are emitted from motor or noises fluctuate	6-29
[6] Motor	is not accelerated or decelerated according to set-up acceleration	
or dec	celeration times	6-29
[7] The n	notor does not restart even after the power recovers	
from a	a momentary power failure	6-30
[8] Motor	generates heat abnormally	6-30
[9] The n	notor does not run as expected	6-30
[10] Motor	stalls during acceleration	6-31
6.5.2 Problem	s with inverter settings	6-32
[1] Nothi	ng appears on the LED monitor	6-32
[2] The d	lesired menu is not displayed	6-32
[3] Displa	ay of under bars ()	6-33
[4] Displa	ay of center bars ()	6-33
[5] [J Display of parenthesis	6-33
[6] Data	of function codes cannot be changed	6-34
[7] Funct	ion code data are not changeable (change from link functions)	6-34
Chapter 7 MAINTENA	NCE AND INSPECTION	
7.1 Inspection	Interval	7-1
7.2 Daily Inspe	ction	7-2
7.3 Periodic Ins	spection	7-3
7.3.1 Periodic	inspection 1Before the inverter is powered ON or after it stops running	7-3
7.3.2 Periodic	inspection 2When the inverter is ON or it is running	7-4
7.4 List of Perio	odic Replacement Parts	7-5
7.4.1 Judgmei	nt on service life	7-6
[1] Meas	uring the capacitance of DC link bus capacitor in comparison	
with in	nitial one at shipment	7-7
[2] Meas	uring the capacitance of the DC link bus capacitor	
under	ordinary operating conditions	7-8

[3] Early warning of lifetime alarm	7-8
7.5 Measurement of Electrical Amounts in Main Circuit	7-9
7.6 Insulation Test	7-10
7.7 Inquiries about Product and Guarantee	7-11
7.7.1 When making an inquiry	7-11
7.7.2 Product warranty	7-11
[1] Free of charge warranty period and warranty range	
[2] Exclusion of liability for loss of opportunity, etc.	
[3] Repair period after production stop, spare parts supply period (holding period)	7-12
[4] Transfer rights	7-12
[5] Service contents	7-12
[6] Applicable scope of service	7-12
Chapter 8 BLOCK DIAGRAMS FOR CONTROL LOGIC	
8.1 Meanings of Symbols Used in the Control Block Diagrams	8-1
8.2 Frequency Setting Section	
8.3 Operation Command Section	8-5
8.4 PID Control Section (for Processing)	8-6
8.5 PID Control Section (External PID)	8-7
8.6 Control Section	8-8
	0-0
8.6.2 Vector Control	
[1] Common	8-10
[2] Torque limit	8-10
[3] Speed limit and Over speed protection processing	8-11
[4] For PMSM	8-12
8.7 FM Output Section	8-14
0.1 Overview of BS 485 Communication	0.1
9.1 Overview of RS-485 Communication	
9.1.1 RS-485 common specifications	
9.1.2 Ierminal specifications	
[1] RS-485 communication port 1 (for connecting the keypad)	
[2] RS-485 communication port 2 (terminal block)	
9.1.3 Connection method	
9.1.4 RS-485 connection devices	
[1] Converter	
[2] Requirements for the cable (COM port 1: for RJ-45 connector)	
[3] Requirements for the cable (COM port 2: for RS-485 connector)	
[4] Branch adapter for multi-drop	
9.1.5 RS-485 noise suppression	
9.2 FRENIC Loader Overview	
9.2.1 Modes	9-8
9.2.2 Connection	
9.2.3 Function overview	
[1] Configuring inverter's function code	
[2] Multi-monitor	
[3] Running status monitor	
[4] Test-running	9-12
[5] Real-time trace	Q_13
[6] Historical trace	Q_1/

Chapter 10 SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES

10.1 N	Notor Output Torque Characteristics	
10.2 S	Selection Procedure	10-3
10.3 E	Equations for Selections	
10.3.1	Load torque during constant speed running	
[1	1] General equation	
[2	2] Obtaining the required force F	
10.3.2	Acceleration and deceleration time calculation	10-8
[1	1] Calculation of moment of inertia	
[2	2] Calculation of the acceleration time	
[3	3] Calculation of the deceleration time	10-11
[4	4] Calculating non-linear acceleration/deceleration time	
[{	5] Calculating non-linear deceleration time	
10.3.3	B Heat energy calculation of braking resistor	10-13
[^	1] Calculation of regenerative energy	10-13
10.3.4	Calculating the RMS rating of the motor	
10.4 S	Selecting an Inverter Drive Mode	10-15
10.4.1	Precaution in making the selection	

Chapter 11 SELECTING PERIPHERAL EQUIPMENT

11.1 Configuring the FRENIC-eHVAC	11-1
11.2 Currents Flowing Across the Inverter Terminals	11-2
11.3 Molded Case Circuit Breaker (MCCB), Residual-current-operated Protective Device (RCD)/	
Earth Leakage Circuit Breaker (ELCB) and Magnetic Contactor (MC)	11-3
11.3.1 Function overview	11-3
11.3.2 Connection example and criteria for selection of circuit breakers	11-4
11.4 Surge Killers for L-load	11-7
11.5 Arresters	11-8
11.6 Surge Absorbers	11-9
11.7 Filtering Capacitors Suppressing AM Radio Band Noises	11-10
11.8 Braking Resistors (DBRs) and Braking Units	11-11
11.8.1 Selecting a braking resistor	11-11
[1] Selection procedure	11-11
[2] Notes on selection	11-11
11.8.2 Braking resistors (DBRs)	11-12
[1] Standard model	11-12
[2] 10%ED model	11-12
11.8.3 Braking units	11-13
11.8.4 Specifications	11-14
11.8.5 External dimensions	11-16
11.9 Power Regenerative PWM Converters, RHC Series	11-18
11.9.1 Overview	11-18
11.9.2 Specifications	11-19
[1] Standard specifications	11-19
[2] Common specifications	11-20
11.9.3 Function specifications	11-21
11.9.4 Converter configuration	11-25
11.9.5 External dimensions	11-27
11.10 DC Reactors (DCRs)	11-32
11.11 AC Reactors (ACRs)	11-35
11.12 Surge Suppression Unit (SSU)	11-37
11.13 Output Circuit Filters (OFLs)	11-38
11.14 Zero-phase Reactors for Reducing Radio Noise (ACLs)	11-40
11.15 External Cooling Fan Attachments	11-41

11.16 External Frequency Command Potentiometer	11-42
11.17 Extension Cable for Remote Operation	11-43
11.18 Frequency Meters	11-44
11.19 Options for communication and operation overview	11-45
11.19.1 Mounting adapter (for communication option card)	11-45
11.19.2 Communication option cards (required mounting adapter required)	11-45
11.19.3 Terminal block type options	11-45
11.19.4 Option keypad	11-45
11.20 DeviceNet communications card (OPC-DEV)	11-46
11.20.1 DeviceNet specifications	11-46
11.21 CC-Link communications card (OPC-CCL)	11-47
11.21.1 CC-Link specifications	11-47
11.22 Analog interface card (OPC-AIO)	11-48
11 23 RTD Card (OPC-PT)	11-51
11 24 JonWorks Card (OPC-I NW)	11-52
11 25 Relay Output Card (OPC-F2-RY)	11-53
11.26 Simple keypad with USB port (TP-F11)	11-54
11.27 Multi functional keynad (TP-A1)	11_55
11.28 EPENIC Visual Customizer	11-56
	11-50
	11-50
11.20.2 Specifications	11-50
11.20.5 Fullouoris	11-50
	11-57
Chapter 12 SPECIFICATIONS	
12.1 Standard Model	. 12-1
12.1.1 Inverters for general load	. 12-1
12.2 Common Specifications	. 12-4
Chapter 13 EXTERNAL DIMENSIONS	
13.1 Standard Model	. 13-1
APPENDICES	
Appendix A Trouble-free Use of Inverters (Notes on electrical noise)	1
A.1 Effect of inverters on other devices	1
[1] Effect on AM radios	1
[2] Effect on telephones	1
[3] Effect on proximity switches	1
[4] Effect on pressure sensors	1
[5] Effect on position detectors (pulse encoders)	1
A.2 Noise	2
[1] Inverter noise	2
[2] Types of noise	3
A.3 Measures	5
[1] Noise prevention prior to installation	5
[2] Implementation of noise prevention measures	5
[3] Noise prevention examples	8
Appendix B Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage (General-purpose inverter)	12
B 1 Application to general-purpose inverters	12
[1] Guideling for suppressing barmonics in home electric and general purpose appliances	i2 10
[1] Guideline for suppressing harmonics in nome electric and general-purpose appliances	12
or special high voltage	12
B 2 Compliance to the harmonic suppression for customers receiving high voltage	
or special high voltage	13
	-

[1] Calculation of equivalent capacity (Pi)	13
[2] Calculation of harmonic current	14
[3] Examples of calculation	16
Appendix C Effect on Insulation of General-purpose Motors Driven with 400 V Class Inverters	17
C.1 Generating mechanism of surge voltages	17
C.2 Effect of surge voltages	18
C.3 Countermeasures against surge voltages	19
[1] Using a surge suppressor unit, SSU (Patent pending)	19
[2] Suppressing surge voltages	19
[3] Using motors with enhanced insulation	19
C.4 Regarding existing equipment	20
[1] In case of a motor being driven with 400 V class inverter	20
[2] In case of an existing motor driven using a newly installed 400 V class inverter	20
Appendix D Inverter Generating Loss	21
Appendix E Conversion from SI Units	22
E.1 Conversion of units	22
E.2 Calculation formulas	23
Appendix F Allowable Current of Insulated Wires	24
Appendix G Conformity with Standards	26
G.1 Compliance with European Standards (CE)	26
[1] Compliance with EMC standards	26
[2] Compliance with the low voltage directive in the EU	29
G.2 Compliance with UL Standards and Canadian Standards (cUL certification) (🖓 usus)	32
Appendix H Compliance with Management Methods for Controlling Pollution Caused	
by Electronic Information Products Regulation (China RoHS)	36

■ Safety precautions

Read this manual thoroughly before proceeding with installation, connections (wiring), operation, or maintenance and inspection. Ensure you have sound knowledge of the device and familiarize yourself with all safety information and precautions before proceeding to operate the inverter.

Safety precautions are classified into the following two categories in this manual.

Failure to heed the information indicated by this symbol may lead to dangerous conditions, possibly resulting in death or serious bodily injuries.
Failure to heed the information indicated by this symbol may lead to dangerous conditions, possibly resulting in minor or light bodily injuries and/or substantial property damage.

Failure to heed the information contained under the CAUTION title can also result in serious consequences. These safety precautions are of utmost importance and must be observed at all times.

Application

• The FRENIC-eHVAC is designed to drive a three-phase induction motor. Do not use it for single-phase motors or for other purposes.

Fire or an accident could occur.

- The FRENIC-eHVAC may not be used for a life-support system or other purposes directly related to the human safety.
- Though the FRENIC-eHVAC is manufactured under strict quality control, install safety devices for applications where serious accidents or property damages are foreseen in relation to the failure of it. **An accident could occur.**

Installation

△ WARNING ▲

- Install the inverter on a base made of metal or other non-flammable material. Otherwise, a fire could occur.
- Do not place flammable object nearby.

Doing so could cause fire.

• Inverters FRN0075F2E-4G or above, whose protective structure is IP00, involve a possibility that a human body may touch the live conductors of the main circuit terminal block. Inverters to which an optional DC reactor is connected also involve the same. Install such inverters in an inaccessible place.

Otherwise, electric shock or injuries could occur.

- Do not support the inverter by its front cover during transportation. Doing so could cause a drop of the inverter and injuries.
- Prevent lint, paper fibers, sawdust, dust, metallic chips, or other foreign materials from getting into the inverter or from accumulating on the heat sink.
- When changing the positions of the top and bottom mounting bases for external cooling, use only the specified screws.

Otherwise, a fire or an accident might result.

Do not install or operate an inverter that is damaged or lacking parts.
 Doing so could cause fire, an accident or injuries.

Wiring

• If no zero-phase current (earth leakage current) detective device such as a ground-fault relay is installed in the upstream power supply line, in order to avoid the entire power supply system's shutdown undesirable to factory operation, install a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) individually to inverters to break the individual inverter power supply lines only.

Otherwise, a fire could occur.

- When wiring the inverter to the power source, insert a recommended molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection) in the path of each pair of power lines to inverters. Use the recommended devices within the recommended current capacity.
- Use wires in the specified size.
- Tighten terminals with specified torque. Otherwise, a fire could occur.
- When there is more than one combination of an inverter and motor, do not use a multicore cable for the purpose of handling their wirings together.
- Do not connect a surge killer to the inverter's output (secondary) circuit.
 Doing so could cause a fire.
- Be sure to connect an optional DC reactor (DCR) when the capacity of the power supply transformer exceeds 500 kVA and is 10 times or more the inverter rated capacity. **Otherwise, a fire could occur.**
- Ground the inverter in compliance with the national or local electric code.
- Be sure to ground the inverter's grounding terminals eG.
 Otherwise, an electric shock or a fire could occur.
- Qualified electricians should carry out wiring.
- Be sure to perform wiring after turning the power OFF. Otherwise, an electric shock could occur.
- Be sure to perform wiring after installing the inverter unit. Otherwise, an electric shock or injuries could occur.
- Ensure that the number of input phases and the rated voltage of the product match the number of phases and the voltage of the AC power supply to which the product is to be connected. **Otherwise, a fire or an accident could occur.**
- Do not connect the power supply wires to output terminals (U, V, and W).
- When connecting a DC braking resistor (DBR), never connect it to terminals other than terminals P(+) and DB.

Doing so could cause fire or an accident.

In general, sheaths of the control signal wires are not specifically designed to withstand a high voltage (i.e., reinforced insulation is not applied). Therefore, if a control signal wire comes into direct contact with a live conductor of the main circuit, the insulation of the sheath might break down, which would expose the signal wire to a high voltage of the main circuit. Make sure that the control signal wires will not come into contact with live conductors of the main circuit.

Doing so could cause an accident or an electric shock.

A WARNING A

 Before changing the switches or touching the control circuit terminal symbol plate, turn OFF the power and wait at least five minutes for inverters FRN0060F2E-4G or below, or at least ten minutes for inverters FRN0075F2E-4G or above. Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).

Otherwise, an electric shock could occur.

 The inverter, motor and wiring generate electric noise. Be careful about malfunction of the nearby sensors and devices. To prevent them from malfunctioning, implement noise control measures.
 Otherwise an accident could occur.

• Be sure to mount the front cover before turning the power ON. Do not remove the cover when the inverter power is ON. Otherwise, an electric shock could occur. Do not operate switches with wet hands. Doing so could cause electric shock. If the auto-reset function has been selected, the inverter may automatically restart and drive the motor depending on the cause of tripping. Design the machinery or equipment so that human safety is ensured at the time of restarting. Otherwise, an accident could occur. If the stall prevention function (current limiter), automatic deceleration (anti-regenerative control), or overload prevention control has been selected, the inverter may operate with acceleration/deceleration or frequency different from the commanded ones. Design the machine so that safety is ensured even in such cases. The *w* key on the keypad is effective only when the keypad operation is enabled with function code F02 (= 0, 2 or 3). When the keypad operation is disabled, prepare an emergency stop switch separately for safe operations. Switching the run command source from keypad (local) to external equipment (remote) by turning ON the "Enable communications link" command *LE* disables the im key. To enable the im key for an emergency stop, select the every key priority with function code H96 (= 1 or 3). • If any of the protective functions have been activated, first remove the cause. Then, after checking that the all run commands are set to OFF, release the alarm. If the alarm is released while any run commands are set to ON, the inverter may supply the power to the motor, running the motor. Otherwise, an accident could occur. If you enable the "Restart mode after momentary power failure" (Function code F14 = 3 to 5), then the inverter automatically restarts running the motor when the power is recovered. Design the machinery or equipment so that human safety is ensured after restarting. If the user configures the function codes wrongly without completely understanding this User's Manual, the motor may rotate with a torque or at a speed not permitted for the machine. Starting auto-tuning involves motor rotation. Sufficiently check that motor rotation brings no danger beforehand. An accident or injuries could occur. Even if the inverter has interrupted power to the motor, if the voltage is applied to the main circuit input terminals L1/R, L2/S, L3/T voltage may be output to inverter output terminals U, V, and W. Even if the motor is stopped due to DC braking or preliminary excitation, voltage is output to inverter output terminals U, V, and W. An electric shock may occur. The inverter can easily accept high-speed operation. When changing the speed setting, carefully check the specifications of motors or equipment beforehand. Otherwise, injuries could occur. • Do not touch the heat sink and braking resistor because they become very hot. Doing so could cause burns. The DC brake function of the inverter does not provide any holding mechanism. Injuries could occur. Ensure safety before modifying the function code settings. Run commands (e.g., "Run forward" FWD), stop commands (e.g., "Coast to a stop" BX), and frequency change commands can be assigned to digital input terminals. Depending upon the assignment states of those terminals, modifying the function code setting may cause a sudden motor start or an abrupt change in speed. When the inverter is controlled with the digital input signals, switching run or frequency command sources with the related terminal commands (e.g., SS1, SS2, SS4, SS8, Hz2/Hz1, Hz/PID, IVS, and LE) may cause a

sudden motor start or an abrupt change in speed.
Ensure safety before modifying customizable logic related function code settings (U codes and related function codes) or turning ON the "Cancel customizable logic" terminal command *CLC*. Depending upon the settings, such modification or cancellation of the customizable logic may change the operation sequence to cause a sudden motor start or an unexpected motor operation.

An accident or injuries could occur.

 Before proceeding to the maintenance/inspection jobs, turn OFF the power and wait at least five minutes for inverters FRN0060F2E-4G or below, or at least ten minutes for inverters FRN0075F2E-4G or above. Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).

Otherwise, an electric shock could occur.

- Always carry out the daily and periodic inspections described in the instruction/user's manual. Use of the
 inverter for long periods of time without carrying out regular inspections could result in malfunction or
 damage, and an accident or fire could occur.
- It is recommended that periodic inspections be carryout every one to two years, however, they should be carried out more frequently depending on the usage conditions.
- It is recommended that parts for periodic replacement be replaced in accordance with the standard replacement frequency indicated in the user's manual. Use of the product for long periods of time without replacement could result in malfunction or damage, and an accident or fire could occur.
- Contact outputs [30A/B/C] use relays, and may remain ON, OFF, or undetermined when their lifetime is reached. In the interests of safety, equip the inverter with an external protective function.

Otherwise, an accident or fire could occur.

- Maintenance, inspection, and parts replacement should be made only by qualified persons.
- Take off the watch, rings and other metallic objects before starting work.
- Use insulated tools.

Otherwise, an electric shock or injuries could occur.

• Never modify the inverter.

Doing so could cause an electric shock or injuries.

Disposal

• Treat the inverter as an industrial waste when disposing of it. Otherwise injuries could occur.

GENERAL PRECAUTIONS

Drawings in this manual may be illustrated without covers or safety shields for explanation of detail parts. Restore the covers and shields in the original state and observe the description in the manual before starting operation.

lcons

Tip

The following icons are used throughout this manual.

Note This icon indicates information which, if not heeded, can result in the inverter not operating to full efficiency, as well as information concerning incorrect operations and settings which can result in accidents.

This icon indicates information that can be useful when performing certain settings or operations.

This icon indicates a reference to more detailed information.

Chapter 1 BEFORE USE

This chapter explains the items to be checked before the use of the inverter.

Contents

1.1	Acce	eptance Inspection (Nameplates and Inverter Type) 1-1
1.2	Exte	rnal View and Terminal Blocks ······ 1-3
1.3	Prec	autions for Using Inverters 1-5
1.	.3.1	Usage environment ······ 1-5
1.	.3.2	Storage environment 1-7
[[1]	Temporary storage ······ 1-7
[[2]	Long-term storage ······ 1-7
1.	.3.3	Precautions for connection of peripheral equipment 1-8
I	[1]	Phase-advancing capacitors for power factor correction 1-8
[[2]	Power supply lines (Application of a DC/AC reactor) 1-8
[[3]	DC reactor (DCR) for correcting the inverter input power factor (for suppressing harmonics)
[[4]	PWM converter for correcting the inverter input power factor
I	[5]	Molded case circuit breaker (MCCB) / residual-current-operated protective device (RCD) /
		earth leakage circuit breaker (ELCB) ······ 1-9
[[6]	Magnetic contactor (MC) in the inverter input (primary) circuit 1-9
[[7]	Magnetic contactor (MC) in the inverter output (secondary) circuit 1-9
[[8]	Surge absorber/surge killer ····· 1-9
1.	.3.4	Noise reduction1-10
1.	.3.5	Leakage current
1.	.3.6	Precautions in driving a permanent magnet synchronous motor (PMSM)1-10

1.1 Acceptance Inspection (Nameplates and Inverter Type)

Unpack the package and check the following:

- (1) An inverter and the following accessories are contained in the package.
 - Accessories Keypad rear cover (with three screws for securing the keypad)
 - Instruction manual
 - CD-ROM (containing the FRENIC-eHVAC User's Manual)
- (2) The inverter has not been damaged during transportation—there should be no dents or parts missing.
- (3) The inverter is the type you ordered. You can check the type and specifications on the main nameplate. (The main and sub nameplates are attached to the inverter as shown on Figure 1.2-1.)

			FO Fuji E	lectric		REE:
			TYPE	FRN0045F2E	-4G	12
			SOURCE	3PH 380-480V 50 60.6A	0/60Hz	
F C Fuii E	lectric	19522	OUTPUT	3PH 380-480 0.1-120Hz 34kVA 45A 120%)V 6 1min	
YPE	FRN0002F2E-4G		NOTOD	20144/		
OURCE	3PH 380-480V 50/60Hz 2.7A		SER.No. 3Y	XX00A0001 AA	301	IP Code IP20
JTPUT	3PH 380-480V	● ※		Fuji Electric	ā 🗉	SCCR 100kA
	0.1-120Hz 1.3kVA 1.8A 120% 1min	Europe GmbH D-63057		IS LISTED Europe GmbH D-63067 7R98 IND CONT FD D-63067	ŭ2	MASS 10.5kg
OTOR	0.75kW	Offenbach am Main	E132902	am Main	- 1	WEIGHT 23lbs
R.No. 3YXX0	20 SCCR 100kA MASS 1.5kg DA0001 AA WEIGHT 3.3lbs	Made in Japan				Made in Japa

(a) Main Nameplate

TYPE	FRN0045F2E-4G	
SER.No.	3YXX00A0001 AA	







Figure 1.1-2 Type of inverter

TYPE: Type of inverter

SOURCE	: Number of input phases (three-phase: 3PH), input voltage, input frequency, input current		
OUTPUT	: Number of output phases, rated output voltage, output frequency range, rated output capacity, rated output current, and overload capability		
SCCR	: Short-circuit capacity		
MASS	: Mass of the inverter in kilogram		
SER. No.	: Product number 68A123A0579E BB 601 Production week This indicates the week number that is numbered from 1st week of January. The 1st week of January is indicated as '01'. Production year: Last digit of year Product version		
CE	: Compliance with European Standards (See Appendix G Section G-1)		
CUL)US LISTED	 Compliance with UL Standards and Canadian Standards (cUL certification) (See Appendix G Section G-2) 		

If you suspect the product is not working properly or if you have any questions about your product, contact your Fuji Electric representative.



1.2 **External View and Terminal Blocks**

(1) Outside and inside views



(b) FRN0176F2E-4G

Figure 1.2-1 Outside and Inside Views of Inverters

(2) Warning plates and label



(a) FRN0011F2E-4G

(b) FRN0060F2E-4G

Figure 1.2-2 Warning Plates and Label

1.3 Precautions for Using Inverters

This section provides precautions in introducing inverters, e.g. precautions for installation environment, power supply lines, wiring, and connection to peripheral equipment. Be sure to observe those precautions.

1.3.1 Usage environment

Install the inverter in an environment that satisfies the requirements listed in Table 1.3-1.

Table 1.3-1	Usage Environment
-------------	-------------------

Item	Specifications				
Site location	Indoors				
Ambient temperature	Standard (Open Type)			
	-10 to +40	0°C (14 to 104°F) (Note 1)			
	-10 to +50	0°C (14 to 122°F) (Note 2)			
	NEMA/UL T	ype1			
	-10 to +40	0°C (14 to 104°F)			
	-10 to +30	0°C (14 to 86°F)			
Relative humidity	5 to 95% RI	H (No condensation)			
Atmosphere	The inverter must not be exposed to dust, direct sunlight, corrosive gases, flammable				
	gases, oil m	nist, vapor or water drops.			
	Pollution degree 2 (IEC60664-1) (Note 3)				
	The atmosphere can contain a small amount of salt (0.01 mg/cm ² or less per year).				
	The inverter must not be subjected to sudden changes in temperature that will cause condensation to form.				
Altitude	1,000 m (3,	300 ft) max. (Note 4)			
Atmospheric pressure	86 to 106 kl	Pa			
Vibration	FRN0176F2	2E-4G or below	FRN0210F2	2E-4G or above	
	3 mm (Max.	amplitude) 2 to less than 9 Hz	3 mm (Max	. amplitude) 2 to less than 9 Hz	
	9.8 m/s ²	9 to less than 20 Hz	2 m/s ²	9 to less than 55 Hz	
	2 m/s ²	20 to less than 55 Hz	1 m/s ²	55 to less than 200 Hz	
	1 m/s ²	55 to less than 200 Hz			

(Note 1) Inverters used at a temperature range of 40°C to 50°C require current reduction. For details, refer to Chapter 10.

(Note 2) When inverters are mounted side-by-side without any clearance between them (FRN0060F2E-4G or below), the ambient temperature should be within the range from -10 to +40°C.

(Note 3) Do not install the inverter in an environment where it may be exposed to lint, cotton waste or moist dust or dirt which will clog the heat sink of the inverter. If the inverter is to be used in such an environment, install it in a dustproof panel of your system.

(Note 4) If you use the inverter in an altitude above 1,000 m (3,300 ft), you should apply an output current derating factor as listed in Table 1.3-2.

Altitude	Output current derating factor
1,000 m or lower (3,300 ft or lower)	1.00
1,000 to 1500 m (3,300 to 4,900 ft)	0.97
1,500 to 2,000 m (4,900 to 6,600 ft)	0.95
2,000 to 2,500 m (6,600 to 8,200 ft)	0.91
2,500 to 3,000 m (8,200 to 9,800 ft)	0.88

Table 1.3-2 Output Current Derating Factor in Relation to Altitude

Fuji Electric strongly recommends installing inverters in a panel for safety reasons, in particular, when installing the ones whose enclosure rating is IP00.

When installing the inverter in a place out of the specified environmental requirements, it is necessary to derate the inverter or consider the panel engineering design suitable for the special environment or the panel installation location. For details, refer to the Fuji Electric technical information "Engineering Design of Panels" or consult your Fuji Electric representative.

The special environments listed below require using the specially designed panel or considering the panel installation location.

Environments	Possible problems	Sample measures	Applications
Highly concentrated sulfidizing gas or other corrosive gases	Corrosive gases cause parts inside the inverter to corrode, resulting in an inverter malfunction.	 Any of the following measures may be necessary. Mount the inverter in a sealed panel with IP6X or air-purge mechanism. Place the panel in a room free from influence of the gases. 	Paper manufacturing, sewage disposal, sludge treatment, tire manufacturing, gypsum manufacturing, metal processing, and a particular process in textile factories.
A lot of conductive dust or foreign material (e.g., metal powders or shavings, carbon fibers, or carbon dust)	Entry of conductive dust into the inverter causes a short circuit.	 Any of the following measures may be necessary. Mount the inverter in a sealed panel. Place the panel in a room free from influence of the conductive dust. 	Wiredrawing machines, metal processing, extruding machines, printing presses, combustors, and industrial waste treatment.
A lot of fibrous or paper dust	Fibrous or paper dust accumulated on the heat sink lowers the cooling effect. Entry of dust into the inverter causes the electronic circuitry to malfunction.	 Any of the following measures may be necessary. Mount the inverter in a sealed panel that shuts out dust. Ensure a maintenance space for periodical cleaning of the heat sink in panel engineering design. Employ external cooling when mounting the inverter in a panel for easy maintenance and perform periodical maintenance. 	Textile manufacturing and paper manufacturing.
High humidity or dew condensation	In an environment where a humidifier is used or where the air conditioner is not equipped with a dehumidifier, high humidity or dew condensation results, which causes a short-circuiting or malfunction of electronic circuitry inside the inverter.	 Put a heating module such as a space heater in the panel. 	Outdoor installation. Film manufacturing line, pumps and food processing.
Vibration or shock exceeding the specified level	If a large vibration or shock exceeding the specified level is applied to the inverter, for example, due to a carrier running on seam joints of rails or blasting at a construction site, the inverter structure gets damaged.	 Insert shock-absorbing materials between the mounting base of the inverter and the panel for safe mounting. 	Installation of an inverter panel on a carrier or self-propelled machine. Ventilating fan at a construction site or a press machine.
Fumigation for export packaging	Halogen compounds such as methyl bromide used in fumigation corrodes some parts inside the inverter.	 When exporting an inverter built in a panel or equipment, pack them in a previously fumigated wooden crate. When packing an inverter alone for export, use a laminated veneer lumber (LVL). 	Exporting.

1.3.2 Storage environment

The storage environment in which the inverter should be stored after purchase differs from the usage environment. Store the inverter in an environment that satisfies the requirements listed below.

[1] Temporary storage

Table 1.3-3	Storage and Tra	ansport Environments

Item	Specifications			
Storage temperature *1	During transport: -25 to +70°C (-13 to +158°F)	Places not subjected to abrupt temperature changes or condensation or freezing		
	During storage: -25 to +65°C (-13 to +153°F)			
Relative humidity	5 to 95% RH * 2			
Atmosphere	The inverter must not be exposed to dust, direct sunlight, corrosive or flammable gases, oil mist, vapor, water drops or vibration. The atmosphere must contain only a low level of salt. (0.01 mg/cm ² or less per year)			
Atmospheric pressure	86 to 106 kPa (during storage)			
	70 to 106 kPa (during transportation)			

*1 Assuming comparatively short time storage, e.g., during transportation or the like.

*2 Even if the humidity is within the specified requirements, avoid such places where the inverter will be subjected to sudden changes in temperature that will cause condensation or freezing.

Precautions for temporary storage

- (1) Do not leave the inverter directly on the floor.
- (2) If the environment does not satisfy the specified requirements listed in Table 1.3-3, wrap the inverter in an airtight vinyl sheet or the like for storage.
- (3) If the inverter is to be stored in a high-humidity environment, put a drying agent (such as silica gel) in the airtight package described in (2) above.

[2] Long-term storage

The long-term storage method of the inverter varies largely according to the environment of the storage site. General storage methods are described below.

(1) The storage site must satisfy the requirements specified for temporary storage.

However, for storage exceeding three months, the surrounding temperature range should be within the range from -10 to +30°C (14 to 86°F). This is to prevent electrolytic capacitors in the inverter from deterioration.

- (2) The package must be airtight to protect the inverter from moisture. Add a drying agent inside the package to maintain the relative humidity inside the package within 70%.
- (3) If the inverter has been installed to the equipment or panel at construction sites where it may be subjected to humidity, dust or dirt, then temporarily remove the inverter and store it in the environment specified in Table 1.3-3.

Precautions for storage over 1 year

If the inverter has not been powered on for a long time, the property of the electrolytic capacitors may deteriorate. Power the inverters on once a year and keep the inverters powering on for 30 to 60 minutes. Do not connect the inverters to the load circuit (secondary side) or run the inverter.

1.3.3 Precautions for connection of peripheral equipment

[1] Phase-advancing capacitors for power factor correction

Do not mount a phase-advancing capacitor for power factor correction in the inverter's input (primary) or output (secondary) circuit. Mounting it in the input (primary) circuit takes no effect. To correct the inverter power factor, use an optional DC reactor (DCR). Mounting it in the output (secondary) circuit causes an overcurrent trip, disabling operation.

An overvoltage trip that occurs when the inverter is stopped or running with a light load is assumed to be due to surge current generated by open/close of phase-advancing capacitors in the power system. An optional DC/AC reactor (DCR/ACR) is recommended as a measure to be taken at the inverter side.

Inverter input current to an inverter contains harmonic components that may affect other motors and phase-advancing capacitors on the same power supply line. If the harmonic components cause any problems, connect a DCR/ACR to the inverter. In some cases, it is necessary to insert a reactor in series with the phase-advancing capacitors.

[2] Power supply lines (Application of a DC/AC reactor)

Use a DC reactor (DCR) when the capacity of the power supply transformer is 500 kVA or more and is 10 times or more the inverter rated capacity or when there are thyristor-driven loads. If no DCR is used, the percentage-reactance of the power supply decreases, and harmonic components and their peak levels increase. These factors may break rectifiers or capacitors in the converter section of the inverter, or decrease the capacitance of the capacitors.

If the input voltage unbalance rate is between 2% and 3%, use an optional AC reactor (ACR).

[3] DC reactor (DCR) for correcting the inverter input power factor (for suppressing harmonics)

To correct the inverter input power factor (to suppress harmonics), use a DCR. Using a DCR increases the reactance of inverter's power source so as to decrease harmonic components on the power source lines and correct the power factor of the inverter.

DCR models	Input power factor	Remarks
	Approx. 90% to 95%	The last letter identifies the capacitance.
DCR4-DDC	Approx. 86% to 90%	Exclusively designed when applying with motors with a rated capacity of 37 kW or above.

Note • Select a DCR matching not the inverter capacity but the rated capacity of the applied motor.

• For applied motors of 75 kW or above, be sure to connect a DCR to the inverter.

[4] PWM converter for correcting the inverter input power factor

Using a PWM converter (High power-factor, regenerative PWM converter, RHC series) corrects the inverter power factor up to nearly "1."

When combining an inverter with a PWM converter, disable the main power down detection by setting the function code H72 to "0" (default). If the main power down detection is enabled (H72 = 1, factory default), the inverter interprets the main power as being shut down, ignoring an entry of a run command.

[5] Molded case circuit breaker (MCCB) / residual-current-operated protective device (RCD) / earth leakage circuit breaker (ELCB)

Install a recommended MCCB or RCD/ELCB (with overcurrent protection) in the primary circuit of the inverter to protect the wiring. Since using an MCCB or RCD/ELCB with a lager capacity than recommended ones breaks the protective coordination of the power supply system, be sure to select recommended ones. Also select ones with short-circuit breaking capacity suitable for the power source impedance.

If no zero-phase current (earth leakage current) detective device such as a ground-fault relay is installed in the upstream power supply line in order to avoid the entire power supply system's shutdown undesirable to factory operation, install a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) individually to inverters to break the individual inverter power supply lines only.

Otherwise, a fire could occur.

[6] Magnetic contactor (MC) in the inverter input (primary) circuit

Avoid frequent ON/OFF operation of the magnetic contactor (MC) in the input circuit; otherwise, the inverter failure may result. If frequent start/stop of the motor is required, use *FWD*/*REV* terminal signals or the \bigcirc / \bigcirc keys on the inverter's keypad.

The frequency of the MC's ON/OFF should not be more than once per 30 minutes. To assure 10-year or longer service life of the inverter, it should not be more than once per hour.

Тір

• From the system's safety point of view, it is recommended to employ such a sequence that shuts down the magnetic contactor (MC) in the inverter input circuit with an alarm output signal **ALM** issued on inverter's programmable output terminals. The sequence minimizes the secondary damage even if the inverter breaks.

When the sequence is employed, connecting the MC's primary power line to the inverter's auxiliary control power input makes it possible to monitor the inverter's alarm status on the keypad.

• The breakdown of a braking unit or misconnection of an external braking resistor may cause damage of the inverter's internal parts (e.g., charging resistor). To avoid such a breakdown linkage, introduce an MC and configure a sequence that shuts down the MC if a DC link voltage establishment signal is not issued within three seconds after the MC is switched on.

For the braking transistor built-in type of inverters, assign a transistor error output signal **DBAL** on inverter's programmable output terminals to switch off the MC in the inverter input circuit.

[7] Magnetic contactor (MC) in the inverter output (secondary) circuit

If a magnetic contactor (MC) is inserted in the inverter's output (secondary) circuit for switching the motor to a commercial power or for any other purposes, it should be switched on and off when both the inverter and motor are completely stopped. This prevents the contact point from getting damaged due to a switching arc of the MC. The MC should not be equipped with any main circuit surge killer.

Applying a commercial power to the inverter's output circuit breaks the inverter. To avoid it, interlock the MC on the motor's commercial power line with the one in the inverter output circuit so that they are not switched ON at the same time.

[8] Surge absorber/surge killer

Do not install any surge absorber or surge killer in the inverter's output (secondary) lines.

1.3.4 Noise reduction

If noise generated from the inverter affects other devices, or that generated from peripheral equipment causes the inverter to malfunction, follow the basic measures outlined below.

- (1) If noise generated from the inverter affects the other devices through power wires or grounding wires:
 - Isolate the grounding terminals of the inverter from those of the other devices.
 - Connect a noise filter to the inverter power wires.
 - Isolate the power system of the other devices from that of the inverter with an insulated transformer.
 - Decrease the inverter's carrier frequency (F26). See Note below.
- (2) If induction or radiated noise generated from the inverter affects other devices:
 - Isolate the main circuit wires from the control circuit wires and other devices wires.
 - Put the main circuit wires through a metal conduit pipe, and connect the pipe to the ground near the inverter.
 - Install the inverter into the metal panel and connect the whole panel to the ground.
 - Connect a noise filter to the inverter's power wires.
 - Decrease the inverter's carrier frequency (F26). See Note below.
- (3) When implementing measures against noise generated from peripheral equipment:
 - For inverter's control signal wires, use twisted or shielded-twisted wires. When using shielded-twisted wires, connect the shield of the shielded wires to the common terminals of the control circuit.
 - Connect a surge absorber in parallel with magnetic contactor's coils or other solenoids (if any).
- **Note**: Running a permanent magnet synchronous motor (PMSM) at a low carrier frequency may heat the permanent magnet due to the output current harmonics, resulting in demagnetization. When decreasing the carrier frequency setting, be sure to check the allowable carrier frequency of the motor.

1.3.5 Leakage current

A high frequency current component generated by insulated gate bipolar transistors (IGBTs) switching on/off inside the inverter produces leakage current through stray capacitance of inverter input and output wires or a motor. If any of the problems listed below occurs, take an appropriate measure against them.

Problem	Measures
An earth leakage circuit breaker* that is connected to the input (primary) side has tripped. * With overcurrent protection	 Decrease the carrier frequency. See Note below. Make the wires between the inverter and motor as short as possible. Use an earth leakage circuit breaker with lower sensitivity than the one currently used. Use an earth leakage circuit breaker that features measures against the high frequency current component (Fuji SG and EG series).
An external thermal relay was falsely activated.	 Decrease the carrier frequency. See Note below. Increase the current setting of the thermal relay. Use the electronic thermal overload protection built in the inverter, instead of the external thermal relay.

Note: Running a permanent magnet synchronous motor (PMSM) at a low carrier frequency may heat the permanent magnet due to the output current harmonics, resulting in demagnetization. When decreasing the carrier frequency setting, be sure to check the allowable carrier frequency of the motor.

1.3.6 Precautions in driving a permanent magnet synchronous motor (PMSM)

When using a PMSM, note the following.

- When using a PMSM other than the Fuji standard synchronous motor (GNB2), consult your Fuji Electric representative.
- A single inverter cannot drive two or more PMSMs.
- A PMSM cannot be driven by commercial power.

Chapter 2 INSTALLATION AND WIRING

This chapter describes the important points in installing and wiring inverters.

Contents

2.1	Instal	llation	···· 2-1
2.2	Wirin	g	2-3
2.2	2.1	Basic connection diagram	2-3
2.2	2.2	Removal and attachment of the front cover/ terminal cover and wiring guide	2-5
2.2	2.3	Precautions for wiring	2-8
2.2	2.4	Precautions for long wiring (between inverter and motor)	2-10
2.2	2.5	Main circuit terminals ·····	2-12
[1]	Screw specifications	2-12
[2]	Terminal layout diagram (main circuit terminal)	2-13
[3]	Recommended wire size (main circuit terminals)	2-14
[4]	Description of terminal functions (main circuit terminal)	2-22
2.2	2.6	Control circuit terminals (common to all models)	2-26
[1]	Screw specifications and recommended wire size (control circuit terminals)	2-26
[2]	Terminal layout diagram (control circuit terminal)	2-26
[3]	Description of terminal functions (control circuit terminal)	2-27
2.2	2.7	Switching connector (types FRN0176F2E-4G or above)	2-35
2.2	2.8	Operating slide switches ·····	2-38

2.1 Installation

(1) Installation Environment

Please install FRENIC-eHVAC in locations which meet the conditions specified in Chapter 1 "1.3.1 Usage environment".

(2) Installation Surface

Please install the inverter on non-combustible matter such as metals. Also, do not mount it upside down or horizontally.

Install on non-combustible matter such as metals.

Risk of fire exists

(3) Surrounding Space

Secure the space shown in Figure 2.1-1 and Table 2.1-1. When enclosing FRENIC-eHVAC in cabinets, be sure to provide adequate ventilation to the cabinet, as the surrounding temperature may rise. Do not contain it in small enclosures with low heat dissipation capacity.

Installation of Multiple Inverters

When installing 2 or more units in the same equipment or cabinet, generally mount them to the side of each other, not above each other. When the inverters are mounted above each other, attach partitioning boards to prevent that the heat dissipated from the lower inverter affects the upper inverter.

For types FRN0060F2E-4G or below and for ambient temperature below 40°C only, the units can be installed side by side without any spacing between them.

Table 2.1-1	Surrounding Space	mm (inch)
-------------	-------------------	-----------

Applicable Capacity	Α	В	С
FRN0011 to 0060F2E-4G	10 (0.39)	100	0 *1
FRN0075 to 0520F2E-4G	50 (1.97)	(3.9)	100 (3.9)

*1 A clearance of 50 mm is required to use RJ45 connector.

C: Space in front of the inverter unit

Installation with External Cooling

The external cooling installation reduces the generated heat inside the panel by dissipating approximately 70% of the total heat generated (total heat loss) by mounting the cooling fins protruding outside the equipment or cabinet.

Installation with external cooling is possible for types FRN0045 and 0060F2E-4G by adding attachments (optional) for external cooling, and for types FRN0075F2E-4G or above by moving the mounting bases.

(Please refer to Chapter 11 Item 11.15 for the external dimensions drawing of the external cooling attachment (optional)).

Prevent lint, wastepaper, wood shavings, dust, metal scrap, and other foreign material from entering the inverter or from attaching to the cooling fins.

Risk of fire and risk of accidents exist



Figure 2.1-2 Installation with External Cooling





Figure 2.1-1 Installation Direction

To install the FRN0075F2E-4G inverter with external cooling, change the mounting position of the mounting bases following the procedure in Figure 2.1-3.

As the type and number of screws differ by inverter type, please review Table 2.1-2.

Inverter type	Mounting base fixation screw	Case attachment screw	Tightening torque N•m (Ib-in)
FRN0075F2E-4G to FRN0150F2E-4G	M6×20 (5 screws on top, 3 screws on bottom)	M6×20 (2 screws on top only)	5.8 (51.3)
FRN0176F2E-4G	M6×20 (3 screws on top and bottom each)	M6×12 (3 screws on top only)	5.8 (51.3)
FRN0210F2E-4G to FRN0253F2E-4G	M5×12 (7 screws on top and bottom each)	M5×12 (7 screws on top only)	3.5 (31.0)
FRN0304F2E-4G to FRN0377F2E-4G	M5×16 (7 screws on top and bottom each)	M5×16 (7 screws on top only)	3.5 (31.0)
FRN0415F2E-4G to FRN0520F2E-4G	M5×16 (8 screws on top and bottom each)	M5×16 (8 screws on top only)	3.5 (31.0)

Table 2.1-2	Type and Number of	Screws, and	Tiahtenina	Torque
	i ypo ana i tainioor or	conono, ana	nginoimig	101940

1) Remove all of the mounting base fixation screws and the case attachment screws on the top of the inverter.

2) Fix the mounting bases to the case attachment screw holes using the mounting base fixation screws. A few screws should remain after changing the position of the mounting bases.

3) Change the position of the mounting bases on the bottom side following the procedure in 1) and 2).



Figure 2.1-3 Method to Change the Mounting Base Positions

Use the specified screws in changing the mounting bases.

Risk of fire and risk of accidents exist

Inverter unit installation screw size

Select the bolt size, considering the thickness of the mounting feet and installation surface so that the bolt protrudes from the nut by 2 threads or more.

Inverter type	Inverter fixation screw	Tightening torque N•m (Ib-in)
FRN0018F2E-4G to FRN0023F2E-4G	M5 (4 screws)	3.5 (31.0)
FRN0031F2E-4G to FRN0176F2E-4G	M8 (4 screws)	13.5 (119)
FRN0210F2E-4G to FRN0377F2E-4G	M12 (4 screws)	48 (425)
FRN0415F2E-4G to FRN0520F2E-4G	M12 (6 screws)	48 (425)

2.2 Wiring

2.2.1 Basic connection diagram



Figure 2.2-1 Standard Terminal Block Board

- (Note 1) Install recommended circuit breakers (MCCB) or residual-current-operated protective device (RCD)/ earth leakage breakers (ELCB) (with overcurrent protective function) on the inputs of each inverter (primary side) for wiring protection. Do not use breakers which exceed the recommended rated current.
- (Note 2) Install recommended magnetic contactors (MC) as necessary on each inverter as these will be used to disconnect the inverter from the power supply separately from the MCCB or RCD / the ELCB. Additionally, when installing coils such as MC or solenoid close to the inverter, connect surge absorbers in parallel.
- (Note 3) When it is desired to retain the alarm signal for the activation of the protective function even inverter main power supply is shut off, or when it is desired continuous display of the keypad, connect this terminal to the power supply. The inverter can be operated without connecting power to this terminal (applicable for types FRN0045F2E-4G or above)
- (Note 4) The terminal does not need to be connected. Use this terminal when operating in combination with a high power factor regenerative PWM converter (RHC series). Applicable for types FRN0176F2E-4G or above)
- (Note 5) Remove the shorting bar between the inverter main circuit terminals P1-P(+) before connecting the direct current reactor (DCR) (option).
 It must be connected in the following cases:
 Types FRN0150F2E-4G or above
 Use the direct current reactor (option) when the power supply transformer capacity is above 500 kVA and the transformer capacity is over 10 times the rated capacity of the inverter, or when "thyristor load exists" in the same power system.
- (Note 6) Types FRN0060F2E-4G or below have built-in braking transistors, allowing direct connection of braking resistors between P(+)-DB.
- (Note 7) When connecting braking resistors to types FRN0075F2E-4G or above, always add the braking unit (option). Connect the braking unit (option) between P(+)-N(-). Auxiliary terminals [1] and [2] have polarity. Please connect as shown in the diagram.
- (Note 8) This terminal is used for grounding the motor. Grounding the motor using this terminal is recommended in order to suppress inverter noise.
- (Note 9) Use twisted lines or shielded lines for the control signals. Generally, the shielded line requires grounding, but when the effect of externally induced noise is large, connecting to [CM] may suppress the effect of noise. Separate the line from the main circuit wiring and do not enclose in the same duct. (Separation distance of over 10 cm is recommended.) When crossing the main circuit wiring, make the intersection perpendicular.
- (Note 10) The various functions listed for terminals[X1] to [X5](digital inputs), terminals [Y1] to [Y3](transistor output), terminals [30A/B/C] [Y5A/C](relay output), and terminal [FM1], [FM2] (monitor output) show the functions assigned as factory default.
- (Note 11) These are connectors for switching the main circuit. For details, refer to "2.2.7 Switching connector (types FRN0176F2E-4G or above)".
- (Note 12) The slide switches on the control printed circuit board define the settings for the inverter operation. For details, refer to "2.2.8 Operating slide switches".
- (Note 13) Make the circuit breakers (MCCB) or the magnetic contactors (MC) trip by the thermal relay auxiliary contacts (manual recovery).
- (Note 14) $\boxed{0V}$ and $\boxed{0V}$ are separated and insulated.
- (Note 15) Charge lamp does not exist in the inverters FRN0038F2E-4G or below.
Route the wiring following the steps below. The descriptions assume that the inverter is already fixed to the cabinet.

2.2.2 Removal and attachment of the front cover/ terminal cover and wiring guide

Always remove the RS-485 communication cable from the RJ-45 connector before removing the front cover.

Risk of fire and risk of accidents exist.

(1) Types FRN0011F2E-4G or below

Removal

- 1) Loosen the terminal cover screws, insert a finger into the gap at the bottom of the cover, and pull toward you to remove.
- 2) Press down on both of the side hooks on the interface board, and pull the board out toward you.
- 3) Slide the wiring guide toward you and remove.
 - (The wiring guide is not mounted on the inverter unit when shipped from the factory, but is stored inside the packing box, and therefore removal is unnecessary.)

Wiring

1) Perform main circuit terminal wiring work

Attachment

- * Perform the attachment procedure using the opposite procedure from that in the diagram below.
- 1) Attach the wiring guide to the unit.
- 2) Attach the control terminal block board to the unit. Press down on both of the side hooks until they click into position.
- 3) Attach the terminal cover, and tighten the screws.



Figure 2.2-2 Removal of the Terminal Cover and the Wiring Guide (for FRN0011F2E-4G)

(2) Types FRN0018F2E-4G to FRN0038F2E-4G

- 1) Loosen the screws of the terminal cover. To remove the terminal cover, put your finger in the dimple of the terminal cover and then pull it up toward you.
- 2) Pull out the wiring guide toward you.
- 3) After routing the wires, attach the wiring guide and the terminal cover reversing the steps above.



Figure 2.2-3 Removal of the Terminal Cover and the Wiring Guide (for FRN0038F2E-4G)

(3) Types FRN0045F2E-4G, FRN0060F2E-4G

- 1) Loosen the screws of the front cover. Hold both sides of the front cover with the hands, slide the cover downward, and pull. Then remove it to the upward direction.
- 2) Push the wiring guide upward and pull. Let the wiring guide slide and remove it.
- 3) After routing the wires, attach the wiring guide and the front cover reversing the steps above.



Figure 2.2-4 Removal of the Front Cover and the Wiring Guide (for FRN0060F2E-4G)

(4) Types FRN0075F2E-4G or above

Tip

- 1) Loosen the screws of the front cover. Hold both sides of the front cover with the hands and slide it upward to remove.
- 2) After routing the wires, align the front cover top edge to the screw holes and attach the cover reversing the steps in Figure 2.2-.



Figure 2.2-5 Removal of the front cover (for FRN0176F2E-4G)

2.2.3 Precautions for wiring

Exercise caution for the following when wiring.

- (1) Confirm that the supply voltage is within the input voltage range described on the rating plate.
- (2) Always connect the power lines to the inverter main power input terminals L1/R, L2/S, L3/T (Three-phase). (The inverter will be damaged when power is applied if the power lines are connected to the wrong terminals.)
- (3) Always route the ground line to prevent accidents such as electric shock and fire and to reduce noise.
- (4) For the lines connecting to the main circuit terminals, use crimped terminals with insulating sleeves or use crimped terminals in conjunction with insulating sleeves for high connection reliability.
- (5) Separate the routing of the lines connected to the main circuit input side terminals (primary side) and the output side terminals (secondary side) and the lines connected to the control circuit terminals. The control circuit terminal lines should be routed as far as possible from the main circuit routing. Malfunction may occur due to noise.
- (6) To prevent direct contact with the main circuit live sections (such as the main circuit terminal block), route the control circuit wiring inside the inverter as bundles using cable ties.
- (7) After removing a main circuit terminal screw, always restore the terminal screw in position and tighten even if lines are not connected.
- (8) The wiring guide is used to separately route the main circuit wiring and the control circuit wiring. The main circuit wiring and the control circuit wiring can be separated. Exercise caution for the order of wiring.



Handling the Wiring Guide

For inverter types FRN0018 to 0060F2E-4G, the wiring space may become insufficient when routing the main circuit wires, depending on the wire material used. In these cases, the relevant cut-off sections (see Figure 2.2-, Figure 2.2-) can be removed using a pair of nippers to secure routing space. Be warned that removing the wiring guide to accommodate the enlarged main circuit wiring will result in non-conformance to IP20 requirements.



Figure 2.2-7 Wiring Guide (FRN0038F2E-4G)



Figure 2.2-8 Wiring Guide (FRN0060F2E-4G)

(9) Depending on the inverter capacity, straight routing of the main circuit wires from the main circuit terminal block may not be possible. In these cases, route the wires as shown in the figure below and securely attach the front cover.



2.2.4 Precautions for long wiring (between inverter and motor)

- (1) When multiple motors are connected to one inverter, the wiring length is the total of all wire lengths.
- (2) Precautions shall be taken for high frequency leak current when the wiring length from the inverter to the motor is long, in this case the high frequency current may flow through the stray capacitance between the wires with various phases. The effect may cause the inverter to become overheated, or trip due to overcurrent. Leak current may increase and the accuracy of the displayed current may not be ensured. Depending on the conditions, excessive leak current may damage the inverter. To avoid the above problems when directly connecting an inverter to a motor, keep the wiring distance 50 m (164 ft) for inverters FRN0011F2E-4G or below, and below 100 m (328 ft) for inverters FRN0018F2E-4G or above.

To operate with longer wiring lengths than the ones above mentioned, reduce the carrier frequency or use an output circuit filter (OFL- \square \square - \square A).

When multiple motors are operated in parallel connection configuration (group operation), and especially when shielded cables are used in the connections, the stray capacitance to ground is large. Reduce the carrier frequency or use output circuit filters (OFL- $\Box\Box$ - \Box A).



When the output circuit filter is used, the total wiring length should be below 400 m (1312ft) in case of using V/f control.

For motors with encoders, the wiring length between the inverter and motor should be below 100 m (328ft). The restriction comes from the encoder specifications. For distances beyond 100 m (328ft), insulation converters should be used. Please contact Fuji Electric when operating with wiring lengths beyond the upper limit.

- (3) Precautions on the surge voltage when driving the inverter (especially for 400 V series motor) When motors are driven by inverters using the PWM method, the surge voltage generated by the switching of the inverter elements is added to the output voltage and is applied onto the motor terminals. Especially when the motor wiring length is long, the surge voltage can cause insulation degradation in the motor. Please perform one of the countermeasures shown below.
 - · Use motor with insulation enhancement (Fuji's standard motors have insulation enhancements)
 - Connect a surge suppression unit on the motor side (SSU50/100TA-NS)
 - Connect an output circuit filter (OFL-□□-□A) to the inverter output side (secondary side)
 - Reduce the wiring length from the inverter to the motor to less than 10 to 20 meters (33 to 66ft).
- (4) When output circuit filters are attached to the inverter or when the wiring length is long, the voltage applied to the motor will decrease due to the voltage drop caused by the filter or wiring. In these cases, current oscillation and lack of torque may occur due to insufficient voltage.

- For each inverter, connect to the power supply via circuit breaker and earth leakage breaker (with overcurrent
 protective function). Use recommended circuit breakers and earth leakage breakers and do not use breakers
 which exceed the recommended rated current.
- Always use the specified sizes for the wires.
- Tighten terminals with the defined tightening torque.
- When multiple combinations of inverters and motors exist, do not use multi-core cables for the purpose of bundling the various wires.
- Do not install surge killers on the inverter output side (secondary side)

Risk of fire exists.

- Ground the inverter in compliance with the national or local electric code.
- Always connect the ground line to the inverter grounding terminal [GG]

Risk of electric shock and risk of fire exist.

- · Qualified personnel should perform the wiring.
- · Perform wiring after confirming that the power is shut off.

Risk of electric shock exists.

• Perform wiring only after the equipment is installed at the location.

Risk of electric shock and risk of injury exist.

- Confirm that the specifications (number of phases and the rated voltage) of the power supply input of the product match with the specifications of the power supply to be connected.
- Do not connect power supply lines to the inverter output terminals (U, V, W).

Risk of fire and risk of accidents exist.

2.2.5 Main circuit terminals

[1] Screw specifications

The specifications for the screws used in the main circuit wiring and the wire sizes are shown below. Exercise caution as the terminal position varies depending on inverter capacity. In the diagram in "[2] Terminal layout diagram (main circuit terminal)", the two ground terminals [$\bigoplus G$] are not differentiated for the input side (primary side) and the output side (secondary side).

Also, use crimped terminals with insulating sleeves compatible for main circuit or terminals with insulating tubes. The recommended wire sizes are shown depending on cabinet temperature and wire type.

						Screw spe	ecifications			
Power		See item	Main	circuit	Grou	nding	Auxiliary p for contro	ower input ol [R0, T0]	Auxiliary p for fan	ower input [R1, T1]
System	Inverter type	[2]	Screw size (driver size)	Tightening torque N•m (lb-in)	Screw size (driver size)	Tightening torque N•m (lb-in)	Screw size	Tightening torque N•m (lb-in)	Screw size	Tightening torque N•m (lb-in)
	FRN0002F2E-4G	Fig. I								
	FRN0003F2E-4G	rig. i		10		1.8 (15.9)				
	FRN0005F2E-4G		M4	1.2 (10.6)	M4					
	FRN0006F2E-4G	Fig. J		()					-	-
	FRN0011F2E-4G									
>	FRN0018F2E-4G	Fia. A	Input M4	Input: 1.8(15.9)	M5	3.0	-	-		
	FRN0023F2E-4G			Other: 3.0(26.6)		(26.6)				
	FRN0031F2E-4G	Fig. B	Input M4 Output M6	Input: 1.8(15.9) Other: 5.8(51.3)	M6 (No.3)	5.8				
e 400	FRN0038F2E-4G					(51.3)				
lase	FRN0045F2E-4G	Fig. C	M6	5.8	M6	5.8				
-ph	FRN0060F2E-4G	Tig. C	(No. 3)	(51.3)	(No.3)	(51.3)				
Jree	FRN0075F2E-4G								_	_
È	FRN0091F2E-4G	Fig D	M8	13.5						
	FRN0112F2E-4G	rig. D	MO	(119)		12 5				
	FRN0150F2E-4G				M8	(119)		1.2		
	FRN0176F2E-4G	Fig. E		27		~ /	M3.5	(10.6)		
	FRN0210F2E-4G	Fia. F	M10	(239)				. ,		
	FRN0253F2E-4G	· .g		. ,						1.2
	FRN0304F2E-4G	Fig. G							M3.5	1.2 (10.6)
	FRN0377F2E-4G	1 ig. 0	M12	48	M10	27 (239)				
-	FRN0415F2E-4G	Fig. H		(425)						
	FRN0520F2E-4G	1.9.11								

Table 2.2-1 Screw Specifications





For the figure I / J, please contact Fuji Electric.

The following terminals will have high voltage when power is ON.							
Main circuit: L1/R, L2/S, L3/T, L1/L, L2/N, P1, P(+), N(-), DB, U, V, W, R0, T0, R1, T1							
Insulation level							
Main circuit - Casing	: Basic insulation (overvoltage category III, degree of contamination 2)						
Main circuit - Control circuit : Enhanced insulation (overvoltage category III, degree of contamination 2)							
Risk of electric shock exists							

[3] Recommended wire size (main circuit terminals)

The following wires are recommended unless special requirements exist.

■ 600 V vinyl insulation wire (IV wire)

This wire is used in circuits except the inverter control circuit. The wire is difficult to twist and is not recommended for inverter control circuit. The maximum allowable temperature for the insulated wire is 60°C.

■ 600 V type 2 vinyl insulation wire or 600 V polyethylene insulation wire (HIV wire)

In comparison to the IV wire, this wire is smaller, more flexible, and the maximum allowable temperature for the insulated wire is 75°C (higher), making it suitable for both the inverter main circuit and control circuit. However, the wiring distance should be short and the wire must be twisted for use in the inverter control circuit.

■ 600 V cross-linked polyethylene insulation wire (FSLC wire)

This wire is used mainly in the main circuit and the grounding circuits. The size is even smaller than the IV wire or the HIV wire and also more flexible. Due to these features, the wire is used to reduce the area occupied by wiring and to improve work efficiency in high temperature areas. The maximum allowable temperature for the insulated wire is 90°C. As a reference, Furukawa Electric Co., Ltd. produces Boardlex which satisfies these requirements.

Shielded-Twisted cables for internal wiring of electronic/electric instruments

This product is used in inverter control circuits. Use this wire with high shielding effect when risk of exposure to or effect of radiated noise and induced noise exists. Always use this wire when the wiring distance is long, even within the cabinet. Furukawa Electric's BEAMEX S shielded cables XEBV or XEWV satisfy these requirements.

Common terminals	Recommended wire size (mm ²) [AWG]	Remarks
Auxiliary power input terminals for control circuit R0, T0	2.0 [14]	FRN0045F2E-4G or above
Auxiliary power input terminals for fan R1, T1	2.0 [14]	FRN0176F2E-4G or above

Table 2.2-2 Recommended Wire Sizes (Common	1 Terminals)
--	--------------

Refer to Appendix G-2 to conform the wire sizes to the UL Standards and Canadian Standards (cUL Certification).

(1) Wire sizes conforming to low voltage directive in Europe

	0.1				Recomme	nded wire siz	e (mm²)		
ower /stem	Applicable Motor	Inverter type	Main power [L1/R, L2	supply input 2/S, L3/T]	Ground [4	terminal 9G]	Inverter	For DC reactor	For braking resistor
ΞÔ	(kW)		With DC reactor	Without DC reactor	With DC reactor	Without DC reactor	[U, V, W]	connection [P1, P(+)]	connection [P(+), DB]
	0.75	FRN0002F2E-4G	2.5	2.5	2.5	2.5	2.5	2.5	2.5
	1.1	FRN0003F2E-4G	2.5	2.5	2.5	2.5	2.5	2.5	2.5
	2.2	FRN0005F2E-4G	2.5	2.5	2.5	2.5	2.5	2.5	2.5
	3.0	FRN0006F2E-4G	2.5	2.5	2.5	2.5	2.5	2.5	2.5
٨	5.5	FRN0011F2E-4G	2.5	2.5	2.5	2.5	2.5	2.5	2.5
	7.5	FRN0018F2E-4G	2.5	4	2.5	4	2.5	2.5	2.5
	11	FRN0023F2E-4G	4	6	4	6	4	4	2.5
	15	FRN0031F2E-4G	6	10	6	10	6	6	2.5
	18.5	FRN0038F2E-4G	6	16	6	16	10	10	2.5
400	22	FRN0045F2E-4G	10	16	10	16	10	16	2.5
ase	30	FRN0060F2E-4G	16	25	16	16	16	25	2.5
-phá	37	FRN0075F2E-4G	25	35	16	16	25	25	-
ree	45	FRN0091F2E-4G	25	50	16	25	35	35	-
Тh	55	FRN0112F2E-4G	35	70	16	35	50	50	-
	75	FRN0150F2E-4G	70	-	35	-	70	95	-
	90	FRN0176F2E-4G	95	-	50	-	95	120	-
	110	FRN0210F2E-4G	120	-	70	-	120	150	-
	132	FRN0253F2E-4G	150	-	95	-	150	95×2	-
	160	FRN0304F2E-4G	185	-	95	-	240	300	-
	200	FRN0377F2E-4G	300	-	150	-	300	150×2	-
	220	FRN0415F2E-4G	300	-	150	-	150×2	185×2	-
	280	FRN0520F2E-4G	185×2	-	185	-	240×2	300×2	-

Table 2.2-3 Recommended Wire Sizes, conforming to low voltage directive in Europe

The recommended wire sizes for the main circuit terminals assume using 70°C 600V PVC wire, in the ambient temperature below 40°C.

(2) Ambient temperature: Below 40 °C, Wire type: 60 °C wire

				Re	commended v	vire size (mm ²)	
Power System	Std Applicable Motor (kW)	Inverter type	Main power s [L1/R, L2/ With DC	supply input 'S, L3/T] Without DC	Ground terminal [⊕ G]	Inverter output [U, V, W]	For DC reactor connection	For braking resistor connection
			reactor	reactor			[P1, P(+)]	[P(+), DB]
	0.75	FRN0002F2E-4G	2	2	2	2	2	2
	1.1	FRN0003F2E-4G	2	2	2	2	2	2
	2.2	FRN0005F2E-4G	2	2	2	2	2	2
	3.0	FRN0006F2E-4G	2	2	2	2	2	2
	5.5	FRN0011F2E-4G	2	2	2	2	2	2
	7.5	FRN0018F2E-4G	2	3.5	2	2	2	2
	11	FRN0023F2E-4G	2	5.5	3.5	3.5	3.5	2
	15	FRN0031F2E-4G	3.5	8	5.5	5.5	5.5	2
Ó	18.5	FRN0038F2E-4G	5.5	14	5.5	5.5	8	2
e 4(22	FRN0045F2E-4G	8 ^{*1}	14	5.5	8 ^{*1}	14	2
าลรเ	30	FRN0060F2E-4G	14	22	8 ^{*1}	14	14	2
-pt	37	FRN0075F2E-4G	14	38	8	22	22	-
Jree	45	FRN0091F2E-4G	22	38	8	22	38	-
È	55	FRN0112F2E-4G	38	60	14	38	38	-
	75	FRN0150F2E-4G	60	-	14	60	60	-
	90	FRN0176F2E-4G	60	-	14	60	100	-
	110	FRN0210F2E-4G	100	-	22	100	-	-
	132	FRN0253F2E-4G	100	-	22	-	-	-
	160	FRN0304F2E-4G	-	-	22	-	-	-
	200	FRN0377F2E-4G	-	-	38	-	-	-
	220	FRN0415F2E-4G	-	-	38	-	-	-
	280	FRN0520F2E-4G	-	-	38	-	-	-

Table 2.2-4Recommended wire size, Ambient temperature: Below 40 °C, Wire type: 60 °C wire

*1 For compatible crimped terminals, please use model 8-L6 by JST Mfg. Co., Ltd. or equivalent.

(3) Ambient temperature: Below 40 °C, Wire type: 75 °C wire

	Std	Inverter type		F	Recommended wire size (mm ²)							
Power System	Applicable Motor (kW)		Main power [L1/R, L2 With DC	supply input 2/S, L3/T] Without DC	Ground terminal [∯ G]	Inverter output [U, V, W]	For DC reactor connection	For braking resistor connection				
	0.75		reactor	reactor		2	[1,1,1(+)]	[[(+), DD]				
	0.75	FRN0002F2E-4G	2	2	2	2	2	2				
	1.1	FRN0003F2E-4G	2	2	2	2	2	2				
	2.2	FRN0005F2E-4G	2	2	2	2	2	2				
	3.0	FRN0006F2E-4G	2	2	2	2	2	2				
	5.5	FRN0011F2E-4G	2	2	2	2	2	2				
	7.5	FRN0018F2E-4G	2	2	2	2	2	2				
/	11	FRN0023F2E-4G	2	3.5	3.5	2	2	2				
	15	FRN0031F2E-4G	2	5.5	5.5	3.5	3.5	2				
ó	18.5	FRN0038F2E-4G	3.5	8	5.5	3.5	5.5	2				
e 4(22	FRN0045F2E-4G	5.5	8 ^{*1}	5.5	5.5	5.5	2				
las	30	FRN0060F2E-4G	8 ^{*1}	14	8 ^{*1}	8 ^{*1}	14	2				
-e	37	FRN0075F2E-4G	14	14	8	14	14	-				
Iree	45	FRN0091F2E-4G	14	22	8	14	22	-				
È	55	FRN0112F2E-4G	22	38	14	22	38	-				
	75	FRN0150F2E-4G	38	-	14	38	38	-				
	90	FRN0176F2E-4G	38	-	14	60	60	-				
	110	FRN0210F2E-4G	60	-	22	60	100	-				
	132	FRN0253F2E-4G	100	-	22	100	100	-				
	160	FRN0304F2E-4G	100	-	22	100	150	-				
	200	FRN0377F2E-4G	150	-	38	150	200	-				
	220	FRN0415F2E-4G	150	-	38	150	200	-				
	280	FRN0520F2F-4G	200	-	38	250	325	-				

Table 2.2-5 Recommended Wire Sizes, Ambient temperature: Below 40 °C, Wire type: 75 °C wire

The recommended wire sizes for the main circuit terminals assume using 75°C 600 V HIV wire.

*1 For compatible crimped terminals, please use model 8-L6 by JST Mfg. Co., Ltd. or equivalent.

(4) Ambient temperature: Below 40 °C, Wire type: 90 °C wire

	0.1			R	ecommended	wire size (mm	²)	
Power System	Std Applicable Motor (kW)	Inverter type	Main power [L1/R, L2 With DC reactor	supply input 2/S, L3/T] Without DC reactor	Ground terminal [ᠿ G]	Inverter output [U, V, W]	For DC reactor connection [P1, P(+)]	For braking resistor connection [P(+), DB]
	0.75	FRN0002F2E-4G	2	2	2	2	2	2
	1.1	FRN0003F2E-4G	2	2	2	2	2	2
	2.2	FRN0005F2E-4G	2	2	2	2	2	2
	3.0	FRN0006F2E-4G	2	2	2	2	2	2
	5.5	FRN0011F2E-4G	2	2	2	2	2	2
	7.5	FRN0018F2E-4G	2	2	2	2	2	2
	11	FRN0023F2E-4G	2	2	3.5	2	2	2
	15	FRN0031F2E-4G	2	3.5	5.5	2	3.5	2
Ó	18.5	FRN0038F2E-4G	3.5	5.5	5.5	3.5	3.5	2
e 4(22	FRN0045F2E-4G	3.5 ^{*4}	5.5	5.5	3.5 ^{*4}	5.5	2
าลร	30	FRN0060F2E-4G	5.5	8 ^{*1}	8 ^{*1}	5.5	8 ^{*1}	2
-p	37	FRN0075F2E-4G	8	14	8	8	14	-
Jree	45	FRN0091F2E-4G	14	22	8	14	14	-
È	55	FRN0112F2E-4G	14	22	14	14	22	-
	75	FRN0150F2E-4G	22	-	14	38	38	-
	90	FRN0176F2E-4G	38	-	14	38	38	-
	110	FRN0210F2E-4G	38	-	22	60	60	-
	132	FRN0253F2E-4G	60	-	22	60	100	-
	160	FRN0304F2E-4G	100	-	22	100	100	-
-	200	FRN0377F2E-4G	100	-	38	100	150	-
	220	FRN0415F2E-4G	150	-	38	150	150	-
	280	FRN0520F2E-4G	150	-	38	200	250	-

Table 2.2-6Recommended Wire Sizes, Ambient temperature: Below 40 °C, Wire type: 90 °C wire

The recommended wire sizes for the main circuit terminals assume using 90 °C 600 V FSLC wire.

*1 For compatible crimped terminals, please use model 8-L6 by JST Mfg. Co., Ltd. or equivalent.

*4 For compatible crimped terminals, please use model R5.5-6 by JST Mfg. Co., Ltd. or equivalent.

(5) Ambient temperature: Below 50 °C, Wire type: 60 °C wire

tem				R	ecommended	wire size (mm	²)	
. Syste	Std Applicable	Inverter type	Main power (Note 1) [L1/F	supply input R, L2/S, L3/T]	Ground terminal	Inverter output	For DC reactor	For braking resistor
Power	(kW)		With DC reactor	Without DC reactor	(Note 1) [∯ G]	(Note 1) [U, V, W]	(Note 1) *[P1, P(+)]	connection [P(+), DB]
	0.75	FRN0002F2E-4G	2	2	2	2	2	2
	1.1	FRN0003F2E-4G	2	2	2	2	2	2
	2.2	FRN0005F2E-4G	2	2	2	2	2	2
	3.0	FRN0006F2E-4G	2	2	2	2	2	2
	5.5	FRN0011F2E-4G	2	3.5	2	2	2	2
	7.5	FRN0018F2E-4G	2	5.5	2	3.5	3.5	2
	11	FRN0023F2E-4G	5.5	8	3.5	5.5	5.5	2
	15	FRN0031F2E-4G	8	14	5.5	8	14	2
	18.5	FRN0038F2E-4G	14	22	5.5	14	14	2
	22	FRN0045F2E-4G	14	22	5.5	14	22	2
3相	30	FRN0060F2E-4G	22	38	8 ^{*1}	22	38	2
400V	37	FRN0075F2E-4G	38	60	8	38	38	-
	45	FRN0091F2E-4G	38	60	8	38	60	-
	55	FRN0112F2E-4G	60	100 ^{*2}	14	60	60	-
	75	FRN0150F2E-4G	100 ^{*2}	-	14	100 ^{*2}	100 ^{*2}	-
	90	FRN0176F2E-4G	100	-	14	-	-	-
	110	FRN0210F2E-4G	-	-	22	-	-	-
	132	FRN0253F2E-4G	-	-	22	-	-	-
	160	FRN0304F2E-4G	-	-	22	-	-	-
	200	FRN0377F2E-4G	-	-	38	-	-	-
	220	FRN0415F2E-4G	-	-	38	-	-	-
	280	FRN0520F2E-4G	-	-	38	-	-	-

Table 2.2-7 Recommended Wire Sizes, Ambient temperature: Below 50°C, Wire type: 60°C wire

Note 1) The rated current must be reduced for operation (Rated current x 80%). Recommended wire sizes assume these conditions.

The recommended wire sizes for the main circuit terminals assume using 60°C IV wire.

*1 For compatible crimped terminals, please use model 8-L6 by JST Mfg. Co., Ltd. or equivalent.

*2 For compatible crimped terminals, please use model CB100-S8 by JST Mfg. Co., Ltd. or equivalent.

(6) Ambient temperature: Below 50 °C, Wire type: 75 °C wire

E				R	ecommended	wire size (mm	²)	
Power Syste	Std Applicable Motor (kW)	Inverter type	Main power (Not [L1/R, L2 With DC reactor	supply input te 1) 2/S, L3/T] Without DC reactor	Ground terminal (Note 1) [∯ G]	Inverter output (Note 1) [U, V, W]	For DC reactor connection (Note 1) [P1, P(+)]	For braking resistor connection [P(+), DB]
	0.75	FRN0002F2E-4G	2	2	2	2	2	2
	1.1	FRN0003F2E-4G	2	2	2	2	2	2
	2.2	FRN0005F2E-4G	2	2	2	2	2	2
	3.0	FRN0006F2E-4G	2	2	2	2	2	2
	5.5	FRN0011F2E-4G	2	2	2	2	2	2
	7.5	FRN0018F2E-4G	2	2	2	2	2	2
	11	FRN0023F2E-4G	2	3.5	3.5	3.5	3.5	2
	15	FRN0031F2E-4G	3.5	5.5	5.5	3.5	5.5	2
20	18.5	FRN0038F2E-4G	5.5	8	5.5	5.5	5.5	2
e 4(22	FRN0045F2E-4G	5.5	14	5.5	8 ^{*1}	8 ^{*1}	2
las	30	FRN0060F2E-4G	14	14	8 ^{*1}	14	14	2
-pr	37	FRN0075F2E-4G	14	22	8	14	22	-
lree	45	FRN0091F2E-4G	22	38	8	22	22	-
È	55	FRN0112F2E-4G	22	38	14	38	38	-
	75	FRN0150F2E-4G	38	-	14	60	60	-
	90	FRN0176F2E-4G	60	-	14	60	100	-
	110	FRN0210F2E-4G	100	-	22	100	100	-
	132	FRN0253F2E-4G	100	-	22	100	150 ^{*3}	-
	160	FRN0304F2E-4G	150	-	22	150	150	-
-	200	FRN0377F2E-4G	150	-	38	200	250	-
	220	FRN0415F2E-4G	200	-	38	200	250	-
	280	FRN0520F2E-4G	250	-	38	325	200×2	-

Table 2.2-8Recommended Wire Sizes, Ambient temperature: Below 50 °C, Wire type: 75 °C wire

Note 1) The rated current must be reduced for operation (Rated current x 80%). Recommended wire sizes assume these conditions.

The recommended wire sizes for the main circuit terminals assume using 75°C 600 V HIV wire.

*1 For compatible crimped terminals, please use model 8-L6 by JST Mfg. Co., Ltd. or equivalent.

*3 For compatible crimped terminals, please use model CB150-10 by JST Mfg. Co., Ltd. or equivalent.

(7) Ambient temperature: Below 50 °C, Wire type: 90 °C wire

Ľ				Recommended wire size (mm ²)							
Power Syste	Std Applicable Motor (kW)	Inverter type	Main power (Not [L1/R, L2 With DC reactor	supply input e 1) 2/S, L3/T] Without DC reactor	Ground terminal (Note 1) [⊕ G]	Inverter output (Note 1) [U, V, W]	For DC reactor connection (Note 1) [P1, P(+)]	For braking resistor connection [P(+), DB]			
	0.75	FRN0002F2E-4G	2	2	2	2	2	2			
	1.1	FRN0003F2E-4G	2	2	2	2	2	2			
	2.2	FRN0005F2E-4G	2	2	2	2	2	2			
	3.0	FRN0006F2E-4G	2	2	2	2	2	2			
	5.5	FRN0011F2E-4G	2	2	2	2	2	2			
/	7.5	FRN0018F2E-4G	2	2	2	2	2	2			
	11	FRN0023F2E-4G	2	3.5	3.5	2	2	2			
	15	FRN0031F2E-4G	2	5.5	5.5	2	3.5	2			
\ 0C	18.5	FRN0038F2E-4G	3.5	5.5	5.5	3.5	5.5	2			
e 4(22	FRN0045F2E-4G	5.5	8 ^{*1}	5.5	5.5	5.5	2			
าลร	30	FRN0060F2E-4G	8 ^{*1}	14	8 ^{*1}	8 ^{*1}	8 ^{*1}	2			
-e	37	FRN0075F2E-4G	8	14	8	14	14	-			
lree	45	FRN0091F2E-4G	14	22	8	14	22	-			
Ţ	55	FRN0112F2E-4G	22	38	14	22	22	-			
	75	FRN0150F2E-4G	38	-	14	38	38	-			
	90	FRN0176F2E-4G	38	-	14	38	60	-			
	110	FRN0210F2E-4G	60	-	22	60	60	-			
	132	FRN0253F2E-4G	60	-	22	100	100	-			
	160	FRN0304F2E-4G	100	-	22	100	150	-			
	200	FRN0377F2E-4G	150	-	38	150	150	-			
	220	FRN0415F2E-4G	150	-	38	150	200	-			
	280	FRN0520F2E-4G	200	-	38	200	250	-			

Table 2.2-9 Recommended Wire Sizes, Ambient temperature: Below 50 °C, Wire type: 90 °C wire

Note 1) The rated current must be reduced for operation (Rated current x 80%). Recommended wire sizes assume these conditions.

The recommended wire sizes for the main circuit terminals assume using 90°C 600 V FSLC wire.

*1 For compatible crimped terminals, please use model 8-L6 by JST Mfg. Co., Ltd. or equivalent.

Classifi- cation	Terminal symbol	Terminal name	Specification
	L1/R, L2/S, L3/T	Main power input	Terminals to connect Three-phase power source.
	U, V, W	Inverter output	Terminals to connect Three-phase motors.
cuit	P (+), P1	For direct current reactor connection	Terminals to connect DC reactor (DCR) for power factor enhancement. It must be connected in the following cases: Types FRN0150F2E-4G or above.
	P (+), N (-) For direct currer bus connection		Terminals to connect direct current intermediate circuit of other inverters and PWM converters.
	P (+), DB	For braking resistor connection	Terminals to connect a braking resistor (optional). Wiring length: Below 5 meters. (Types FRN0060F2E-4G or below)
Main cii	G For inverter chassis (case) grounding		Grounding terminal for inverter chassis (case).
	R0, T0	Auxiliary power input for control circuit	When it is desired to retain the alarm signal for the activation of the protective function even inverter main power supply shut off or when continuous display of the keypad is desired, connect this terminal to the power supply. (Types FRN0045F2E-4G or above)
	R1, T1 Auxiliary power input for fan		Ordinarily, these terminals do not need to be connected. Connect these terminals to AC power supply when operating with direct current power input (such as in combination with PWM converters). (Types FRN0176F2E-4G or above)

[4] Description of terminal functions (main circuit terminal)

Follow the sequence below when wiring.

(1) Inverter ground terminal ($\bigoplus G$)

- (2) Inverter output terminals (U, V, W), motor ground terminal (GG)
- (3) Direct current reactor connection terminals (P1, P(+))*
- (4) Braking resistor connection terminals (P(+), DB)*
- (5) Direct current bus connection terminals(P(+), N(-))*
- (6) Main power supply input terminals (L1/R, L2/S, L3/T)
- (7) Auxiliary power input for control circuit (R0,T0) *
- *: Connect if necessary.

Connect in the order (1), (2), (6), (3), (4), (5), (7) for the following models.

FRN0002 to 0011F2E-4G

(1) Main power source input terminals L1/R, L2/S, L3/T (Three-phase input)

Connect the Three-phase power source for Three-phase input model.Connect the Single-phase power source for Single-phase input model.

- 1) For safety, confirm that the circuit breaker (MCCB) or the magnetic contactor (MC) is OFF prior to wiring the power lines.
- Connect the power lines (L1/R, L2/S, L3/T) to MCCB or residual-current-operated protective device (RCD)/ the earth leakage breaker (ELCB)*, or connect via MC if necessary. The phase sequence of the power lines and the inverter do not need to be matched.
 - *: With overcurrent protection

Tip In emergencies such as when the inverter protective function is activated, disconnecting the inverter from the power source to prevent magnification of failure or accident may be desired. Installation of an MC which allows manual disconnection of the power source is recommended.

(2) Inverter output terminals U, V, W, motor ground terminal GG

- 1) Connect the Three-phase motor terminals U, V, and W while matching the phase sequence.
- 2) Connect the ground line of the outputs (U, V, W) to the ground terminal (G).

Note When multiple combinations of inverters and motors exist, do not use multi-core cables for the purpose of bundling the various wires.



(3) Direct current reactor connection terminals P1, P(+)

Connect the direct current reactor (DCR) for power factor enhancement.

- Remove the shorting bar from terminals P1-P(+). (Types FRN0150F2E-4G or above will not have the shorting bar connected.)
- 2) Connect the P1, P(+) terminals to the direct current reactor (option).

Note • Keep the wiring length below 10 meters.

- Do not remove the shorting bar if the direct current reactor is not used.
- When the capacity of the motor to be used is above 75 kW, always connect the direct current reactor.
- Direct current reactors do not have to be connected when connecting PWM converters.

Always connect the direct current reactor (option) when the power supply transformer capacity is above 500 kVA and is over 10 times the rated capacity of the inverter.

Risk of fire exists.

(4) Braking resistor connection terminals P(+) DB (Types FRN0060F2E-4G or below)

- 1) Connect terminals P(+), DB of the inverter to braking resistor terminals (option).
- 2) Mount the inverter main body and the braking resistor such that the wiring length will be less than 5m (16ft) and route the two wires twisted or in contact with each other (parallel).

Do not connect to terminals other than P(+)-DB when connecting braking resistors.

Risk of fire exists.

(5) Direct current bus terminals P(+), N(-)

1) Connecting the braking unit/braking resistor (option)

Inverter type	Braking transistor	Additional instruments for connection (option)	Instruments connected/connection terminals
Types		Braking unit	Inverter (P(+), N(-)) - Braking unit (P(+), N(-))
FRN0075F2E-4G or below	Not equipped	Braking resistor	Braking unit (P(+) R, DB) - Braking resistor (P, DB)

Braking units are necessary when using braking resistors for types FRN0075F2E-4G or above.

Connect terminals P(+), N(-) of the braking unit to the inverter terminals P(+), N(-). Mount the equipment such that the wiring length is below 5m (16ft) and route the two wires twisted or in contact with each other (parallel).

Connect the terminals P(+) R, DB of the braking unit to terminals P(+), DB of the braking resistor. Mount the equipment such that the wiring length is below 10m (33ft) and route the two wires twisted or in contact with each other (parallel).

For details such as other wirings, refer to the user's manual for the braking unit.



Figure 2.2-2

2) Connection of other instruments

The direct current intermediate circuit of other inverters and PWM converters can be connected. (For connection with the PWM converter, refer to Chapter 11 "11.9 Power Regenerative PWM Converters, RHC Series").

(6) Inverter ground terminal @G

This terminal is the ground terminal for the inverter chassis (case). Always connect to ground for safety and as a countermeasure for noise. To prevent accidents such as electric shock and fire, the electrical safety standards require grounding construction for metallic frames in electric instruments.

Follow the steps below in connecting the ground terminal on the power supply side.

- 1) Ground the inverter in compliance with the national or local electric code.
- 2) The grounding wire size should be as described before in this chapter, with large surface area, and as short as possible.

(7) Auxiliary power input terminals for control circuit R0, T0 (Types FRN0045F2E-4G or above)

The inverter can be operated without power input to the auxiliary power input terminals for control circuit. However, the inverter output signals and the keypad display will be shut off when the inverter main power is shut off and the control power source is lost.

When it is desired to retain the alarm signal for the activation of the protective function even inverter main power supply shut off, or when continuous display of the keypad is desired, connect these terminals to the power supply. When the inverter input side has a magnetic contactor (MC), wire from the input side (primary side) of the magnetic contactor (MC).

Terminal rating: AC 380 to 480 V, 50/60 Hz, maximum current 0.5 A (400 V series)

Note When using the earth leakage breaker, connect terminals R0, T0 to the output side of the earth leakage breaker.

When connections are made to the input side of the earth leakage breaker, the earth leakage breaker will malfunction because the inverter input is three-phase and the terminals R0, T0 are single phase. When connecting to terminals R0, T0 to the input side of the earth leakage breaker, make sure that the connection is done through an insulating transformer or, alternatively, through the auxiliary B contacts of the magnetic contactor as shown in the figure below.



Figure 2.2-3 Connection of the Earth Leakage Breaker

Note When connecting with the PWM converter, do not connect power source directly to the inverter's auxiliary power input terminals (R0, T0) for control circuit. Insert an insulating transformer or the auxiliary B contacts of a magnetic contactor on the power supply side.

On connection examples for the PWM converter side, refer to Chapter 11 "11.9 Power Regenerative PWM Converters, RHC Series".



Figure 2.2-4 Example of connection of R0, T0 terminals in combination with PWM converter

(8) Auxiliary power input terminals for fan R1, T1 (Types FRN0176F2E-4G or above)

These terminals are equipped on types FRN0176F2E-4G or below, but are not used ordinarily.

Connect the AC power source when using direct current power supply input (such as in combination with PWM converters).

Also switch the fan power supply switching connectors "CN R", "CN W".

Terminal rating: AC 380 to 440 V/50 Hz, 380 to 480 V/60 Hz, maximum current 1.0 A (400 V series)

2.2.6 Control circuit terminals (common to all models)

[1] Screw specifications and recommended wire size (control circuit terminals)

The screw specifications and wire sizes to be used for control circuit wiring are shown below. The control circuit terminal board differs depending on the destination.

	Sci	rew specification	Allowable wire	Driver	Removal size of	Gauge size to
Terminal symbol	Size	Tightening torque	sizes	(shape of tip)		insert wire
30A, 30B, 30C Y5A, Y5C	М3	0.5 N⋅m (4.43 lb-in)	0.14 to 1.5 mm ² (AWG26 to 16)	Minus (0.6mm×3.5mm)	6 mm (0.24 in)	A1 ^{*1}
Others	M2	0.19 N⋅m (1.68 lb-in)	0.25 to 1 mm ² (AWG24 to 18)	Minus (0.4mm×2.5mm)	5 mm (0.20 in)	φ1.6

Table 2.2-2 Screw Specifications and Recommended Wire Sizes

* Recommended rod terminal: Phoenix Contact Refer to Table 2.2-3 for details.

*1 Defined according to IEC/EN 60947-1.

Scrow size			Туре		
Scie	w size	WIFE SIZE	With insulating collar	Without insulating collar	
		0.25 mm ² (AWG24)	AI 0.25-6 BU	A 0.25-7	
	M2	0.34 mm ² (AWG22)	AI 0.34-6 TQ	A 0.34-7	
MO		0. 5 mm ² (AWG20)	AI 0.5-6 WH	A 0.5-6	
IVIS		0.75 mm ² (AWG18)	AI 0.75-6 GY	A 0.75-6	
		1 mm ² (AWG18)	AI 1-6 RD	A 1-6	
	ſ	1.5 mm ² (AWG16)	AI 1.5-6 BK	A 1.5-7	

Table 2.2-3 Recommended Rod Terminals

Note) When sizes exceeding the recommended wire sizes are used, the front cover may be pushed outward depending on the number of wires, causing erroneous operation of the keypad.

[2] Terminal layout diagram (control circuit terminal)



The following terminals may have high voltage when the power is ON. Control terminals: AUX-contact (30A, 30B, 30C, Y5A, Y5C) Insulation level Contact output – control circuit : Enhanced insulation (overvoltage category II, degree of contamination 2)

Risk of electric shock exists

[3] Description of terminal functions (control circuit terminal)

Generally, the insulation for control signal lines is not enhanced. When the control signal lines come into direct contact with the main circuit live section, the insulation cover may be damaged. High voltage of the main circuit may be applied on the control signal lines, so exercise caution such that the main circuit live sections do not contact the control signal lines.

Risk of accidents and risk of electric shock exist.

Noise is generated by the inverter, motor, and wiring.

Exercise caution to prevent malfunction of peripheral sensors and instruments.

Risk of accidents exists.

Table 2.2-4 shows the functional explanations for the control circuit terminals. The connection method of the control circuit terminals differs depending on the functional code setting matching the purpose of inverter operation. Properly wire such that the impact of noise generated by the main circuit wiring is reduced.

Classification	Terminal symbol	Terminal name	Functional description
	[13]	Power supply for the potentiometer	The terminal is used for the power supply (DC+10 V 10 mA Max) for the external frequency command potentiometer (variable resistor: 1 to 5 k Ω). Connect variable resistors larger than 1/2 W.
nalog input	[12]	Analog setup voltage input	 (1) Frequency is set up according to the external analog voltage input command value. Normal operation DC0 to +10 V/0 to 100(%) (DC0 to +5 V/0 to 100%) DC0 to ±10 V/0 to ±100(%) (DC0 to ±5 V/0 to ±100%) Reverse operation DC+10 to 0V/0 to 100(%) (DC+5 to 0 V/0 to 100%) DC±10 to 0V/0 to ±100(%) (DC±5 to 0V/0 to ±100%) (2) The terminal can be assigned to PID command, feedback signal of PID control, auxiliary frequency setup, ratio setup, torque limit setup, and analog input monitor aside from the frequency setup by analog input. (3) Hardware specification Input impedance: 22 (kΩ) Up to DC±15 V can be input. However, input exceeding DC±10 V will be recognized as DC±10 V.
A	[C1]	Analog setup current input (C1 function)	 Frequency is set up according to the external analog current input command value. Normal operation DC4 to 20 mA/0 to 100(%)/-100% to 0 to 100% DC0 to 20 mA/0 to 100(%)/-100% to 0 to 100% Reverse operation DC20 to 4 mA/0 to 100(%)/-100% to 0 to 100% DC20 to 0 mA/0 to 100(%)/-100% to 0 to 100% DC20 to 0 mA/0 to 100(%)/-100% to 0 to 100% DC20 to 0 mA/0 to 100(%)/-100% to 0 to 100% (2) The terminal can be assigned to PID command, feedback signal of PID control, auxiliary frequency setup, ratio setup, torque limit setup, and analog input monitor aside from the frequency setup by analog input. (3) Hardware specification Input impedance: 250 (Ω) Up to DC 30 mA can be input. However, input exceeding DC 20 mA will be recognized as DC 20 mA.

Table 2.2-4	Functional Description	of Control	Circuit	Terminals
-------------	------------------------	------------	---------	-----------

[C1]	Analog setup voltage input (V2 function)	(1) Frequency is set up according to the external analog voltage input command value. SW3 (refer to "2.2.8 Operating slide switches") must be switched on the printed circuit board. Normal operation
	PTC thermistor input (PTC function)	 DC0 to +10 V/0 to 100(%) (DC0 to +5 V/0 to 100%) DC0 to +10 V/-100 to 0 to 100(%) (DC0 to +5 V/-100 to 0 to 100%) Reverse operation DC+10 to 0 V/0 to 100(%) (DC+5 V to 0 V/0 to 100%) DC+10 to 0 V/-100 to 0 to 100(%) (DC+5 to 0 V/-100 to 0 to 100%) (2) The terminal can be assigned to PID command, feedback signal of PID control, auxiliary frequency setup, ratio setup, torque limit setup, and analog input monitor aside from the frequency setup by analog input. (3) Hardware specification Input impedance: 22(kΩ) (1) PTC (Positive Temperature Coefficient) thermistor for motor protection can be connected. SW3 (C1/V2 Switch) and SW4 (PTC /AI Switch) (refer to "2.2.8 Operating slide switches") must be switched on the printed circuit board. Figure 2.2-5 shows the internal circuit when SW3 and SW4 are set for PTC thermistor input. For details on SW3 and SW4, refer to "2.2.8 Operating slide switches". When SW3 and SW4 are switched to the PTC side, function codes H26 and H27 also needs to be changed.
		changed. <pre></pre>
	Analog input monitor (Al function)	(1) The analog input monitor can be used to monitor the status of peripheral instruments using communication by inputting the analog signals of various sensors such as temperature sensors. Data can be converted to physical property values such as temperature and pressure by using display factors and shown on the keypad display.
[11]	Analog input common	The terminal is the common terminal for analog input signals (terminals [12], [13], [C1]). The terminal is insulated from terminals [CM], [CMY].
Note	 Use shielde which are su external indu increases th When insert Also, do not When extern due to the ne the output te control signa Variable resistor 1 to 5 kΩ 	d lines and keep the wiring to the minimum as possible (below 20 meters) for control signals usceptible to external noise. Grounding the shielded lines is generally recommended, but if uction noise is large, connecting to terminal 11 may reduce the noise. The shielded line e blocking effect. Always ground one end as shown in Figure 2.2-6. ing a relay contact at analog input signal lines, use the twin contacts relay for small signals. insert a relay to terminal 11. mal analog signal generators are connected, the analog signal generator circuit may malfunction noise created by the inverter. In these cases, connect ferrite core (toroidal shape or equivalent) to erminals of the analog signal generator or connect high frequency capacitors between the al lines, as shown in Figure 2.2-7.
	[11] Note	PTC thermistor input (PTC function) Analog input Analog input Monitor (Al function) [11] Analog input (Note) • Use shielder which are su external induincreases the • Also, do not • When insert Also, do not • When external induincreases the • • When insert Also, do not • When external induincreases the •

Table 2.2-4	Functional Description of Control Circuit Terminals (continued)

Classification	Terminal symbol	Terminal name	Functional description
	[X1]	Digital input 1	(1) Various signals (coast to a stop command, external alarm, multi-speed selection, etc) set up by function codes E01 to E05, E98, E99 can be set up. For details, refer to Chapter 5 "FUNCTION CODES"
	[X2]	Digital input 2	 (2) Input mode, sink/source can be switched using SW1. (Refer to "2.2.8 Operating slide switches")
	[X3]	Digital input 3	 (1) The operating mode of the various digital input terminals when connected with terminal CM (sink mode) (PL (source mode) are no suitable to "ON when shorted with CM/PL (
	[X4]	Digital input 4	(active ON)" or "OFF when shorted with CM/PLC (active OFF)"
	[X5]	Digital input 5/pulse train input	 (4) Digital input terminal [X5] can be set up as a pulse train input terminal by changing the function code Maximum wiring length 20 meters Maximum input pulse
	[FWD]	Run forward command	30 kHz: When connected to open collector output pulse generator 100 kHz: When connected to complementary output pulse generator For function code settings, refer to Chapter 5 "ELINCTION CODES"
out	[REV]	Run reverse command	<digital circuit="" input="" specification=""></digital>
al inp			<control block="" circuit=""> Item Minimum Maximum</control>
igita			DC+24 V Operating ON level 0 V 2 V
			PLC Voltage OFF level 22 V 27 V
			swi Operating ON level 22 V 27 V
			Voltage (SOURCE) OFF level 0 V 2 V
			X1 to X5, FWD, REV 6.6 kΩ Operating current at ON (at input voltage 0 V) (for [X5] input terminal) (9.7 mA) (16 mA)
			Allowable leak current at OFF - 0.5 mA
			Figure 2.2-8 Digital Input Circuit
	[PLC]	Programmable controller signal power source	 The terminal is used for connecting the output signal power source of the programmable controller (rated voltage DC +24 V (power supply voltage fluctuation range: DC +22 to +27 V) maximum 100 mA). The terminal can also be used for the power source for the load connected to the transistor outputs. For details, refer to the page on "Transistor outputs".

Table 2.2-4	Functional Description of Control Circuit Terminals	(continued)
		(0011011000)



Table 2.2-4 Functional Description of Control Circuit Terminals (continued)

Chap 2 INSTALLATION AND WIRING

Classification	Terminal symbol	Terminal name	Functional description
Analog output/pulse output	[FM1]	Analog monitor FMV function FMI function Pulse monitor FMP function	This terminal outputs analog direct current voltage DC0 to 10 V or analog direct current DC4 to 20 mA / DC0 to 20mA monitor signal. The output form (FMV/FMI) can be switched using SWS on the printed circuit board and function code F29. Refer to "Table 2.2-5 Functional Description of Slide switches". The signal content can be chosen in the function code F31 data setting among the following items. Output frequency 1 (Command:PM) Output frequency 2 (Estimate:PM) Output trequency 2 (Estimate:PM) Output output Output trequency 2 (Estimate:PM) Output torque Load factor Input power PID feedback value Estimated speed DC link bus voltage Universal AO Motor output Calibration (+) PID command (SV) PID output (MV) Inverter heat sink temperature Estemal PID1 Feedback value External PID1 Set value External PID1 Set value Customizable logic output signal 1 to 10 Allowable impedance for connection: Min 5 kΩ (at DC to 10 V output) (up to 2 analog volt meters (DC0 to 10 V, input impedance 10 kΩ) can be connected.) Allowable impedance for connection: Max 500 Ω (at DC4 to 20 mA/DC0 to 20 mA) Cain adjustable range: 0 to 300% The terminal outputs pulse signal. Signal content can be chosen same as for the FMV function by function code F39. Refer to "Table 2.2-5 Functional Description of Slide switches". Allowable impedance for connection: Min 5 kΩ (at DC to 10 V output) (up to 2 analog volt meters (DC0 to 10 V, input impedance 10 kΩ) can be connected.) Allowable impedance for connection: Min 5 kΩ (at DC to 10 V output) function by function code F39. Refer to "Table 2.2-5 Functional Description of Slide switches". Allowable impedance for connection: Min. 5 kΩ (at DC to 10 V output) (up to 2 analog volt meters (DC0 to 10 V, input impedance 10 kΩ) can be connected.) Pulse duty: Approximately 50%, pulse rate: 25 to 32000 p/s (at full scale) Pulse duty: Approximately 50%, pulse rate: 25 to 32000 p/s (at full scale) Pulse duty: Approximately 50%, pulse rate: 25 to 32000 p/s (at full scale) Pulse utp
	[FM2]	Analog monitor FMV2 function FMI2 function	 This terminal outputs analog direct current voltage DC0 to 10 V or analog direct current DC4 to 20 mA (DC0 to 20mA) monitor signal. The output form (FMV2/FMI2) can be switched using SW7 on the printed circuit board and function code F32. Refer to "Table 2.2-5 Functional Description of Slide switches". The signal content can be chosen in the function code F35 data setting among the same items with [FM1] (F31). * Allowable impedance for connection: Min 5 kΩ (at DC to 10 V output) (up to 2 analog volt meters (DC0 to 10 V, input impedance 10 kΩ) can be connected.) * Allowable impedance for connection: Max 500 Ω (at DC4 to 20 mA/DC0 to 20 mA) * Gain adjustable range: 0 to 300%
	[11]	Analog output common terminal	This terminal is the common terminal for analog input and analog/pulse output signals. The terminal is insulated from terminals [CM] and [CMY]. Do not use [CM] and [CMY] as common terminals for [FM1], [FM2].

Classification	Terminal symbol	Terminal name	Functional description
	[Y1]	Transistor output 1	 Various signals (running signal, frequency reached signal, overload forecast signal, etc. set up by function code E20, E21, E22 can be output. For details, refer to Chapter 5
	[Y2]	Transistor output 2	 "FUNCTION CODES". (2) The operating mode of the transistor output terminals [Y1], [Y2], [Y3] can be switched to "ON (active ON) at signal output" or "OEE (active OEE) at signal output".
	[Y3]	Transistor output 3	<transistor circuit="" output="" specification=""></transistor>
			<control block="" circuit=""></control>
			Photo coupler Current Item Maximum
			$\begin{array}{c c} \downarrow \downarrow \downarrow \\ \downarrow \downarrow \downarrow \\ \downarrow \downarrow \downarrow \downarrow \\ \downarrow \downarrow \downarrow \downarrow \\ \downarrow \downarrow \downarrow \downarrow \downarrow \\ \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \\ \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \\ \downarrow \downarrow$
			Voltage OFF level 27 V
			Max load current at ON 50 mA
			Leak current at OFF 0.1 mA
			Figure 2.2-11 Transistor Output Circuit
			Note • Connect a surge absorbing diode between the terminals the excitation coil when connecting control relays.
outs			When a power source is needed for the circuit to be connected, terminal PLC
outp			can be used as a power source terminal. Rated voltage: DC+24 V (power supply voltage fluctuation range: DC+22 to +27 V) maximum 50 mA). In this
stor			case, terminal [CMY] must be shorted to terminal [CM].
Transi	[CMY]	Transistor output common	This terminal is the common terminal for transistor output signals. This terminal is insulated from terminals [CM] and [11]
	Tin	When conne	cting the programmable controller to terminals [Y1], [Y2], [Y3].
	TIP	The circuit config shown in Figure 2 input and circuit (iration example for connecting the inverter transistor output to the programmable controller is .2-12. Circuit (a) in Figure 2.2-12 shows the programmable controller input circuit as sink b) shows as the source input case.
		<co< td=""><td>trol circuit block-></td></co<>	trol circuit block->
			31 to 35 V CMY 31 to CO CO CO CO CO CO CO CO CO CO
		(a) Connection	diagram for sink input type ble controller (b) Connection diagram for source input type programmable controller
		(a) Connection programma Figure 2.2-12	image: sink type input image: sink type input image: sink type inp
	[Y5A/C]	(a) Connection programma Figure 2.2-12 Relay output	 diagram for sink input type of connection Circuit Configuration with Programmable Controller (b) Various signals similar to those on terminals [Y1] to [Y3] can be selected and output as multipurpoper relay output.
utput	[Y5A/C]	(a) Connection programma Figure 2.2-12 Relay output	 diagram for sink input type (b) Connection diagram for source input type programmable controller Example of Connection Circuit Configuration with Programmable Controller (1) Various signals similar to those on terminals [Y1] to [Y3] can be selected and output as multipurpose relay output. Contact rating: AC250 V 0.3 A cos \$\phi\$ = 0.3, DC48 V 0.5 A (2) Terminals can be switched to "Terminals [Y5A to Y5C] shorted (excitation: active ON) ar ON signal output" or "Terminals [Y5A to Y5C] open (non-excitation: active OFF) at ON signal output"
act output	[Y5A/C]	(a) Connection programma Figure 2.2-12 Relay output	 diagram for sink input type (b) Connection diagram for source input type programmable controller (b) Connection diagram for source input type programmable controller Example of Connection Circuit Configuration with Programmable Controller (1) Various signals similar to those on terminals [Y1] to [Y3] can be selected and output as multipurpose relay output. Contact rating: AC250 V 0.3 A cos \$\phi\$ = 0.3, DC48 V 0.5 A (2) Terminals can be switched to "Terminals [Y5A to Y5C] shorted (excitation: active ON) ar ON signal output" or "Terminals [Y5A to Y5C] open (non-excitation: active OFF) at ON signal output"
Contact output	[Y5A/C] [30A/B/C]	(a) Connection programma Figure 2.2-12 Relay output	 diagram for sink input type (b) Connection diagram for source input type programmable controller (b) Connection diagram for source input type programmable controller (c) Various signals similar to those on terminals [Y1] to [Y3] can be selected and output as multipurpose relay output. Contact rating: AC250 V 0.3 A cos \$\phi\$ = 0.3, DC48 V 0.5 A (2) Terminals can be switched to "Terminals [Y5A to Y5C] shorted (excitation: active ON) at ON signal output" (1) When the inverter stops with an alarm, output is generated on the relay contact (1C). Contact rating: AC250 V 0.3 A cos \$\phi\$ = 0.3, DC48 V 0.5 A

Table 2.2-4	Functional Descri	ption of Control	Circuit Terminals	(continued)
-------------	-------------------	------------------	-------------------	-------------

Classification	Terminal symbol	Terminal name	Functional description				
Communication	RJ-45 connector for keypad connection	RJ-45 connector for keypad connection RS-485 communication port 1	 (1) Used to connect the keypad. The power to the keypad will be supplied from the inverter through this connector. (2) Also can be used to connect a computer, programmable controller, etc by RS-485 communication, after removing the keypad. (On terminating resistor, refer to "2.2.8 Operating slide switches"). Image: the termination of termination of termination of the termination of t				
	[DX+/DX-]	RS-485 communication port 1 [Terminal block]	Also can be used to connect a computer, programmable controller, etc by RS-485 communication. (On terminating resistor, refer to "2.2.8 Operating slide switches"). TXD TXD TXD RXD DE/RE GND Terminating SW6				

Table 2.2-4	Functional Description of Control Circuit Terminals (continued)

Wiring for control circuit terminals

For FRN0304F2E-4G □ to FRN0520F2E-4G □

- (1) As shown in Figure 2.2-14, route the control circuit wires along the left side panel to the outside of the inverter.
- (2) Secure those wires to the wiring support, using a cable tie (e.g., Insulok) with 3.8 mm (0.15 inch) or less in width and 1.5 mm (0.06 inch) or less in thickness.



Figure 2.2-14 Wiring Route and Fixing Position for the Control Circuit Wires



Route the wiring of the control circuit terminals as far as possible from the wiring of the main circuit. Otherwise electric noise may cause malfunctions.

- Fix the control circuit wires with a cable tie inside the inverter to keep them away from the live parts of the main circuit (such as the terminal block of the main circuit).

2.2.7 Switching connector (types FRN0176F2E-4G or above)

Position of each connector

The individual switching connectors are located on the power supply printed circuit board as shown in Figure 2.2-15.



Figure 2.2-15 Switching Connector Positions

Note



When removing the individual connectors, pinch the upper portion of the connector with the fingers, unlock the fastener, and pull. When inserting the connector, push in until the fastener lock engages with the receiving end with a click.

Figure 2.2-16 Attachment and Removal of the Switching Connector

■ Power supply switching connector "CN UX" (types FRN0176F2E-4G or above)

This power supply switching connector "CN UX" is equipped on FRN0176F2E-4G or above. Set the connector CN UX to U1 side (default) or U2 side depending on the power supply voltage specifications to be connected to the main power supply input terminals (L1/R, L2/S, L3/T) and/or the auxiliary power input terminals for the fan (R1, T1), according to the table below.

For details on the switching procedure, refer to "Figure 2.2-15 Switching Connector Positions" and "Figure 2.2-16 Attachment and Removal of the Switching Connector".

(a) FRN0176F2E-4G to FRN0253F2E-4G

Setting	CN UX (red)	CN UX (red)
Applicable voltage	398 to 440 V/ 50 Hz, 430 to 480 V/ 60 Hz	380 to 398 V/ 50 Hz, 380 to 430 V/ 60 Hz (Factory default)

(b) FRN0304F2E-4G to FRN0520F2E-4G

Setting	CN UX (red)	CN UX (red)
Applicable voltage	398 to 440 V/ 50 Hz, 430 to 480 V/ 60 Hz	380 to 398 V/ 50 Hz, 380 to 430 V/ 60 Hz (Factory default)

■ Fan power source switching connector "CN R", "CN W" (types FRN0176F2E-4G or above)

FRENIC-eHVAC supports direct current power supply input with PWM converters in the standard specification. However, FRN0176F2E-4G or above contains parts which are driven by AC power supply such as the AC fan, so AC power must also be supplied. When using DC power for the inverter, move connector "CN R" to <u>NC</u> side, move connector "CN W" to <u>FAN</u> side, and connect an AC power source to the auxiliary power input terminals for the fan (R1, T1).

For details on the switching procedure, refer to "Figure 2.2-15 Switching Connector Positions" and "Figure 2.2-16 Attachment and Removal of the Switching Connector".

Setting	CN R (red)	CN W (white)
Purpose	In the case terminals R1 and T1 are NOT used (Factory default)	In the case terminals R1 and T1 are used • DC bus input type • Combination with PWM converter

(a) FRN0176F2E-4G to FRN0253F2E-4G

FRN0304F2E-4G to FRN0520F2E-4G (b)



The fan power source switching connector "CN R" is on FAN and "CN W" is on NC when shipped from Note the factory. When direct current power supply input is not used, do not modify this setting.

Mistakes in the fan power source switching connector setting may prevent the cooling fan from operating, and alarms such as cooling fin overheat 2i + i and charging circuit error 2i + i may be generated.

2.2.8 Operating slide switches

A WARNING A

Operation of the slide switches should be conducted **after more than 5 minutes has elapsed** since power is shut off **for types FRN0060F2E-4G or below** and **after more than 10 minutes has elapsed for types FRN0075F2E-4G or above**. Confirm that the LED monitor and the charge lamp are turned off, and that the direct current intermediate circuit voltage between the main circuit terminals P(+)-N(-) is below the safe voltage (below DC+25 V) with a tester before operating the switches.

Risk of electric shock exists.

The I/O terminal specification can be changed, such as switching the analog output form, by operating the slide switches on the printed circuit board (Figure 2.2-17 The Slide Switch Locations on the Control Printed Circuit Board).

To operate the slide switches, remove the front cover and make the control printed circuit board visible. (For types FRN0075F2E-4G or above, also open the keypad case).

Refer to "2.2.2 Removal and attachment of the front cover/ terminal cover and wiring guide" to remove the front cover and to open/close the keypad case.

The switch locations on the control printed circuit board are shown in Figure 2.2-17 below.



Figure 2.2-17 The Slide Switch Locations on the Control Printed Circuit Board

	SW1	SW2	SW3	SW4	SW5	SW6	SW7
Various	SINK SOURCE	OFF		AI PTC			FMV2
Factory default	SINK	OFF				OFF	FMV2



Use pointed devices (such as tweezers) to operate the switches. Avoid touching other electronic parts when moving the switches. The switch will be at open state when the slider is in the middle, so make sure to push the slider to the ends.

Functional description of the slide switches is explained in Table 2.2-5 Functional Description of Slide switches.

Table 2.2-5	Functional	Description	of	Slide	switches	s
-------------	------------	-------------	----	-------	----------	---

Switch symbol	Functional description					
SW1	<switch change="" digital="" input="" of="" setting="" sink="" source="" terminals="" to=""> This switch determines the type of input (sink or source) to use for digital input terminals [X1] to [X5], FWD, and REV. </switch>					
SW2	<switch (on="" (rs-485="" 1="" change="" communication="" control="" pcb))="" port="" resistor="" rs-485="" terminating="" the="" to=""> Move the switch to the ON side when RS-485 communication is used and the inverter is located at either end of the communication network. </switch>					
SW3 SW4	<switch [c1]="" change="" input<br="" terminal="" to="">This switch changes the input type for</switch>	setting to current terminal [C1].	/voltage/PTC the	rmistor>		
	Input type	SW3	SW4	E59	H26	
	Current input (factory default)	C1 side	AI side	0	0	
	Voltage input	V2 side	AI side	1	0	
	PTC thermistor input	C1 side	PTC side	0	1	
This switch changes the output type for terminal [FM1]. When operating this switch, also change for code F29. Output type SW5 F29						
	Voltage output (factory default)	FMV side		0		
	Pulse output	FMP	side	3		
SW6	Switch to change the RS-485 communication port 2 terminating resistor (RS-485 communication port (on the terminal board))> • Used for the RS-485/CANopen communication. Move the switch to the ON position when the inverter is located at either end of the communication network.					
SW7	<switch [fm2]="" change="" outp<br="" terminal="" to="">with the destination code -C. This switch changes the output type for code F32.</switch>	out setting to volta	age/current> The When operating	terminal is used o	only on the model	
	Output type	SW7		F32		
	Voltage output	FMV2	2 side	0		
	Current output FMI2 side 1 or 2					



Exercise caution as expected operation may not result if the setting above is not conducted accurately.


OPERATION USING THE KEYPAD

This chapter describes keypad operation of the inverter.

Contents

3.1	Name	es and Functions of Keypad Components	3-1	
3.2	Overview of Operation Modes ······			
3.3	Runn	ning Mode ·····	3-5	
3.3	3.1	Monitoring the running status	3-5	
3.3	3.2	Monitoring light alarms	3-7	
3.3	3.3	Running or stopping the motor	3-8	
3.3	3.4	Setting up reference frequency from the keypad	3-9	
3.3	3.5	Setting up PID commands from the keypad	3-10	
]	1]	Settings under PID process control	3-10	
[2]	Settings under external PID control	3-12	
3.3	3.6	Remote and local modes	3-13	
3.4	Prog	ramming Mode	3-14	
3.4	4.1	Setting up function codes "Data Setting: $//_{-}$ through $/_{\square}$ "	3-15	
3.4	4.2	Checking changed function codes "Data Checking: $c^2, -c^2, c^2$ "	3-16	
3.4	4.3	Monitoring the running status "Drive Monitoring:	3-17	
3.4	4.4	Checking I/O signal status "I/O Checking: 4. ,_ ," ""	3-21	
3.4	4.5	Reading maintenance information "Maintenance Information: 5.54" "	3-25	
3.4	4.6	Reading alarm information "Alarm Information: 5,9," "	3-29	
3.4	4.7	Copying data "Data Copying: '', '', '', ''', ''', '''', '''', '''', ''''''	3-32	
3.4	4.8	Setting up basic function codes quickly "Quick Setup: [], -, -, "	3-36	
3.5	Alarm	n Mode	3-38	
3.5	5.1	Releasing the alarm and switching to Running mode	3-38	
3.5	5.2	Displaying the alarm history	3-38	
3.5	5.3	Displaying the status of inverter at the time of alarm	3-38	
3.5	5.4	Switching to Programming mode	3-38	

3.1 Names and Functions of Keypad Components

The keypad allows you to run and stop the motor, display various data, configure function code data, and monitor I/O signal states, maintenance information and alarm information.



Table 3.1-1	Overview (of Keypad	Functions
		orneypuu	i unctions

Item	LED Monitor, Keys, and LED Indicators					
		Four-digit, 7-segment LED monitor which displays the followings according to the operation modes.				
LED	5000	In Running mode:	Running status information (e.g., output frequency, current, and voltage)			
Monitor	00.00		When a light alarm occurs, $\angle -h'_{-}$ is displayed.			
		 In Programming mode: 	Menus, function codes and their data			
		In Alarm mode:	the protective function.			
		Program/Reset key which	switches the operation modes of the inverter.			
	PBG	In Running mode:	Pressing this key switches the inverter to Programming mode.			
	RESET	In Programming mode:	Pressing this key switches the inverter to Running mode.			
		In Alarm mode:	Pressing this key after removing the alarm factor resets the alarm and switches back to Running mode.			
		Function/Data key which switches the operations you want to do in each mode as follows:				
		In Running mode:	Pressing this key switches the information to be displayed concerning the status of the inverter (output frequency (Hz), output current (A), output voltage (V), etc.).			
o "	FUNC DATA		When a light alarm is displayed, holding down this key resets the light alarm and switches back to Running mode.			
Operation Keys		In Programming mode:	Pressing this key displays the function code or establishes the data entered with \bigodot and \bigodot keys.			
		In Alarm mode:	Pressing this key displays the details of the problem indicated by the alarm code that has come up on the LED monitor.			
	RUN	RUN key. Press this key to run the motor.				
	STOP	STOP key. Press this key to stop the motor.				
	\bigcirc and \bigcirc	UP and DOWN keys. Pre- code data displayed on th	ss these keys to select the setting items and change the function e LED monitor.			
	\otimes	Shift key. Press this key to shift the cursor to the right for entry of a numerical value. Keeping this key pressed will set the keypad to full menu mode.				

Item	LED Monitor, Keys, and LED Indicators	Functions		
	RUN LED	Lights when running with a run command entered by the \overline{PUN} key, by terminal command <i>FWD</i> or <i>REV</i> , or through the communications link.		
	KEYPAD CONTROL LEDLights when the inverter is ready to run with a run command entered by the 2, or 3). In Programming and Alarm modes, however, pressing the will key inverter even if this indicator lights.			
LED Indicators	Unit LEDs (3 LEDs)	These three LED indicators identify the unit of numeral displayed on the LED monitor in Running mode by combination of lit and unlit states of them. Unit: Hz, A, kW, r/min and m/min Refer to "3.3.1 Monitoring the running status" for details.		
		While the inverter is in Programming mode, ■Hz the LEDs of Hz and kW light. □A ■kW		
	x10 LED	Lights when the data to display exceeds 9999. When this LED lights, the "displayed value x 10" is the actual value. Example: If data is "12,345," the LED monitor displays $\frac{1}{2} - \frac{1}{2} - \frac{1}{2}$ and the x10 LED lights, meaning that "1,234 × 10 = 12,340."		

Table 3.1-1 Overview of Keypad	Functions (continued)
--------------------------------	-----------------------

LED monitor

In Running mode, the LED monitor displays running status information (output frequency, current or voltage); in Programming mode, it displays menus, function codes and their data; and in Alarm mode, it displays an alarm code which identifies the alarm factor that has activated the protective function.

If one of LED4 through LED1 is blinking, it means that the cursor is at this digit, allowing you to change it. If the decimal point of LED1 is blinking, it means that the currently displayed data is a value of the PID command, not the frequency data usually displayed.

LED4 LED3 LED2 LED1

8.8.8.8.

Figure 3.1-1 7-Segment LED Monitor

|--|

Character	7-segment	Character	7-segment	Character	7-segment	Character	7-segment	
0	0	9	5	i	1	r	r	
1	/	А	R	J	ل	S	5	
2	2	b	Ь	К	Ч	Т	Г	
3	З	С	Ĺ	L	L	u	U	
4	4	d	ď	М	Π	V	U	
5	5	E	Ε	n	п	W	لخ	
6	6	F	F	0	٥	Х	F	
7	7	G	Ľ	Р	P	у	У	
8	8	Н	Н	q	9	Z	2	
	Special characters and symbols (numbers with decimal point, minus and underscore)							
09. <i>D.</i> - <i>9.</i>								

Тір

Password protection is valid when the decimal point of LED1 is blinking while the keypad in program mode is displaying a function code number. Contact the machine manufacturer if you need to make a display change in the function code.

3.2 Overview of Operation Modes

The FRENIC-eHVAC features the following three operation modes.

Table 3.2-1 Operation Modes

Operation mode	Description
Running mode	When powered ON, the inverter automatically enters this mode. This mode allows you to specify the reference frequency, PID command value and etc., and run/stop the motor with the (a) / (a) keys. It is also possible to monitor the running status in real time. If a light alarm occurs, the ∠ -兄∠ appears on the LED monitor.
Programming mode	This mode allows you to configure function code data and check a variety of information relating to the inverter status and maintenance.
Alarm mode	 If an alarm condition arises, the inverter automatically enters Alarm mode in which you can view the corresponding alarm code* and its related information on the LED monitor. * Alarm code: Indicates the cause of the alarm condition. For details, first see "Table 6.1-1 Abnormal States Detectable ("Heavy Alarm" and "Light Alarm" Objects)" in Chapter 6 "6.1 Protective Function", and then read the troubleshooting of each alarm.

Figure 3.2-1 shows the status transition of the inverter between these three operation modes.



Figure 3.2-1 Status Transition between Operation Modes

Simultaneous keying

Tip

Simultaneous keying means pressing two keys at the same time. The simultaneous keying operation is expressed by a "+" letter between the keys throughout this manual.

For example, the expression "" + " keys" stands for pressing the " key with the key held down.

Figure 3.2-2 illustrates the transition of the LED monitor screen during Running mode, the transition between menu items in Programming mode, and the transition between alarm codes at different occurrences in Alarm mode.



Figure 3.2-2 Transition between Basic Screens in Individual Operation Mode

- (*1) The speed monitor allows you to select the desired one from the speed monitor items by using function code E48.
- (*2) Applicable only when PID control is active (J01 = 1, 2 or 3).
- (*3) The analog input monitor can appear only when the analog input monitor function is assigned to one of the analog input terminals by one of function codes E61 to E63 (= 20).
- (*4) This item will be displayed only in the case of implementing external PID control (J501 = 1 to 32).
- (*5) This item will be displayed only if the auto/manual terminal function of external PID control 1 (i.e., external PID control 1 cancel "%/EPID1") is assigned.
- (*6) Applicable only when the full-menu mode is selected (E52 = 2). When a remote keypad with USB is equipped, '...', '...' is displayed.

3.3 Running Mode

3.3.1 Monitoring the running status

In Running mode, the 17 items listed below can be monitored. Immediately after the inverter is turned on, the monitor item specified by function code E43 is displayed. Press the 🛞 key to switch between monitor items.

Monitor items		Display sample on the LED monitor *1	LED indicator ■: on, □: off	Unit	Meaning of displayed value	Function code data for E43	
Speed monitor		Function coc indicators.	Function code E48 specifies what to be displayed on the LED monitor and LED indicators.				
	Output frequency 1 Speed command value *11	<i>50.00</i>	■Hz □A □kW	Hz	Frequency actually being output (Speed command value)	(E48 = 0)	
	Output frequency 2 Speed estimated value *11	<i>50.00</i>	■Hz □A □kW	Hz	Frequency actually being output (Speed estimated value)	(E48 = 1)	
	Reference frequency	<i>50.00</i>	■Hz □A □kW	Hz	Reference frequency being set	(E48 = 2)	
	Motor speed	<i>1500</i>	■Hz ■A □kW	r/min	Outputfrequency(Hz)× $\frac{120}{P01}$	(E48 = 3)	
	Load shaft speed	300.0	■Hz ■A □kW	r/min	Output frequency (Hz) × E50	(E48 = 4)	
	Speed (%)	50.0	DHz DA DkW	%	Outputfrequency ×100 Maximumfrequency	(E48 = 7)	
Οι	itput current	12.34	⊡Hz ∎A ⊡kW	А	Current output from the inverter in RMS	3	
Inp	out power	10.25	□Hz □A ■kW	kW	Input power to the inverter	9	
Ca	Iculated torque *2	50	□Hz □A □kW	%	Motor output torque (Calculated value)	8	
Output voltage *3		2000	□Hz □A □kW	V	Voltage output from the inverter in RMS	4	
Motor output *4		<i>9.85</i>	□Hz □A ■kW	kW	Motor output (kW)	16	
Load factor *5		50L	□Hz □A □kW	%	Load factor of the motor in % as the rated output being at 100%	15	
ΡI	D command *6, *7	10.00.	□Hz □A □kW	-	PID command/feedback amount converted to a physical quantity of the object to be	10	
*6, *8 PID feedback amount		<i>9.00</i> .	□Hz □A □kW	_	Refer to function codes J106 and J107 for details.	12	
PID output *6, *7		ההה	□Hz □A □kW	%	PID output in % as the maximum frequency (F03) being at 100%	14	
Analog input monitor *9		82.00	□Hz □A □kW	_	An analog input to the inverter in a format suitable for a desired scale. Refer to the following function codes. Terminal [12]: C59, C60 Terminal [C1] (C1 function): C65, C66 Terminal [C1] (V2 function): C71, C72	17	
Input watt-hour		100.0	□Hz □A □kW	kWh	Input watt-hour (kWh) 100	25	
External PID command *12, *7		12.00.	□Hz □A □kW	_	PID command/feedback amount converted to a physical quantity of the object to be	60	
External PID feedback amount *12, *8		<i>9.00.</i>	□Hz □A □kW	_	controlled Refer to function codes J506 and J507 for details.	61	
Ex	ternal PID output *12, *7	100.0.	□Hz □A □kW	%	PID output in % as the maximum output frequency (F03) being at 100%	62	
Manual external PID command *12, *7		10.00.	□Hz □A □kW	%	PID command in % as the maximum output frequency (F03) being at 100%.	63	

Table 3.3-1 Monitoring Items

- *1 A value exceeding 9999 cannot be displayed as is on the 4-digit LED monitor screen, so the LED monitor displays one-tenth of the actual value with the x10 LED lit.
- *2 Calculated torque 100% is equal to the motor rated torque. For the calculation formula of the motor rated torque, refer to E.2 "Calculation formulas" (1) in Appendix E "Conversion from SI Units."
- *3 When the LED monitor displays the output voltage, the 7-segment letter $\angle /$ in the lowest digit stands for the unit of the voltage "V."
- *4 When the LED monitor displays the motor output, the unit LED indicator "kW" blinks.
- *5 When the LED monitor displays the load factor, the 7-segment letter L in the lowest digit stands for "%."
- *6 These PID related items appear only under the PID control specified by function code J01 (= 1, 2 or 3).
- *7 When the LED monitor displays a PID command or its output amount, the dot (decimal point) attached to the lowest digit of the 7-segment letter blinks.
- *8 When the LED monitor displays a PID feedback amount, the dot (decimal point) attached to the lowest digit of the 7-segment letter lights.
- *9 The analog input monitor appears only when the analog input monitor function is assigned to one of the analog input terminals by one of function codes E61 to E63 (= 20). Specify the unit with C58, C64 and C70. When the displayed value is less than -999, the x10 LED is lit.
- *10 *[]* appears under the V/f control.
- *11 Both values will display output frequencies in the case of induction motor control. Output frequency 1 will display the frequency conversion of the speed command value and output frequency 2 will display the frequency conversion of the estimated speed value in the case of permanent magnet synchronous motor control.
- *12 This item will be displayed only in the case of implementing external PID control (with J501 set to 1 or a larger value).



The monitoring signals for the monitor items such as output frequency and output current can be filtered with function code E42 (LED display filter). Increase the E42 data if the monitored values are unstable and unreadable due to fluctuation of load. (

3.3.2 Monitoring light alarms

The FRENIC-eHVAC identifies abnormal states in two categories--Heavy alarm and Light alarm. If the former occurs, the inverter immediately trips; if the latter occurs, the inverter shows the $\angle - \neg \Box$ on the LED monitor and blinks the KEYPAD CONTROL LED but it continues to run without tripping.

Which abnormal states are categorized as a light alarm ("Light alarm" object) should be defined with function codes H81 and H82 beforehand.

Assigning the *L-ALM* signal to any one of the digital output terminals with any of function codes E20 to E22, E24 and E27 (= 98) enables the inverter to output the *L-ALM* signal on that terminal upon occurrence of a light alarm.

For details of the light alarm objects, refer to Chapter 6 "TROUBLESHOOTING."



How to check a light alarm factor

If a light alarm occurs, $L - R_{L}$ appears on the LED monitor. To check the current light alarm factor, enter Programming mode by pressing the result is key and select $5_{-} 3 - 3 - 5$ on Menu #5 "Maintenance Information."

It is also possible to check the factors of the last three light alarms $5_2 \exists 7$ (last) to $5_2 \exists 2$ (3rd last). To check the light alarm factors in Menu #5 "Reading maintenance information," it is necessary to set the data of function code E52 to "2" (Full-menu mode) beforehand.

For details of the menu transition of the maintenance information, refer to "3.4.5 Reading maintenance information "Maintenance Information: $5.2H^{2}$ "."

How to reset a light alarm

After checking the current light alarm factor, to switch the LED monitor from the $\angle -\beta'_{\perp}$ indication state back to the running status display (e.g., output frequency), press the $\frac{\beta_{LRC}}{\beta_{RR}}$ key in Running mode.

If the light alarm factor has been removed, the KEYPAD CONTROL LED stops blinking and the *L-ALM* signal turns OFF. If not (e.g. DC fan lock), the KEYPAD CONTROL LED continues blinking and the *L-ALM* signal remains ON.

3.3.3 Running or stopping the motor

By factory default, pressing the (1) key starts running the motor in the forward direction and pressing the (1) key decelerates the motor to stop. The (1) key is enabled only in Running mode.

When the inverter is running, the RUN LED lights.

To run the motor in the reverse direction or to run it reversibly, change the data of function code F02 to "3" or "0," respectively.



Note: The rotation direction of IEC-compliant motors is opposite to the one shown above.

Data for F02	Pressing the Run key runs the motor:
0	In the direction commanded by terminal [FWD] or [REV]
1	Disable we (The motor is driven by terminal [FWD] or [REV] command.)
2	In the forward direction
3	In the reverse direction

Table 3.3-2	Motor Rotatio	n Direction	Specified	by F02
-------------	---------------	-------------	-----------	--------

3.3.4 Setting up reference frequency from the keypad

You can set up the desired reference frequency with the \bigcirc and \bigcirc keys on the keypad. It is also possible to set up the reference frequency as load shaft speed, motor speed or speed (%) by setting function code E48.

Using the keypad (F01 = 0 (factory default) or 8)

- (1) Set function code F01 to "0" (Keypad operation using \bigcirc / \bigcirc keys) or "8" (Keypad operation using \bigcirc / \bigcirc keys, balanceless-bumpless). Frequency setting with the keypad is disabled in Programming or Alarm mode. To enable it, switch to Running mode.
- (2) Press the \bigcirc / \bigcirc key to display the current reference frequency. The lowest digit blinks.
- (3) To change the reference frequency, press the \bigcirc / \bigcirc key again. The new setting can be saved into the inverter's internal memory.





- Holding down the 🔿 / 🔗 key changes data in the least significant digit and generates a carry.
- The reference frequency can be saved either automatically by turning the main power OFF or only by pressing the (key) key. You can choose either way using function code E64. The factory default is "0" (Automatic saving when main power is turned OFF).
- To set the reference frequency, first press the () key once to blink the least significant digit. After that, each time the () key is pressed, the cursor moves to the next higher digit where data can be changed. This cursor movement allows you to easily move the cursor to the desired digit and change the data in higher digits.
- Setting F01 data to "8" (Keypad operation using ⊘ / ⊗ keys, balanceles-bumpless) enables balanceless-bumpless switching.

Balanceless-bumpless switching refers to the function that makes the inverter inherit the current frequency that has applied before the frequency command source is switched to the keypad from any other source, providing smooth switching and shockless running.

3.3.5 Setting up PID commands from the keypad

You can set up the desired PID commands with the \odot and \odot keys on the keypad.

[1] Settings under PID process control

To enable the PID process control, you need to set the J01 data to "1" or "2."

Under the PID control, the items that can be specified or checked with \triangle and \bigcirc keys are different from those under regular frequency control, depending upon the current LED monitor setting. If the LED monitor is set to the speed monitor (E43 = 0), the item accessible is a manual speed command (reference frequency); if it is set to any other, the item is a PID process command.

Setting the PID process command with \bigcirc and \bigcirc keys

Tip

- (1) Set function code J02 to "0" (\bigcirc / \bigcirc keys on keypad).
- (2) Set the LED monitor to something other than the speed monitor (E43=0) when the inverter is in Running mode. When the keypad is in Programming or Alarm mode, you cannot modify the PID process command with the ⊘ / ⊘ key. To enable the PID process command to be modified with the ⊘ / ⊘ key, first switch to Running mode.
- (3) Press the 🔿 / 🛇 key to display the PID process command. The lowest digit and its decimal point blink on the LED monitor.
- (4) To change the PID process command, press the 🔿 / 🛇 key again. The new setting can be saved into the inverter's internal memory.
 - The PID process command can be saved either automatically by turning the main power OFF or only by pressing the key. You can choose either way using function code E64.
 - Even if multistep PID command is selected as a PID command (*PID-SS1* or *PID-SS2* = ON), it is
 possible to set a PID command using the keypad.
 - When function code J02 is set to any value other than "0," pressing the 🔿 / 🛇 key displays, on the LED monitor, the PID command currently selected, but does not allow any change.
 - On the LED monitor, the decimal point of the lowest digit is used to discriminate the PID related data from the reference command. The decimal point blinks or lights when a PID command or PID feedback amount is displayed, respectively.



PID control (Mode selection) J01	PID control (Remote command SV) J02	LED monitor E43	PID control multistage command PID-SS1 , PID-SS2	With 🔿 / 🛇 key
1 or 2	0 Other than 0	Other than 0		PID process command <u>by keypad</u>
T OF 2		Other than 0		PID process command currently selected

Table 3.3-3 PID Process Command Manually Set with 🔿 / 🔗 Key and Requirements

Setting up the reference frequency with \bigotimes and \bigotimes keys under PID process control

When function code F01 is set to "0" (\bigcirc / \bigcirc keys on keypad) and frequency setting 1 is selected as a manual speed command (when disabling the frequency setting command via communications link, multistep frequency command, and PID control), switching the LED monitor to the speed monitor in Running mode enables you to modify the reference frequency with the \bigcirc / \bigcirc keys.

In Programming or Alarm mode, the \bigcirc / \bigcirc keys are disabled to modify the reference frequency. You need to switch to Running mode.

Table 3.3-4 lists the combinations of the commands. Figure 3.3-1 illustrates how the manual speed command ① entered via the keypad is translated to the final frequency command ②.

The setting procedure is the same as that for setting of a usual reference frequency.

PID control (Mode selection) J01	LED monitor E43	Frequency setting 1 F01	Multistep frequency SS2	Multistep frequency SS1	Select link operation <i>LE</i>	Cancel PID control Hz/PID	Pressing ⊘ / ⊘ keys controls:
		0	OFF	OFF	OFF	ON	Manual speed command (frequency) set by keypad
1 or 2	0		Other than	the above		(PID disabled)	Manual speed command (frequency) currently selected
			Don't	care		OFF (PID enabled)	PID output (as final frequency command)

Table 3.3-4 Manual Speed (Frequency) Command Specified with 🔿 / 🔗 Keys and Requirements



Figure 3.3-1

[2] Settings under external PID control

External PID control will be enabled if function code J501 is set to 1 or a larger value.

For more information on external PID control, refer to Chapter 5 "5.3.7 J codes (Applied functions)".

The displayed content at the time of \bigcirc/\bigcirc key control will change according to the LED monitor (E43) settings when external PID control is enabled.

PID control (remote command) J502	LED monitor E43	Displayed with the \bigcirc / \bigcirc key turned ON.
	0~25 : Other than monitors related to external PID control	Inverter frequency set value
0	60~62 : External PID control command, feedback amount, and output	External PID process command (settings enabled) by the keypad
	63 : Manual external PID control command	Manual external PID command (settings enabled) by the keypad *1
	0~25 : Other than monitors related to external PID control	Inverter frequency set value
Other than 0	60~62 : External PID control command, feedback amount, and output	External PID control process command
	63 : Manual external PID control command	Manual external PID command (settings enabled) by the keypad *1

Table 3.3-5 LED Monitor Display under

*1: Enabled when the external PID control 1 cancel command "%/EPD1" is assigned to the control terminal.

3.3.6 Remote and local modes

The inverter is available in either remote or local mode. In the remote mode that applies to ordinary operation, the inverter is driven under the control of the data settings stored in the inverter, whereas in the local mode that applies to maintenance operation, it is separated from the control system and is driven manually under the control of the keypad.

- Remote mode: Run and frequency commands are selected by function codes or source switching signals except
 LOC ("Select local (keypad) command").
- Local mode: The command source is the keypad, regardless of the settings specified by function codes. The keypad takes precedence over the settings specified by communications link operation signals.

Run commands from the keypad in local mode

The table below shows the input procedures of run commands from the keypad in the local mode.

	Data for F02	Input Procedures of Run Commands from Keypad
0:	Enable (IN) / (TOP) keys on keypad (Motor rotation direction from digital terminals [FWD]/[REV])	Pressing the we runs the motor in the direction specified by command <i>FWD</i> or <i>REV</i> assigned to terminal [FWD] or [REV], respectively. Pressing the ^{stop} key stops the motor.
1:	Enable terminal command FWD/REV	Pressing the RUN key runs the motor in the forward direction only. Pressing the ROP key stops the motor.
2:	Enable (PUN) / (STOP) keys on keypad (Forward)	No specification of the motor rotation direction is required.
3:	Enable (Reverse) / (TOP) keys on keypad (Reverse)	Pressing the function key runs the motor in the reverse direction only. Pressing the for key stops the motor. No specification of the motor rotation direction is required.

Switching between remote and local modes

The remote and local modes can be switched by a digital input signal provided from the outside of the inverter. To enable the switching, you need to assign *LOC* as a digital input signal to any of terminals [X1] to [X5] by setting "35" to any of E01 to E05, E98 and E99.

Switching from remote to local mode automatically inherits the frequency settings used in remote mode. If the motor is running at the time of the switching from remote to local, the run command will be automatically turned ON so that all the necessary data settings will be carried over. If, however, there is a discrepancy between the settings used in remote mode and ones made on the keypad (e.g., switching from the reverse rotation in remote mode to the forward rotation only in local mode), the inverter automatically stops.

The transition paths between remote and local modes depend on the current mode and the value (ON/OFF) of *LOC*, as shown in the status transition diagram given Figure 3.3-2. Also, refer to above table for details



Figure 3.3-2 Transition between Remote and Local Modes by LOC

3.4 **Programming Mode**

The Programming mode provides you with the following functions--setting and checking function code data, monitoring maintenance information and checking input/output (I/O) signal status. The functions can be easily selected with the menu-driven system. Table 3.4-1 lists menus available in Programming mode. The leftmost digit (numerals) of each letter string on the LED monitor indicates the corresponding menu number and the remaining three digits indicate the menu contents.

When the inverter enters Programming mode from the second time on, the menu selected last in Programming mode will be displayed.

Menu #	Menu	LED monitor shows:	Main functions					
		!,F	F codes (Fundamental functions)					
		1.E	E codes (Extension terminal functions)					
		//¯	C codes (Control functions)					
		!/P	P codes (Motor 1 parameters)					
		/,/ /	H codes (High performance functions)					
		!,H	H1 codes (100s) (High performance functions)					
		I,R	A codes (Motor 2 parameters)	Selecting each of				
1	"Data Sotting"	,_	J codes (Application functions 1)	codes enables its	Section			
1	Data Setting	_!!-! 	J4 codes (400s) (PID functions)	data to be	3.4.1			
		1.15_	J5 codes (500s) (PID functions)	changed.				
		<i>\.</i> ₫	d codes (Application functions 2)	_				
		<u>, </u> _	U codes (Customizable logic functions)					
		1.L1 1_	U1 codes (100s) (Customizable logic functions)					
		! <u>.</u>	y codes (Link functions)					
		//_/	K code (Keypad functions)					
		l	o codes (Optional functions) (Note)					
2	"Data Checking"	2,-62	Displays only function codes that have b their factory defaults. You can refer to or function code data.	een changed from change those	Section 3.4.2			
3	"Drive Monitoring"	3.oPE	Displays the running information required or test running.	d for maintenance	Section 3.4.3			
4	"I/O Checking"	40	Displays external interface information.		Section 3.4.4			
5	"Maintenance Information"	S.CHE	Displays maintenance information includ time.	ing cumulative run	Section 3.4.5			
6	"Alarm Information"	5.AL	Displays the recent four alarm codes. Yo running information at the time when the	u can refer to the alarm occurred.	Section 3.4.6			
7	"Data Copying"	נייזר	Allows you to read or write function code verifying it. (Only available with TP-E1U)	data, as well as	Section 3.4.7			
0	"Quick Setup"	D.F.n.E	Displays only basic function codes to cus operation.	stomize the inverter	Section 3.4.8			

Table 3.4-1 Menus Available in Programming Mode

(Note) The "o" codes are displayed only when the corresponding option is mounted. For details, refer to the Instruction Manual for the corresponding option.

Selecting menus to display

The menu-driven system allows you to cycle through menus. To cycle through necessary menus only for simple operation, use function code E52 that provides a choice of the display modes as listed Table 3.4-2.

The factory default (E52 = 0) is to display three menus--Menu #1 "Data Setting," Menu #7 "Data Copying," and Menu #0 "Quick Setup," allowing no switching to any other menu.

Data for E52	Mode	Menus selectable
0	Function code data setting mode (factory default)	Menu #1 "Data Setting" Menu #7 "Data Copying" Menu #0 "Quick Setup"
1	Function code data check mode	Menu #2 "Data Checking" Menu #7 "Data Copying"
2	Full-menu mode	Menus #0 through #8

Table 0.4.0	Kaymad Diamlay	Mada Calastian	Function	Code EFO
Table 3.4-2	Keypad Display	/ wode Selection -	- Function	Code ESZ



Press the \bigotimes key to enter Programming mode and display menus. While cycling through the menus with the \bigotimes / \bigotimes key, select the desired menu item with the \bigotimes key. Once the entire menu has been cycled through, the display returns to the first menu item.

3.4.1 Setting up function codes "Data Setting: l_{-} through l_{-} "

Menu #1 "Data Setting" (L_{--} through L_{--}) in Programming mode allows you to configure all function codes.

($L_{\mathcal{D}}$ is displayed only when the option is installed.)

To use "Data Setting," you need to set function code E52 to "0" (Function code data setting mode) or "2" (Full-menu mode).

Figure 3.4-1 shows the menu transition and the function code data change procedure in "Data Setting."



Basic key operation

- (1) Turn the inverter ON. It automatically enters Running mode in which you press the regramming mode. The function selection menu appears.
- (2) Use the \bigotimes and \bigotimes keys to select the desired function code group from the choices \mathscr{I}_{-} through \mathscr{I}_{-} .
- (3) Press the 🕮 key to proceed to the list of function codes for the selected function code group.
- (4) Use the ⊗ and ⊗ keys to display the desired function code, then press the key. The data of this function code appears.
- (5) Change the function code data using the \triangle and \bigcirc keys.
- (6) Press the \bigoplus key to establish the function code data.

The SRUE appears (blinking) and the data will be saved in the memory inside the inverter. After that, the display will return to the function code list and then move to the next function code.

Pressing the key instead of the key cancels the change made to the data. The data reverts to the previous value, the display returns to the function code list, and the original function code reappears.

(7) Press the key to return to the menu from the function code list.



Cursor movement

When changing function code data, pressing the \bigotimes key once blinks the least significant digit. After that, each time the \bigotimes key is pressed, the cursor moves to the next higher digit where data can be changed. This cursor movement allows you to easily move the cursor to the desired digit and change the data in higher digits.

3.4.2 Checking changed function codes "Data Checking: 2,-EP "

Menu #2 "Data Checking" $(\underline{c}, -\underline{c}, \underline{c})$) in Programming mode allows you to check function codes that have been changed. Only the function codes whose data has been changed from the factory defaults are displayed on the LED monitor. You can refer to the function code data and change it again if necessary.

To check function codes in Menu #2 "Data Checking," you need to set function code E52 to "1" (Function code data check mode) or "2" (Full-menu mode).

The menu transition in "Data Checking" is the same as the one in Menu #1 "Data Setting."

3.4.3 Monitoring the running status "Drive Monitoring: <u>J.o.PE</u>"

Menu #3 "Drive Monitoring" ($\exists \Box \vdash \Box \vdash \Box$) is used to monitor the running status during maintenance and test running. The display items for "Drive Monitoring" are listed in Table 3.4-3. Figure 3.4-2 shows the menu transition in "Drive Monitoring."



Figure 3.4-2 Menu Transition in Menu #3 "Drive Monitoring"

Basic key operation

To monitor the running status in "Drive monitoring," set function code E52 to "2" (Full-menu mode) beforehand.

- (1) Turn the inverter ON. It automatically enters Running mode in which you press the regramming mode. The function selection menu appears. (In this example, D,F,-,L) is displayed.)
- (3) Press the \bigotimes key to proceed to a list of monitoring items (e.g. $\exists_{-} \Box \Box$).
- (4) Use the ⊗ and ⊗ keys to display the desired monitoring item, then press the key. The running status information for the selected item appears.
- (5) Press the 🕮 key to return to the list of monitoring items. Press the 🕮 key again to return to the menu.

LED monitor shows:	Item	Unit	Description
3_00	Output frequency 1	Hz	Output frequency 1 (Command: PM)
3_07	Output frequency 2	Hz	Output frequency 2 (Estimate: PM)
3_02	Output current	А	Output current
3_03	Output voltage	V	Output voltage
3_ <i>0</i> 4	Calculated torque	%	Calculated output torque of the motor
3_05	Reference frequency	Hz	Frequency specified by a frequency command
3_05	Rotation direction	N/A	Rotation direction of current output /=: forward, /=: reverse,: stop
3_07	Running status	N/A	Running status in 4-digit hexadecimal format Refer to " Displaying running status ($\underline{-},\underline{-},\overline{-},\overline{-},\overline{-},\overline{-},\overline{-},\overline{-},\overline{-},\overline$
פת ב	Motor speed	r/min	Display value = (Output frequency Hz) $\times \frac{120}{(No. of poles)}$
_1_1_1_1	Notor speed	1/11111	If the value is 10000 or greater, the x10 LED turns ON and the LED monitor shows one-tenth of the value.
		, .	Display value = (Output frequency Hz) × (Function code E50: Coefficient for speed indication)
ש'יק	Load shaft speed	r/min	If the value is 10000 or greater, the x10 LED turns ON and the LED monitor shows one-tenth of the value.
3_ 10	PID command value	N/A	Virtual physical value (e.g., temperature or pressure) of the object to be controlled, which is converted from the PID command value using function code J106 and J107 data (PID display Maximum scale/ minimum scale) Display value = (PID command value (%)) / 100 * (Max. scale - Min. scale) + Min. scale
			If PID control is disabled, "" appears.
3_ 11	PID feedback amount	N/A	Virtual physical value (e.g., temperature or pressure) of the object to be controlled, which is converted from the PID feedback amount using function codeJ106 and J107 data (PID display Maximum scale/ minimum scale) Display value = (PID feedback value (%)) / 100 * (Max. scale - Min. scale) + Min. scale
בי ב	Torque limit value A	%	Driving forque limit value A (based on motor rated forque)
"-	Torque limit value R	%	Braking torque limit value B (based on motor rated torque)

Table 3.4-3 "Drive Monitoring" Display Items

LED monitor shows:	Item	Unit	Description
3_27	PID output value	%	PID output value. (100% at the maximum frequency) If PID control is disabled, "" appears.
3_23	Running status 2	N/A	Running status 2 in 4-digit hexadecimal format Refer to " Displaying running status ($\underline{3}$, $\underline{3}$, $\underline{3}$) and running status 2 ($\underline{3}$, $\underline{23}$)" given below.
3_60	External PID command	N/A	Virtual physical value (e.g., temperature or pressure) of the object to be controlled, which is converted from the external PID command value using function code J506 and J507 data (PID display Maximum scale/ minimum scale) Display value = (PID command value (%))/100 * (Max. scale - Min. scale) + Min. scale If external PID control is disabled (J501 = 0), "" appears.
3_6 (External PID feedback amount	N/A	Virtual physical value (e.g., temperature or pressure) of the object to be controlled, which is converted from the external PID feedback amount using function code J506 and J507 data (PID display Maximum scale/ minimum scale) Display value = (PID feedback value (%))/100 * (Max. scale - Min. scale) + Min. scale If external PID control is disabled (J501 = 0), "" appears.
3_62	External PID output value	%	External PID output value (100% at the maximum frequency) If external PID control is disabled (J501 = 0), "" appears.
3_63	Manual external PID command value	%	Manual external PID command value (100% at the maximum frequency) If external PID control is disabled (J501 = 0), "" appears.

Table 3.4-3	"Drive	Monitoring"	Display	Items	(Continued)
-------------	--------	-------------	---------	-------	-------------

Displaying running status $(\underline{J}_{\underline{D}}, \underline{J}, \underline{J}$

To display the running status and running status 2 in 4-digit hexadecimal format, each state has been assigned to bits 0 to 15 as listed in Table 3.4-4 and Table 3.4-5 respectively. Table 3.4-6 shows the relationship between each of the status assignments and the LED monitor display.

Table 3.4-7 gives the conversion table from 4-bit binary to hexadecimal.

Table 3.4-4 Running Status ($\exists_- \Box \exists_-$) Bit Assignment

Bit	Notation	Content	Bit	Notation	Content
15	BUSY	"1" when function code data is being written.	7	VL	"1" under voltage limiting control.
14		Always "0."	6	TL	"1" under torque limiting control.
13	WR	Always "0."	5	NUV	"1" when the DC link bus voltage is higher than the under voltage level.
12	RL	"1" when communication is enabled (when ready for run and frequency commands via communications link).	4	BRK	"1" during braking.
11	ALM	"1" when an alarm has occurred.	3	INT	"1" when the inverter output is shut down.
10	DEC	"1" during deceleration.	2	EXT	"1" during DC braking.
9	ACC	"1" during acceleration.	1	REV	"1" during running in the reverse direction.
8	IL	"1" under current limiting control.	0	FWD	"1" during running in the forward direction.

Bit	Notation	Content	Bit	Notation	Content
15		Motor type0: Induction motor control1: Permanent magnet synchronous motor control	7	_	Speed limiting (under torque control)
14			6	_	
13			5	_	(Not used.)
12			4	_	
11	—	(Not used.)	3	—	Inverter drive control
10			2	_	0000: V/f control
9			1	_	0101: Vector control for PMSM without speed sensor and magnetic
8			0	_	pole position sensor

Table 3.4-6 Running Status Display

LI	LED No. LED4			LED3				LED2				LED1					
	Bit	15 14 13 12		11	10	9	8	7	6	5	4	3	2	1	0		
Ν	otation	BUSY	WR	R	L	ALM	DEC	ACC	IL	VL	TL	NUV	BRK	INT	EXT	REV	FWD
	Binary	1	0	0	0	0	0	1	1	0	0	1	0	0	0	0	1
Example	Hexa- decimal on the LED monitor										LED1						

Hexadecimal expression

A 4-bit binary number can be expressed in hexadecimal (1 hexadecimal digit). Table 3.4-7 shows the correspondence between the two notations. The hexadecimals are shown as they appear on the LED monitor.

	Bin	Binary Hexadecimal				Bin		Hexadecimal	
0	0	0	0	D	1	0	0	0	8
0	0	0	1	/	1	0	0	1	3
0	0	1	0	2	1	0	1	0	R
0	0	1	1	-	1	0	1	1	6
0	1	0	0	4	1	1	0	0	Ĺ
0	1	0	1	5	1	1	0	1	ď
0	1	1	0	6	1	1	1	0	E
0	1	1	1	7	1	1	1	1	F

Table 3.4-7 Binary and Hexadecimal Conversion

3.4.4 Checking I/O signal status "I/O Checking: 4, /___"

Using Menu #4 "I/O Checking" ($\frac{1}{2}$, $\frac{1}{2}$) displays the I/O status of external signals including digital and analog I/O signals without using a measuring instrument. Table 3.4-8 lists check items available. The menu transition in "I/O Checking" is shown in Figure 3.4-3.



Figure 3.4-3 Menu Transition in Menu #4 "I/O Checking"

Basic key operation

To check the status of the I/O signals, set function code E52 to "2" (Full-menu mode) beforehand.

- (1) Turn the inverter ON. It automatically enters Running mode in which you press the rogramming mode. The function selection menu appears.
- (2) Use the \bigotimes and \bigotimes keys to display "I/O Checking" ($\overset{\prime}{\neg}$, $_{-\Box}$).
- (3) Press the $\textcircled{\mbox{\tiny BM}}$ key to proceed to a list of I/O check items (e.g. $\mbox{\it H}_{-}\ensuremath{\square}$).
- (4) Use the \bigotimes and \bigotimes keys to display the desired I/O check item, then press the \bigotimes key. The corresponding I/O check data appears. For the item $\frac{1}{2} \frac{1}{2}$ or $\frac{1}{2} \frac{1}{2}$ using the \bigotimes and \bigotimes

The corresponding I/O check data appears. For the item 4_2D or 4_2D , using the \bigcirc and \bigcirc keys switches the display method between the segment display (for external signal information in Table 3.4-9) and hexadecimal display (for I/O signal status in Table 3.4-10).

(5) Press the 🕮 key to return to the list of I/O check items. Press the 🕮 key again to return to the menu.

Table 3.4-8	I/O Check Items
-------------	-----------------

LED monitor shows:	ltem	Unit	Description
4_ <i>0</i> 0	I/O signals on the control circuit terminals		Shows the ON/OFF state of the digital I/O terminals. Refer to " <u>■ Displaying control I/O signal terminals</u> " on the next page for details.
4_ <i>0</i> /	I/O signals on the control circuit terminals under communications control		Shows the ON/OFF state of the digital I/O terminals that received a command via RS-485 or field bus option. Refer to " Displaying control I/O signal terminals" and Displaying control I/O signal terminals under communications control" on the following pages for details.
4_02	Input voltage on terminal [12]	~	Shows the input voltage (with sign) on terminal [12] in volts (V).
4_03	Input current on terminal [C1] (C1 function)	mA	Shows the input current on terminal [C1] (C1 function) in milliamperes (mA).
4_04	Output voltage on terminal [FM1] (FMV)	V	Shows the output voltage on terminal [FM1] (FMV) in volts (V).
4_05	Output voltage on terminal [FM2] (FMV)	v	Shows the output voltage on terminal [FM2] (FMV) in volts (V).
4_05	Output frequency on terminal [FM1] (FMP)	p/s	Shows the output pulse rate per unit of time on terminal [FM1] (FMP) in (p/s). (If the value is 10000 or greater, the x10 LED turns ON and the LED monitor shows one-tenth of the value.)
4_07	Input voltage on terminal [C1] (V2 function)	V	Shows the input voltage on terminal [C1] (V2 function) in volts (V).
4_08	Output current on terminal [FM1] (FMI)	mA	Shows the output current on terminal [FM1] (FMI) in milliamperes (mA).
4_09	Output current on terminal [FM2] (FMI)	mA	Shows the output current on terminal [FM2] (FMI) in milliamperes (mA).
4_ 10	Relay output card output terminal	_	Shows the ON/OFF state of the relay output terminal of the relay output card (optional). For more information on the displayed content, refer to "Displaying output on the relay output card terminal" on page 3-24.
4_ //	Terminal [X5] pulse input monitor		Shows the pulse rate of the pulse train signal on terminal [X5].
4_ 13	PT detection temperature (Ch.1)	°C	Shows the detection temperature of the PT option (Ch.1). If the PT option is not mounted, "" appears.
4_ 14	PT detection temperature (Ch.2)	°C	Shows the detection temperature of the PT option (Ch.2). If the PT option is not mounted, "" appears.
4_20	Input voltage on terminal [32]	v	Shows the input voltage on terminal [32] on the analog interface card (AIO option) in volts (V).
4_21	Input current on terminal [C2]	mA	Shows the input current on terminal [C2] on the analog interface card (AIO option) in milliamperes (mA).
4_22	Output voltage on terminal [AO]	V	Shows the output voltage on terminal [AO] on the analog interface card (AIO option) in volts (V).
4_23	Output current on terminal [CS]	mA	Shows the output current on terminal [CS] on the analog interface card (AIO option) in milliamperes (mA).
	Customizable logic timer monitor		Monitors the timer or counter value in the customizable logic specified by U91.

■ Displaying control I/O signal terminals

The status of control I/O signal terminals can be displayed in two ways: with ON/OFF of each LED segment and in hexadecimal.

• Displaying the I/O signal status with ON/OFF of each LED segment

As shown in Table 3.4-9 and the figure below, each of segments "a" to "dp" on LED1 and LED2 lights when the corresponding digital input terminal circuit ([FWD], [REV], [X1] to [X5]) is closed (ON); it goes OFF when it is open (OFF). Segment "a" to "c" on LED3 lights when the circuit between output terminal [Y1] to [Y3] and terminal [CMY] is closed, respectively; it goes OFF when the circuit is open. Segment "a" on LED4 is for terminals [30A/B/C] and lights when the circuit between output terminals [30A/B/C] and lights when the circuit between output terminals [30C] and [30A] is short-circuited (ON) and goes OFF when it is open. When the circuit between output terminals [Y5A] and [Y5C] is closed, segment "e" on LED3 lights, and when the circuit is open, the segment goes OFF.

(Tip If all terminal signals are OFF (open), segments "g" on all of LED1 to LED4 will light ("---").

	Segment	LED4	LED3	LED2	LED1
LED4 LED3 LED2 LED1	а	30A/B/C	Y1-CMY	_	FWD
	b	_	Y2-CMY	_	REV
_1, 1_1, 1_1, 1_1,	С	_	Y3-CMY	-	X1
	d	_	_	-	X2
g b	е	_	Y5A-Y5C	_	X3
e c	f	_	_	(XF) *	X4
d dp	g	_	_	(XR) *	X5
	dp	_	_	(RST) *	_

Table 3.4-9 Display of I/O Signal Status with ON/OFF of each LED segment

—: No corresponding control circuit terminal exists

* (XF), (XR), and (RST) are assigned for communications control. Refer to "<u>■ Displaying control I/O signal</u> <u>terminals under communications control</u>" on page 3-24.

Displaying I/O signal status in hexadecimal

Each I/O terminal is assigned to bit 15 through bit 0 as shown in Table 3.4-10. An unassigned bit is interpreted as "0." Allocated bit data is displayed on the LED monitor as four hexadecimal digits (\pounds to \pounds each).

On the FRENIC-eHVAC, digital input terminals [FWD] and [REV] are assigned to bits 0 and 1, respectively. Terminals [X1] through [X5] are assigned to bits 2 through 6. The bit is set to "1" when the corresponding input terminal is short-circuited (ON), and it is set to "0" when the terminal is open (OFF). For example, when [FWD] and [X1] are ON (short-circuited) and all the others are OFF (open), Clock is displayed on LED4 to LED1.

Digital output terminals [Y1] through [Y3] are assigned to bits 0 through 2, respectively, and "1" is set when the circuit between output terminals [Y1] through [Y3] and [CMY] is ON (short-circuited) and "0" is set when the circuit is OFF (open). The state of contact output terminal [Y5A/C] and that of contact output terminal [30A/B/C] are assigned to bit 4 and bit 8, respectively. When the circuits between [Y5A] and [Y5C], and between [30A] and [30C] are closed, "1" is set. When the circuits are opened, "0" is set. For example, LED4 through LED1 display [7] [7] /on the condition that [Y1] is ON, [Y2] and [Y3] are OFF, and the circuits between [Y5A] and [Y5C], and between [30A] and [30C] are closed.

Table 3.4-10 presents bit assignment and an example of corresponding hexadecimal display on the 7-segment LED.

L	ED No.		LEI	D4			LE	D3			LE	D2			LE	D1	
	Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Inpu	it terminal	(RST)*	(XR)*	(XF)*		_	_	_	_	l	X5	X4	X3	X2	X1	REV	FWD
Outp	ut terminal	_	_			_	_	_	30A/ B/C		_		Y5A/ C		Y3	Y2	Y1
	Binary	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1
Example	Hexa- decimal on the LED monitor																

Table 3.4-10 Display of I/O Signal Status in Hexadecimal (Example)

- : No corresponding control circuit terminal exists.

* (XF), (XR), and (RST) are assigned for communications control. Refer to "■ Displaying control I/O signal terminals under communications control" given below.

Displaying control I/O signal terminals under communications control

Under communications control, input commands (function code S06) sent via RS-485 or other optional communications can be displayed in two ways: "with ON/OFF of each LED segment" and "in hexadecimal." The content to be displayed is basically the same as that for the control I/O signal terminal status display; however, (XF), (XR), and (RST) are added as inputs. Note that under communications control, the I/O display is in normal logic (using the original signals not inverted)

For details about input commands sent through the communications link, refer to the "RS-485 Communication User's Manual" or the instruction manual of communication-related options as well.

Displaying output on the relay output card terminal

LED4 I

The LED monitor can also show the signal status of the terminals on the optional relay output interface cards, same as the signal status of the control circuit terminals.

Table 3.4-11 lists the assignment of relay output signals to the LED segments.

Table 3.4-11 Display of Output Signal Status with ON/OFF of each LED segment (Relay output interface cards)

	Segment	LED4	LED3	LED2	LED1
	а	_	Y6A/C	_	_
ED3 LED2 LED1	b	_	Y7A/C	_	_
	С	_	Y8A/C	_	_
a	d	_	_	_	_
g b	е	_	_	_	_
	f	-	_	—	
d dp	g		_	_	
	dp		_	_	

LED No.	LED4					LED3 LED2			LED1							
Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Output terminal	-	-	-	-	-	-	-	-	-	-	-	-	-	Y8A/C	Y7A/C	Y6A/C

3.4.5 Reading maintenance information "Maintenance Information: 5.[HE "

Menu #5 "Maintenance Information" (5.CHC) contains information necessary for performing maintenance on the inverter. The menu transition in "Maintenance Information" is same as that in Menu #3 "Drive Monitoring." (Refer to Section 3.4.3.)

Basic key operation

To view the maintenance information, set function code E52 to "2" (Full-menu mode) beforehand.

- (1) Turn the inverter ON. It automatically enters Running mode in which you press the rogramming mode. The function selection menu appears.
- (2) Use the \bigotimes and \bigotimes keys to display "Maintenance Information" (5.2 Hz).
- (3) Press the $\frac{1}{2}$ key to proceed to the list of maintenance items (e.g. 5_{-} G_{-}).
- (4) Use the ⊗ and ⊗ keys to display the desired maintenance item, then press the key. The data of the corresponding maintenance item appears.
- (5) Press the (a) key to return to the list of maintenance items. Press the (a) key again to return to the menu.

LED Monitor shows:	Item	Description
		Shows the content of the cumulative power-ON time counter of the inverter.
		Counter range: 0 to 65,535 hours
5_00		Display: Upper 2 digits and lower 3 digits are displayed alternately.
		Example: $\Box \Leftrightarrow \underline{535H}$ (535 hours) $\underline{55} \Leftrightarrow \underline{535H}$ (65,535 hours) The lower 3 digits are displayed with $\underline{5}$ (hour)
		When the count exceeds 65,535, the counter will be reset to "0" and start over again.
		Shows the DC link bus voltage of the inverter main circuit.
5_07	DC link bus voltage	Unit: V (volts)
5_02		Shows the maximum temperature inside the inverter for every hour.
	Max. temperature inside the inverter	Unit: °C (Temperatures below 20 °C are displayed as 20 °C.)
		The internal temperature is not measured at inverters of FRN0038F2E-4G or below models, and therefore the temperature is not displayed.
5_03	Max. temperature of heat	Shows the maximum temperature of the inverter heat sink for every hour.
	SILIK	Unit: °C (Temperatures below 20°C are displayed as 20°C.)
5_04	Max. effective output current	Shows the maximum current in RMS for every hour.
5_05	Capacitance of the DC link bus capacitor	Shows the current capacitance of the DC link bus capacitor (reservoir capacitor) in %, based on the capacitance when shipping as 100%. Refer to Chapter 7 "MAINTENANCE AND UNSPECTION" for details
	•	Unit: %

Table 3.4-12	Display	Items in	"Maintenance	Information
	Diopidy		Maintenance	monnation

LED Monitor shows:	Item	Description
	Cumulative run time of	Shows the content of the cumulative run time counter of the electrolytic capacitors on the printed circuit boards, which is calculated by multiplying the cumulative run time count by the coefficient based on the surrounding temperature condition. Counter range: 0 to 99.990 hours
5,75	electrolytic	Display range: 7 to 99999 (the x10 LED turns ON)
2200	capacitors on the printed circuit boards	Actual cumulative run time of electrolytic capacitors on the printed circuit boards (hours) = Displayed value x 10
		When the count exceeds 99,990 the counter stops and the LED monitor sticks to 9999.
	Cumulative run time of the	Shows the content of the cumulative run time counter of the cooling fan.
5_07	cooling fan	This counter does not work when the cooling fan ON/OFF control (function code H06) is enabled and the fan stops.
		The display method is the same as for 5_2 above.
		Shows the content of the motor 1 startup counter (i.e., the number of run commands issued).
5_ <i>0</i> 8	Number of startups	Counter range: 0 to 65,530 times
		Display range: 1/ to 3339
		ON and the LED monitor shows one-tenth of the value.
		When the count exceeds 65,530, the counter will be reset to "0" and start over again.
		Shows the input watt-hour of the inverter. Display range: 0.00 / to 9999
5_09	Input watt-hour	Input watt-hour = Displayed value \times 100 kWh
5205		To reset the integrated input watt-hour and its data, set function code E51 to "0.000." When the input watt-hour exceeds 999,900 kWh, the counter will be reset to "0."
		Shows the value expressed by "input watt-hour (1.000=100 kWh) × E51 (whose data range is 0.000 to 9,999)."
	Input watt-hour data	Unit: None (Display range: 2,22 / to 3332. The count cannot exceed 9999. (It will be fixed at 9,999 once the calculated value exceeds 9999.))
5_ 11		Depending on the value of integrated input watt-hour data, the decimal point on the LED monitor shifts to show it within the LED monitors' resolution.
		To reset the integrated input watt-hour data, set function code E51 to "0.000."
5_ //	Number of RS-485 communications errors	Shows the total number of errors that have occurred in RS-485 communication (COM port 1, connection to keypad) after the power is turned ON.
	(COM port 1)	Once the count exceeds 9999, the counter will be reset to "0."
רו ב	Content of RS-485	Shows the latest error that has occurred in RS-485 communication (COM port 1) in decimal.
ש <i>ב וב</i> י	communications error (COM port 1)	For error contents, refer to the "RS-485 Communication User's Manual."
5_ 13	Number of option errors 1	Shows the total number of errors that have occurred in the option. Once the count exceeds 9999, the counter will be reset to "0."

Table 3.4-12 Display Items in "Maintenance Information" (Continued	Table 3.4-12	Display Items in	"Maintenance	Information"	(Continued
--	--------------	------------------	--------------	--------------	------------

LED Monitor shows:	Item	Description
5_ 14	Inverter's ROM version	Shows the inverter's ROM version as a 4-digit code.
5_ 15	Inverter's ROM version Sub CPU	Shows the inverter's Sub CPU ROM version as a 4-digit code. (Only type of FRN0011F2E-4G)
5_ 15	Keypad's ROM version	Shows the keypad's ROM version as a 4-digit code.
5_ 17	Number of RS-485 communications errors (COM port 2)	Shows the total number of errors that have occurred in RS-485 communication (COM port 2, connection to terminal block) after the power is turned ON. Once the count exceeds 9999, the counter will be reset to "0."
5_ <i>1</i> 8	Content of RS-485 communications error (COM port 2)	Shows the latest error that has occurred in RS-485 communication (COM port 2, connection to terminal block) in decimal. For error contents, refer to the "RS-485 Communication User's Manual."
5_ 19	Option's ROM version 1	Shows the ROM version of the option as a 4-digit code. If the option has no ROM, "" appears on the LED monitor.
5_23	Cumulative run time of motor 1	Shows the content of the cumulative power-ON time counter of motor 1. Counter range: 0 to 99,990 hours Display range: 2 to 333 (the x10 LED turns ON) Actual cumulative motor run time (hours) = Displayed value x 10 When the count exceeds 99,990, the counter will be reset to "0" and start over again.
5_24	Temperature inside the inverter (real-time value)	Shows the current temperature inside the inverter. Unit: °C The internal temperature is not measured at inverters of FRN0038F2E-4G or below models, and therefore the temperature is not displayed.
5_25	Temperature of heat sink (real-time value)	Shows the current temperature of the inverter heat sink. Unit: $^{\circ}$ C
5_26	Lifetime of DC link bus capacitor (elapsed hours)	Shows the cumulative time during which a voltage is applied to the DC link bus capacitor. When the main power is shut down, the inverter automatically measures the discharging time of the DC link bus capacitor and corrects the elapsed time. The display method is the same as for $5_0D_0^2$ above.
5_27	Lifetime of DC link bus capacitor (remaining hours)	Shows the remaining lifetime of the DC link bus capacitor, which is estimated by subtracting the elapsed time from the lifetime (10 years). The display method is the same as for 5_0 above.

Table 3.4-12	Display Items in	"Maintenance	Information"	(Continued)
	Biopiay iterite in	Mainternarioe	monnation	(Containaca)

LED Monitor shows:	Item	Description
5_37	Remaining hours before the	Shows the hours remaining before the next maintenance, which is estimated by subtracting the cumulative run time of motor 1 from the maintenance interval specified by H78. (This function applies to motor 1 only.)
		Display range: 🛛 to 🖙 🕾 (the x10 LED turns ON)
		Actual remaining hours before maintenance = Displayed value x 10
5_35	Remaining startup times before the next maintenance 1	Shows the startup times remaining before the next maintenance, which is estimated by subtracting the number of startups from the preset startup count for maintenance specified by H79. (This function applies to motor 1 only.) The display method is the same as for $5 \sqrt{2}$ above.
		Shows the factor of the latest light alarm as an alarm code
5_35	Light alarm factor (Latest)	For details, refer to Chapter 6, "6.1 Protective Functions."
5_37	Light alarm factor (Last)	Shows the factor of the last light alarm as an alarm code. For details, refer to Chapter 6 "6.1 Protective Function."
5_38	Light alarm factor (2nd last)	Shows the factor of the 2nd last light alarm as an alarm code. For details, refer to Chapter 6 "6.1 Protective Function."
5_39	Light alarm factor (3rd last)	Shows the factor of the 3rd last light alarm as an alarm code. For details, refer to Chapter 6 "6.1 Protective Function."
5_40	Option error factor 1	Shows the factor of the error that has occurred in the option being connected to the A-port.

Table 3.4-12	Display Item	s in "Maintenance	Information"	(Continued)
1able 3.4-12	Display nem		mormation	Continu

3.4.6 Reading alarm information "Alarm Information: *5*,*R*^{*L*}."

Menu #6 "Alarm Information" ($\underline{\beta}, \underline{\beta}_{L}^{\prime}$) shows the causes of the past 4 alarms with an alarm code. Further, it is also possible to display alarm information that indicates the status of the inverter when the alarm occurred. Figure 3.4-4 shows the menu transition in "Alarm Information" and Table 3.4-13 lists the details of the alarm information.



Figure 3.4-4 Menu Transition in Menu #6 "Alarm Information"

Basic key operation

To view the alarm information, set function code E52 to "2" (Full-menu mode) beforehand.

- (1) Turn the inverter ON. It automatically enters Running mode in which you press the entermode with the Programming mode. The function selection menu appears.
- (2) Use the \bigcirc or \bigcirc key to display "Alarm Information" (\pounds . β ").
- (3) Press the B key to proceed to the list of alarm codes (e.g. $/ \square /)$.

In the list of alarm codes, the alarm information for the last 4 alarms is saved as an alarm history.

- (4) Each time the ⊘ or ⊗ key is pressed, the last 4 alarms are displayed beginning with the most recent one in the order of *l*, *, , , , , and 4*.
- (5) Press the $\frac{6}{3}$ key with an alarm code being displayed.

The item number (e.g. $\mathcal{E}_{-}\mathcal{D}\mathcal{D}$) and the inverter status information (e.g. Output frequency) at the time of the alarm occurrence alternately appear at approx. 1-second intervals.

Pressing the \bigotimes and \bigotimes keys displays other item numbers (e.g. $\mathcal{L}_{-}\mathcal{D}$ /) and the status information (e.g. Output current) for that alarm code.

(6) Press the 🕮 key to return to the list of alarm codes. Press the 🕮 key again to return to the menu.

LED monitor shows: (item No.):	Item	Description		
6_00	Output frequency	Output frequency		
6_07	Output current	Output current when alarm occurred. Display unit: A (Amperes)		
6_ <i>02</i>	Output voltage	Output voltage when alarm occurred. Display unit: V (Volts)		
6_03	Calculated torque	Calculated motor output torque when alarm occurred.		
5_04	Reference frequency	Frequency specified by frequency command when alarm occurred.		
6_05	Rotation direction	Shows the current rotation direction when alarm occurred. /-: forward, /-: reverse,: stop		
6_06	Running status	Running status when alarm occurred as four hexadecimal digits. Refer to "■ <u>Displaying running status (3 27 9</u> , and running status 2 (3 23 9)" in Section 3.4.3 on page 3-19 for details.		
<i>6_0</i> 7	Cumulative run time	Shows the content of the cumulative power-ON time counter of the inverter when alarm occurred. Counter range: 0 to 65,535 hours Display: Upper 2 digits and lower 3 digits are displayed alternately. Example: $\Box \Leftrightarrow \Box \Box \Box \Leftrightarrow \Box \Box \Box \Leftrightarrow$ $\Box \Box \Leftrightarrow \Box \Box \Box \Leftrightarrow$ $\Box \Box \Box \Leftrightarrow \Box \Box \Box \Leftrightarrow$ $\Box \Box \Leftrightarrow \Box \Box \Box \Leftrightarrow$ $\Box \Box \Leftrightarrow \Box \Box \Box \Leftrightarrow$ (65,535 hours) The lower 3 digits are displayed with H' (hour). When the count exceeds 65,535, the counter will be reset to "0" and start over again.		
5_ <i>0</i> 8	No. of startups	Shows the content of the motor startup counter (i.e., the number of run commands issued) when alarm occurred. Counter range: 0 to 65,530 times Display range: 1 to 9999 If the count exceeds 10,000, the x10 LED turns ON and the LED monitor shows one-tenth of the value. When the count exceeds 65,530, the counter will be reset to "0" and start over again.		
6_03	DC link bus voltage	Shows the DC link bus voltage of the inverter main circuit when alarm occurred. Unit: V (volts)		
6_ 10	Temperature inside the inverter	Shows the temperature inside the inverter when alarm occurred. Unit: °C The internal temperature is not measured at inverters of FRN0038F2E-4G or below capacity models, and therefore the temperature is not displayed.		
6_ //	Max. temperature of heat sink	Shows the temperature of the inverter heat sink when alarm occurred. Unit: °C		
6_ IZ	Terminal I/O signal status (displayed with ON/OFF of LED segments)	Shows the ON/OFF states of the digital I/O terminals when alarm occurred.		
6_ 13	Terminal input signal status (in hexadecimal)	For the contents of the display, refer to "Table 3.4-9 Display" and "Table 3.4-10 Display of I/O Signal Status in Hexadecimal (Example)" in 3.4.4 Checking I/O signal status "I/O Checking"		
6_ <i>1</i> 4	Terminal output signal status (in hexadecimal)			
6_ 15	No. of consecutive occurrences	Shows how many times the same alarm has occurred consecutively.		
6_ 16	Multiple alarm 1	Simultaneously occurring alarm code (1) ("" is displayed if no alarm has occurred.)		

LED monitor shows: (item No.):	Item	Description	
6_ 17	Multiple alarm 2	Simultaneously occurring alarm code (2)	
		("" is displayed if no alarm has occurred.)	
6_ <i>1</i> 8	Terminal I/O signal status under communications control (displayed with the ON/OFF of LED segments)	Shows the ON/OFF state of the digital I/O terminals under	
6_ 19	Terminal input signal status under communications control (in hexadecimal)	 RS-485 communications control when alarm occurred. Refer to "■ <u>Displaying control I/O signal terminals under communications</u> <u>control</u>" in "3.4.4 Checking I/O signal status "I/O Checking: '-', ' □" for details. 	
6_20	Terminal output signal status under communications control (in hexadecimal)		
5_27	Error sub code	Secondary error code for an alarm.	
		Running status 2 when alarm occurred as four hexadecimal digits.	
6_22	Running status 2	For details, refer to "Table 3.4-5 Running Status 2 $(\exists_{-}c^{-}d^{-})$ Bit Assignment" in "3.4.3 Monitoring the running status "Drive Monitoring: $\exists_{-}c^{-}d^{-}c^{-}$ "."	
5_23	Detected speed	Shows the detected speed value when alarm occurred.	
5_24	Running status 3	Running status 3 when alarm occurred as four hexadecimal digits. For details, refer to "Table 3.4-14 Running Status 3 $(\exists_{-}c^{-1}d')$ Bit	
		Assignment" given below.	
6_25	Multiple alarm sub code	Secondary error code for a multiple alarm.	

Note When the same alarm occurs repeatedly in succession, the alarm information for the first and the most recent occurrences will be preserved and the information for other occurrences in-between will be discarded. The number of consecutive occurrences will be preserved as the first alarm information.

Bit	Notation	Content	Bit	Notation	Content
15	_	Always "0."	7	FAN	"1" when the fan is in operation.
14	ID2	"1" when current 2 is detected.	6	KP	"1" during keypad operation.
13	IDL	"1" when low current is detected.	5	OL	"1" when a motor overload early warning is issued.
12	ID	"1" when current is detected.	4	IPF	"1" during auto-restarting after momentary power failure.
11	OLP	"1" under overload prevention control.	3	SWM2	"1" when speed control parameter 2 is selected.
10	LIFE	"1" when a lifetime early warning is issued.	2	RDY	"1" when the inverter is ready to run.
9	ОН	"1" when a heat sink overheat early warning is issued.	1	FDT	"1" when frequency is detected.
8	TRY	"1" during auto-resetting.	0	FAR	"1" when a frequency arrival signal is issued.

Table 3 1-11	Punning Status 3 $(-7, -74)$	
Table 3.4-14	Running Status 3 ($\underline{\neg}_{\underline{\neg}}$) Bit Assignment

Chap 3 OPERATION USING THE KEYPAD

3.4.7 Copying data "Data Copying: 7_[Py"]

The data copy function can only be used when the keypad with USB (option: TP-E1U) is connected. Menu #7 "Data Copying" is used to read function code data out of an inverter for storing it in the keypad or writing it into another inverter. It is also used to verify the function code data stored in the keypad with the one configured in the inverter. The keypad serves as a temporary storage media. The copy function of the TP-A1 as an optional multifunction keypad is available, which, however, varies in operation method. For details, refer to the Instruction Manual of the TP-A1.

In addition, using Menu #7 allows you to store the running status information in the keypad, detach the keypad from the inverter, connect it to a PC running FRENIC Loader at an office or off-site place, and check the inverter running status without removing the inverter itself.

To store the inverter running status information into the keypad, use "Read data" (read) or "Read inverter running information" (chec) function. For details on how to connect the keypad to a PC and check the inverter running status information stored in the keypad, refer to the FRENIC Loader Instruction Manual.

Figure 3.4-5 shows the menu transition in Menu #7 "Data Copying." The keypad can hold function code data for a single inverter.



Figure 3.4-5 Menu Transition in Menu #7 "Data Copying"

Basic keying operation

- (1) Turn the inverter ON. It automatically enters Running mode. In that mode, press the regramming mode. The function selection menu appears.
- (2) Use the \bigotimes and \bigotimes keys to display "Data Copying" (7.272).
- (3) Press the \bigotimes key to proceed to the list of data copying functions (e.g. $-E \neg E \neg C'$).
- (4) Use the ⊗ and ⊗ keys to select the desired function, then press the key to execute the selected function. (e.g. *¬ER_* will blink.)
- (5) When the selected function has been completed, *end* appears. Press the ekey to return to the list of data copying functions. Press the key again to return to the menu.

Table 3.4-15 below lists details of the data copying functions.

Table 3.4-15 List of Data Copying Functions

Display on LED Monitor	Function	Description
rEAd	Read data	Reads the function code data out of the inverter's memory and stores it into the keypad memory.
		Also reads out inverter's current running status information which can be checked by FRENIC Loader, such as information of I/O, system, alarm, and running status.
		Pressing the $$ key during a read operation (when $-\mathcal{E}\mathcal{H}_{\mathcal{D}}$ is blinking) immediately aborts the operation and displays $\mathcal{E}_{\mathcal{D}}$ (blinking).
		If this happens, the entire contents of the memory of the keypad will be completely cleared.
CoPy	Write data	Writes data stored in the keypad memory into the inverter's memory.
		If you press the $$ key during a write operation (when $\int_{\Box} e^{\frac{D}{L}}$ is blinking), the write operation that is under way will be aborted and $\int_{\Box} e^{-r}$ will appear (blinking). If this happens, the contents of the inverter's memory (i.e., function code data) have been partly updated and remain partly old. Therefore, do not operate the inverter. Instead, perform initialization or rewrite the entire data.
		If this function does not work, refer to "If data copying does not work" on page 3-34.
		After the copy is completed, the inverter Verifies data automatically. Displays the function code that was not been copied when copying in case that the model and voltage capacity is different.
ו-גובר	Verify data	Verifies (compares) the data stored in the keypad memory with that in the inverter's memory.
		If any mismatch is detected, the verify operation will be aborted, with the function code that differs displayed blinking. Pressing the result were again causes the verification to continue from the next function code.
		Pressing the $$ key during a verify operation (when $\pounds \pounds - i$ is blinking) immediately aborts the operation and displays $\pounds i$ (blinking).
		$\mathcal{E}_{\mathcal{T}\mathcal{T}}$ appears blinking also when the keypad does not contain any valid data.
Prof	Enable	Enables the Data protection of data stored in the keypad's memory.
	Data protection	In this state, you cannot read any data stored in the inverter's memory, but can write data into the memory and verify data in the memory.
		Upon pressing the key the inverter immediately displays Errr.
EHEE	Read inverter running	Reads out inverter's current running status information that can be checked by FRENIC Loader, such as information of I/O, system, alarm, and running status, excluding function code data.
	information	Use this command when the function code data saved in the keypad should not be overwritten and it is necessary to keep the previous data.
		Pressing the \textcircled{R} key during a read operation ($\sub{L} H \sub{L}$ blinking) immediately aborts the operation and displays $\sub{L} $ (blinking).

■ If data copying does not work

Check whether \mathcal{E}_{r-r} or $\mathcal{E}_{r}\mathcal{E}_{r}$ or $\mathcal{E}_{r-r}\mathcal{E}_{L}$ is blinking.

Table 3.4-16 List of Data Copying error

Display on LED Monitor	Error content	Description
Err	Write data	Error generated during $\sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} (Write data)$ operation.
	choi	If \underline{c}_{r} - is blinking (a write error), any of the following problems has arisen:
		 No data exists in the keypad memory. (No data read operation has been performed since shipment, or a data read operation has been aborted.)
		 Data stored in the keypad memory contains any error.
		The models of copy source and destination inverters are different.
		A data write operation has been performed while the inverter is running.
		 The copy destination inverter is data-protected. (function code F00 = 1)
		 In the copy destination inverter, the "Enable write from keypad" command WE-KP is OFF.
		 A data read operation has been performed for the inverter whose data protection was enabled.
EPEr-	Write data	Error generated during $\int_{-\Box} d^{\Box} d^{\Box} d^{\Box}$ (Write data) operation.
	error	If <i>[PEr</i> is blinking, any of the following problems has arisen:
		 The function codes stored in the keypad and ones registered in the inverter are not compatible with each other. (Either of the two may have been revised or upgraded in a non-standard or incompatible manner.)
		 Press to continue []^D' (Write data) operation.
		 Press et discontinue [] (Write data) operation.
ErEL	Verify data	Error generated during
	error	If <i>LEr</i> is blinking, any of the following problems has arisen:
		 The number of customizable logic function codes stored in the keypad differs from the number of customizable logic function codes in the inverter.
		・ Press to continue ニー ィ (Verify data) operation.
		・ Press 🌐 to discontinue ビニィ (Verify data) operation.
Data protection

You can protect data saved in the keypad from unexpected modifications. Enabling the data protection changes the display on the "Data Copying" function list from $-ER_{D}$ to P-D, and disables to read data from the inverter. To enable or disable the data protection, follow the next steps.

- Select the "Data Copying" $(''_{l,L}, ''_{l,L}, ''_{l,L})$ on the function selection menu in Programming mode. (1)
- When the 7.224 is displayed, holding the extension for at least 5 seconds alternates data protection (2) status between enabled or disabled.

Note

For switching the data protection status, be sure to hold the like key down for at least 5 seconds. Once the key is released within 5 seconds, press the extreme key to go back to the CLPL display and perform the keying operation again.

· Enabling the disabled data protection



While $7 \pounds P'_{2}$ is displayed, holding down the \bigotimes key for at least 5 seconds shows $-\xi R_{2}$ for 5 seconds and then switches to $\frac{1}{2} - \frac{1}{2} \frac{1}{2}$, enabling the data protection.

Disabling the enabled data protection



While 7.27' is displayed, holding down the (key for at least 5 seconds shows 7-16' for 5 seconds and then switches to $-E \overline{B} d$, disabling the data protection.

The following are restrictions and special notes concerning "Data Copying."

3.4.8 Setting up basic function codes quickly "Quick Setup: $\square \vdash \neg \sqsubseteq$ "

Menu #0 "Quick Setup" in Programming mode allows you to quickly display and set up a predetermined basic set of function codes.

To use Menu #0 "Quick Setup," you need to set function code E52 to "0" (Function code data setting mode) or "2" (Full-menu mode).

The predefined set of function codes that are subject to quick setup is stored in the inverter.

Figure 3.4-6 shows the menu transition in "Quick Setup" and function code data changing procedure.



Figure 3.4-6 Menu Transition in Menu #0 "Quick Setup" and Function Code Data Changing Procedure

Basic key operation

This section gives a description of the basic key operation in "Quick Setup," following the example of the function code data changing procedure shown in Figure 3.4-6.

This example shows you how to change function code F01 data (Frequency setting 1) from the factory default " \bigcirc / \bigcirc keys on keypad (F01 = 0)" to "Current input to terminal [C1] (C1 function) (4 to 20 mA DC) (F01 = 2)."

- (1) Turn the inverter ON. It automatically enters Running mode in which you press the regramming mode. The function selection menu appears. (In this example, $\Box F \neg L$ is displayed.)
- (2) If anything other than $\square \not\vdash \neg \not\vdash$ is displayed, use the \bigcirc and \bigcirc keys to display $\square \not\vdash \neg \not\vdash$.
- (3) Press the key to proceed to the list of function codes.
- (4) Use the \bigotimes and \bigotimes keys to display the desired function code ($\digamma \square$ / in this example), then press the \bigotimes key. The data of this function code appears. In this example, data \square of $\digamma \square$ /appears.
- (5) Change the function code data using the (△) and (△) keys. In this example, press the (△) key two times to change data () to ().
- (6) Press the $\bigoplus_{n \to \infty}$ key to establish the function code data.

The SRUE appears (blinking) and the data will be saved in the memory inside the inverter. After that, the display will return to the function code list and then move to the next function code. In this example, F GE. Pressing the Reg key instead of the Reg key cancels the change made to the data. The data reverts to the previous value, the display returns to the function code list, and the original function code reappears.

(7) Press the even to return to the menu from the function code list.

Cursor movement

When changing function code data, pressing the \bigotimes key moves the cursor to the desired digit and change the data in that digit is done in the same say as with the frequency setting. This action is called "Cursor movement."

Тір

Tip

It is possible to change or add function code items subject to quick setup. For details, consult your Fuji Electric representatives.

3.5 Alarm Mode

If an abnormal condition arises, the protective function is invoked and issues an alarm, then the inverter automatically enters Alarm mode. At the same time, an alarm code appears on the LED monitor.

3.5.1 Releasing the alarm and switching to Running mode

Remove the cause of the alarm and press the like key to release the alarm and return to Running mode. The alarm can be removed using the like key only when the alarm code is displayed.

3.5.2 Displaying the alarm history

It is possible to display the most recent 3 alarm codes in addition to the one currently displayed. Previous alarm codes can be displayed by pressing the $\bigotimes I \bigotimes$ key while the current alarm code is displayed.

3.5.3 Displaying the status of inverter at the time of alarm

When the alarm code is displayed, you may check various running status information when the alarm occurred (output frequency and output current, etc.) by pressing the key. The item number and data for each running status information will be displayed alternately.

Further, you can view various information items on the running status of the inverter using the \bigcirc / \bigcirc key. The information displayed is the same as for Menu #6 "Alarm Information" in Programming mode. Refer to Table 3.4-13 in "3.4.6 Reading alarm information "Alarm Information: \pounds , β , ℓ "."

Pressing the me key while the running status information is displayed returns to the alarm code display.

Note When the running status information is displayed after removal of the alarm cause, pressing the end key twice returns to the alarm code display and releases the inverter from the alarm state. This means that the motor starts running if a run command has been received by this time.

3.5.4 Switching to Programming mode

You can also switch to Programming mode by pressing "for + (a) keys" simultaneously with the alarm displayed, and modify the function code data.





List of alarm codes

Figure 3.5-1 Menu Transition in Alarm Mode

Chapter 4 TEST RUN PROCEDURE

This chapter describes basic settings required for making a test run.

Contents

4.1	Test Run Procedure Flowchart 4-1					
4.2	Cheo	ecking Prior to Powering On ······ 4-2				
4.3	Powe	ering ON and Checking ······ 4-3				
4.4	Sele	cting a Desired Motor Drive Control 4-4				
4.4	4.1	V/f control with slip compensation inactive for IM 4-4				
4.4	4.2	Vector Control without speed sensor and magnetic pole position sensor for PMSM 4-4				
4.5	Conf	iguring Function Codes for Drive Controls 4-5				
4.	5.1	Driving an Induction Motor (IM)				
[1]	Driving a non-Fuji motor or Fuji non-standard IM under the V/f control 4-6				
[2]	Driving a Fuji general-purpose IM under the V/f control 4-7				
[3]	Tuning (For IM)				
4.	5.2	Driving a permanent magnet synchronous motor (PMSM) without pole sensor and magnetic pole position sensor4-11				
[1]	Driving a non-Fuji PMSM ······4-11				
[2]	Driving a Fuji dedicated PMSM (GNB2 series)4-16				
[3]	Driving a Fuji non-dedicated PMSM (non-GNB2 series)4-16				
4.6	Runr	ning the Inverter for Motor Operation Check4-17				
4.	6.1	Test run procedure ······4-17				
4.	6.2	Check points during a test run4-17				
4.	6.3	Modification of motor control function code data4-18				
4.7	Sele	cting a Frequency Command Source4-19				
4.	7.1	Setting up a frequency command from the keypad4-19				
4.	7.2	Setting up a frequency command with an external potentiometer4-19				
4.	7.3	Setting up a frequency command with multistep frequency selection4-20				
4.8	Sele	cting a Run Command Source4-21				
4.8	8.1	Setting up a run command from the keypad4-21				
4.	8.2	Setting up a run command with digital input signals (terminals [FWD] and [REV])4-21				

4.1 Test Run Procedure Flowchart

Make a test run of the motor using the flowchart given below.

For the function codes dedicated to motor 2, see Chapter 5 "FUNCTION CODES."



Figure 4.1-1 Test Run Procedure

4.2 Checking Prior to Powering On

Check the following before powering on the inverter.

(1) Check that the wiring is correct.

Especially check the wiring to the inverter input terminals (L1/R, L2/S, L3/T) and output terminals (U, V, and W). Also check that the grounding wires are connected to the grounding terminals (\bigoplus G) correctly. See Figure 4.2-1.

- Never connect power supply wires to the inverter output terminals U, V, and W. Doing so and turning the power ON breaks the inverter.
- Be sure to connect the grounding wires of the inverter and the motor to the ground electrodes.

Otherwise, an electric shock could occur.

- (2) Check the control circuit terminals and main circuit terminals for short circuits or ground faults.
- (3) Check for loose terminals, connectors and screws.
- (4) Check that the motor is separated from mechanical equipment.
- (5) Make sure that all switches of devices connected to the inverter are turned OFF. Powering on the inverter with any of those switches being ON may cause an unexpected motor operation.
- (6) Check that safety measures are taken against runaway of the equipment, e.g., a defense to prevent people from access to the equipment.
- (7) Check that a power factor correction DC reactor (DCR) is connected to the DC reactor terminal P1 and P(+).(Case of FRN0150F2E-4G or above must be used with a DCR. Be sure to connect the DCR to the inverter.)



Figure 4.2-1 Connection of Main Circuit Terminals

4.3 Powering ON and Checking



- Be sure to mount the front cover before turning the power ON. Do not remove the cover when the inverter power is ON.
- Do not operate switches with wet hands.

Otherwise, an electric shock could occur.

Turn the power ON and check the following points. The following is a case when no function code data is changed from the factory defaults.

- (1) Check that the display of the LED monitor is blinking at 2.22 (a set frequency of 0 Hz) (See Figure 4.3-1).
- (2) Check that the inverter (built-in) cooling fans rotate.(This item applies only to models incorporating a cooling fan.)



Figure 4.3-1 Display of the LED Monitor after Power-on

4.4 Selecting a Desired Motor Drive Control

F42 data	Drive control	Basic control	Applicable Motor type	Speed feedback	Speed control	For configuration, refer to:
0	V/f control with slip compensation inactive	V/f control	IM	Disable	Frequency control	4.5.1 [1] 4.5.1 [2]
15	Vector Control without speed sensor and magnetic pole position sensor	Vector control	РМ	Estimated Speed	Speed control with automatic speed regulator (ASR)	4.5.2 [1] 4.5.2 [2] 4.5.2 [3]

The FRENIC-eHVAC supports the following motor drive control.

4.4.1 V/f control with slip compensation inactive for IM

Under this control, the inverter controls a motor with the voltage and frequency according to the V/f pattern specified by function codes.

4.4.2 Vector Control without speed sensor and magnetic pole position sensor for PMSM

This control estimates the motor speed based on the inverter's output voltage and current to use the estimated speed for speed control. In addition, it decomposes the motor drive current into the exciting and torque current components, and controls each of those components in vector. No PG (pulse generator) interface card is required. It is possible to obtain the desired response by adjusting the control constants (PI constants) using the speed regulator (PI controller).

Note Since "Vector control for PMSM without speed sensor and magnetic pole position sensor" uses motor parameters, the following conditions should be satisfied; otherwise, full control performance may not be obtained.

- A single motor should be controlled per inverter.
- Motor parameters P02, P03, P30 and P60 to P63 should be properly configured. Or, auto-tuning (P04) should be performed.
- The capacity of the motor to be controlled should be the same as that of the inverter; otherwise, the inverter may not control the motor due to decrease of the current detection resolution.
- The wiring distance between the inverter and motor should be 100 m (328 ft) or less. If it is longer, the inverter may not control the motor due to leakage current flowing through stray capacitance to the ground or between wires. Especially, small capacity inverters whose rated current is also small may be unable to control the motor correctly even when the wiring is less than 100 m (328 ft). In that case, make the wiring length as short as possible or use a wire with small stray capacitance (e.g., loosely-bundled cable) to minimize the stray capacitance.
- Do not use it outside of the speed control range (1:10).

4.5 Configuring Function Codes for Drive Controls

The relation of the motor control method, motor selection and motor parameter setting is shown in Figure 4.5-1. It is necessary to change the motor parameter setting depending on the driven motor.



Figure 4.5-1

(Note Factory defaults are set to drive the induction motor with V/f control. (F42 = 0)

The motor can not be driven properly if the synchronous motor is connected.

If the synchronous motor is driven, it is necessary to set F42=15 to change the drive control mode for driving the synchronous motor.

It is also necessary to set the motor parameters for the synchronous motor. Refer to "4.4.2 Vector Control without speed sensor and magnetic pole position sensor for PMSM" for the explanation of the test run of the synchronous motor.

Note

If F42 is changed to any other value from 15 or vice versa, setting related to motor parameters such as F04, F05, P01, etc... will be changed, In this case, re-configuration is required. For details, refer to Chapter 5 "5.3.4 P codes (Motor 1 parameters)".

4.5.1 Driving an Induction Motor (IM)

[1] Driving a non-Fuji motor or Fuji non-standard IM under the V/f control

(1) Configuring the function codes of motor parameters

Under the V/f control (F42 = 0), any of the following cases requires configuring the basic function codes given below and auto-tuning.

- Driving a non-Fuji motor or non-standard motor.
- Driving a Fuji general-purpose motor, provided that the wiring distance between the inverter and motor is long or a reactor is connected.

Configure the function codes listed below according to the motor ratings and design values of the machine. For the motor ratings, check the ratings printed on the motor's nameplate. For design values of the machine, ask system integrators or machine manufacturers about them.

For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $//_{-}$ through $/_{D--}$ "."

Function code	Name	Function code data
F []4	Base frequency 1	
F 05	Rated voltage at base frequency 1	Motor ratings
P D2	Motor 1 (Rated capacity)	(printed on the nameplate of the motor)
P 03	Motor 1 (Rated current)	
P 99	Motor 1 selection	4: Other motors (Select "1" for HP rating motors)
F 03	Maximum frequency 1	Machine design values
F []7	Acceleration time 1 (Note)	(Note) For the test run of the motor, increase values so that they are longer than your machine design values. If the specified time is short, the inverter may not run the motor property
F 08	Deceleration time 1 (Note)	

Note

When accessing the function code P02, take into account that changing the P02 data automatically updates the data of the function codes P03, P06 to P08, and H46.

[2] Driving a Fuji general-purpose IM under the V/f control

(1) Configuring the function codes of motor parameters

Driving a Fuji general-purpose motor under the V/f control (F42 = 0) requires configuring the following basic function codes.

Select Fuji standard 8-series motors with the function code P99.

Configure the function codes listed below according to the motor ratings and design values of the machine. For the motor ratings, check the ratings printed on the motor's nameplate. For design values of the machine, ask system integrators or machine manufacturers about them.

For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $\frac{1}{2}$ through $\frac{1}{2}$ "."

Function code	Name	Function code data	
F []4	Base frequency 1	Motor ratings (printed on the nameplate of the motor)	
F 05	Rated voltage at base frequency 1		
P 99	Motor 1 selection	Motor characteristics 0 (Fuji standard motors, 8-series)	
P D2	Motor 1 (Rated capacity)	Applicable motor capacity	
F 03	Maximum frequency 1	Machine design values	
F 07	Acceleration time 1 (Note)	(Note) For the test run of the motor, increase values so that they are longer than your machine design values. If the specified time is	
F 08	Deceleration time 1 (Note)	short, the inverter may not run the motor properly.	

After the above configuration, initialize motor 1 with the function code (H03 = 2). It automatically updates the motor parameters P01, P03, P06 to P08, and H46.

Note When accessing the function code P02, take into account that changing the P02 data automatically updates the data of the function codes P03, P06 to P08, and H46.

The motor rating should be specified properly when performing auto-torque boost, torque calculation monitoring, auto energy saving, torque limiting, automatic deceleration (anti-regenerative control) or auto search for idling motor speed.

In any of the following cases, the full control performance may not be obtained from the inverter because the motor parameters differ from the factory defaults, so perform auto-tuning. (Refer to 4.5.1 [3] Tuning (For IM).)

- The driven motor is a non-Fuji or a Fuji non-standard one.
- The wiring distance between the inverter and the motor is too long (generally 20 m or more).
- A reactor is installed between the inverter and the motor.

[3] Tuning (For IM)

Selection of tuning type

Check the situation of the machine and select "Tuning with the motor stopped (P04 = 1)" or "Tuning with the motor running (P04 = 2)." For the latter tuning, adjust the acceleration and deceleration times (F07 and F08) and specify the rotation direction that matches the actual rotation direction of the machine.



If tuning (P04 = 2) with motor running cannot be selected due to the machine, refer to "
Countermeasures when tuning for motor rotation cannot be executed".

P04 data	Tuning type	Motor parameters subjected to tuning	Tuning	Select under the following conditions
1	Tune while the motor stops.	Primary resistance (%R1) (P07) Leakage reactance (%X) (P08)	Tuning with <u>the motor</u> stopped.	Cannot rotate the motor.
2	Tune while the motor is rotating	No-load current (P06) Primary resistance (%R1) (P07) Leakage reactance (%X) (P08)	Tuning the %R1 and %X, with the motor stopped. Tuning the no-load current and magnetic saturation factor, with the motor running at 50% of the base frequency.	Can rotate the motor, provided that it is safe. Note that little load should be applied during tuning. Tuning with load applied decreases the tuning accuracy.

The tuning results of motor parameters will be automatically stored into their respective function codes.

Preparation of machine

In preparation for tuning, remove the motor coupling with the load and deactivate the safety devices before rotation tuning.

Tuning procedure

- 1) Set function code P04 to "1" or "2" and press the 🔤 key. (The blinking of / or c^2 on the LED monitor will slow down.)
- 2) Enter a run command. The factory default is "we key on the keypad for forward rotation." To switch to reverse rotation or to select the terminal signal *FWD* or *REV* as a run command, change the data of function code F02.
- 3) The moment a run command is entered, the display of / or ⁻⁷ lights up, and tuning starts with the motor stopped. (Maximum tuning time: Approx. 40 to 80 s.)
- 4) If P04 = 2, after the tuning in "3)" above, the motor is accelerated to approximately 50% of the base frequency and then tuning starts. Upon completion of measurements, the motor decelerates to a stop. (Estimated tuning time: Acceleration time + 20 to 75 s + Deceleration time)
- 5) If the terminal signal *FWD* or *REV* is selected as a run command (F02 = 1), Ernd' appears upon completion of the measurements. Turning the run command OFF completes the tuning.
 If the run command has been given through the keypad or the communications link, it automatically turns OFF upon completion of the measurements, which completes the tuning.
- 6) Upon completion of the tuning, the subsequent function code appears on the keypad.



Countermeasures when tuning for motor rotation cannot be executed

If "rotation tuning (P04 = 2)" cannot be executed due to the machine, execute "stop tuning (P04* = 1)" by the following procedure. Compared to "rotation tuning", characteristics including the speed control accuracy and stability might be inferior. Execute the connection test with the machine completely.

1) In the case of Fuji non-standard induction motor:

- ① Set the function code P99 to "4" depending on the motor type.
- ② Initialize the motor 1 by function code H03. (H03 = 2)
- ③ Set function codes F04, F05, P02, and P03 depending on the rated values of the motor.
- ④ Execute "stop tuning (P04 = 1)".

2) In case of the motors whose parameters are unknown or manufactured by other manufacturers: (Stop tuning)

- ① Set function codes F04, F05, P02, and P03 depending on the ratings nameplate of the motor.
- ② Set the motor constant (P06) from the test report of the motor.
- Consult Fuji Electric for details of conversion from the test report to various data.
- ③ Execute "stop tuning (P04 = 1)".
- 3) In case of the motors whose parameters are unknown or manufactured by other manufacturers: (Manual setting)
 - $\odot\,$ Set the function code P99 to "4" depending on the motor type.
 - @ Initialize motor 1 by function code H03. (H03 = 2)
 - ③ Set each function code based on Table 4.5-1.

Consult Fuji Electric us for details of conversion to various data.

Table 4.5-1

Function code	Name	Function code data	
P 99	Motor 1 selection	4: Other motors	
F DY	Base frequency 1		
F 05	Rated voltage at base frequency 1	Motor ratings (printed on the nameplate of the motor) If the motor synchronous speed is known, calculate F04 by the following	
PD/	Motor 1 (No. of poles)	Tormula and set it. Synchronosrotationspeed	
P D2	Motor 1 (Rated capacity)	$\frac{\text{Synchronizationspecea}}{120}$ × Number of poles	
P 03	Motor 1 (Rated current)		
P 05	Motor 1 (No-load current)	Set the value described in motor test report.	
P 07	Motor 1 (%R1)	Calculated from value described in motor test report. Refer to Chapter 5 "5.3.4 P codes (Motor 1 parameters)".	
P 08	Motor 1 (%X)	Calculated from value described in motor test report. Refer to Chapter 5 "5.3.4 P codes (Motor 1 parameters)".	
F 03	Maximum frequency 1	Machine design values	
F [] 7	Acceleration time 1 (Note)	(Note) For the test run of the motor, increase values so that they are	
F 08	Deceleration time 1 (Note)	short, the inverter may not run the motor properly.	

■ Tuning errors (For IM)

If the inverter finds any abnormality in the tuning results or any error in the tuning process, it displays $\mathcal{E}r^{-7}$ and discards the tuning data.

When the tuning error $(\cancel{2}-7)$ appears, check that:

- The inverter's output (secondary) circuit is opened or not.
- The mechanical brake is applied or not.
- The terminal command **BX** ("Coast to a stop") is turned ON or not.
- Any function code is wrongly configured.

Listed below are possible causes that trigger tuning errors and measures.

Possible tuning error causes	<i>Er</i> - 7 error subcode	Details and Measures
Sequence error	7 8 9	Before completion of tuning, a run command has been turned OFF. Or during tuning, terminal command <i>STOP</i> ("Force to stop") or <i>BX</i> ("Coast to a stop") has been entered. → Do not stop the inverter running until completion of tuning.
Output current error	6 10	 During tuning, an excessively large current has flown. → Release a mechanical brake or take any other measure to remove the cause resulting in overcurrent.
Error in tuning results	ן ב א	 An interphase voltage unbalance or output phase loss has been detected. Tuning has resulted in an abnormally high or low value of a parameter due to the output circuit opened. → Check motor cable (disconnection, short circuit or grounded).
Rotation direction restriction	12	The rotation direction restriction has been set with function code H08.
Tuning frequency error (only when P04=2)	E	 The maximum frequency or the frequency limiter (high) has limited the output frequency. → Increase the F03 and F15 settings to values greater than 50% of the base frequency 1 (F04).
Occurrence of alarm	15	 During tuning, any alarm has occurred. → Check the contents of the multiple alarm and remove the error cause. For details, refer to Chapter 6 "TROUBLESHOOTING."
Acceleration timeout (only when P04=2)	IB	The output frequency has not reached 50% of the base frequency within the specified acceleration time "F07×300%". → Increase the F07 setting.

For a checking method of error sub codes, refer to Chapter 3 "3.4.6 Reading alarm information "Alarm Information: *a,BL*"."

If any of these errors occurs, remove the error cause and perform tuning again, or consult your Fuji Electric representative.

Note If a filter other than the Fuji optional output filter (OFL-□□□-□A) is connected to the inverter's output (secondary) circuit, the tuning result cannot be assured. When replacing the inverter connected with such a filter, make a note of the old inverter's settings for the primary resistance %R1, and leakage reactance %X, no-load current, and specify those values to the new inverter's function codes.

Vibration that may occur when the motor's coupling is elastic can be regarded as normal vibration due to the output voltage pattern applied in tuning. The tuning does not always result in an error; however, run the motor and check its running state.

4.5.2 Driving a permanent magnet synchronous motor (PMSM) without pole sensor and magnetic pole position sensor

Selection of PMSM type and pole position detection method

The permanent magnet type synchronous motor is classified as follows depending on the rotor structure (magnet layout):

- a) Surface magnet assembling magnet on rotor surface (SPM: Surface Permanent Magnet)
- b) Buried magnet assembling magnet into rotor iron core (IPM: Interior permanent magnet)

The starting magnetic pole position detection method depends on the motor type.

In most cases, the IPMPMs are generally used, but the SPMSMs are sometimes used. Consult with the motor manufacturer before use. Set the Initial magnetic position detection mode to the function code P30. (For details, refer to Chapter 5 "5.3.4 P codes (Motor 1 parameters)."

If the motor type is unknown, set P30 = 0.

[1] Driving a non-Fuji PMSM

To drive other manufacturer's synchronous motor, set the motor parameters shown in Table 4.5-2 and execute offline tuning.

Check the motor parameters on the motor rating nameplate or consult with the motor manufacturer before setting them.

Note There is the case that the customer's order, the motor parameters have been set at the factory. Please note that you do data initialized using the H03, motor parameters will be lost. Before initialization, record the data to be changed to memorize the motor constant.

(1) Configuring the function codes of motor parameters

When driving PMSM without speed sensor and magnetic pole position sensor, set the motor parameters after selecting F42=15.

Configure the function codes listed Table 4.5-2 according to the motor ratings and design values of the machine. For the motor ratings, check the ratings printed on the motor's nameplate. For design values of the machine, ask system integrators or machine manufacturers about them.

For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $\frac{1}{2}$ through $\frac{1}{2}$ "."

Function code	Name	Function code data	
F 42	Drive control selection 1	 15: Vector control for synchronous motor without speed sensor and pole position sensor Note: Setting value "20" or "21" in P99 does not appeared if F42 is not set to "15". 	
P 99	Motor 1 selection	20: Other motors (PMSMs)	
F []4	Base frequency 1	Motor rated value	
F 05	Rated voltage at base frequency 1	(printed on motor rated nameplate or motor test report)	
P D I	Motor 1 (No. of poles)	If the motor rated speed is known, calculate F04 by the following formula and set it	
P D2	Motor 1 (Rated capacity)	Rated rotation speed (Rotational speed [r/m]) / (120 / Number of	
P 03	Motor 1 (Rated current)	poles)	
P 30	PMSM Motor 1 (Magnetic pole position detection mode)	Motor type and starting method If 0: Rotor structure (magnet layout) is unknown: 1,3: IPM 2: SPM	
P 63	PMSM Motor 1 (Induced voltage)	Value described in motor test report If the value is unknown, execute rotation tuning.	
P 64	PMSM Motor 1 (Iron loss)	Set "the iron loss described in motor test report divided by Motor rated capacity: $P \square P$ ". Set 0%, if the iron loss is unknown.	
P 90	PMSM Motor 1 (Overcurrent protection level)	Demagnetization limit current of motor [A] (Effective value) Over current protection level [Arms] * This is used for protection from demagnetization by motor ove current. Set this function code if it is known. If it is unknown, set approx. 200% of motor rated current.	
F 03	Maximum frequency 1		
F 15	Frequency Limiter (Upper)	Note) For the test run of the motor, increase values so that thev	
F 07	Acceleration time 1 (Note)	are longer than your machine design values. If the specified	
F 08	Deceleration time 1 (Note)	ume is short, the inverter may not run the motor properly.	

Table 4.5-2	Motor parameters i	equired for tuning	g and function	code to be set	(Synchronous motor)

(2) Tuning under vector control for PMSM without speed sensor and magnetic pole position sensor

Selection of PMSM type and pole position detection method

(

After identifying the type of the synchronous motor and selecting the magnetic pole position detection mode, execute tuning based on Figure 4.5-2.

Tip Tuning errors might occur during tuning depending on the type of the synchronous motor and mismatching of P30 setting. Consult with the motor maker for the type and set the type to P30. If it is unknown, execute tuning as P30=0. In this case, it might be necessary to adjust the starting frequency setting F23 or starting frequency continuous time F24.



Figure 4.5-2

Selection of tuning type

Check the situation of the machine and select either "Tuning with the motor stopped (P04 = 1)" or "Tuning with the motor running (P04 = 2)." For the latter tuning, adjust the acceleration and deceleration times (F07 and F08) and specify the rotation direction that matches the actual rotation direction of the machine.

When P30 = 0 (Pull-in by current) or 3 (Pull-in by current for IPMSM), "Tuning with the motor stopped" cannot be performed. In this case the alarm \mathcal{E}_{r} 7 with subcode \mathcal{G}_{a} occurs.

P04 data		Motor parameters subjected to tuning	Tuning	Select under the following conditions
1	Tune while the motor stops.	Armature resistance (P60) d-axis inductance (P61) q-axis inductance (P62) Reserved (P84, P88)	Tuning with the motor stopped.	 Impossible to rotate the motor (e.g., when a mechanical load has already been applied to the motor). P30 is set to "1" or "2." See (Note 1).
2	Tune while the motor is rotating	Armature resistance (P60) d-axis inductance (P61) q-axis inductance (P62) Induced voltage (P63) Reserved (P84, P88)	Tuning the armature resistance, d-axis inductance, q-axis inductance, and parameter values (P84 and P88) <u>with</u> <u>the motor stopped</u> . Tuning the induced voltage <u>with the</u> <u>motor running</u> at 50 % of the base frequency.	 Possible to rotate the motor, provided that it is safe.

(Note 1) When P30 = 0 (Pull-in by current) or 3 (Pull-in by current for IPMSM), "Tuning with the motor stopped" cannot be performed. In this case the alarm \mathcal{E}_{-7} with subcode \mathcal{G}_{-7} occurs.

The tuning results of motor parameters will be automatically saved into their respective function codes.

Preparation of machine

In preparation for tuning, remove the motor coupling with the load and deactivate the safety devices before rotation tuning.

Tuning procedure

- Set function code P04 to "1" or "2" and press the make key. (The blinking of / or [¬] on the LED monitor will slow down.)
- 2) Enter a run command. (The factory default is "we key on the keypad for forward rotation.") To switch to reverse rotation or to select the terminal signal *FWD* or *REV* as a run command, change the data of function code F02.
- 3) The moment a run command is entered, the display of $/ \text{or } c^{-7}$ lights up, and tuning starts with the motor stopped. (Tuning time: Approx. 5 to 40 s.)
- 4) If P04 = 2, after the tuning in "3)" above, the motor is accelerated to approximately 50% of the base frequency and then tuning starts. Upon completion of measurements, the motor decelerates to a stop.
 (Estimated tuning time: Acceleration time + 10 s + Deceleration time)
- 5) If the terminal signal *FWD* or *REV* is selected as a run command (F02 = 1), E_{□□□} appears upon completion of the measurements. Turning the run command OFF completes the tuning.

If the run command has been given through the keypad or the communications link, it automatically turns OFF upon completion of the measurements, which completes the tuning.

6) Upon completion of the tuning, the subsequent function code appears on the keypad.



Note The default value of the speed regulator is set low to prevent your system from oscillation (hunting). However, hunting may occur during tuning due to mechanical conditions, causing a tuning error $(\mathcal{E}_{r}, 7)$, a stepout detection error $(\mathcal{E}_{r}, 2)$ or a speed mismatch error $(\mathcal{E}_{r}, 2)$. If a tuning error $(\mathcal{E}_{r}, 7)$ or a stepout protection error $(\mathcal{E}_{r}, 2)$ occurs, reduce the gain for the speed regulator; if a speed mismatch error $(\mathcal{E}_{r}, 2)$ occurs, cancel the speed mismatch detection function (d23=0). After that, perform tuning again.

Tuning errors (For PMSM)

Improper tuning would negatively affect the operation performance and, in the worst case, could even cause hunting or deteriorate precision. Therefore, if the inverter finds any abnormality in the tuning results or any error in the tuning process, it displays E_{1-7} and discards the tuning data.

When the tuning error $(\pounds - 7)$ appears, check that:

- The inverter's output (secondary) circuit is not opened.
- The mechanical brake is released. -

The terminal command **BX** ("Coast to a stop") is ON. -

- Any function code is wrongly configured.

Listed below are possible causes that trigger tuning errors and measures.

Possible tuning error causes	<i>E</i> ,- 7error subcode	Details and Measures
Sequence error	7 8 9	Before completion of tuning, the run command has been turned OFF. Or during tuning, terminal command STOP ("Force to stop") or BX ("Coast to a stop") has been entered. → Do not stop the inverter running until completion of tuning.
Output current error	5 10	 During tuning, an excessively large current has flown. → Release a mechanical brake or take any other measure to remove the cause resulting in overcurrent.
Tuning frequency error (only when P04=2)	13	 The maximum frequency or the frequency limiter (high) has limited the output frequency. → Increase the F03 and F15 settings to values greater than 50% of the base frequency 1 (F04).
Occurrence of alarm	15	 During tuning, any alarm has occurred. → Check the contents of the multiple alarm and remove the error cause. For details, refer to Chapter 6 "TROUBLESHOOTING."
Acceleration timeout (only when P04=2)	B	The output frequency has not reached 50% of the base frequency within the specified acceleration time "F07×300%". → Increase the F07 setting.
Parameter setting error	5003	The rated impedance or rated inductance is out of the effective range. → Check the F04, F05 and P03 settings.
Magnetic pole position calculation failure	5005	 When P30 = 1 or 3: The saliency ratio of the motor inductance is low. When P30 = 2: The motor has no magnetic saturation characteristic. → If this error occurs when P30 = 1, decrease the P87 setting. Note that it may fail to tune the motor that does not easily cause magnetic saturation. → If this error occurs when P30 = 2 or 3, change the P30 setting to "0" and adjust the F24 setting (Starting Frequency 1, Holding time) by gradually increasing it in increments of 0.5 to 5.0 s until rotational tuning succeeds.
Lack of magnetic saturation	5055	 The magnetic saturation characteristic of the motor is low so that the inverter has failed to discriminate the magnetic pole position. → Gradually increase the P87 setting up a maximum of 120%. If it produces no effect, change the P30 setting to "0" or "3," and the F24 setting to 0.5 to 5.0 s.
Excessive magnetic saturation	<i>50</i> 57	The magnetic saturation characteristic of the motor is high so that an excessively large current could flow at the discrimination time of the magnetic pole position. It is dangerous. → Decrease the P87 setting.
Error in tuning results	5053 to 5065	 An interphase voltage unbalance or output phase loss has been detected during tuning. Or tuning has resulted in an abnormally high or low value due to the output circuit opened. → Check that there is no abnormality in the inverter's output (secondary) circuit. → If a magnetic contactor (MC) is inserted in the inverter's output (secondary) circuit, circuit, check that it is closed.

For error sub codes, refer to Chapter 3 "3.4.6 Reading alarm information "Alarm Information: 5.9"."

If an error other than 2-7 occurs, remove the error cause, referring to Chapter 6 "TROUBLESHOOTING."

If a tuning error persists, consult your Fuji Electric representative.

- If a filter other than the Fuji optional output filter (OFL-□□□-□A) is connected to the inverter's output (secondary) circuit, the tuning result cannot be assured.
 - Vibration or noise that may occur when the motor's coupling is elastic can be regarded as normal since it is due to the output voltage pattern applied in tuning. The tuning does not always result in an error; however, run the motor and check its running state.

[2] Driving a Fuji dedicated PMSM (GNB2 series)

For 90 kW or less, the motor parameters are prepared beforehand. After setting P99=21 and initializing by H03=2, required parameters are set.

For more than 90 kW, the motor parameters are notified separately. Never start operation of the synchronous motor until the notified parameters are set.

* To change the data of function code H03, double key operation " ∞ key + $\sqrt{2}$ key" is necessary.

* After initialization, the data of function code H03 automatically returns to "0" (Factory default value).

For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $/F_{-}$ through $/_{D_{-}}$."



If Fuji standard synchronous motor without magnetic pole position sensor (GNB2 series 1800 r/min specification) of the capacity different from the inverter is used, change P02 accordingly and initialize motor 1 parameters by H03 = 2 (PM motor).

[3] Driving a Fuji non-dedicated PMSM (non-GNB2 series)

Motor parameters are notified separately. After setting P99=20 and initializing by H03=2, set the notified parameters.

Never start operation of the synchronous motor until the notified parameters are set.

To change the data of function code H03, double key operation " ∞ key + $\sqrt{2}$ key" is necessary.

After initialization is completed, the data of function code H03 automatically returns to "0" (Factory default value).

For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $/-_{-}$ through $/_{--}$ "."

4.6 Running the Inverter for Motor Operation Check

After completion of preparations for a test run as described above, start running the inverter for motor operation check using the following procedure.

If the user configures the function codes wrongly without completely understanding this User's Manual, the motor may rotate with a torque or at a speed not permitted for the machine.

Accident or injury may result.

If any abnormality is found in the inverter or motor, immediately stop operation and investigate the cause referring to Chapter 6 "TROUBLESHOOTING."

4.6.1 Test run procedure

- (1) Turn the power ON and check that the reference frequency 222 Hz is blinking on the LED monitor.
- (2) Set a low reference frequency such as 5 Hz, using \bigotimes / \bigotimes keys. (Check that the frequency is blinking on the LED monitor.)
- (3) Press the we key to start running the motor in the forward direction. (Check that the reference frequency is lit on the LED monitor.)
- (4) To stop the motor, press the \overline{m} key.

4.6.2 Check points during a test run

- (1) Check that the motor is running in the forward direction.
- (2) Check for smooth rotation without motor humming or excessive vibration.
- (3) Check for smooth acceleration and deceleration.

When no abnormality is found, press the \bigoplus key again to start driving the motor, then increase the reference frequency using \bigotimes / \bigotimes keys. Check the above points again.

Tip Depending on the settings of function codes, the motor speed may rise to an unexpectedly high and dangerous level, particularly. To avoid such an event, the speed limiting function is provided.

If the user is unfamiliar with the function code settings (e.g., when the user starts up the inverter for the first time), it is recommended that the "F15: Frequency limiter (Upper limit)" and the torque control "d32: Speed limit 1" and "d33: Speed limit 2" are used. At the startup of the inverter, to ensure safer operation, specify small values to those function codes at first and gradually increase them while checking the actual operation.

The speed limiting function serves as an overspeed level barrier, or as a speed limiter under torque control. For details of the speed limiting function, refer to Chapter 5.



For driving PMSM under vector control without magnetic pole position sensor, when P30 is set to any value other than "0," noise that may occur from the motor at the start of running can be regarded as normal.

4.6.3 Modification of motor control function code data

Modifying the current function code data sometimes can solve an insufficient torque or overcurrent or overvoltage incident. Table 4.6-1 lists the major function codes to be accessed. For details, see Chapter 5 "FUNCTION CODES" and Chapter 6 "TROUBLESHOOTING."

Function code	Name	Modification key points
F []7	Acceleration time 1	If the current limiter is activated due to a short acceleration time and large drive current, prolong the acceleration time.
F 08	Deceleration time 1	If an overvoltage trip occurs due to a short deceleration time, prolong the deceleration time.
F 09	Torque boost 1	If the starting motor torque is deficient under V/f control mode, increase the torque boost. If the motor with no load is overexcited (current increasing), decrease the torque boost.
<i>F 4</i> 4	Current limiter (Mode selection)	If the stall prevention function is activated by the current limiter during acceleration or deceleration, increase the operation level.
P []7	Motor 1 (%R1)	If the starting motor torque is insufficient under automatic torque boost and torque vector control, increase %R1. If the motor with no load is over-excited (current increasing), decrease %R1.
H 07	Curve acceleration/ deceleration	If overshoot to the change in speed command is large, make curve acceleration/deceleration speed effective.
H 69	Anti-regenerative control (Mode selection)	If overvoltage trip occurs when executing acceleration/deceleration without using the braking resistor, prevent overvoltage trip by making anti-regenerative control effective.
H 80	Output current fluctuation damping gain for motor 1	It is not necessary to change the setting normally. If the current vibrates by the stall prevention function due to current limitation or the high speed motor is driven, decrease the suppression gain. Even though the stall prevention does not function, if the motor vibrates due to current fluctuation, increase the suppression gain.

	Та	ble	4.6	5-1
--	----	-----	-----	-----

In the case of Vector control for synchronous motor without speed sensor and magnetic pole position sensor, if the problem is not solved by adjusting the function code in Table 4.6-1, adjust the function code in Table 4.6-2.

In the above control methods, PI regulator is used for speed control. The desired response can be obtained by adjusting the control constants (PI constants) to match the load inertia. The major function codes to adjust are shown below.

For details, see Chapter 5 "FUNCTION CODES" and Chapter 6 "TROUBLESHOOTING."

Table 4.6-2

Function code	Name	How to adjust
d 0 I	Speed control 1 (Speed command filter)	If an excessive overshoot or undershoot occurs for a speed command change, increase the filter constant. If motor response is slow for a speed command change, decrease the filter constant.
d 02	Speed control 1 (Speed detection filter)	If ripples are superimposed on the speed detection signal so that the speed control gain cannot be increased, increase the filter constant to obtain a larger gain. It is not necessary to change the factory default normally.
d 03	Speed control 1 P (Gain)	If hunting is caused in the motor speed control, decrease the gain. If speed mismatch or excessive speed deviation $(\mathcal{E} - \mathcal{E})$ occurs because the motor response is slow, increase gain.
d 04	Speed control 1 I (Integral time)	If speed mismatch or excessive speed deviation $(\mathcal{E} - \mathcal{E})$ occurs because the motor response is slower, decrease the integration time. If the load inertia is large, increase the integration time.

4.7 Selecting a Frequency Command Source

The frequency command source by factory default is the keypad (\bigotimes / \bigotimes keys). This section provides the frequency command setting procedures using the frequency command sources of the keypad, external potentiometer, and frequency selection terminal commands.

4.7.1 Setting up a frequency command from the keypad

Follow the procedure given below.

(1) Configure the function codes as listed below.

Function code	Name	Function code data	Factory default
F01	Frequency Command 1	0: Keypad (⊘ / ⊗ keys)	0

- When the inverter is in Programming or Alarm mode, frequency command setting with ⊗ / ⊗ keys is disabled. To enable it, switch to Running mode.
 - If any of higher priority frequency command sources (multistep frequency commands and frequency commands via communications link) is specified, the inverter may run at an unexpected frequency.
- (2) Press the \bigotimes / \bigotimes key to display the current frequency command on the LED monitor. The least significant digit blinks.
- (3) To change the frequency command, press the
 /
 key again.
 When you start specifying the frequency command with the
 /
 key, the least significant digit on the display blinks; that it, the cursor is located in the least significant digit. Holding down the
 /
 key changes data in the least significant digit and generates a carry, while the cursor remains in the least significant digit.
- (4) To save the new setting into the inverter's memory, press the key.
- For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $\frac{1}{2}$ through $\frac{1}{2}$ "."

4.7.2 Setting up a frequency command with an external potentiometer

Follow the procedure given below.

(1) Configure the function codes as listed below.

Function code	Name	Function code data	Factory default
F01	Frequency Command 1	1: Analog voltage input to terminal [12] (0 to ±10 V)	0

Note If terminal [FWD] and [REV] are ON (short-circuited), the F01 data cannot be changed. First turn those terminals OFF and then change the F01 data.

- (2) Connect an external potentiometer to terminals [11] through [13] of the inverter.
- (3) Rotate the external potentiometer to apply voltage to terminal [12] for a frequency command input.
- For precautions in wiring, refer to Chapter 2 "INSTALLATION AND WIRING."
- For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $\frac{1}{2}$ through $\frac{1}{2}$ "."

4.7.3 Setting up a frequency command with multistep frequency selection

Follow the procedure given below.

(1) Configure the function codes as listed below.

Function code	Name	Function code data	Factory default
E01 to E05	Terminal [X1] to [X5] Functions	0, 1, 2, 3: Multistep frequency 1 to 15 (0: "SS1", 1: "SS2", 2: "SS4", 3: "SS8")	0
C05 to C19	Multistep Frequency 1 to 15	0.00 to 120.00 Hz	0.00

Assign signals "SS1", "SS2", "SS4" and "SS8" to four out of five digital input terminals [X1] to [X5] by respective function codes E01 to E05 (data = 0, 1, 2 and 3). Specify multistep frequency commands with C05 to C19.

Turning digital signals "SS1", "SS2", "SS4" and "SS8" ON or OFF selectively switches the multistep frequency commands specified beforehand, as shown in the table below.

Combination of input signals					
3 "SS8"	2 "SS4"	1 "SS2"	0 "SS1"	Selected frequen	cy command
OFF	OFF	OFF	ON	C05 (Multistep frequency 1)	
OFF	OFF	ON	OFF	C06 (Multistep frequency 2)	
OFF	OFF	ON	ON	C07 (Multistep frequency 3)	
OFF	ON	OFF	OFF	C08 (Multistep frequency 4)	
OFF	ON	OFF	ON	C09 (Multistep frequency 5)	
OFF	ON	ON	OFF	C10 (Multistep frequency 6)	
OFF	ON	ON	ON	C11 (Multistep frequency 7)	C05 to C19
ON	OFF	OFF	OFF	C12 (Multistep frequency 8)	
ON	OFF	OFF	ON	C13 (Multistep frequency 9)	Data setting range:
ON	OFF	ON	OFF	C14 (Multistep frequency 10)	0.00 10 120.00
ON	OFF	ON	ON	C15 (Multistep frequency 11)	
ON	ON	OFF	OFF	C16 (Multistep frequency 12)	
ON	ON	OFF	ON	C17 (Multistep frequency 13)	
ON	ON	ON	OFF	C18 (Multistep frequency 14)	
ON	ON	ON	ON	C19 (Multistep frequency 15)	

(2) Connect a multistep frequency switch to an X terminal and [CM].

(3) Turn the multistep frequency switch ON (short-circuit). The combination of those input signals selects a multistep frequency command.

- For precautions in wiring, refer to Chapter 2 "INSTALLATION AND WIRING."
- For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $//_{-}$ through $/_{D--}$ "."

Note Enabling a multistep frequency command with a multistep frequency switch (ON between X terminal and [CM]) disables the frequency command 1 specified by F01.

4.8 Selecting a Run Command Source

A run command source is the keypad (w and w keys) by factory default.

4.8.1 Setting up a run command from the keypad

Follow the procedure given below.

(1) Configure the function codes as listed below.

Function code	Name	Function code data	Factory default
F02	Operation Method	 Keypad operation (Rotation direction input: Terminal block) Keypad operation (Forward direction) Keypad operation (Reverse direction) 	2: Keypad operation (Forward direction)

(2) When F02 = 0: Press the we key to run the motor. Press the we key to stop it. The rotation direction is specified by terminals [FWD] and [REV]. Connect the run forward switch between terminals [FWD] and [CM] and the run reverse switch between [REV] and [CM].

Note Make sure that the SINK/SOURCE slide switch (SW1) is turned to the SINK position. If SW1 is in the SOURCE position, the inverter cannot run the motor.

- (3) When F02 = 2: Press the W key to run the motor in the forward direction. Press the W key to stop it.
- (4) When F02 = 3: Press the key to run the motor in the reverse direction. Press the key to stop it.
- For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $\frac{1}{2}$ through $\frac{1}{2}$ "."

4.8.2 Setting up a run command with digital input signals (terminals [FWD] and [REV])

Follow the procedure given below.

(1) Configure the function codes as listed below.

Function code	Name	Function code data	Factory default
F02	Operation Method	1: External digital input signal	2: Keypad operation (Forward direction)

Note If terminal [FWD] and [REV] are ON (short-circuited), the F02 data cannot be changed. First turn those terminals OFF and then change the F02 data.

(2) Connect the run forward switch between terminals [FWD] and [CM] and the run reverse switch between [REV] and [CM].

Note Make sure that the SINK/SOURCE slide switch (SW1) is turned to the SINK position. If SW1 is in the SOURCE position, the inverter cannot run the motor.

- (3) Turn the run forward switch or run reverse switch ON (short-circuit) to run the motor in the forward or reverse direction, respectively.
- For precautions in wiring, refer to Chapter 2 "INSTALLATION AND WIRING."
- For details on how to modify the function code data, see Chapter 3 "3.4.1 Setting up function codes "Data Setting: $/-_{-}$ through $/_{-}$."



Chapter 5 FUNCTION CODES

This chapter explains the table of function codes used in FRENIC-eHVAC, index per purpose, and the detail of each function code.

Contents

5.1 Fur	nction Codes Overview ······ 5-1
5.2 Fur	nction Codes Table 5-2
5.2.1	Supplementary note 5-2
5.2.2	Function codes table 5-4
5.2.3	Factory default value per applicable electric motor capacitance
5.2.4	Motor constants
[1]	When Fuji standard motor 8-series, or other motors are selected by motor selection (Function code P99 = 0 or 4)5-32
[2]	When HP rating motor is selected by motor selection (Function code P99/A39 = 1) ·····5-33
5.3 Des	scription of Function Codes ······5-34
5.3.1	F codes (Basic functions)······5-34
[1]	Frequency setting by keypad (F01 = 0 (Factory default state), 8)5-36
[2]	Setting up a reference frequency using analog input (F01 = 1 to 3, 5)5-37
[3]	Frequency setting by digital input signal "UP"/"DOWN" (F01=7)5-43
[4]	Frequency setting using pulse train input (F01=12)5-44
5.3.2	E codes (Extension terminal functions) ······5-80
5.3.3	C codes (Control functions) 5-116
5.3.4	P codes (Motor 1 parameters)5-125
5.3.5	H codes (High performance functions) 5-130
[1]	Measuring the capacitance of DC link bus capacitor in comparison with initial one
	at shipment ······ 5-142
[2]	Measuring the capacitance of DC link bus capacitor under ordinary operating conditions at power shutdown
5.3.6	A codes (Motor 2 parameters)5-160
5.3.7	J codes (Applied functions) ······5-161
[1]	PID command with the \bigcirc / \bigcirc keys on the keypad (J02 = 0, factory default)
[2]	PID command by analog inputs (J02 = 1) ······ 5-162
[3]	PID command with UP/DOWN control (J02 = 3)5-165
[4]	PID command via communications link (J02 = 4) ······ 5-165
[5]	Pump control······ 5-176
5.3.8	d codes (Applied functions 2)5-228

[1]	Speed control
	(Vector control without speed sensor nor pole position sensor for PMSM)5-228
5.3.9	U codes (Customizable logic operation) 5-232
5.3.10	U1 codes (Customizable logic operation)5-257
5.3.11	y codes (Link functions) ······ 5-261

5.1 Function Codes Overview

Function codes are used for selecting various functions of FRENIC-eHVAC. Function codes comprise 3 digits or 4 digits of alphanumeric character. The first digit categorizes the group of function code alphabetically and the subsequent 2 or 3 digits identify each code within the group by number. Function code comprises 11 groups: <u>Basic function (F code)</u>, <u>Terminal function (E code)</u>, <u>Control code (C code)</u>, <u>Motor 1 parameter (P code)</u>, <u>High-level function (H code) (H1 code)</u>, <u>Speed control 2 parameter (A code)</u>, <u>Application function 1 (J code) (J1 code) (J4 code) (J5 code)</u>, <u>Application function 2 (d code)</u>, <u>Customizable logic (U code) (U1 code)</u>, <u>Link function (y code)</u>, <u>Keypad functions (K code)</u>, and Option function (o code). The function of each function code is determined according to the data to be set. The following descriptions are for supplementary explanation of function code table. Refer to instruction manual of each option to find the details of the option function (o code).

5.2 Function Codes Table

5.2.1 Supplementary note

■ Change, reflect, and save function code data during operation

Function codes are categorized into those which data change is enabled during operation of the inverter and those which such change is disabled. The meaning of the code in the "Change during operation" column of the function code table is described in the following table.

Code	Change during operation	Reflect and save data
Y*	Allowed	At the point when data is changed by \bigcirc / \bigcirc key, the changed data is immediately reflected on the operation of inverter. However, at this stage, the changed value is not saved to the inverter. In order to save it to the inverter, press $$ key. Without saving by $$ key and leaving the state of when the change was made by the $$ key, the data before the change is reflected on the operation of inverter.
Y	Allowed	Even if data is changed by the \bigcirc / \bigcirc key, the changed data will not be reflected on the operation of the inverter as is; by pressing the \textcircled{bm} key, the changed value is reflected on the operation of the inverter and is also saved to the inverter.
N	Not allowed	—

Copying data

Function code data can be copied collectively by using the optional keypad "TP-E1U" (program mode menu number 7 "Data copy") or "TP-A1". By using this function, it is possible to read out all function code data and write the same data to a different inverter.

However, if the specification of inverter at the copy source and copy destination is not identical, some function codes may not be copied due to security reason. According to necessity, configure the settings individually for the function codes that are not copied. The behaviour of the function codes regarding data copy is indicated in the "data copy" column in the function code table in the next page and following.

- Y: to be copied.
- Y1: When inverter capacity is different, copying will not be performed.
- N: not to be copied.

Negative logic setting of data

Digital input terminal and transistor/contact output terminal can become a signal for which negative logic is specified by function code data setting. Negative logic is a function to reverse ON and OFF state of input or output, and switch Active ON (function enabled with ON: positive logic) and Active OFF (function enabled with OFF: negative logic). However, negative logic may not be enabled depending on the function of the signal.

Negative logic signal can be switched by setting the data with 1000 added to the function code data of the function to be set. For example, the following example shows when coast to a stop command "BX" is selected by function code E01.

Function code data	Action
7	"BX" is ON and coast to a stop (Active ON)
1007	"BX" is OFF and coast to a stop (Active OFF)

Drive control

The FRENIC-eHVAC runs under any of the following drive controls. Some function codes apply exclusively to the specific drive control, which is indicated by letters Y (Applicable) and N (Not applicable) in the "Drive control" column in the function code tables given on the following pages.

Abbreviation in "Drive control" column in function code tables	Drive control (F42)
V/f	0: V/f control for induction motor
РМ	 Vector control without speed sensor nor pole position sensor for permanent magnet synchronous motor (PMSM)

For details about the drive control, refer to the description of F42 "Drive control selection 1."

Note The FRENIC-eHVAC is a general-purpose inverter whose operation is customized by frequency-basis function codes, like conventional inverters. Under the speed-basis drive control, however, the control target is a motor speed, not a frequency, so convert the frequency to the motor speed according to the following expression.

Motor speed (r/min) = $120 \times$ Frequency (Hz) \div Number of poles

5.2.2 **Function codes table**

The table of function codes to be used in FRENIC-eHVAC is shown below.

F codes: Fundamental Functions (Basic function)

Code	Name	Data setting range		Change when running	Data copying	Factory Default	//f Drive	M control	Related page
F00	Data protection	 No data protection, no digital setting protection With data protection, no digital setting protection No data protection, with digital setting protection With data protection, with digital setting protection 	1	Y	Y	0	Y	Y	5-34
F01	Frequency setting 1	 Keypad key operation (⊘/⊙key) Analog voltage input (Terminal [12]) (from 0 to ±10 VDC) Analog current input (Terminal [C1] (C1 function)) (4 to 20mA DC, 0 to 20mA DC) Analog voltage input (Terminal [12]) + Analog current input (Terminal [C1] (C1 function)) Analog voltage input (Terminal [C1] (V2 function)) (0 to 10 VDC) UP/DOWN control Keypad key operation (⊘/⊙key) (With balanceless bumpless) Pattern operation Pulse train input 	1	Z	Y	0	Y	Y	5-35
F02	Operation method	 Keypad operation (rotation direction input: terminal block) External signal (digital input) Keypad operation (forward rotation) Keypad operation (Reverse rotation) 	1	Z	Y	2	Y	Y	5-46
F03	Maximum output frequency 1	25.0 to 120.0 Hz	3	Ν	Υ	50.0	Υ	Υ	5-47
F04	Base frequency 1	25.0 to 120.0 Hz	3	Ν	Υ	50.0	Υ	Υ	5-48
F05	Rated voltage at base frequency 1	 AVR disable (output voltage proportional to power voltage) 160 to 500V: AVR operation (400V class) 		Ν	Y	380	Y	Y	
F06	Maximum output voltage 1	160 to 500V: AVR operation (400V class)	1	Ν	Υ		Υ	Υ	
F07 F08	Acceleration time1 Deceleration time1	0.00 to 3600 s * 0.00 is for acceleration and deceleration time cancel (when performing soft-start and stop externally)	12	Y Y	Y Y	20.0	Y Y	Y Y	5-50
F09	Torque boost 1	0.0 to 20.0% (% value against base frequency voltage 1)	3	Y	Y	*2	Y	N	5-52
F10	Electronic thermal overload protection for motor 1 (Select motor characteristics)	Enable (For a general-purpose motor with self-cooling fan) Enable (For an inverter-driven motor (FV) with separately powered cooling fan)	1	Y	Y	1	Y	Y	5-52
F11	(Overload detection level)	0.00 (disable)	24	Y	Y1	*3	Y	Y	
F12	(Thermal time constant)	0.5 to 75.0 min	3	Y	Y	*4	Y	Y	
F14	Restart mode after momentary power failure (Mode selection)	 Trip immediately Trip after a recovery from power failure Trip after momentary deceleration is stopped Continue to run (for heavy inertia load or general load) Restart from frequency at power failure (for general load) Restart from starting frequency 	1	Y	Y	1	Y	Y	5-55
F15	Frequency limiter (Upper limit)	0.0 to 120.0 Hz	3	Υ	Υ	70.0	Υ	Y	5-62
F16	(Lower limit)	0.0 to 120.0 Hz	3	Υ	Υ	0.0	Υ	Υ	
F18	Bias (for frequency setting 1)	-100.00 to 100.00%	6	Y*	Υ	0.00	Υ	Y	5-62
F20	DC braking 1 (Braking starting frequency)	0.0 to 60.0Hz	3	Y	Y	0.0	Y	Y	5-63
F21	(Braking level)	0 to 80%	1	Υ	Υ	0	Υ	Υ	
F22	(Braking time)	0.00 (Disable): 0.01 to 30.00 s	5	Υ	Υ	0.00	Υ	Y	
F23	Starting frequency 1	0.1 to 60.0Hz	3	Υ	Υ	0.5	Υ	Y	5-66
F24	(Holding time)	0.00 to 10.00 s	5	Y	Υ	0.00	Υ	Y	
F25	Stop frequency	0.0 to 60.0 Hz	3	Υ	Υ	0.2	Υ	Υ	

indicates quick setup target function code.
*2: Factory defaults are depended on motor capacity. Refer to "5.2.3 Factory default value per applicable electric motor capacitance".
*3: The motor rated current is automatically set. Refer to "5.2.4 Motor constant".
*4: 5.0min for inverters of nominal applied motor 22kW or below; 10.0min for those of 30kW or above.

Code	Name	Data setting range	munication ^{for} mat	nge when unning	a copying	⁻ actory Default	Drive control		ated page
				Cha	Dat		J/Λ	PM	Rela
F26	Motor sound (Carrier frequency)	- 0.75 to 16 kHz (FRN0002 to 0045F2E-4G) - 0.75 to 10 kHz (FRN0060 to 0150F2E-4G) - 0.75 to 6 kHz (FRN0176F2E-4G or above)	1	Y	Y	2	Y	Υ	5-67
F27	(Tone)	0: Level 0 (Disable) 1 to 3 : Level 1 to 3	1	Y	Y	0	Y	Ν	
F29	Terminal FM1 (Mode selection)	0: Voltage output (0 to +10 VDC) 1: Current output (4 to 20 mA DC) 2: Current output (0 to 20 mA DC) 3: Pulse output	1	Y	Y	0	Y	Y	5-68
F30	(Output gain)	0 to 300%	1	Y*	Υ	100	Υ	Υ	
F31	(Function selection)	 Output frequency 1 (PM: Speed command value) Output frequency 2 (PM: Speed estimated value) Output current Output voltage Output torque Load factor Input power PID feedback value Estimated speed D Clink bus voltage Universal AO Motor output Calibration (+) PID command (SV) PID output (MV) Inverter heat sink temperature Reference frequency External PID control1 feedback value (EPID1-PV) External PID control1 output (EPID1-OUT) to 120 Customizable logic output signal 1 to 10 	1	Y	Y	0	Y	Y	
F32	Terminal FM2 (Mode selection)	0: Voltage output (0 to +10 VDC) 1: Current output (4 to 20 mA DC) 2: Current output (0 to 20 mA DC)	1	Y	Y	0	Y	Y	
F33	Terminal FM1 (Pulse rate)	25 to 32000 p/s (number of pulse at monitor value 100%)	1	Y*	Υ	1440	Υ	Υ	
F34	Terminal FM2 (Output gain)	0 to 300%	1	Y*	Υ	100	Υ	Υ	
F35	(Function selection)	Same as F31	1	Υ	Υ	2	Υ	Υ	
F37	Load selection/ Auto torque boost/ Auto energy-saving operation 1	 Variable torque load Constant torque load Constant torque load Auto torque boost Auto energy-saving operation (variable torque load) Auto energy-saving operation (constant torque load) Auto energy-saving operation with auto torque boost 	1	N	Y	1	Y	Ν	5-71
F40	Torque limiter 1 (Driving)	20 to 150%; 999 (Disable)	1	Y	Y	999	Y	Y	5-73
F41	(Braking)	20 to 150%; 999 (Disable)	1	Y	Y	999	Y	Y	
F42	Drive control selection 1	 V/f control without slip compensation 15: Vector control for synchronous motor without speed sensor nor pole position sensor 	1	N	Y	0	Y	Y	5-75
F43	Current limiter (Mode selection)	 Disable (No current limiter works.) Enable at constant speed (Disable during ACC/DEC) Enable during ACC/constant speed operation 	1	Y	Y	2	Y	Ν	5-77
F44	(Level)	20 to 150% (Rated current of the inverter for 100%)	1	Y	Υ	130	Υ	Ν	
F50	Electronic thermal overload protection for braking resistor (Discharging capacity)	1 to 9000 kWs OFF: Cancel	1	Y	Y1	OFF	Y	Y	5-78
F51	(Allowable average loss)	0.001 to 99.99 kW	45	Y	Y1	0.001	Y	Υ	
F52	(Braking resistance value)	0.00: Resistance not required (Compatible mode with FRENIC-Multi series) 0.01 to 999 Ω	12	Y	Y1	0.00	Y	Y	

5.2 Function Codes Table

indicates quick setup target function code.

Chap 5 FUNCTION CODES

■ E code: Extension Terminal Functions (Terminal function)

Code	Name		Data setting range		munication ormat	nge when unning	a copying	Factory Default	Drive	control	ated page
					Comr	Chai	Data	шо	V/f	PM	Rela
E01	Terminal [X1] function	0 (1000):	Select multistep frequency (0 to 1 steps)	'SS1"	1	Ν	Υ	6	Υ	Y	5-80
E02	Terminal [X2] function	1 (1001):	Select multistep frequency (0 to 3 steps)	'SS2"	1	Ν	Υ	7	Υ	Y	
E03	Terminal [X3] function	2 (1002):	Select multistep frequency (0 to 7 steps)	"SS4"	1	Ν	Υ	8	Υ	Υ	
E04	Terminal [X4] function	3 (1003):	Select multistep frequency (0 to 15 steps)	"SS8"	1	Ν	Υ	11	Υ	Υ	
E05	Terminal [X5] function	4 (1004):	Select ACC/DEC time (2 steps)	'RT1"	1	Ν	Υ	35	Y	Y	
		5 (1005):	Select ACC/DEC time (4 steps)	"RT2"					Υ	Υ	
		6 (1006):	Select 3-wire operation "	'HLD"					Υ	Y	
		7 (1007):	Coast to a stop command	"BX"					Y	Y	
		8 (1008):	Reset alarm (Abnormal) '	'RST"					Y	Y	
		9 (1009):	External alarm "	THR"					Υ	Y	
			(9 = Active OFF/ 1009 = Active ON)								
		11 (1011):	Select frequency setting 2/ frequency setting 1 "Hz2/	Hz1"					Y	Y	
		13:	DC braking command "DC	BRK"					Y	N	
		14 (1014)	Select torque limit 2/ torque limit 1						Ŷ	Y	
			"TL2/	' TL1"							
		15:	Switch to commercial power (50 Hz) "S	W50"					Y	Ν	
		16:	Switch to commercial power (60 Hz) "S	W60"					Y	Ν	
		17 (1017):	UP command	"UP"					Υ	Y	
		18 (1018):	DOWN command "DO	DWN"					Y	Y	
		19 (1019):	Allow function code editing						Y	Y	
			(Data change enabled) "WI	E-KP"							
		20 (1020):	Cancel PID control "Hz	/PID"					Y	Y	
		21 (1021):	Switch normal/ inverse operation	"IVS"					Y	Y	
		22 (1022):	Interlock	"IL"					Y	Y	
		24 (1024):	Select link operation (RS-485, BUS option)	"LE"					Y	Y	
		25 (1025):	Universal DI "	U-DI"					Y	Y	
		26 (1026):	Select auto search for idling motor speed at startin	ng STM"					Y	Y	
		30 (1030):	Force to stop "S (30 = Active OFF/1030 = Active ON)	TOP"					Y	Y	
		33 (1033):	Reset PID integral and differential terms "PID-	RST"					Y	Υ	
		34 (1034):	Hold PID integral term "PID-	HLD"					Y	Y	
		35 (1035):	Select local (Keypad) command "	LOC"					Y	Y	
		38 (1038):	Run enable	"RE"					Υ	Y	
		39 :	Dew condensation prevention "I	DWP"					Y	Υ	
		40 :	Enable integrated sequence to switch to commerce power (50Hz) "IS	ial W50"					Y	N	
		41:	Enable integrated sequence to switch to commerc power (60Hz) "IS	ial W60"					Y	N	
		48:	Pulse train input (Only for X5 terminal (E05))	"PIN"					Y	Y	
		49 (1049):	Pulse train sign "S (Other than X5 terminal (E01 to E04))	SIGN"					Y	Y	
		50 (1050):	Clear running motor regular switching time "N	ICLR"					Y	Y	
		72 (1072):	Count the run time of commercial power-driven m "CRUN	otor 1 N-M1"					Y	Ν	
		78 (1078):	Select speed control parameter 1 "MP	RM1"					N	Y	
		80 (1080):	Cancel customizable logic "	CLC"					Y	Y	
		81 (1081):	Clear all customizable logic timers "C	LTC"					Y	Y	
		82 (1082):	Cancel anti-regenerative control "AR-	CCL"					Y	Y	
		87 (1087):	Run command 2/1 "FR2	/FR1"	İ				Y	Y	
		88 (1088):	Run forward / stop 2 "FV	WD2"				L	Y	Y	
		89 (1089):	Run reverse / stop 2 "R	EV2"					Y	Y	
		100:	No function assigned "N	ONE"					Y	Y	
		149 (1149)	: Switch pump control "Po	CHG"	İ				Y	Y	
		150 (1150)	: Enable master motor drive in mutual operation"M	1EN0"	 				Y	Y	
		151 (1151)	: Enable pump control motor 1 to be driven "M	EN1"					Y	Y	
		152 (1152)	: Enable pump control motor 2 to be driven "M	EN2"	İ				Y	Y	
		153 (1153)	: Enable pump control motor 3 to be driven "M	EN3"	 				Y	Y	
		154 (1154)	: Enable pump control motor 4 to be driven "M	EN4"					Y	Y	
Code	Name	Data setting range	Communication format	Change when running	Data copying	Factory Default	V/f Drive	M control	Related page		
------	-----------------------------	---	-------------------------	------------------------	--------------	--------------------	-----------	-----------	--------------		
			_				- 	ш.			
		171 (1171): PID control multistage command 1 "PID-SS1"					Y	Y			
		1/2 (11/2): PID control multistage command 2 "PID-SS2"					Y	Y			
		181 (1181): External PID1 multistage command 1 "EPID-SS1"					Y	Y			
		182 (1182): External PID1 multistage command 2 "EPID-SS2"					Y	Υ			
		201 (1201): External PID1 ON command "EPID1-ON"					Y	Υ			
		202 (1202): External PID1 Cancel "%EPID1'					Y	Y			
		203 (1203): External PID1 Switch normal/inverse operation "EPID1-IVS"					Y	Y			
		204 (1204): External PID1 reset integral and differential components "EPID1-RST"					Y	Y			
		205 (1205): External PID1 hold integral component "EPID1-HLD"					Y	Y			
		* Inside the () is the negative logic signal (OFF at short-circuit)									
E10	Acceleration time 2	0.00 to 3600 s	12	Υ	Υ	20.0	Υ	Υ	5-97		
E11	Deceleration time 2	* 0.00 is for acceleration and deceleration time cancel (when									
E12	Acceleration time 3	performing solt-start and stop externally)									
E13	Deceleration time 3										
E14	Acceleration time 4										
E15	Deceleration time 4										
E16	Torque limiter 2 (Driving)	20 to 150%; 999 (Disable)	1	Υ	Υ	999	Υ	Υ	5-97		
E17	(Braking)										
E20	Terminal [Y1] function	0 (1000): Inverter running "RUN"	1	Ν	Υ	0	Υ	Υ	5-98		
E21	Terminal [Y2] function	1 (1001): Frequency (speed) arrival "FAR"	1	Ν	Υ	1	Y	Y			
E22	Terminal [Y3] function	2 (1002): Frequency (speed) detected "FDT"	1	Ν	Υ	2	Υ	Υ			
E24	Terminal [Y5A/C] function	3 (1003): Under voltage detected (inverter stopped) "LU	1	N	Y	15	Y	Y			
F27	Terminal [30A/B/C] function	5 (1005): Inverter output limiting "IOI "	1	N	Ŷ	99	Ŷ	Ŷ			
		6 (1006): Auto-restarting after momentary power failure "IPF"					Ŷ	Ŷ			
		7 (1007): Motor overload early warning "OL"					Y	Y			
		8 (1008): Keypad operation enabled "KP"					Y	Y			
		10 (1010): Inverter ready to run "RDY"					Y	Y			
		11: Switch motor drive source between commercial power and inverter output (For MC on commercial line) "SW88"					Y	N			
		12: Switch motor drive source between commercial power and inverter output (For secondary side) "SW52-2"					Y	N			
		13: Switch motor drive source between commercial power and inverter output (For primary side) "SW52-1"					Y	N			
		15 (1015): Switch MC on the input power lines "AX"					Y	Y			
		16 (1016): Pattern operation stage transition "TU"	+	†			Y	Y			
		17 (1017): Pattern operation cycle completed "TO"					Y	Y			
		18 (1018): Pattern operation stage 1 "STG1"		-			Y	Y			
		19 (1019): Pattern operation stage 2 "STG2"	†	†			Y	Y			
		20 (1020): Pattern operation stage 4 "STG4"	+	†			Y	Y			
		25 (1025): Cooling fan in operation "FAN'					Y	Y			
		26 (1026): Auto-resetting "TRY"		†			Y	Y			
		27 (1027): Universal DO "U-DO"	+	†			Y	Y			
		28 (1028): Heat sink overheat early warning "OH"					Y	Y			
		30 (1030): Lifetime alarm "LIFE"					Y	Y			
		33 (1033): Reference loss detected "REF OFF"					Y	Y			
		35 (1035): Inverter outputting "RUN 2"		1			Y	Y			
		36 (1036): Overload prevention controlling "OLP"					Y	Y			
		37 (1037): Current detected "ID'					Y	Y			
		41 (1041): Low current detected "IDL'		1			Y	Y			
		42 (1042): PID alarm "PID-ALM"		1			Y	Y			
		43 (1043): Under PID control "PID-CTL"					Y	Y			
		44 (1044): Under sleep mode of PID control "PID-STP"		-			Y	Y			
		45 (1045): Low torque detected "U-TL'		1			Y	Y			
		52 (1052): Running forward "FRUN"					Y	Y			
		53 (1053): Running reverse "RRUN'		-			Y	Y			
		54 (1054): Under remote mode "RMT"		1			Y	Y			
		55 (1055): Run command entered "AX2"	T	-			Y	Y			

5.2 Function Codes Table

Code	Name	Data setting range	ommunication format	thange when running	Data copying	Factory Default	f Drive	A control	telated page
			ŏ	0			1/2	РР	Ľ.
		56 (1056): Motor overheat detected by thermistor "THM"					Y	Υ	
		59 (1059): Terminal [C1] (C1 function) wire break detected					Y	Y	
		68(1068): Motor regular switching early warning "MCHG"	+				v	v	
		69(1069): Pump control output limit signal "MLIM"	+				Y	Y	
		76 (1076): Speed deviation excess "PG-FRR"					N	Y	
		77 (1077): Low DC link bus voltage detection "U-EDC"					Y	Ŷ	
		79 (1079): During decelerating at momentary power failure "IPF2"	+				Y	Y	
		84 (1084): Maintenance timer counted up "MNT"					Y	Y	
		87 (1087): Frequency arrival and detected "FARFDT"					Y	Y	
		88 (1088): Auxiliary motor drive signal "AUX_L"	+				Y	Y	
		98 (1098): Light alarm "L-ALM"					Y	Y	
		99 (1099): Alarm output "ALM"					Y	Y	
		111 (1111): Customizable logic output signal 1 "CLO1"					Y	Y	
		112 (1112): Customizable logic output signal 2 "CLO2"					Y	Y	
		113 (1113): Customizable logic output signal 3 "CLO3"					Y	Y	
		114 (1114): Customizable logic output signal 4 "CLO4"					Y	Y	
		115 (1115): Customizable logic output signal 5 "CLO5"					Y	Y	
		116 (1116): Customizable logic output signal 6 "CLO6"					Y	Y	
		117 (1117): Customizable logic output signal 7 "CLO7"					Y	Y	
		118 (1118): Customizable logic output signal 8 "CLO8"					Y	Y	
		119 (1119): Customizable logic output signal 9 "CLO9"	 				Y	Y	
		120 (1120): Customizable logic output signal 10 "CLO10"					Y	Y	
		160 (1160): Motor 1 being driven by inverter "M1_I"					Y	Y	
		161 (1161): Motor 1 being driven by commercial power "M1_L"					Y	Y	
		162 (1162): Motor 2 being driven by inverter "M2_I"					Y	Y	
		163 (1163): Motor 2 being driven by commercial power "M2_L"					Y	Y	
		164 (1164): Motor 3 being driven by inverter "M3_I"					Y	Y	
		165 (1165): Motor 3 being driven by commercial power "M3_L"					Y	Y	
		167 (1167): Motor 4 being driven by inverter "M4_L"					Y	Y	
		180 (1180): In mutual operation "M-RUN"					Y	Y	
		181 (1181): Alarm in mutual operation "M-ALM"					Y	Y	
		211 (1211): Under external PID1 control "EPID1-CTL"					Y	Y	
		212 (1212): External PID1 output "EPID1-OUT"					Y	Y	
		213 (1213): Running under external PID1 "EPID1-RUN"					Y	Y	
		214 (1214): External PID1 alarm "EPV1-ALM"					Y	Y	
		215 (1215): External PID1 feedback error "EPV1-OFF"					Y	Y	
		 Inside the () is written the negative logic signal setting (OFF at short-circuit) 							
E30	Frequency arrival detection width (Detection width)	0.0 to 10.0 Hz	3	Y	Y	2.5	Y	Y	5-105
E31	Frequency detection 1 (Level)	0.0 to 120.0 Hz	3	Υ	Υ	50.0	Υ	Υ	5-107
E32	(Hysteresis width)	0.0 to 120.0 Hz	3	Υ	Υ	1.0	Υ	Υ	5-107
E34	Overload early warning/Current detection	0.00 (Disable)	24	Y	Y	*3	Y	Y	5-108
E35	(Timer)	0.01 to 600.00 s	5	Y	Y	10.00	Y	Y	5-108
E37	Current detection 2/	0.00 (Disable)	24	Ŷ	Y1	*3	Ŷ	Ý	5-108
	Low current detection (Level)	· · ·				-			
E38	(Timer)	0.01 to 600.00 s	5	Y	Y	10.00	Y	Y	5-108
E42	LED display filter	0.0 to 5.0 s	3	Y	Υ	0.5	Y	Y	5-109

*3: The motor rated current is automatically set. Refer to "5.2.4 Motor constant".

Code	Name	Data setting range	munication format	ange when unning	a copying	⁻ actory Default	Drive	control	ated page
			Com	Cha	Dat	± =	V/f	ΜЧ	Rel
E43	LED monitor (Item selection)	 0: Speed monitor (Selectable with E48) 3: Output current 4: Output voltage 8: Calculated torque 9: Input power 10: PID process command 12: PID feedback value 14: PID output 15: Load factor 16: Motor output 17: Analog signal input monitor 25: Input watt-hour 60: External PID1 process command (final) (physical value) 61: External PID1 feedback value (physical value) 62: External PID1 manual command (%) 	1	Y	Y	0	Y	Y	5-109
E44	(Display when stopped)	0: Specified value 1: Output value	1	Y	Y	0	Y	Y	5-110
E48	LED monitor (Speed monitor item)	0: Output frequency 1 (PM: Speed command value) 1: Output frequency 2 (PM: Speed estimated value) 2: Reference frequency 3: Motor rotation speed 4: Load rotation speed 7: Speed (%)	1	Y	Y	0	Y	Y	5-110
E50	Display coefficient for speed monitor	0.01 to 200.00	5	Y	Y	30.00	Y	Y	5-110
E51	Display coefficient for "Input watt-hour data"	0.000 (Cancel/Reset). 0.001 to 9999	45	Y	Y	0.010	Y	Y	5-110
E52	Keypad (Menu display mode)	 Function code data setting mode (Menu 0, Menu1, and Menu 7) Function code data check mode (Menu 2 and Menu 7) Full-menu mode 	1	Y	Y	0	Y	Y	5-111
E59	Terminal [C1] function selection	0: Current input (C1 function) 1: Voltage input (V2 function)	1	Ν	Y	0	Y	Y	5-112
E61	Terminal [12] extended function	0: None 1: Auxiliary frequency setting 1	1	Ν	Y	0	Y	Y	5-113
E62	Terminal [C1] (C1 extended function)	Auxiliary frequency setting 2 PID process command FUD freedback value	1	Ν	Y	0	Y	Y	
E63	Terminal [C1] (V2 extended function)	 a) Analog signal input monitor 40: External PID process command 41: External PID feedback value 42: External PID manual command 	1	N	Y	0	Y	Y	
E64	Saving of digital reference frequency	0: Auto saving (main power is turned off) 1: Save by turning 鼸 key ON	1	Y	Y	0	Y	Y	5-113
E65	Reference loss detection	0: Stop deceleration 20 to 120%, 999: Cancel	1	Y	Y	999	Y	Y	5-114
E76	DC link bus low-voltage detection level	400 to 800 V (400 V class)	1	Y	Y	470	Y	Y	5-114
E80	Low torque detection (Level)	0 to 300%	1	Υ	Y	20	Y	Υ	5-115
E81	(Timer)	0.01 to 600.00 s	5	Y	Y	20.00	Y	Y	E 44E
E90	Terminal [REV] function	1 (1000). Select multistep frequency (0 to 1 steps) 331	1	N	Y	90	Y	Y	5-115
		2 (1002): Select multistep frequency (0 to 7 steps) "SS4"					Y	Y	
		3 (1003): Select multistep frequency (0 to 15 steps) "SS8"					Y	Y	
		4 (1004): Select ACC/DEC time (2 steps) "RT1"					Y	Y	
		5 (1005): Select ACC/DEC time (4 steps) "RT2"					Y	Y	
		6 (1006): Select 3-wire operation "HLD"					Y	Y	
		8 (1008): Reset alarm (Abnormal) "RST"					Y	Y	
		9 (1009): External alarm "THR" (9 = Active OFF/1009 = Active ON)					Y	Y	
		11 (1011): Select frequency setting 2/ frequency setting 1 "Hz2/ Hz1"					Y	Y	
		13: DC braking command "DCBRK"					Y	N	
		14 (1014): Select torque limit 2/ torque limit 1 "TL2/ TL1"					Υ	Y	
		15: Switch to commercial power (50 Hz) "SW50"					Y	Ν	
		16: Switch to commercial power (60 Hz) "SW60"					Y	N	
		۲۲ (۱۵۱7): OP command "UP" 18 (1018): DOWN command "DOWN"					Y Y	Y Y	

Chap 5 FUNCTION CODES

indicates quick setup target function code.

Code	Name	Data setting range	munication	ange when unning	a copying	⁻ actory Default	Drive	control	ated page
			Com	- Ch	Dai		٧/f	РМ	Rel
		19 (1019): Allow function code editing (Data change enabled) "WE-KP	,				Y	Y	
		20 (1020): Cancel PID control "Hz/PID	,	-			Y	Y	
		21 (1021): Switch normal/ inverse operation "IVS	,	-			Υ	Y	
		22 (1022): Interlock "IL	,				Y	Y	
		24 (1024): Select link operation (RS-485, BUS option) "LE	,				Y	Y	
		25 (1025): Universal DI "U-DI	,	-			Υ	Y	
		26 (1026): Select auto search for idling motor speed at starting"ST	/				Y	Y	
		30 (1030): Force to stop "STOP (30 = Active OFF/1030 = Active ON)	,				Y	Y	
		33 (1033): Reset PID integral and differential terms "PID-RST	"	-			Y	Y	
		34 (1034): Hold PID integral term "PID-HLD	"	†			Y	Y	
		35 (1035): Select local (Keypad) command "LOC	"	+			Y	Y	
		38 (1035): Run enable "RE					Y	Y	
		39: Dew condensation prevention "DWP					Y	Y	
		40: Enable integrated sequence to switch to commercial power (50Hz) "ISW50	'				Y	Y	
		41: Enable integrated sequence to switch to commercial power (60Hz) "ISW60	'				Y	Y	
		49 (1049): Pulse train sign "SIGN	"				Y	Y	
		50 (1050): Clear running motor regular switching time "MCLR	,				Y	Y	
		72 (1072): Count the run time of commercial power-driven motor 1 *5 "CRUN-M1	"				Y	N	
		78 (1078): Select speed control parameter 1 *5 "MPRM1	"				Ν	Y	
		80 (1080): Cancel customizable logic "CLC	"				Y	Y	
		81 (1081): Clear all customizable logic timers "CLTC	"				Y	Y	
		82 (1082): Cancel anti-regenerative control "AR-CCL	"				Y	Y	
		87 (1087): Run command 2/ 1 "FR2/FR1"					Y	Y	
		88 (1088): Run forward / stop 2 "FWD2	,				Y	Y	
		89 (1089): Run reverse / stop 2 "REV2	,				Y	Y	
		98: Run forward / stop command "FWD	"				Y	Y	
		99: Run reverse / stop command "REV	"				Υ	Y	
		100: No function assigned "NONE	"				Y	Y	
		149 (1149): Switch pump control "PCHG	,				Y	Y	
		150 (1150): Enable master motor drive in mutual operation "MEN0	,				Υ	Y	
		151 (1151): Enable pump control motor 1 to be driven "MEN1	,				Υ	Y	
		152 (1152): Enable pump control motor 2 to be driven "MEN2	,				Y	Y	
		153 (1153): Enable pump control motor 3 to be driven "MEN3	,				Y	Y	
		154 (1154): Enable pump control motor 4 to be driven "MEN4	,				Υ	Y	
		171 (1171): PID control multistage command 1 "PID-SS1	"				Υ	Y	
		172 (1172): PID control multistage command 2 "PID-SS2	,,				Y	Y	
		181 (1181): External PID1 multistage command 1 "EPID-SS1					Y	Y	
		182 (1182): External PID1 multistage command 2 "EPID-SS2	1	-			Y	Y	
		201 (1201): External PID1 ON command "EPID1-ON	'	1			Y	Y	
		202 (1202): External PID1 Cancel "%EPID1	'				Y	Y	
		203 (1203): External PID1 Switch normal/inverse operation "EPID	+	1		<u> </u>	Y	Y	
		204 (1204): External PID1 reset integral and differential components "EPID1-RST	, 	-			Y	Y	
		205 (1205): External PID1 hold integral component "EPID1-HLD		+		<u> </u>	Y	Y	
		* Inside the () is the negative logic signal. (OFF at short-circuit)	+	+		†			

*5: Available at ROM version 0300 or later.

■ C code: Control Functions of Frequency (Control function)

Code	Name	Data setting range	Communication format	Change when running	Data copying	Factory Default	V/f Drive	PM control	Related page
C01	lump frequency 1	0.0 to 120.0 Hz	3	v	v	0.0	V	V	5-116
C02	2		Ŭ		·	0.0		•	0 110
C03	3								
C04	(Skin width)	0.0 to 30.0Hz	3	Y	Y	3.0	Y	Y	
C05	Multisten frequency 1	0.00 to 120 00Hz	22	·	v	0.00	v	v	5-117
C06	2				·	0.00		•	0 1 11
C07	3								
001	0								
008	4								
C09	5								
C10	6								
C11	/								
C12	8								
013	9								
C14	10								
C15	11								
C16	12								
C17	13								
C18	14								
C19	15								
C21	Pattern operation (Mode selection)	 1 cycle operation Repetition operation Constant speed operation after 1 cycle operation 	1	N	Y	0	Y	Y	5-118
C22	(Stage 1)	Special setting: Press 🕮 key three times.	84	Y	Y	1st:	Y	Y	
C23	(Stage 2)	1st: Set run time 0.0 to 3600 s and press (and key.				0.00			
C24	(Stage 3)	2nd: Set rotational direction F (forward) or r (reverse) and press				2nd: F 3rd: 1			
C25	(Stage 4)	tind tey.				orar r			
C26	(Stage 5)	3rd: Set acceleration/deceleration time 1 to 4 and press (HING) key.							
C27	(Stage 6)								
C28	(Stage 7)								
C30	Frequency setting 2	 Keypad ⊗√⊗ key operation Analog voltage input (Terminal [12]) (from 0 to ±10 VDC) Analog current input (Terminal [C1] (C1 function)) (4 to 20 mA DC, 0 to 20 mA DC) Analog voltage input (Terminal [12]) + Analog current input (Terminal [C1] (C1 function)) Analog voltage input (Terminal [C1] (V2 function)) (0 to 10 VDC) UP DOWN control Keypad key operation (⊘/⊗ key) (With balanceless bumpless) Pattern operation Pulse train input 	1	N	Y	2	Y	Y	5-120
C31	Analog input adjustment	-5.0 to 5.0%	4	Y*	Υ	0.0	Y	Y	5-121
C22	(Terminar [12]) (Offset)	0.00 to 200.00%	5		v	100.0	v	V	
032	(Gain)	0.00 to 200.00%	5	Y.	Y	100.0	Y	Y	
033		0.00 to 5.00 S	5	I V*	T V	0.05	T	T V	
C34	(Gain base point)	0.00 to 100.00%	3	T NI	T V	100.0	T V	T V	
035			1	IN V*	I V	0.0	T V	ı V	
U30	(Terminal [C1] (C1 function)) (Offset)	-3.0 10 3.0%	4	T.	ľ	0.0	T	T	
C37	(Gain)	0.00 to 200.00%	5	Y*	Υ	100.0	Υ	Y	
C38	(Filter)	0.00 to 5.00 s	5	Υ	Υ	0.05	Υ	Y	
C39	(Gain base point)	0.00 to 100.00%	5	Y*	Υ	100.0	Υ	Υ	
C40	Terminal [C1] (C1 function) range / polarity selection	0: 4 to 20 mA Unipolar 1: 0 to 20 mA Unipolar 10: 4 to 20 mA Bipolar 11: 0 to 20 mA Bipolar	1	N	Y	0	Y	Y	

Code	Name	Data setting range	ommunication format	thange when running	Jata copying	Factory Default	f Drive	A control	telated page
			ŏ	0			٨N	РР	Ľ.
C41	Analog input adjustment (Terminal [C1] (V2 function)) (Offset)	-5.0 to 5.0%	4	Y*	Y	0.0	Y	Y	5-121
C42	(Gain)	0.00 to 200.00%	5	Y*	Υ	100.0	Υ	Υ	
C43	(Filter)	0.00 to 5.00 s	5	Υ	Υ	0.05	Υ	Υ	
C44	(Gain base point)	0.00 to 100.00%	5	Y*	Υ	100.0	Υ	Υ	
C45	(Polarity selection)	0: Bipolar 1: Unipolar	1	Ν	Y	1	Y	Y	
C50	Bias (for frequency setting 1) (Bias base point)	0.00 to 100.00%	5	Y*	Y	0.00	Y	Y	5-123
C53	Selection of normal/inverse operation(Frequency setting 1)	0: Normal 1: Inverse	1	Y	Y	0	Y	Y	5-123
C55	Analog input adjustment (Terminal 12) (Bias)	-100.00 to 100.00%	6	Y*	Y	0.00	Y	Y	5-121
C56	(Bias base point)	0.00 to 100.00 %	5	Y*	Υ	0.00	Υ	Υ	
C58	(Display unit)	* Same as J105 (However, setting range is, 1 to 80)	1	Υ	Υ	2	Υ	Υ	5-124
C59	(Maximum scale)	-999 to 0.00 to 9990	12	Ν	Υ	100	Υ	Υ	5-124
C60	(Minimum scale)	-999 to 0.00 to 9990	12	Ν	Υ	0.00	Υ	Υ	
C61	Analog input adjustment (Terminal[C1](C1 function)) (Bias)	-100.00 to 100.00 %	6	Y*	Y	0.00	Y	Y	5-121
C62	(Bias base point)	0.00 to 100.00 %	5	Y*	Υ	0.00	Υ	Υ	
C64	(Display unit)	* Same as J105 (However, setting range is, 1 to 80)	1	Υ	Υ	2	Υ	Υ	5-124
C65	(Maximum scale)	-999 to 0.00 to 9990	12	Ν	Υ	100	Υ	Υ	5-124
C66	(Minimum scale)	-999 to 0.00 to 9990	12	Ν	Υ	0.00	Υ	Υ	
C67	Analog input adjustment (Terminal [C1] (V2 function)) (Bias)	-100.00 to 100.00 %	6	Y*	Y	0.00	Y	Y	5-121
C68	(Bias base point)	0.00 to 100.00 %	5	Y*	Υ	0.00	Υ	Υ	
C70	(Display unit)	* Same as J105 (However, setting range is,1 to 80)	1	Y	Υ	2	Υ	Υ	5-124
C71	(Maximum scale)	-999 to 0.00 to 9990	12	Ν	Υ	100	Υ	Υ	5-124
C72	(Minimum scale)	-999 to 0.00 to 9990	12	Ν	Y	0.00	Υ	Υ	

P codes: Motor 1 Parameters (Motor 1 parameter)

Code	Name	Data setting range	ommunication format	thange when running	Jata copying	Factory Default	Drive	1 control	telated page
			ŏ	Ö			٨	Δd	Ľ.
P01	Motor 1 (No. of poles)	2 to 22 poles	1	Ν	Y1	4	Υ	Υ	5-125
P02	(Rated capacity)	0.01 to 1000 kW (At P99 = 0, 4, 21, or 22) 0.01 to 1000 HP (At P99 = 1)	11	Ν	Y1	*6	Y	Y	5-125
P03	(Rated current)	0.00 to 2000A	24	Ν	Y1	*6	Υ	Y	5-125
P04	(Auto-tuning)	0: Disable 1: Stop tuning 2: Rotation tuning	21	N	N	0	Y	Y	5-126
P06	(No-load current)	0.00 to 2000A	24	Ν	Y1	*6	Υ	Ν	5-127
P07	(%R1)	0.00 to 50.00%	5	Υ	Y1	*6	Υ	Ν	
P08	(%X)	0.00 to 50.00%	5	Υ	Y1	*6	Υ	Ν	
P30	(PMSM drive magnetic pole position detection mode)	 Pull-in by current For IPMSM (Interior permanent magnet synchronous motor) For SPMSM (Surface permanent magnet synchronous motor) Pull-in by current for IPMSM (Interior permanent magnet synchronous motor) 	1	N	Y1	1	N	Y	5-128
P60	(PMSM armature resistance)	0.000 to 50.000 ohm	45	Ν	Y1	*7	Ν	Υ	5-128
P61	(PMSM d-axis inductance)	0.00 to 500.00 mH	24	Ν	Y1	*7	Ν	Υ	
P62	(PMSM q-axis inductance)	0.00 to 500.00 mH	24	Ν	Y1	*7	Ν	Υ	
P63	(PMSM induced voltage)	160 to 500V (400Vclass)	1	Ν	Y1	*7	Ν	Υ	
P64	(PMSM iron loss)	0.0 to 20.0 %	3	Υ	Y1	*7	Ν	Υ	
P65	(PMSM d-axis inductance magnetic saturation correction)	0.0 to 100.0 % ; 999	3	Y	Y1	*7	Ν	Y	5-128
P74	(PMSM reference current at starting)	10 to 200 % (100%= motor rated current)	1	Y*	Y1	*7	N	Y	5-128
P83	(Reserved for PMSM) *9	0.0 to 50.0; 999	3	Υ	Y1	999	Ν	-	5-129
P84	(Reserved for PMSM) *9	0.0 to 100.0; 999	3	Ν	Y1	999	Ν	-	
P85	(PMSM flux limitation value)	50.0 to 150.0; 999	3	Υ	Y1	999	Ν	Υ	5-128
P86	(Reserved for PMSM)	0.0 to 100.0%	3	Ν	Ν	0.0	Ν	١	5-129
P87	(PMSM reference current for polarity discrimination)	0 to 200 %	1	Ν	Y1	60	Ν	Y	-
P88	(Reserved for PMSM) *9	0 to 100 %; 999	1	Ν	Y1	999	Ν	١	5-129
P89	(Reserved for PMSM) *9	0; 1 to 100	1	Ν	Y1	0	Ζ	١	
P90	(PMSM overcurrent protection level)	0.00(disable); 0.01 to 2000 A	24	Ν	Y1	*7	z	Y	5-129
P99	Motor 1 selection	 Motor characteristics 0 (Fuji standard IM, 8-series) Motor characteristics 1 (HP rating IMs) Other IMs Other motors(PMSMs) Motor characteristics (Fuji PMSM GNB2 series) 	1	N	Y1	0	Y	Y	5-129

indicates quick setup target function code.
*6: Factory defaults are depended on motor capacity. Refer to "5.2.4 Motor constant".
*7: Factory defaults are the parameters for Fuji standard PMSM and depended on motor capacity.
*9: Factory use. Do not access these function codes.

■ H codes: High Performance Functions (High level function)

-						-			
Code	Name	Data setting range	nunication ormat	nge when Inning	t copying	actory befault	Drive	control	ited page
			Comr	Char ru	Data	Ш	V/f	РМ	Rela
H02	Data initialization (Method)	0: Standard 1: User	1	Ν	Y	0	Y	Y	5-130
H03	(Target)	 Manual setting value Initial value (factory default value) Initialize motor 1 parameters Initialize the parameters(excluding parameters related to communication) Initialize the parameters related to customizable logic 	1	N	N	0	Y	Y	
H04	Auto-reset (Times)	0: Disable 1 to 20: Number of retries	1	Y	Y	0	Y	Y	5-132
H05	(Interval)	0.5 to 20.0 s	3	Y	Y	5.0	Υ	Υ	
H06	Cooling fan ON/OFF control	0: Disable (Always Fan ON) 1: Enable (ON/OFF control effective)	1	Y	Y	0	Y	Y	5-133
H07	Curve acceleration/ deceleration	0: Disable (Linear acceleration/deceleration) 1: S-curve acceleration/deceleration (Weak) 2: S-curve acceleration/deceleration (Strong) 3: Curve acceleration/deceleration	1	Y	Y	0	Y	Y	5-133
H08	Rotational direction limitation	0: Disable 1: Enable (Reverse rotation inhibited) 2: Enable (Forward rotation inhibited)	1	N	Y	0	Y	Y	5-133
H09	Starting mode (Auto search)	0: Disable 1: Enable (Only at restart after momentary power failure) 2: Enable (At normal start and at restart after momentary power failure)	1	N	Y	0	Y	N	5-134
H11	Deceleration mode	0: Normal deceleration 1: Coast to a stop	1	Y	Y	0	Y	Y	5-136
H12	Instantaneous overcurrent limiting (Mode selection)	0: Disable 1: Enable	1	Y	Y	1	Υ	Ν	5-136
H13	Restart mode after momentary power failure (Restart timer)	0.1 to 20.0 s	3	Y	Y1	*2	Y	Ν	5-136
H14	(Frequency fall rate)	0.00: Selected deceleration time 0.01 to 100.00Hz/s 999: According to current limiter)	5	Y	Y	999	Y	Ν	
H15	(Continuous running level)	400 to 600V	1	Υ	Υ	470	Υ	Υ	
H16	(Allowable momentary power failure time)	0.0 to 30.0s, 999 (Depend on inverter judgment)	3	Y	Y	999	Y	Y	
H26	Thermistor (for motor) (Mode selection)	0: Disable 1: PTC: 개낙 trip and stop the inverter 2: PTC: Output motor overheat detected "THM" and continue to run	1	Y	Y	0	Y	Y	5-136
H27	(Level)	0.00 to 5.00 V	5	Υ	Υ	1.60	Υ	Υ	
H30	Communication link function (Mode selection)	Frequency command Run command 0: F01/C30 F02 1: RS-485 (Port 1) F02 2: F01/C30 RS-485 (Port 1) 3: RS-485 (Port 1) RS-485 (Port 1) 4: RS-485 (Port 2) F02 5: RS-485 (Port 2) RS-485 (Port 1) 6: F01/C30 RS-485 (Port 2) 7: RS-485 (Port 1) RS-485 (Port 2) 8: RS-485 (Port 2) RS-485 (Port 2)	1	Y	Y	0	Y	Y	5-138
H42	Capacitance of DC link bus capacitor	For adjustment at replacement (0000 to FFFF (in hexadecimal))	1	Y	N	-	Y	Y	5-140
H43	Cumulative run time of cooling fan	For adjustment at replacement Displays the cumulative run time of cooling fan in units of ten hours.	74	Y	N	-	Y	Y	
H44	Startup count for motor 1	For adjustment at replacement (0000 to FFFF in hexadecimal)	1	Y	Ν	-	Y	Y	5-144
H45	Mock alarm	0: Disable 1: Occurrence of mock Alarm	1	Y	N	0	Y	Y	5-144
H46	Starting mode (Auto search delay time 2)	0.1 to 20.0 s	3	Y	Y1	*6	Y	Y	5-144

*2: Factory defaults are depended on motor capacity. Refer to "5.2.3 Factory default value per applicable electric motor capacitance".*6: Factory defaults are depended on motor capacity. Refer to "5.2.4 Motor constant".

Code	Name	Data setting range	munication ormat	nge when unning	a copying	actory Default	Drive	control	ated page
			Com	Cha	Dati		٧/f	РМ	Rela
H47	Initial capacitance of DC link bus capacitor	For adjustment at replacement (0000 to FFFF in hexadecimal)	1	Y	Ν	-	Y	Y	5-144
H48	Cumulative run time of capacitors on printed circuit boards	For adjustment at replacement Change in cumulative motor run time (Reset is enabled) (in units of ten hours)	74	Y	N	-	Y	Y	5-140 5-144
H49	Starting mode (Auto search delay time 1)	0.0 to 10.0 s	3	Y	Y	0.0	Y	Y	5-145
H50	Non-linear V/f 1 (Frequency)	0.0: Cancel 0.1 to 120.0 Hz	3	Ν	Y	0.0	Y	Ν	5-145
H51	(Voltage)	0 to 500V:AVR operation (400V class)	1	Ν	Υ	0	Υ	Ν	
H52	Non-linear V/f 2 (Frequency)	0.0: Cancel 0.1 to 120.0 Hz	3	Ν	Y	0.0	Y	Ν	
H53	(Voltage)	0 to 500V:AVR operation (400V class)	1	Ν	Y	0	Y	Ν	
H56	Deceleration time for forced stop	0.00 to 3600 s	12	Y	Y	20.0	Y	Y	5-145
H63	Low limiter (Mode selection)	 Limit by F16 (Frequency limiter: Low) and continue to run If the output frequency lowers below the one limited by F16 (Frequency limiter: Low), decelerate to stop the motor. 	1	Y	Y	0	Y	Y	5-145
H64	(Lower limiting frequency)	0.0: Depends on F16 (Frequency limiter, Low) 0.1 to 60.0 Hz	13	Y	Y	1.6	Y	Y	5-145
H69	Anti-regenerative control (Mode selection)	 Disable Torque limit control with force-to-stop (Cancel limit control after three times of deceleration time has passed) DC link bus voltage control with force-to-stop (Cancel voltage control after three times of deceleration time has passed) Torque limit control without force-to-stop DC link bus voltage control without force-to-stop 	1	Y	Y	0	Y	Y	5-146
H70	Overload prevention control	0.00: Follow the deceleration time selected 0.01 to 100.00 Hz/s, 999 (Cancel)	5	Y	Y	999	Y	Y	5-147
H71	Deceleration characteristics	0: Disable 1: Enable	1	Y	Y	0	Y	Ν	5-147
H72	Main power shutdown detection (Mode selection)	0: Disable 1: Enable (Available FRN0045F2E-4G or above)	1	Y	Y	1	Y	Y	5-147
H76	Torque limiter (Braking) (Frequency rising limiter for braking)	0.0 to 120.0 Hz	3	Y	Y	5.0	Y	Ν	5-148
H77	Service life of DC link bus capacitor	0 to 8760 (in units of ten hours)	74	Y	N	6132 (ND spec)	Y	Y	5-148
H78	Maintenance interval (M1)	0 (Disable): 1 to 9999 (in units of ten hours)	74	Y	N	6132 (ND spec)	Y	Y	5-148
H79	Preset startup count for maintenance (M1)	0000 (Disable): 0001 to FFFF (in hexadecimal)	1	Y	Ν	0	Y	Y	5-149
H80	Output current fluctuation damping gain for motor 1	0.00 to 1.00	5	Y	Y	0.20	Y	Z	5-149
H81	Light alarm selection 1	0000 to FFFF (in hexadecimal)	1	Υ	Υ	0	Υ	Υ	5-150
H82	Light alarm selection 2	0000 to FFFF (in hexadecimal)	1	Υ	Υ	0	Y	Υ	
H86	Reserved *9	0 to 2	1	Υ	Υ	0	-	-	5-152
H89	Electronic Thermal Overload Protection for Motor 1 (data store)	0: Inactive 1: Active	1	Y	Y	1	-	-	5-152
H90	Reserved *9	0 to 1	1	Υ	Υ	0	_	-	5-152
H91	PID feedback wire break detection	0.0 (Alarm disable): 0.1 to 60.0 s	3	Y	Y	0.0	Y	Y	5-152

5.2 Function Codes Table

*9: Factory use. Do not access these function codes.

			1	-					
Code	Name	Data setting range	nunication ormat	nge when unning	a copying	actory Default	Drive	control	ated page
			Comr	Chai	Data	1	١//	ΜЧ	Rela
H92	Continuous running at the momentary power failure (P)	0.000 to 10.000 times; 999 999:Manufacturer adjustment value	7	Y	Y1	999	Y	Y	5-152
H93	(1)	0.010 to 10.000 s; 999 999:Manufacturer adjustment value	7	Y	Y1	999	Y	Y	
H94	Cumulative motor run time 1	0 to 9999 Change in cumulative motor run time (Reset is enabled) (in units of 10 hours)	74	N	N	-	Y	Y	5-148 5-153
H95	DC braking (Braking response mode)	0: Slow response 1: Quick response	1	Y	Y	1	Y	Ν	5-63 5-153
H96	STOP key priority/ Start check function	 STOP key priority disable/ Start check function disable STOP key priority enable/ Start check function disable STOP key priority disable/ Start check function enable STOP key priority enable/ Start check function enable 	1	Y	Y	0	Y	Y	5-153
H97	Clear alarm data	0: Disable 1: Alarm data clear (Automatically return to 0 after clearing data)	1	Y	Ν	0	Y	Y	5-153
H98	Protection/Maintenance function (Mode selection)	0 to 127 (Data is displayed in decimal) Bit 0: Lower the carrier frequency automatically (0: Disable; 1: Enable) Bit 1: Input phase loss protection (0: Disable; 1: Enable) Bit 2: Output phase loss protection (0: Disable; 1: Enable) Bit 3: Main circuit capacitor life judgment selection (0: Factory default referenced; 1 User measurement value standard) Bit 4: Judge the life of main circuit capacitor (0: Disable; 1: Enable) Bit 5: Detect DC fan lock (0: Enable; 1: Disable) Bit 6: Braking transistor error detection (0: Disable; 1: Enable)	1	Y	Y	*11	Y	Y	5-154
H99	Password 2 setting/check	0000 to FFFF (Hexadecimal)	1	Υ	Ν	0	Υ	Υ	5-156
H114	Anti-regenerative control (Level)	0.0 to 50.0%, 999: disabled	3	Y	Y	999	Y	Y	5-159
H116	Fire Mode (Mode selection)	0: FMS: ON 1: FMS toggle method 2: FMS latch method		N	Y	0			
H117	(Confirmation time)	0.5 to 10.0 s * Set ON/OFF setting time for FMS signals.		Y	Y	3.0			
H118	(Reference frequency)	Inherit: Follow the ordinary reference frequency specified with F01, etc. 0.1 to 120.0 Hz		Y	Y	Inherit			
H119	(Rotation direction)	 Follow the run command specified with F02, etc. Forward rotation Reverse rotation 		N	Y	0			
H120	(Start method)	 Follows the start methods specified with instant power failure restart Auto search 		Y	Y	0			
H121	(Reset interval)	0.5 to 20.0 s		Υ	Υ	5.0			
H193	User initial value (Save)	0: Disable 1: Save	1	Y	N	0	Y	Y	5-131
H194	(Protection)	0: Save enable 1: Protected (Save disable)	1	Y	Y	0	Y	Y	
H195	DC braking (Braking timer at the startup)	0.00: Disable 0.01 to 30.00 s	5	Y	Y	0.00	Y	Ν	5-63 5-159
H197	User password 1 (Selection of protective operation)	 All function codes are disclosed, but the change is not allowed. Only the function code for quick setup can be disclosed/changed. Only the function code for customize logic setting is not disclosed/not changed. 	1	Y	Y	0	Y	Y	5-156
H198	(Setting/check)	0000 to FFFF (Hexadecimal)	1	Υ	Ν	0000	Υ	Υ	
H199	User password protection valid	0: Disable 1: Protected	1	Y	Ν	0	Y	Y	

*11:FRN0060F2E-4G or below: 83, FRN0075F2E-4G or above: 19.

■ A codes: Motor 2 Parameters (Motor 2 parameters)

Code	Name	Name Data setting range	mmunication format	ange when running	ata copying	Factory Default	Drive	control	elated page
			Col	ά	Õ		٧/f	ΡМ	Re
A43	Speed control 2	0.000 to 5.000 s	7	Y	Υ	0.200	Ν	Υ	5-228
	(Speed command filter)								
A44	(Speed detection filter)	0.000 to 0.100 s	7	Y*	Υ	0.025	Ν	Υ	
A45	P (Gain)	0.1 to 200.0 times	3	Y*	Υ	2.0	Ν	Υ	
A46	I (Integral time)	0.001 to 9.999 s 999: Cancel integral term	7	Y	Y	0.600	Ν	Y	

J codes: Application Functions 1 (Application function 1)

Code	Name	Data setting range	imunication format	ange when running	ta copying	Factory Default	Drive	control	ated page
			Com	Cha	Dat		V/f	МЧ	Rel
J01	PID control (Mode selection)	0: Disable 1: Process (normal operation) 2: Process (inverse operation)	1	Ν	Y	0	Y	Y	5-161
J02	(Remote command)	0: Keypad key operation (⊘/⊗key) 1: PID process command 1 (Analog input: Terminals 12, C1 and V2) 3: UP/DOWN 4: Communication	1	Ν	Y	0	Y	Y	5-162
J03	P (Gain)	0.000 to 30.000 times	7	Υ	Υ	0.100	Υ	Υ	5-167
J04	I (Integral time)	0.0 to 3600.0 s	3	Υ	Υ	0.0	Υ	Υ	
J05	D (Differential time)	0.00 to 600.00 s	5	Υ	Υ	0.00	Υ	Υ	
J06	(Feedback filter)	0.0 to 900.0 s *1	3	Υ	Y	0.5	Υ	Υ	
J10	(Anti-reset windup)	0 to 200%	1	Υ	Υ	200	Υ	Υ	5-170
J11	(Select Warning output)	 Warning caused by process command value Warning caused by process command value with hold Warning caused by process command value with latch Warning caused by process command value with hold and latch Warning caused by PID error value Warning caused by PID error value with hold 	1	Y	Y	0	Y	Y	5-171
J12	(Upper limit of warning (AH))	0% to 100%	1	Υ	Υ	100	Υ	Y	
J13	(Lower limit of warning (AL))	0% to 100%	1	Υ	Υ	0	Υ	Υ	
J15	(Sleep frequency)	0.0: Disable 1.0 to 120.0 Hz	3	Y	Y	0.0	Y	Y	5-173
J16	(Sleep timer)	0 to 60 s	1	Υ	Υ	30	Υ	Υ	
J17	(Wakeup frequency)	0.0 to 120.0 Hz	3	Υ	Υ	0.0	Υ	Υ	
J18	(Upper limit of PID process output)	0% to 150% ; 999 (Depends on setting of F15)	1	Y	Υ	999	Y	Y	5-174
J19	(Lower limit of PID process output)	0% to 150% ; 999 (Depends on setting of F16)	1	Y	Y	999	Y	Y	
J21	Dew Condensation Prevention (Duty)	1~50 %	1	Ν	Υ	0	Y	N	5-175
J22	Commercial Power Switching Sequence	 Keep inverter operation (Stop due to alarm) Automatically switch to commercial-power operation 	1	Y	Y	0.0	Y	Y	-
J23	(Wakeup level of PID error)	0.0 to 100.0%	3	Υ	Υ	0.0	Υ	Y	5-173
J24	(Wakeup timer)	0 to 3600 s	1	Υ	Y	0	Υ	Υ	

Code	Name	Name Data setting range	munication format	ange when unning	a copying	⁻ actory Default	Drive	control	ated page
			Com	Cha	Dat	-	J//	ΡM	Rel
J105	PID control (Display unit)	0 to 80 0: Inherit (PID Control 1 feedback unit) 1: none 2: % 4: r/min 7: kW [Flow] 20: m3/s 21: m3/min 22: m3/h 23: L/s 24: L/min 25: L/h [Pressure] 40: Pa 41: kPa 42: MPa 43: mbar 44: bar 45: mHg 46: psi PSI (Pounds per square inch absolute) 47: mWG 48: inWG [Temperature] 60: K 61: degreeC 62: degreeF [Concentration]		Ζ	Y	0	Y	Y	5-175
1106	(Maximum scale)	80: ppm		N	V	100	v	v	
J107	(Minimum scale)	-999 to 0.00 to 9990		N	Y	0.00	Y	Y	
J136	PID multistep command (Multistep command 1)	-999 to 0.00 to 9990		Y	Y	0.00	Y	Ŷ	5-175
J137	(Multistep command 2)	-999 to 0.00 to 9990		Y	Υ	0.00	Υ	Υ	
J138	(Multistep command 3)	-999 to 0.00 to 9990		Υ	Υ	0.00	Υ	Υ	

5.2 Function Codes Table

-					_		_		
Code	Name	Data setting range	nunication	nge when unning	a copying	actory Default	Drive	control	ated page
			Comr	Chai	Data	шц	٧/f	М	Rela
J401	Pump Control Mode Selection	 Disable Enable (Inverter drive motor fixed system, judged by MV) Enable (Inverter drive motor floating system, judged by MV) Enable (Inverter drive motor floating + commercial power-driven motor system, judged by MV) Enable (Inverter drive motor fixed system, judged by output frequency) *7 Enable (Inverter drive motor floating system, judged by output frequency) *7 Enable (Inverter drive floating + commercial power-driven motor system, judged by output frequency) *7 Enable (Inverter drive floating + commercial power-driven motor system, judged by output frequency) *7 Enable (Communications-linked inverter drive motor floating system) Enable (Communications-linked all motors simultaneous PID control system) 	1	N	Y	0	Y	Y	5-194
J402	Communication Master/Slave Selection	0: Communication master inverter 1: Communication slave inverter	1	N	Y	1	Y	Y	5-196
J403	Number of Slaves	1 to 3 units * Set for a master only.	1	N	Y	1	Y	Y	5-196
J404	Master Input Permeation Selection	0000H to 007FH (hexadecimal) Bit 0: FWD Bit 1: REV Bit 2: X1 Bit 3: X2 Bit 4: X3 Bit 5: X4 Bit 6: X5 * The inverter sends the master terminal input info to the slave. * The slave stores the received data to S06 after masking.	1	N	Y	0000H	Y	Y	5-196
J411	Motor 1 Mode Selection	0: Disable (off at all times)	1	Υ	Y	0	Υ	Υ	5-197
J412	Motor 2 Mode Selection	2: Forced drive ON (forced commercial power drive)	1	Y	Y	0	Y	Y	
J413	Motor 3 Mode Selection		1	Y	Y	0	Y	Y	
J414	Motor 4 Mode Selection		1	Y	Y	0	Y	Y	
J425	Motor Switching Procedure	 Fixing procedure Equal operating time (Cumulative run time of each motor is equalized.) Fixing procedure (Switching the motor at slow flowrate stop) Equal operating time (Switching the motor at slow flowrate stop) 	1	N	Y	0	Y	Y	5-198
J430	Stop of Commercial Power-driven Motors	 0: Stop commercial power-driven motors 1: Stop commercial power-driven motors only when an inverter alarm occurs 2: Continue to run 	1	Y	Y	0	Y	Y	5-199
J435	Motor Regular Switching Mode Selection	 Inverter-driven pumps are subject to switching. Commercial power-driven pumps are subject to switching. All pumps (inverter-driven pumps/commercial power-driven pumps) are subject to switching. 	1	Y	Y	1	Y	Y	5-201
J436	Motor Regular Switching Time	0.0: Disable 0.1 to 720.0 h: Enable: (Switching time) 999: Enable (Switching time fixed at three minutes)	3	Y	Y	0.0	Y	Y	
J437	Motor Regular Switching Signal Output Time	0.00 to 600.00 s	5	Y	Y	0.10	Y	Y	
J450	Motor Increase Judgment (Judgment frequency)	0 to 120 Hz 999: Depends on J18	1	Y	Y	999	Y	Y	5-204
J451	(Duration time)	0.00 to 3600.00 s	12	Υ	Y	0.00	Υ	Υ	
J452	Motor Decrease Judgment (Judgment frequency)	0 to 120 Hz 999: Depends on J19	1	Y	Y	999	Y	Y	
J453	(Duration time)	0.00 to 3600.00 s	12	Y	Y	0.00	Υ	Υ	
J454	Contactor Restart Time when Switching the Motor	0.01 to 2.00 s	5	Y	Y	0.10	Y	Y	5-205
J455	Motor Increase Switching Time (Deceleration time)	0.00: Depends on F08 0.01 to 3600.00 s	12	Y	Y	0.00	Y	Y	5-205
J456	Motor Increase Switching Level	0 to 100%	1	Y	Y	0	Y	Y	
J457	Motor Increase PID Control Start Frequency	0 to 120 Hz 999: Depends on J452	1	Y	Y	999	Y	Y	
J458	Motor Decrease Switching Time (Acceleration time)	0.00: Depends on F07 0.01 to 3600.00 s	12	Y	Y	0.00	Y	Y	5-206
J459	Motor Decrease Switching Level	0 to 100% 999: Depends on J456	1	Y	Y	999	Y	Y	
J460	Motor Decrease PID Control Start Frequency	0 to 120 Hz 999: Depends on J450	1	Y	Y	999	Y	Y	

Code	Name	Data setting range	nunication ormat	nge when Inning	a copying	actory befault	Drive	control	ited page
			Comr	Char ru	Data	Ш	٧/f	ΡM	Rela
J461	Motor Increase/Decrease Switching Judgment Non-responsive Area Width	0.0: Disable 0.1 to 50.0%	3	Y	Y	0.0	Y	Y	5-206
J462	Failure Inverter Judgment Time	0.0: Disable 0.5 to 600.0 s	3	Y	Y	5.0	Y	Y	5-207
J463	PID control start frequency	0: Disable 1 to 120Hz 999: Depends on J19	1	Y	Y	999	Y	Y	5-207
J465	Auxiliary Motor (Frequency operation level)	0.0: Disable 0.1 to 120.0 Hz	3	Y	Y	50.0	Y	Y	5-207
J466	(Hysteresis width)	0.0 to 120.0 Hz	3	Y	Y	1.0	Y	Y	
J467	(PV operation level)	0.00: Disable 0.01 to 9990	12	Y	Y	0.00	Y	Y	5-207
J468	(Connection timer)	0.00 to 2.00 s	5	Y	Υ	0.00	Υ	Υ	
J469	(Interrupting timer)	0.00 to 2.00 s	5	Υ	Y	0.00	Υ	Υ	
J480	Motor Cumulative Run Time (Motor 0)	0 to 65535 For adjustment at the replacement time	1	Y	Ν	0	Y	Y	5-209
J481	(Motor 1)		1	Υ	Ν	0	Υ	Υ	
J482	(Motor 2)		1	Υ	Ν	0	Υ	Υ	
J483	(Motor 3)		1	Y	Ν	0	Υ	Υ	
J484	(Motor 4)		1	Y	Ν	0	Y	Υ	
J490	Y Terminal ON Maximum Cumulation Count (Y1,Y2,Y3)	0.000 to 1000 (The display of "1.000" indicates 1000 times.)	45	Y	Ν	0.000	Y	Y	5-210
J491	Relay ON Maximum Cumulation Count (Y5A/C)		45	Y	Ν	0.000	Y	Y	
J492	(30A/B/C)		45	Υ	Ν	0.000	Υ	Υ	
J493	(Y6RY to Y8RY)		45	Y	Ν	0.000	Y	Υ	
0001	(Mode selection)	 Enable process control (Normal operation) Enable process control (Inverse operation) Enable process control, interlocking with inverter running (Normal operation) Enable process control, interlocking with inverter running (Inverse operation) Enable process control by external digital signal (Normal operation) Enable process control by external digital signal (Inverse operation) Enable process control by external digital signal (Inverse operation) Enable process control by external digital signal, interlocking with inverter running (Normal operation) Enable process control by external digital signal, interlocking with inverter running (Inverse operation) 	•				•	•	0.211
J502	(Remote command selection)	 Keypad (⊘/⊘key) Terminal command "UP/DOWN" Command via communications link (Use function code S13) External PID command 1 (Analog input: Terminals [12], [C1] and [V2]) 	1	Z	Y	0	Y	Y	5-212
J505	(Display unit)	Same as J105	1	Ν	Y	0	Υ	Υ	5-217
J506	(Maximum scale)	-999 to 0.00 to 9990	12	Ν	Y	100.0	Υ	Υ	5-218
J507	(Minimum scale)	-999 to 0.00 to 9990	12	Ν	Y	0.00	Y	Y	
J510	P (Gain)	0.000 to 30.000 times 999: ON/OFF control	7	Y	Y	0.100	Y	Y	5-219
J511	I (Integral time)	0.0 to 3600.0 s	3	Υ	Y	0.0	Υ	Υ	
J512	D (Differential time)	0.00 to 600.00 s	5	Y	Y	0.00	Υ	Υ	
J513	(Feedback filter)	0.0 to 900.0 s	3	Y	Y	0.5	Y	Υ	
J514	(Anti-reset wind-up)	0.00 to 9990 0.00: Disable Upper/lower limit values are restricted by the maximum/minimum scales.	12	Y	Y	0.00	Y	Y	5-220
J515	(ON/OFF control hysteresis width)	0.00 to 9990 Upper/lower limit values are restricted by the maximum/minimum scales.	12	Y	Y	0.00	Y	Y	5-220
J516	(Proportional operation output convergent value)	0 to 150%	1	Y	Y	0	Y	Y	5-221
J517	(Proportional cycle)	1 to 150 s	1	Y	Y	30	Y	Y	5-221

Code	Name	Data setting range	munication	ange when unning	a copying	⁻ actory Default	Drive	control	ated page
			Com	Cha	Dat	-	V/f	ΜЧ	Rel
J518	External PID Control 1 (Upper limit of PID process output)	-10 to +110%	2	Y	Y	100	Y	Y	5-222
J519	(Lower limit of PID process output)	-10 to +110%	2	Y	Y	0	Y	Y	
J520	(Upper and lower limits)	 Limit PID output with J518, J519 110%, -10% of PID output with J518 exceeded or less than J519 	1	Y	Y	0	Y	Y	
J521	(Alarm output selection)	 0: Absolute-value alarm (PV) 1: Absolute-value alarm (PV) (with Hold) 2: Absolute-value alarm (PV) (with Latch) 3: Absolute-value alarm (PV) (with Hold and Latch) 4: Deviation alarm (PV) (with Hold) 6: Deviation alarm (PV) (with Hold and Latch) 7: Deviation alarm (PV) (with Hold and Latch) 8: Absolute-value alarm (SV) 9: Absolute-value alarm (SV) (with Hold) 10: Absolute-value alarm (SV) (with Hold) 11: Absolute-value alarm (SV) (with Hold and Latch) 12: Absolute-value alarm (MV) 13: Absolute-value alarm (MV) (with Hold) 14: Absolute-value alarm (MV) (with Hold) 15: Absolute-value alarm (MV) (with Hold and Latch) 	1	Y	Y	0	Y	Y	5-223
J522	(Upper level alarm (AH))	OFF: Disable -999 to 0.00 to 9990 Upper/lower limit values are restricted by the maximum/minimum scales.	12	Y	Y	OFF	Y	Y	
J524	(Lower level alarm (AL))	OFF: Disable -999 to 0.00 to 9990 Upper/lower limit values are restricted by the maximum/minimum scales.	12	Y	Y	OFF	Y	Y	
J527	(Feedback error detection mode)	 Disable (Turns ON output signals (EPV1-ERR) and continues operation.) Enable (Free run stop (PVA trip)) Enable (Deceleration and stop (PVA trip)) 	1	Y	Y	0	Y	Y	5-226
J529	(Feedback error upper-limit)	Auto: 105% equivalent -999 to 0.00 to 9990 Upper/lower limit values are restricted by the maximum/minimum scales.	12	Y	Y	AUTO	Y	Y	
J530	(Feedback error lower-limit)	Auto: -5% equivalent -999 to 0.00 to 9990 Upper/lower limit values are restricted by the maximum/minimum scales.	12	Y	Y	AUTO	Y	Y	
J531	(Feedback error detection time)	0.0 to 300.0 s	3	Y	Y	0.1	Y	Y	
J540	(Manual command)	0: Keypad (⊘/⊘key) 8: Keypad (⊘/⊘key) (Balanceless-bumpless) 51: External PID command 1 (Analog input: Terminals [12], [C1] and [V2])	1	N	Y	0	Y	Y	5-227
J551	External PID 1 Multistep Command (Multistep command 1)	-999 to 0.00 to 9990	12	Y	Y	0.00	Y	Y	5-227
.1552	(Multisten command 2)	-999 to 0 00 to 9990	12	Y	Y	0.00	Y	Y	
J553	(Multistep command 3)	-999 to 0.00 to 9990	12	Ŷ	Y	0.00	Ŷ	Ŷ	
	(· · · · · · · · · · · · · · · · · · ·		1						

d codes: Application Functions 2 (Application function 2)

Code	Name	Data setting range	mmunication format	nange when running	ata copying	Factory Default	Drive	control	elated page
			ပိ	Ö			٧/f	РМ	Ř
d01	Speed control 1 *5 (Speed command filter)	0.000 to 5.000 s	7	Y	Y	0.200	Ν	Y	5-228
d02	(Speed detection filter)	0.000 to 0.100 s	7	Y*	Υ	0.025	Ν	Υ	
d03	P (Gain)	0.1 to 200.0 times	3	Y*	Υ	2.0	Ν	Υ	
d04	I (Integral time)	0.001 to 9.999 s 999 : Cancel integral term	7	Y	Y	0.600	Ν	Y	
d21	Speed agreement / PG error (Hysteresis width)	0.0 to 50.0 %	3	Y	Y	10.0	Ν	Y	5-230
d22	(Detection timer)	0.00 to 10.00 s	5	Υ	Υ	0.50	Ν	Υ	
d23	PG error processing	0: Continue to run 1 1: Stop with alarm 1 2: Stop with alarm 2 3: Continue to run 2 4: Stop with alarm 3 5: Stop with alarm 4	1	N	Y	2	Ν	Y	
d25	ASR switching time	0.000 to 1.000 s	7	Υ	Υ	0.000	Ν	Υ	5-230
d32	Speed limit / Over speed level 1	0 to 110 %	1	Y	Y	100	Ν	Y	5-230
d33	Speed limit / Over speed level 2	0 to 110 %	1	Y	Y	100	Ν	Y	
d35	Over speed detection level	0 to 120 %; 999 999: Depend on d32, d33	1	Y	Y	999	N	Y	5-231
d51	Reserved *9	-500 to 500 *12	2	Ν	Υ	*12	Υ	Υ	5-231
d55	Reserved *9	0000 to 00FF (Display in hexadecimal)	1	Ν	Υ	0	Y	Υ	
d61	Command pulse input (Filter time constant)	0.000 to 5.000 s	7	Y	Y	0.005	Y	Y	5-231
d62	(Pulse scaling factor 1)	1 to 9999	1	Υ	Υ	1	Υ	Υ	
d63	(Pulse scaling factor 2)	1 to 9999	1	Y	Υ	1	Υ	Υ	
d67	PMSM starting mode *5 (Auto search)	 Disable Enable (At restart after momentary power failure) Enable (At restart after momentary power failure and at normal start) 	1	N	Y	2	Ν	Y	5-134 5-231
d69	Reserved *9	30.0 to 100.0Hz	3	Υ	Υ	30.0	Υ	Ν	5-231
d79	Reserved *5 *9	0; 160 to 500 V (400V order); 999	1	Ν	Υ	0	Ν	Υ	
d91	Reserved *9	0.00 to 2.00, 999	5	Υ	Υ	999	-	-	5-231
d92	Reserved *5 *9	0.00 to 10.00	5	Υ	Υ	0.30	-	-	
d99	Extension function 1	0 to 127	1	Y	Υ	0			
		Bit 0-8: Reserved *9					-	-	

*5: Available at ROM version 0300 or later.
*9: Factory use. Do not change these function codes.
*12:FRN0253F2E-4G or below: 20, FRN0304F2E-4G and FRN0377F2E-4G:50, FRN0415F2E-4G or above: 100.

U	codes: Apr	olication	Functions	3 ((Customizable logic)	

Code	Name	Data setting range	Communication	format	Change when running	Data copying	Factory Default	// Drive	M control	Related page
			0					>	Ъ	
U00	Customizable logic (Mode selection)	0: Disable 1: Enable (Customizable logic operation) ECL alarm occurs when the value is changed from 1 to 0 during operation.	1		Y	Y	0	Y	Y	5-234
U01	Customizable logic: Step 1 (Block selection)	[Digital]0:No function assigned10 to 15:Through output + General-purpose timer20 to 25:Logical AND + General-purpose timer30 to 35:Logical XOR + General-purpose timer40 to 45:Logical XOR + General-purpose timer60 to 65:Reset priority flip-flop + General-purpose timer70, 72, 73:Rising edge detector + General-purpose timer90, 92, 93:Rising & falling edges detector + General-purpose timer100 to 105:Hold + General-purpose timer100 to 105:Hold + General-purpose timer100 to 105:Hold + General-purpose timer100:Increment counter120:Decrement counter130:Timer with reset inputGeneral-purpose timer function(Least significant digit 0 to 5)_0: No timer_1: On-delay timer_3: Pulse (1 shot)_4: Retriggerable timer_5: Pulse train output(Analog)2001:Adder2002:Subtracter2003:Multiplier2004:Divider2005:Limiter2005:Comparator1 to 62071:Inverting adder2081:Variable limiter2092:Scale converter2003:Average of inputs2151:Loading function from S132201:Clip and map function202:Scale converter203:Average of inputs2151:Loading function202:Scale cor 1, 2203:Averag			Ζ	Y	0	Y	Y	

						1			
Code	Name	Data setting range	munication format	ange when unning	a copying	⁻ actory Default	Drive	control	ated page
			Com	Cha	Dat		٧/f	PM	Rela
						100		-	
002	Customizable logic: Step 1 (Input 1)	[Digital] 0 to 105: The same as E20 value. However, 27, 111 to 120 cannot be selected	1	N	Ŷ	100	Y	Y	
U03	(Input 2)	2001 to 2200 (3001 to 3200): Output of Step 1 to 200	1	Ν	Υ	100	Υ	Υ	
		"SO01" to"SO200"							
		4001 (5001): X1 terminal input signal "X1"							
		4002 (5002): X2 terminal input signal "X2"							
		4003 (5003): X3 terminal input signal "X3"							
		4004 (5004): X4 terminal input signal "X4"							
		4005 (5005): X5 terminal input signal "X5"							
		4010 (5010): FWD terminal input signal "FWD"							
		4011 (5011): REV terminal input signal "REV"							
		6000 (7000): Final run command RUN "FL_RUN"							
		6001 (7001): Final run command FWD "FL_FWD"							
		6002 (7002): Final run command REV "FL_REV"							
		6003 (7003): Accelerating "DACC"							
		6004 (7004): Decelerating "DDEC"							
		6005 (7005): Under anti-regenerative control "REGA"							
		6007 (7007): With/without alarm factor "ALM_ACT" * Inside the () is the negative logic signal. (OFF at short-circuit)							
		[Analog] 8000 to 8065: The value with 8000 added to F31 9001: Analog 12 terminal input signal [12] 9002: Analog C1 terminal input signal [C1] (C1) 9003: Analog V2 terminal input signal [C1] (V2) *9004: Analog 32 terminal input signal [32] *9005: Analog C2 terminal input signal [C2] *9006: RTD1 [PT1] *9007: RTD2 [PT2]							
U04	(Function 1)	-9990 to 0.00 to 9990	12	Ν	Y	0.00	Y	Y	
U05	(Function 2)		12	Ν	Y	0.00	Υ	Υ	

5.2 Function Codes Table

*: The use of the option card lets those functions remain in effect.

Customizable logic Step 1 to	14 function code is assigned	as follows: Setting value	is the same as U01 to U05.
		J	

	Step1	Step2	Step3	Step4	Step5	Step6	Step7	Step8	Step9	Step10
Block selection	U01	U06	U11	U16	U21	U26	U31	U36	U41	U46
Input 1	U02	U07	U12	U17	U22	U27	U32	U37	U42	U47
Input 2	U03	U08	U13	U18	U23	U28	U33	U38	U43	U48
Function 1	U04	U09	U14	U19	U24	U29	U34	U39	U44	U49
Function 2	U05	U10	U15	U20	U25	U30	U35	U40	U45	U50
	Step11	Step12	Step13	Step14						
Block selection	U51	U56	U61	U66						
Input 1	U52	U57	U62	U67						
Input 2	U53	U58	U63	U68						
Function 1	U54	U59	U64	U69						
Function 2	U55	U60	U65	U70						

Code	Name	Data setting range	nunication ormat	nge when unning	a copying	actory Default	Drive	control	ated page
			Com	Cha	Dati		٧/f	ΡM	Rel
U71	Customizable logic	0: Disable	1	Ν	Υ	0	Υ	Υ	
	(Output selection) Output signal 1	1 to 200: Output of Step 1 to 200 "S001" to "S0200"							
U72	Output signal 2								
U73	Output signal 3								
U74	Output signal 4								
U75	Output signal 5								
U76	Output signal 6								
U77	Output signal 7								
U78	Output signal 8								
U79	Output signal 9								
U80	Output signal 10								
U81	Customizable logic (Function selection) Output signal 1	0 to 205 (1000 to 1205): Same as E98 8001 to 8043: The value with 8000 added to E61	1	N	Y	100	Y	Y	
U82	Output signal 2								
U83	Output signal 3								
U84	Output signal 4								
U85	Output signal 5								
U86	Output signal 6								
U87	Output signal 7								
U88	Output signal 8								
U89	Output signal 9								
U90	Output signal 10								
U91	Customizable logic timer monitor (Step selection)	0: Monitor disable 1 to 200: Step 1 to 200	1	Y	N	0	Y	Y	
U92	Customizable logic	-9.999 to 9.999	8	Ν	Υ	0.000	Υ	Υ	
	(The coefficients of the approximate formula)								
- 1100	(Mantissa of KA1)		0		V		V		
093	(Exponent part of KA1)	-5 t0 5	2	IN N	Y	0	Y	Y	
094	(Mantissa of KB1)	-9.999 to 9.999	8	IN NI	Y V	0.000	Y	Y	
095	(Exponent part of KB1)	-5 10 5	2	IN NI	T	0	T V	T	
1107	(Manussa of KC1)	-9.333 (0 9.333	0 2	IN N	T V	0.000	T V	T V	
11100	Task process cycle setting	0: Auto select from 2, 5, 10 or 20 ms depending on the number	2	N	۱ ۷	0	۱ ۷	V	
0100	Task process cycle setting	of steps	1	IN		Ū			
		2: 2 ms (Up to 10 step)							
		10: 10 ms (Up to 100 step)							
		20: 20 ms (Up to 200 step)							
U101	Customizable logic (Operating point 1 (X1))	-999 to 0.00 to 9990	12	Y	Y	0.00	Y	Y	5-234 5-257
U102	(Operating point 1 (Y1))								
U103	(Operating point 2 (X2))								
U104	(Operating point 2 (Y2))								
U105	(Operating point 3 (X3))								
U106	(Operating point 3 (Y3))								
U107	Customizable logic	0: Invalid	1	Ν	Ν	0	Y	Y	5-234
	(Auto calculation of the coefficients of the	 Execute calculation (When the calculation is finished, the results are stored to the 							o-∠58
	approximate formula)	function code U92 to U97)							

-									
Code	Name	Data setting range	nunication ormat	nge when unning	a copying	actory Default	Drive	control	ated page
			Com	Cha	Dati		١//f	РМ	Rela
U121	Customizable logic (User parameter 1)	-9990 to 0.00 to 9990	12	Y	Y	0.00	Y	Y	5-234
U122	(User parameter 2)								
U123	(User parameter 3)								
U124	(User parameter 4)								
U125	(User parameter 5)								
U126	(User parameter 6)								
U127	(User parameter 7)								
U128	(User parameter 8)								
U129	(User parameter 9)								
U130	(User parameter 10)								
U131	(User parameter 11)								
U132	(User parameter 12)								
U133	(User parameter 13)								
U134	(User parameter 14)								
U135	(User parameter 15)								
U136	(User parameter 16)								
U137	(User parameter 17)								
U138	(User parameter 18)								
U139	(User parameter 19)								
U140	(User parameter 20)								
U171	Customizable logic (Storage area 1)	-9990 to 0.00 to 9990	12	Y	Y	0.00	Y	Y	
U172	(Storage area 2)								
U173	(Storage area 3)								
U174	(Storage area 4)								
U175	(Storage area 5)								
U190	Customizable logic setting step (Step number)	1 to 200	1	Y	Y	15	Y	Y	
U191	Setting step (Select block)	Same as U01	1	Ν	Υ	0	Y	Y	
U192	(Input 1)	Same as U02	1	Ν	Υ	100	Y	Y	
U193	(Input 2)	Same as U03	1	Ν	Υ	100	Y	Y	
U194	(Function 1)	Same as U04	12	Ν	Υ	0.00	Y	Y	
U195	(Function 2)	Same as U05	12	Ν	Y	0.00	Y	Y	
U196	Customizable logic ROM version Upper digit (Monitor)	0 to 9999	1	N	Ν	0	Y	Y	
U197	Customizable logic ROM version Upper digit (For User setting)	0 to 9999	1	N	Y	0	Y	Y	
U198	Customizable logic ROM version Lower digit (Monitor)	0 to 9999	1	N	N	0	Y	Y	
U199	Customizable logic ROM version Lower digit (For User setting)	0 to 9999	1	Ν	Y	0	Y	Y	

■ y codes: LINK Functions (Link function)

Code	Name	Data setting range		Change when running	Data copying	Factory Default	/f Drive	M control	Related page
			0	_			>	٩	
y01	RS-485 Communication 1 (Station address)	0 to 255 *Set 1 when other than BACnet is 0. *Set 127 when BACnet is 128 or above.	1	N	Y	1	Y	Y	5-261
y02	(Communications error processing)	 Immediately trip with alarm Er-B Trip with alarm Er-B after running for the period specified by timer y03 Retry during the period specified by timer y03. If the retry fails, trip with alarm Er-B. If it succeeds, continue to run. Continue to run 	1	Y	Y	0	Y	Y	
y03	(Timer)	0.0 to 60.0 s	3	Y	Υ	2.0	Υ	Y	
y04	(Baud rate)	0: 2400 bps 1: 4800 bps 2: 9600 bps 3: 19200 bps 4: 38400 bps	1	Y	Y	3	Y	Y	
y05	(Data length selection)	0: 8 bit 1: 7 bits	1	Y	Υ	0	Υ	Υ	
y06	(Parity selection)	 None (Stop bit: 2 bits) Even number parity (Stop bit: 1 bits) Odd number parity (Stop bit: 1 bits) None (Stop bit: 1 bits) 	1	Y	Y	0	Y	Y	
y07	(Stop bit selection)	0: 2 bits 1: 1 bits	1	Y	Y	0	Y	Y	
y08	(Communication time-out detection timer)	0: Not check of the time-out 1 to 60 s	1	Y	Y	0	Y	Y	
y09	(Response interval time)	0.00 to 1.00 s	5	Y	Y	0.01	Y	Y	
y10	(Protocol selection)	0: Modbus RTU protocol 1: FRENIC Loader protocol (SX protocol) 2: Fuji general-purpose inverter protocol 3: Metasys N2 5: BACnet protocol	1	Y	Y	1	Y	Y	
y11	RS-485 Communication 2 (Station address)	1 to 255	1	N	Y	1	Y	Y	
y12	(Communications error processing)	 Immediately trip with alarm Er-P Trip with alarm Er-P after running for the period specified by timer y13 Retry during the period specified by timer y13. If the retry fails, trip with alarm Er-P. If it succeeds, continue to run. Continue to run 	1	Y	Y	0	Y	Y	
y13	(Timer)	0.0 to 60.0 s	3	Y	Y	2.0	Υ	Y	
y14	(Baud rate)	0: 2400 bps 1: 4800 bps 2: 9600 bps 3: 19200 bps 4: 38400 bps	1	Y	Y	3	Y	Y	
y15	(Data length selection)	0: 8 bits 1: 7 bits	1	Υ	Y	0	Υ	Υ	
y16	(Parity selection)	 None (Stop bit: 2 bits) Even number parity (Stop bit: 1 bits) Odd number parity (Stop bit: 1 bits) None (Stop bit: 1 bits) 	1	Y	Y	0	Y	Y	
y17	(Stop bit selection)	0: 2 bits 1: 1 bit	1	Y	Y	0	Y	Υ	
y18	(Communication time-out detection timer)	0: Not check of the time-out 1 to 60 s	1	Y	Y	0	Y	Y	
y19	(Response interval time)	0.00 to 1.00 s	5	Y	Y	0.01	Y	Υ	
y20	(Protocol selection)	0: Modbus RTU protocol 1: FRENIC Loader protocol (SX protocol) 2: Fuji general-purpose inverter protocol 3: Metasys N2 5: BACnet protocol 50: Pump control protocol	1	Y	Y	0	Y	Y	

Code	Name		Data setting range			munication format ange when unning	a copying	Factory Default	Drive control		ated page
						Ch	Da		٧/f	Md	Re
y95	Data clear processing for communications error	0: Do r com Clea com 2: Clea whe 3: Clea bit o * Re	Do not clear the data of function codes Sxx when a communications error occurs. (compatible with the conventional inverters) Clear the data of function codes S01/S05/S19 when a communications error occurs. Clear the run command assigned bit of function code S06 when a communications error occurs. Clear both data of S01/S05/S19 and run command assigned bit of S06 when a communications error occurs.		1	Y	Y	0	Y	Y	5-264
y97	Communication data storage selection	0: Stor 1: Writ unlir 2: Save (Afte	Store into nonvolatile memory (Rewritable times are limited) Write into temporary memory (Rewritable times are unlimited) Save all data from temporary memory to nonvolatile memory (After all save, return to Data 1)		1	Y	Y	0	Y	Y	5-264
y98	Bus link function (Mode selection)	Frec 0: Follo 1: Bus 2: Follo 3: Bus	quency command ow H30 link ow H30 link	Run command Follow H30 Follow H30 Bus link Bus link	1	Y	Y	0	Y	Y	5-264
y99	Loader link function (Mode selection)	Frec 0: Follo 1: FRE 2: Follo 3: FRE	quency command ow H30, y98 ENIC loader ow H30, y98 ENIC loader	Run command Follow H30, y98 Follow H30, y98 FRENIC loader FRENIC loader	1	Y	N	0	Y	Y	5-265

5.2 Function Codes Table

■ K codes: Keypad functions for TP-A1-E2C

Code Name		Data setting range	nunication ormat	nge when unning	a copying	Factory Default	Drive	control	ited page
			Comr	Chai	Data	шп	٧/f	PM	Rela
K01	Multifunction keypad TP-A1 (Language selection)	0: Japanese 1: English 2: German 3: French 4: Spanish 5: Italian 6: Chinese 8: Russian 9: Greek 10: Turkish 11: Polish 12: Czech 13: Swedish 14: Portuguese 15: Dutch 16: Malay 17: Vietnamese 18: Thai 19: Indonesian 100: User-Customizable language	1	Y	Y	6	Y	Y	_
K02 K03	(Backlight OFF time) (Backlight brightness	0: Always OFF 1 to 30 min 0 (dark) - 10 (bright)	1	Y Y	Y Y	5	Y Y	Y Y	-
1/04	adjustment)		4	V	V	-	V	V	
K04 K08	(Contrast adjustment) (I CD monitor status display)	0 (low) - 10 (high) 0: Not displayed	1	Y Y	Y Y	5	Y Y	Y Y	-
		1: Fully displayed				-		'	
K15	(Sub-monitor display selection)	0: Operation guide display 1: Bar graph display	1	Y	Y	0	Y	Y	-
K16	(Sub-monitor 1 display selection)	1 to 35 1: Output frequency 1 (PM: Speed command value)	1	Y	Y	13	Y	Y	-
K17	(Sub-monitor 2 display selection)	 Output frequency 2 (PM: Speed estimated value) Reference frequency Motor rotation speed Speed (%) Output current Output voltage Calculated torque Input power Load factor Motor output Analog input monitor Input watt-hour PID command (final)(physical data) PID control1 command (physical data) PID control1 feedback value (physical data) PID control2 feedback value (physical data) PID control2 feedback value (physical data) External PID command (final)(physical data) External PID manual command (%) 	1	Y	Y	19	Y	Y	_
K20	(Bar graph 1 display selection)	1: Output frequency 1 (PM: Speed command value) 13: Output current 14: Output voltage	1	Y	Y	1	Y	Y	-
K21	(Bar graph 2 display selection)	18: Calculated torque	1	Υ	Υ	13	Y	Y	-
K22	(Bar graph 3 display selection)	25: Load factor 26: Motor output	1	Y	Y	19	Y	Y	_
K91	(< key shortcut selection)	0: disabled	1	Υ	Υ	0	Y	Y	_
K92	(> key shortcut selection)	11 to 99: respective mode	1	Y	Υ	64	Y	Υ	-

The keypad function K codes are used when the multi-function keypad (TP-A1) is connected. For details about the K codes, refer to the instruction manual for the keypad.

Applicable electric motor capacity		Torque boost 1 to 2	Restart mode after momentary
kW	HP	F09/ A05	power failure (Restart timer) H13
0.1	1/8	6.7	
0.2	1/4	4.0	
0.4	1/2	3.5	
0.75	1	6.5	
1.5	2	4.9	0.5
2.2	3	4.5	
3.7	5	4.1	
5.5	7.5	3.4	-
7.5	10	2.7	
11	15	2.1	
15	20	1.6	
18.5	25	1.3	
22	30	1.1	1.0
30	40		
37	50	0.0	
45	60		
55	75		
75	100		1.5
90	125		
110	150		
132	175		
160	200	0.0	2.0
200	250		
220	300		2.5
280	400		
315	450		
355	500		4.0

5.2.3 Factory default value per applicable electric motor capacitance

5.2.4 Motor constants

[1] When Fuji standard motor 8-series, or other motors are selected by motor selection (Function code P99 = 0 or 4)

3-phase 400V class, Fuji standard motor	
---	--

Motor rated capacity setting range (kW) P02	Applicable motor capacity (kW)	Rated current (A) P03	No-load current (A) P06	%R1 (%) P07	%X (%) P08	Starting mode (Auto search delay time 2) H46
0.01 to 0.09	0.06	0.22	0.20	13.79	11.75	
0.10 to 0.19	0.1	0.35	0.27	12.96	12.67	
0.20 to 0.39	0.2	0.65	0.53	12.95	12.92	0.5
0.40 to 0.74	0.4	1.15	0.83	10.20	13.66	0.5
0.75 to 1.49	0.75	1.80	1.15	8.67	10.76	
1.50 to 2.19	1.5	3.10	1.51	6.55	11.21	
2.20 to 3.69	2.2	4.60	2.43	6.48	10.97	0.6
3.70 to 5.49	3.7	7.50	3.84	5.79	11.25	0.8
5.50 to 7.49	5.5	11.50	5.50	5.28	14.31	1.0
7.50 to 10.99	7.5	14.50	6.25	4.50	14.68	1.2
11.00 to 14.99	11	21.00	8.85	3.78	15.09	1.3
15.00 to 18.49	15	27.50	10.00	3.25	16.37	
18.50 to 21.99	18.5	34.00	10.70	2.92	16.58	2.0
22.00 to 29.99	22	39.00	12.60	2.70	16.00	
30.00 to 36.99	30	54.00	19.50	2.64	14.96	2.3
37.00 to 44.99	37	65.00	20.80	2.76	16.41	2.5
45.00 to 54.99	45	78.00	23.80	2.53	16.16	2.5
55.00 to 74.99	55	95.00	29.30	2.35	16.20	2.6
75.00 to 89.99	75	130.0	41.60	1.98	16.89	2.8
90.00 to 109.9	90	155.0	49.60	1.73	16.03	3.2
110.0 to 131.9	110	188.0	45.60	1.99	20.86	3.5
132.0 to 159.9	132	224.0	57.60	1.75	18.90	4.1
160.0 to 199.9	160	272.0	64.50	1.68	19.73	4.5
200.0 to 219.9	200	335.0	71.50	1.57	20.02	4.7
220.0 to 249.9	220	365.0	71.80	1.60	20.90	4.7
250.0 to 279.9	250	415.0	87.90	1.39	18.88	5.0
280.0 to 314.9	280	462.0	93.70	1.36	19.18	5.5
315.0 to 354.9	315	520.0	120.0	0.84	16.68	5.0
355.0 to 399.9	355	580.0	132.0	0.83	16.40	5.0
400.0 to 449.9	400	670.0	200.0	0.62	15.67	7.5
450.0 to 499.9	450	770.0		0.48	13.03	
500.0 to 559.9	500	835.0	270.0	0.51	12.38	9.8
560.0 to 629.9	560	940.0		0.57	13.94	
630.0 to 709.9	630	1050.0	355.0	0.46	11.77	105
710.0 or above	710	1150.0	290.0	0.54	14.62	10.5

[2] When HP rating motor is selected by motor selection (Function code P99/A39 = 1)

3-phase 400V class, HP rating motor

Motor rated capacity setting range (HP) P02/A16	Applicable motor Capacity (HP)	Rated current (A) P03	No-load current (A) P06	%R1 (%) P07	%X (%) P08	Starting mode (Auto search delay time 2) H46
0.01 to 0.11	0.1	0.22	0.20	13.79	11.75	
0.12 to 0.24	0.12	0.34	0.27	12.96	12.67	
0.25 to 0.49	0.25	0.70	0.56	11.02	13.84	0.5
0.50 to 0.99	0.5	1.00	0.61	6.15	8.80	0.5
1.00 to 1.99	1	1.50	0.77	3.96	8.86	
2.00 to 2.99	2	2.90	1.40	4.29	7.74	
3.00 to 4.99	3	4.00	1.79	3.15	20.81	0.6
5.00 to 7.49	5	6.30	2.39	3.34	23.57	0.8
7.50 to 9.99	7.5	9.30	3.12	2.65	28.91	1.0
10.00 to 14.99	10	12.7	4.37	2.43	30.78	1.2
15.00 to 19.99	15	18.7	6.36	2.07	29.13	1.3
20.00 to 24.99	20	24.6	4.60	2.09	29.53	
25.00 to 29.99	25	30.0	8.33	1.75	31.49	2.0
30.00 to 39.99	30	36.2	9.88	1.90	32.55	
40.00 to 49.99	40	45.5	6.80	1.82	25.32	2.3
50.00 to 59.99	50	57.5	9.33	1.92	24.87	25
60.00 to 74.99	60	68.7	10.4	1.29	26.99	2.5
75.00 to 99.99	75	86.9	14.3	1.37	27.09	2.6
100.0 to 124.9	100	113.0	18.7	1.08	23.80	2.8
125.0 to 149.9	125	134.0	14.9	1.05	22.90	3.2
150.0 to 174.9	150	169.0	45.2	0.96	21.61	3.5
175.0 to 199.9	175	188.5	45.2	0.96	21.61	4.1
200.0 to 249.9	200	231.0	81.8	0.72	20.84	4.5
250.0 to 299.9	250	272.0	41.1	0.71	18.72	47
300.0 to 324.9	300	323.0	45.1	0.53	18.44	4.1
325.0 to 349.9	325	342.9	45.1	0.53	18.44	5.0
350.0 to 399.9	350	375.0	68.3	0.99	19.24	5.5
400.0 to 449.9	400	429.0	80.7	1.11	18.92	5.6
450.0 to 499.9	450	481.0	85.5	0.95	19.01	0.0
500.0 to 599.9	500	534.0	99.2	1.05	18.39	7.5
600.0 to 699.9	600					
700.0 to 749.9	700	000.0	140.0	0.05	40.00	9.8
750.0 to 799.9	750	638.0	140.0	0.85	18.38	
800.0 or above	800					10.5

5.3 Description of Function Codes

This section describes details of function code. In principle, explanation is given for each function code in order of group and numerical order. However, function codes that are strongly related to one function are explained together in the first paragraph.

5.3.1 F codes (Basic functions)

Data protection

This is a function to protect currently set data by disabling to make changes in function code data (except F00) and all types of command values (frequency setting, PID command) by \bigotimes key operation from keypad.

	Change of f	Changing digital reference data with the \bigcirc / \oslash keys	
FUU data	Change from keypad Change from communication		
0	Allowed	Allowed	Allowed
1	Not allowed *	Allowed	Allowed
2	Allowed	Allowed	Not allowed
3	Not allowed *	Allowed	Not allowed

*Although it is not possible to change function code from keypad, function code F00 can be changed.

F00 data can be changed by the double key operation using "fighter response respon

As a similar function related to data protection, "Allow function code editing (Data change enabled) 'WE-KP'" which can be assigned to a digital input terminal is available (\square Function code E01 to E05 Data = 19).

By combining data protection F00, protection of function code functions as follows:

Input signal "M/E KD"	Change in function code			
	Change from keypad	Change from communication		
OFF	Not allowed	Allowed		
ON	Follow setting of F00	Allowed		

Note

If "enable data change with keypad" [WE-KP] is set to a digital input terminal by mistake, it is not
possible to make changes in function codes. In this case, after shortening (ON) the terminal to which
temporarily "WE-KP" function is assigned, and the terminal [CM], change to a different function.

* "WE-KP" is the change enable signal for function code, this is not the function to protect frequency setting and PID command by 🛇 key operation.

F01	Frequency setting 1
	Related function codes:
	F18 bias (for frequency setting 1)
	C30 frequency setting 2
	C31 to C35 analog input adjustment (Terminal [12])
	C36 to C39 analog input adjustment (Terminal [C1] (C1 function))
	C40 terminal [C1] (C1 function) (Range / polarity selection)
	C41 to C45 analog input adjustment (Terminal [C1] (V2 function))
	C55 to C56 analog input adjustment (Terminal [12]) (Bias-Bias base point)
	C61 to C62 analog input adjustment (Terminal [C1] (C1 function)
	(Bias-Bias base point)
	C67 to C68 analog input adjustment (Terminal [C1] (V2 function))
	(Bias-Bias base point)
	C50 bias (for frequency setting 1) (Bias base point)
	d61 to d63 Command (Pulse train input)

Select setting method of frequency setting. Set frequency setting 1 by function code F01, frequency setting 2 by C30.

F01, C30 data	Command sources
0	Frequency setting by keypad (refer to the following descriptions to find the setting method)
1	Set by voltage value to be input in the terminal [12] (0 to \pm 10VDC, Maximum output frequency /DC \pm 10V)
	Setting by current value to be input in the terminal [C1] (C1 function) (4 to 20mADC or 0 to 20 mADC, Maximum output frequency / 20 mADC)
2	(Set slide switch SW4 of printed circuit board to [AI] side (factory default state), SW3 to [C1] side (factory default state), respectively.)
	(It is necessary to select C1 function (factory default state) by E59=0)
	(It is necessary to disable PTC input function by H26=0)
3	Set by the addition result of voltage value to be input in the terminal [12] (0 to ±10VDC, Maximum output frequency /±10 VDC) and current value to be input in the terminal [C1] (C1 function) (4 to 20 mA DC or 0 to 20 mA DC, Maximum output frequency/20 mA DC)
	when the addition result becomes maximum output frequency or higher, it is restricted by the maximum output frequency)
	Set by voltage value to be input in the terminal [C1] (V2 function) (0 to +10 VDC, Maximum output frequency /+10 VDC)
5	(Set slide switch SW4 of printed circuit board to [AI] side (factory default state), SW3 to [V2] side, respectively.)
	(It is necessary to select V2 function by E59 = 1)
	(It is necessary to disable PTC input function by $H26 = 0$)
	Set by UP command "UP" and DOWN command "DOWN" assigned to the digital input terminal
7	It is necessary to assign UP command (Data = 17) and DOWN command (Data =18) to the digital input terminal [X1] to [X5]. (E01 toE05)
8	Frequency setting by keypad (with balanceless bumpless function)
10	Set by pattern operation (C21 to C28)
12	Setting by pulse train input "PIN" (Data = 48), which was assigned to the digital input terminal [X5].
12	Note: When using X5 terminal with pulse train input, it might be affected by noise from other wire. Keep away from other wire from the wire to X5 terminal as far as possible.

Setting method of reference frequency

Tip

[1] Frequency setting by keypad (F01 = 0 (Factory default state), 8)

- (1) Set the data of function code F01 to "0" or "8". When keypad is at program mode or alarm mode, it is not possible to perform frequency setting with ⊘√⊗ keys. In order to enable frequency setting with ⊘√⊗ keys, shift to the operation mode.
- (2) When $\bigotimes \bigotimes$ key is pressed, reference frequency is displayed and the least significant digit of the reference frequency flashes.
- (3) By pressing the ⊘/⊗ key again, it is possible to change the reference frequency. To save the set frequency, press 💮 key. (E64=0: Factory default state). When the frequency is saved, it is possible to operate with the saved frequency next time the power is turned on.
 - Automatic saving method (Function code E64 = 0) is available other than the above method as a data saving method of frequency setting.
 - While the data of function code F01 is set to "0" or "8", when frequency setting method other than frequency setting 1 (frequency setting 2, communication, multistep frequency) is selected as frequency setting, it is not possible to change the reference setting with ⊘V keys even if keypad is at operation mode. In this case, pressing ⊘/⊗ keys displays the currently selected reference frequency.
 - When frequency setting is performed with keys, the least significant digit displayed flashes and the data is changed from the least significant digit and the changing digit gradually shifts to the upper digit.
 - In order to perform setting such as reference frequency, press ⊘/⊗ once and when the least significant digit flashes, push down the () key, and then, the flashing digit will move. Therefore, it is possible to change the large numerical number easily. This operation is called cursor movement.
 - When the data of function code F01 is set to "8", balanceless bumpless function becomes enabled. When switching to frequency setting with keypad from frequency setting method other than keypad, the switched initial value of frequency setting with keypad takes the value of the frequency setting before it is switched. By using this function, even if frequency setting is switched, it is possible to perform operation without shock.

[2] Setting up a reference frequency using analog input (F01 = 1 to 3, 5)

It is possible to arbitrarily specify a frequency setting from the analog inputs (voltage value to be input to terminal [12] or terminal [C1] (V2 function) or current value to be input to terminal [C1] (C1 function)) by multiplying them with the gain and adding the bias. The polarity can be selected and the filter time constant and offset can be adjusted.

F01 data	Input terminal		Bias		Gain		Delerity		
		Input range	Bias	as Base o	Gain	Base point	selection	Filter	Offset
1	[12]	0 to +10V, -10 to +10V	F18	C50	C32	C34	C35	C33	C31
2	[C1] (C1 function)	4 to 20 mA 0 to 20 mA	F18	C50	C37	C39	C40	C38	C36
3	[12]+ [C1] (C1 function)	0 to +10V, -10 to +10V	F18	C50	C32	C34	C35	C33	C31
	(Set by result of addition)	4 to 20 mA 0 to 20 mA	F18	C50	C37	C39	C40	C38	C36
5	[C1] (V2 function)	0 to +10V	F18	C50	C42	C44	C45	C43	C41

Adjustment constants of frequency setting 1

Adjustment constants of frequency setting 2

C30 data	Input terminal	Input range	Bias		Gain		Delority		
			Bias	Base point	Gain	Base point	selection	Filter	Offset
1	[12]	0 to +10V, -10 to +10V	C55	C56	C32	C34	C35	C33	C31
2	[C1] (C1 function)	4 to 20 mA 0 to 20 mA	C61	C62	C37	C39	C40	C38	C36
3	[12]+ [C1] (C1 function)	0 to +10V, -10 to +10V	C55	C56	C32	C34	C35	C33	C31
	(Set by result of addition)	4 to 20 mA 0 to 20 mA	C61	C62	C37	C39	C40	C38	C36
5	[C1] (V2 function)	0 to +10V	C67	C68	C42	C44	C45	C43	C41

Offset (C31, C36, C41)

C31, C36 or C41 configures an offset for an analog voltage/current input. The offset also applies to signals sent from the external equipment.

Filter (C33, C38, C43)

C33, C38, and C43 provide the filter time constants for the voltage and current of the analog input. The larger the time constant, the slower the response. Specify the proper filter time constant taking into account the response speed of the machine (load). If the input voltage fluctuates due to line noises, increase the time constant.

■ Terminal [12] Polarity selection (C35)

C35 configures the polarity and therefore the input range for analog input voltage.

C35 data	Modes for terminal inputs			
0	-10 to +10 V			
1	0 to +10 V (Negative value of voltage is regarded as 0 V)			

■ Terminal [C1] (C1 function) range / polarity selection (C40)

C40 data Terminal input range		Handling when bias value is set to minus			
0 4 to 20 mA (Factory default)		Limit below 0 point with 0			
1	0 to 20mA				
10 4 to 20mA		Enchle helew 0 point as minus value			
11	0 to 20mA	Enable below 0 point as minus value.			

■ Terminal [C1] (V2 function) polarity selection (C45)

C45 data	Modes for terminal inputs				
0	0 to +10V When bias value is set to minus, enable below 0 point as a minus value.				
1	0 to +10V (factory default) When bias value is set to minus, limit below 0 point by 0.				

In order to use [C1] terminal as C1 function, V2 function, and PTC function, the following setting are necessary.

[C1] terminal	SW3	SW4	E59	H26	C40
When using C1 function (4 to 20 mA)	C1 side	Al side	0	0	0,10
When using C1 function (0 to 20 mA)	C1 side	AI side	0	0	1,11
When using V2 function (0 to +10V)	V2 side	AI side	1	0	Not relevant
When using PTC function	C1 side	PTC side	Not relevant	1, 2	Not relevant

For details of SW3 and SW4, refer to Chapter 2, Section 2.2.8.

Caution is necessary because if the above switch settings are not performed accurately, unexpected frequency setting may be performed for the inverter.

Gain-Bias





For [12] + [C1] (C1 function) (setting by the result of addition), bias and gain are reflected to [12] and [C1] (C1 function) individually, and added by frequency command value of the result.



For single polarity (Terminal [12] (C35=1), Terminal [C1] (C1 function), Terminal [C1] (V2 function)

As the above diagram indicates, for reference frequency and analog input of frequency setting 1, it is possible to set arbitrary relationship by A point (determined by bias (F18) and bias reference point (C50)) and B point (determined by the gain corresponding to each analog input and the gain reference point (C32 and C34, C37 and C39, and C42 and C44)).

For reference frequency and analog input of frequency setting 2 (C30), it is possible to set arbitrary relationship by A point (determined by bias and bias reference point (C55 and C56, C61 and C62, and C67 and C68)) and B point (determined by the gain corresponding to each analog input and the gain reference point (C32 and C34, C37 and C39, and C42 and C44)).

Both data of bias and gain are set with 100% as the maximum frequency. The data of bias reference point and gain reference point are set up with full scale of analog input (10V or 20mA) as100%.

By setting the bias to minus value, even if the analog input is unipolar, it is possible to perform frequency setting as bipolar. For terminal [C1] (C1 function), C40 is set to 10 or 11, and for terminal [C1] (V2 function), C45 is set to 1, and then, the frequency setting at analog input at or below 0 point becomes negative polarity, as a result, it becomes possible to perform forward and reverse operation only by analog command.



<Frequency setting 1: F01>

- Analog input at or below bias reference point (C50) is restricted by bias value (F18).
- When the value set in bias reference point (C50)≥ each gain reference point (C34, C39, C44), it is judged as incorrect setting and reference point becomes 0 Hz.

<Frequency setting 2: C30>

- Analog input at or below bias reference point (C56, C62, and C68) is restricted by bias value (C55, C61 and C67).
- When the value set in bias reference point (C56, C62, C68) ≧ each gain reference point (C34, C39, C44), it is judged as incorrect setting and reference point becomes 0 Hz.
- Example) When setting reference frequency to 0 to 60 Hz by analog input (terminal [12]) 1 to 5V (When maximum frequency is F03=60 Hz)



(A point)

In order to set reference frequency to 0 Hz when analog input is 1V, set bias (F18) to 0%. At this point, 1V has to become the bias reference point and 1V is equivalent to 10% against full scale 10V of terminal [12], therefore, set the bias reference point (C50) to 10%.

(B point)

In order to set reference frequency so that the frequency becomes the highest when analog input is 5V, set the gain (C32) to 100%. At this point, 5V has to become the gain reference point and 5V is equivalent to 50% against full scale 10V of terminal [12], therefore, set the gain reference point (C34) to 50%.



The setting method without changing reference point and by using gain and bias individually is the same as for Fuji Electric inverter of old model.

For bipolar (Terminal [12] (C35=0))

For terminal [12], by setting function code C35 to "0", it is possible to use bipolar input (-10V to +10V).

When both bias (F18) and bias reference point (C50) are set to "0", command becomes forward and reverse symmetric as shown in the diagram below.



• When bias (F18) and bias reference point (C50) is set to arbitrary value (A1 point, A2 point, and A3 point, etc.), as shown in the diagram below, it is determined by the bias value (F18).



Note

Note

- To input bipolar (0 to ±10 VDC) analog voltage at analog input (terminal [12]), set function code C35 to "0". When the data of C35 is "1", only DC 0 to +10V is effective and negative polar input DC0 to -10V is regarded as 0 (Zero) V.
- When setting reference frequency by display other than frequency (Hz), please change the speed monitor unit in E48.

When operating unipolar analog input as bipolar (terminal [C1] (C1 function) (C40 = 10, 11), terminal [C1] (V2 function) (C45 = 0)

For C1 function set C40 = 10, 11, for V2 function set C45 = 0, and by setting bias value to minus value, it is possible to obtain a negative reference frequency.

Example of frequency setting by V2 function when -100% is set to the bias value is shown in the diagram below.


[3] Frequency setting by digital input signal "UP"/"DOWN" (F01=7)

As frequency setting, UP/DOWN control is selected, and when the terminal command UP or DOWN is turned on with Run command ON, the output frequency increases or decreases accordingly, within the range from 0 Hz to the maximum frequency.

The set frequency is stored internally, and the previous operating frequency is set first when resuming operation (including when turning ON power, switching the setting means).

To perform frequency setting by UP/DOWN control, it is necessary to set the data of function code F01 to "7" and assign "UP command [UP], down command [DOWN]" to the digital input terminals. (I Function code E01 to E05 Data = 17, 18)

Input signal "UP"	Input signal "DOWN"	Action	
Data = 17	Data = 18		
OFF	OFF	The output frequency will be held	
ON	OFF	Increase output frequency by currently selected acceleration time	
OFF	ON	Decrease output frequency by currently selected deceleration time	
ON	ON	The output frequency will be held	



At the restart of operation, before the internal frequency reaches the previous output frequency, when UP/DOWN command is input, output frequency at the point is held internally and UP/DOWN control starts from that value. Therefore, the previous output frequency data is overwritten and deleted.



[4] Frequency setting using pulse train input (F01=12)

The pulse train input format

By assigning a "PIN" (E05= 8) to terminal [X5] and inputting a serial pulse, a frequency proportional to the pulse frequency can be set. "SIGN" can also be assigned (E01 is E4=49) to other than terminal [X5], and pulse train sign commands can also be specified. If no "SIGN" is assigned, the polarity will be positive.

The command polarity is determined by the pulse train sign. Motor rotation direction is determined by a combination of the pulse train input polarity and "FWD"/"REV" commands. The relationship between pulse train input polarity and rotation direction is shown in Table 5.3-1.

Table 5.3-1	The relationship between the pulse train input polarity and rotation direction
-------------	--

Polarity according to the pulse train input	Run command	Rotational direction
+	"FWD" (Forward rotation command)	Forward rotation
+	"REV" (Reverse rotation command)	Reverse rotation
-	"FWD" (Forward rotation command)	Reverse rotation
-	"REV" (Reverse rotation command)	Forward rotation



Figure 5.3-1 Pulse train sign/Pulse train input.

Pulse scaling factor 1 (d62), pulse scaling factor 2 (d63)

For pulse train input, set the relationship between input pulse frequency and frequency setting value by function code d62 (Command (pulse train input) pulse scaling factor 1) and d63 (command (pulse train input) pulse scaling factor 2).



Figure 5.3-2 Relationship between input pulse frequency and frequency setting value

As shown in the figure above, set input pulse frequency [kp/s] to function code d62 (command (pulse train input) pulse scaling factor 1) and set frequency setting value [Hz] (when the input pulse frequency becomes the value set to function code d62) to function code d63 (command (pulse train input) pulse scaling factor 2). At this time, the relationship formula of input pulse frequency to be entered and frequency setting value f (or speed command value) is as follows:

f^{*} [Hz] = Np [kp/s] × $\frac{Pulse \ scaling \ factor \ 2 \ (d63)}{Pulse \ scaling \ factor \ 1 \ (d62)}$ f* [Hz]: Frequency setting value Np [kp/s]: Input pulse frequency to be input

Depending on the pulse train sign, polarity of the command is determined. Rotation direction of the motor is determined by the polarity of pulse train input and "FWD"/"REV" command. The relationship between the pulse train input polarity and rotation direction is specified in Table 5.3-1.

■ Filter time constant (d61)

Set filter time constant for pulse train input. The larger the time constant, the slower the response. Specify the proper filter time constant by taking into account the response speed of the machine. If the pulse is lower and frequency command fluctuates, set larger time constant.

Switching frequency setting

Switch frequency setting 1 (F01) and frequency setting 2 (C30) by the signal "Frequency setting 2/frequency setting 1" "Hz2/ Hz1", which was assigned to the external digital input terminal.

(Refer to Function code E01 to E05 (Data =11) to find the details of "Hz2/ Hz1".

Input signal "Hz2/ Hz1"	Frequency setting method to be selected
OFF	Frequency setting 1 (F01)
ON	Frequency setting 2 (C30)

Operation method

Select setting method of run command. Indicate instruction method of run/stop and rotation direction (forward/reverse rotation) for each setting method.

	Setting method of run command		
FUZ data	Run/stop	Rotation direction command	
0: Keypad operation (Rotation direction input: Terminal block)	(FUN)/(STOP) keys "FWD", "REV"		
1: External signal (digital input)	"FWD", "REV"		
2: Keypad operation (forward rotation)	Run)/STOP keys	Rotation direction command is unnecessary (Forward rotation operation only, reverse rotation operation disabled)	
3: Keypad operation (Reverse rotation)	RUN/STOP keys	Rotation direction command is unnecessary (Reverse rotation operation only, forward rotation operation disabled)	

Digital input signal, "FWD", "REV" needs to be assigned to terminals [FWD], [REV]. (III) Function code E98, E99 data = 98, 99)



F02

- F02 cannot be changed when "FWD" or "REV" is ON.
- If F02 = 1 and when assignment of terminal [FWD] or [REV] is changed from other function to "FWD" function or "REV" function, turn the terminal [FWD] and [REV] off in advance (motor may rotate due to change in the setting).

3-wire operation by external signal

Although external signal of "FWD" and "REV" is 2-wire operation at the initial state, by assigning "Select 3-wire operation (HLD)", it is possible to use as self-hold signal at 3-wire operation by using "FWD", "REV" and "HLD" signals. When "HLD" is ON, inverter self-holds "FWD" or "REV" signal, and the hold state can be released by OFF. If there is no "HOLD" function assignment, "FWD" and "REV" become 2-wire operation.

Refer to Function code E01 to E05 (Data =6) to find the details of "HLD".



As a setting method of run command, high-priority setting methods (remote/local switch (refer to Chapter 3, Section 3.3.6), communication, etc.) are available in addition to the above mentioned settings.

F03

Maximum frequency 1

F03 specifies the maximum frequency that the inverter outputs. When the device to be driven is set to rated or higher, the device may be damaged. Make sure to make an adjustment to design mode value of the machinery.

• Data setting range: 25.0 to 120.0 (Hz)

Inverter can perform setting of high speed operation easily. When changing the setting, make sure to check the motor and machine mode before use.

Injuries could occur. Failure may occur.

Note When changing maximum output frequency (F03) in order to make the operation frequency a larger value, change the frequency limiter (upper limit) (F15) as well.

F04, F05	Base frequency 1, Rated voltage at base frequency 1
F06	Maximum output voltage 1
	Related function codes: H50, H51 Non-linear V/f 1 (Frequency, voltage)
	H52, H53 Non-linear V/f 2 (Frequency, voltage)

Set the base frequency and base frequency voltage that are essential to operation of the motor. By combining related function codes H50 to H53, it is possible to set non-linear V/f pattern (weak or strong voltage by arbitrary point) and perform setting of V/f characteristics that is suitable for the load.

Impedance of the motor becomes larger with high frequency, and when output voltage becomes less, output torque may be reduced. In order to prevent this, increase the voltage at high frequency by setting function code F06 (maximum output voltage 1). However, it is not possible to output voltage at or higher than the input power voltage of the inverter.

	Function code		Demorika	
Point of V/r	Frequency	Voltage	Remarks	
Maximum output frequency	F03	F06	During auto torque boost, vector control with/ without speed sensor, the maximum output voltage setting is disabled.	
Base frequency	F04	F05		
Non-linear V/f 2	H52	H53	This code is disabled during auto torque boost, vector control	
Non-linear V/f 1	H50	H51	with/ without speed sensor.	

<Setting example>

Normal V/f pattern setting



Non-linear V/f pattern setting (2 points)



Figure 5.3-4

■ Base frequency (F04)

Set the data in accordance with rated frequency of the motor (given on the nameplate of the motor).

• Data setting range: 25.0 to 120.0 (Hz)

Rated voltage at base frequency (F05)

Set the data to "0" in accordance with rated voltage of the motor (given on the nameplate of the motor).

- Data setting range: 0 : AVR disable
 - 160 to 500 (V) : AVR operation (at 400 V class)
- When data is set to "0", the base frequency voltage becomes equivalent to inverter input voltage. When input voltage fluctuates, output voltage fluctuates as well.
- When data is set to arbitrary voltage other than "0", automatically keeps the output voltage constant. When control function such as auto torque boost and auto energy-saving operation is used, it is necessary to adjust to the rated voltage (given on the nameplate of the motor) of the motor.



The voltage that the inverter can output is lower than the input voltage of the inverter. Appropriately set the voltage in accordance with the motor.

■ Non-linear V/f 1, 2 (Frequency) (H50, H52)

Set frequency at the arbitrary point of non-linear V/f pattern.

• Data setting range: 0.0 (Cancel), 0.1 to 120.0 (Hz)

Note When 0.0 is set, the setting becomes the pattern without using non-linear V/f pattern.

■ Non-linear V/f 1, 2 (Voltage) (H51, H53)

Set voltage at the arbitrary point of non-linear V/f pattern.

Data setting range: 0 to 500 (V) : AVR operation (at 400 V class)

Maximum output voltage 1 (F06)

Set the voltage at maximum output frequency 1 (F03).

• Data setting range: 160 to 500 (V) : AVR operation (at 400V class)

Note When rated voltage at base frequency (F05) is "0", the data of non-linear V/f (H50 to H53, H65, and H66) and F06 becomes invalid (linear V/f for at or below base frequency, and constant voltage for at or higher than base frequency).

F07, F08	Acceleration time1, Deceleration time 1			
	Related function codes:			
	E10, E12, E14 Acceleration time 2, 3, 4			
	E11, E13, E15 Deceleration time 2, 3, 4			
	H07 Curve acceleration/deceleration			
	H56 Deceleration time for forced stop			

Acceleration time sets the time taken by the output frequency to reach the maximum output frequency from 0Hz, and deceleration time sets the time taken by the output frequency to reach 0Hz from the maximum frequency.

• Data setting range: 0.00 to 3600 (s)

For V/f control



Acceleration/Deceleration time

Type of	Function code		Salact ACC/DEC time			
Acceleration/decele ration time	Acceleration time	Deceleration time	(P Function code E01 to E05)			
ACC/DEC time 1	F07	F08	"RT2"	"RT1"	Switch by acceleration/deceleration selection "RT1" "RT2". (Data = 4 or 5)	
ACC/DEC time 1	FU7		OFF	OFF		
ACC/DEC time 2	E10	E11	OFF	ON	When there is no assignment, acceleration/deceleration time 1 (F07, F08) are valid.	
ACC/DEC time 3	E12	E13	ON	OFF		
ACC/DEC time 4	E14	E15	ON	ON		
At Force to stop	-	H56	Turning the Force to stop "STOP" command OFF causes the motor to decelerate to a stop in accordance with the deceleration time for forced stop (H56). After the motor stops, the inverter enters the alarm state with the alarm \mathcal{E}_{T} - \mathcal{E} displayed. (Data = 30)			

■ Curve acceleration/deceleration (H07)

Select acceleration/deceleration	nattern (change	nattern of frequency	at acceleration/deceleration
	pallenn (change	pattern of nequency	

H07 data	Curve acceleration/ deceleration	Action	
0	Disable (Linear acceleration/deceleration)	Acceleration/deceleration with constant ac	celeration.
1	S-curve acceleration/deceleration (Weak)	Smoothen the speed change and reduce shock when starting acceleration and right before the speed becomes	Weak: Fix acceleration/deceleration change rate to 5% of the maximum output frequency within each S-curve range.
2	S-curve acceleration/deceleration (Strong)	constant, as well as when starting deceleration and right before the deceleration stops.	Strong: Fix acceleration/deceleration change rate to 10% of the maximum output frequency within each S-curve range.
3	Curve acceleration/deceleration	Linear acceleration/deceleration (constant torque) at or below base frequency and acceleration becomes gradually slower at or higher than the base frequency, and acceleration/deceleration with constant load rate (rated output). It is possible to accelerate/decelerate with the maximum capability.	

S-curve acceleration/deceleration

For the purpose of decreasing the shock on the load machine side, smoothen the speed change at the start of acceleration and right before it becomes constant speed, and at the start of deceleration and right before the stop of deceleration. As for s-curve acceleration/deceleration values, fix with 5% (Weak) or 10% (Strong) for S-curve acceleration/deceleration/deceleration time determines acceleration of linear part and the actual acceleration/deceleration time becomes longer than the specified acceleration /deceleration time.



Acceleration/Deceleration time

< S-curve acceleration/deceleration (Weak): When frequency change is 10% or higher than the maximum frequency>

Acceleration or deceleration time (s) = $(2 \times 5/100 + 90/100 + 2 \times 5/100) \times$ reference acceleration or deceleration time

= $1.1 \times$ reference acceleration or deceleration time

< S-curve acceleration/deceleration (Strong): When frequency change is 20% or higher than the maximum frequency.>

Acceleration or deceleration time (s) = $(2 \times 10/100 + 80/100 + 2 \times 10/100) \times$ (reference acceleration or deceleration time)

= $1.2 \times$ (reference acceleration or deceleration time)

Curve acceleration/deceleration

This is a pattern to perform linear acceleration/deceleration (rated torque) at or below base frequency and acceleration becomes gradually slower at or higher than the base frequency, and acceleration/deceleration with constant load rate (rated output).

It is possible to accelerate/decelerate with the maximum capability of the motor to be driven by the inverter.



- Note When S-curve acceleration/deceleration and curve acceleration/deceleration is selected by curve acceleration/decele
 - If acceleration/deceleration time is set shorter than necessary, current limiting function, torque limit or anti-regenerative function may operate and acceleration/deceleration time may become longer than the set value.

500	Townships of 4	(Defects 507)
F09	lorque boost 1	(Refer to F37)

For details of torque boost 1 setting, refer to the section of function code F37.



In order to detect overload of motor (electronic thermal function by inverter output current), set temperature characteristics of motor (Select motor characteristics (F10), thermal time constant (F12), and overload detection level (F11).

When overload of motor is detected, inverter is turned off, protecting the motor with motor overload alarm 2/2 /.



Improper setting of the electronic thermal function may result in a failure to protect the motor from burning.

Note Temperature characteristics of motor is used for motor overload early warning "OL" as well. Even if only overload early warning is used, it is necessary to set temperature characteristics of the motor (F10, F12). (III) Function code E34)

For disabling motor overload alarm, set F11 = 0.00 (Disable).



For PTC thermistor built-in motor, by connecting PTC thermistor to terminal [C1], it is possible to protect the motor. Refer to H26 to find the details.

Select motor characteristics (F10)

F10 selects characteristics of cooling system of the motor.

F10 data	Function
1	Self-cooling fan of general-purpose motor (Self-cooling) (When operating with low frequency, cooling performance decreases.)
2	Inverter-driven motor, High-speed motor with separately powered cooling fan (Keep constant cooling capability irrespective to output frequency)

Figure 5.3-5 shows electronic thermal operation characteristics diagram when F10=1 is set. The characteristics coefficient α 1 and α 3 and the switch coefficient f2, f3 differ depending on the characteristics of the motor.

Each coefficient that is set by motor characteristics that is selected by motor capacitance and motor selection (P99) is shown in Table 5.3-2, Table 5.3-3 and Table 5.3-4.



Figure 5.3-5 Characteristics diagram of motor cooling system

Motor capacity	Thermal time	Thermal time constant setting	Characteristics coefficient switch frequency		Characteristics coefficient				
(Factory default)	Standard current value Imax	f2	fз	α1	α2	α3			
0.4, 0.75 kW		Continuous allowance current value x 150%		フ니ㅋ	75%	85%	100%		
1.1 to 3.0 kW			5 Hz Continuous		7112	85%	85%	100%	
5.5 to 11 kW	5 min			5 Hz	6Hz	90%	95%	100%	
15 kW				Continuous	Continuous		7Hz	85%	85%
18.5, 22 kW				5Hz	92%	100%	100%		
30 to 45 kW			Base	Base	54%	85%	95%		
55 to 90 kW	10 min		frequency ×	frequency ×	51%	95%	95%		
110 kW or above			33%	83%	53%	85%	90%		

Table 5.3-2 When $P99 = 0, 4$ (Notor characteristics 0, Othe	Table 5.3-2	When P99 = 0, 4	(Motor characteristics	0, Other)
--	-------------	-----------------	------------------------	-----------

Table 5.3-3	When P99 =	1 (Motor characteristics 1)
-------------	------------	----------------------------	---

Motor capacity	Thermal time	Thermal time constant setting	Characteristics coefficient switch frequency		Characteristics coefficient		stics nt	
	(Factory default)	Standard current value Imax	f2	fз	α1	α2	α3	
0.2 to 22 kW	5 min	Continuous	ntinuous Base	Base frequency × 33%	69%	90%	90%	
30 to 45 kW		allowance current value x 150%	frequency ×	Base	54%	85%	95%	
55 to 90 kW	10 min		value x 150% 55%	3376	frequency	51%	95%	95%
110 kW or above				× 83%	53%	85%	90%	

Motor capacity	Thermal time	Thermal time constant T		Characteristics coefficient switch frequency		Characteristics coefficient		
(F	(Factory default) Standard current value Imax	f2	fз	α1	α2	α3		
90 kW or below	5 min	Continuous allowance current value x 150%Base frequency x 33%	Base	53%	85%	95%		
110 kW or above	10 min		frequency × 33%	frequency × 83%	53%	85%	90%	

Table 5.3-4 When P99 = 20,21 (Motor characteristics)

When F10=2 is set, cooling effect by output frequency will not decrease, therefore, overload detection level becomes constant value (F11) without decrease.

Overload detection level (F11)

F11 sets operation level of electronic thermal.

Data setting range: 1 to 135% of the rated current value of inverter (continuous allowance current value)

Normally, set to the motor continuous allowance current (in general, about 1.0 to 1.1 times of motor rated current) when operating at base frequency.

For disabling electronic thermal as disable, set F11 = 0.00: Disable.

Thermal time constant (F12)

F12 sets thermal time constant of the motor. For overload detection level that is set by F11, set the electronic thermal operation time when 150% of current is flowing continuously. Thermal time constant of general-purpose motor of Fuji Electric and general motors is 5 minutes for 22 kW or lower, and 10 minutes (factory default state) for 30kW or higher.

• Data setting range: 0.5 to 75.0 (min)

(Example) When the data of function code F12 is set to "5" (5 minutes).

As shown in Figure 5.3-6, when 150% of current of operation level that was set flows for 5 minutes, motor overload (alarm $\frac{2}{L}$ /) protection function will operate. In addition, with 120%, it operates after 12.5 minutes.

The time when alarm actually occurs is shorter than the set data because the time until the current reaches 150% level after exceeding the continuous allowance current (100%) is considered.



Figure 5.3-6 Example of current-operation time characteristics

F14	Restart mode after momentary power failure (Mode selection)
	Related function codes: H13 (Restart timer)
	H14 (frequency lowering rate)
	H15 (Continuous running level)
	H16 (Allowable momentary power failure time)
	H92 Continuous running at the momentary power failure (P)
	H93 Continuous running at the momentary power failure (I)

Set the operation for when momentary power failure occurs (trip operation, restart operation method at auto-restarting)

Restart mode after momentary power failure (Mode selection) (F14)

V/f control (F42=0),	PM motor control(F42=15)
----------------------	--------------------------

F14 data	Operation contents		
F 14 dala	Without auto search	With auto search	
0: Trip immediately	When momentary power failure occurs while operating the inverter, and at the time when undervoltage is detected by the DC link bus voltage of the inverter, undervoltage alarm lu is outputted, the inverter output shuts down, and the motor coasts to a stop.		
1: Trip after a recovery from power failure	When momentary power failure occurs while operating the inverter, and at the time when undervoltage is detected by the DC link bus voltage of the inverter , the inverter output shuts down and the motor coasts to stop, but the undervoltage alarm will not be outputted. When auto-started from momentary power failure, undervoltage alarm lu is outputted.		
2: Trip after momentary deceleration is stopped	As soon as the DC link bus voltage drops below the power failure, decelerate-to-stop control is invoke	he continuous running level due to a momentary d.	
	Decelerate-to-stop control regenerates kinetic end down the motor and continuing the deceleration of undervoltage alarm lu is issued.	ergy from the load's moment of inertia, slowing operation. After decelerate-to-stop operation, an	
 Continue to run (for heavy inertia load 	As soon as the DC link bus voltage drops below t power failure, decelerate-to-stop control is invoke	he continuous running level due to a momentary d.	
or general load)	Decelerate-to-stop control regenerates kinetic energy from the load's moment of inertia, slowing down the motor, and operation is continued to wait for auto-restarting. If there is not enough energy for regeneration and when undervoltage is detected, the inverter output shuts down and the motor coasts to a stop.		
	If run command is entered at auto-restarting, restart from the frequency of when undervoltage is detected.	If run command is entered at auto-restarting, auto-searching is performed, motor speed is estimated, and restart from the frequency.	
	This setting is most suitable for the fan with large	inertia moment of load.	
4: Restart from frequency at power failure (for general load)	When momentary power failure occurs while open undervoltage is detected by the DC link bus voltage and the motor coasts to a stop.	rating the inverter, and at the time when ge of the inverter, the inverter output shuts down,	
	If run command is entered at auto-restarting, restart from the frequency of when undervoltage is detected.	If run command is entered at auto-restarting, auto-searching is performed, motor speed is estimated, and restart from the frequency.	
	This setting is most suitable for the case (fan) who speed does not decrease so much even if the mo failure.	en load inertial moment is large, and motor tor coasts to a stop due to momentary power	
5: Restart from starting frequency	When momentary power failure occurs while operating the inverter, and at the time when undervoltage is detected by the DC link bus voltage of the inverter, the inverter output shuts dowr and the motor coasts to a stop.		
	If run command is entered at auto-restarting, restart from the starting frequency that was set by function code F23.	If run command is entered at auto-restarting, auto-searching is performed, motor speed is estimated, and restart from the frequency.	
	This setting is most suitable for the case (pump er load is heavy, and motor speed decreases up to 0 due to momentary power failure.	tc.) when load inertia moment is small, when the) in a short time after the motor coasts to a stop	
With auto-searching: Aut Refer function code H09/d6	o-searching is selected by starting mode sele 7 (Starting mode) to find the detail of starting mode	ection "STM" ON or H09/d67 = 1 or 2. e selection "STM" ON auto-searching.	

When momentary power failure restart operation (F14 = 3 to 5) is selected, operation will resume automatically at auto-restarting. Design your machinery so that safety is ensured even at restarting.

Otherwise an accident could occur.

Restart mode after momentary power failure (Basic operation: Without auto-searching setting)

When inverter detected that DC link bus voltage becomes at or drops below undervoltage level while operating, it is judged as a momentary power failure. When load is light and momentary power failure is very short, momentary power failure may not be detected and motor operation might be continued because DC link bus voltage does not drop so much.

When inverter judges the state as momentary power failure, returns to momentary power failure restart mode and prepares for restart. After power is auto-restarted, the inverter becomes at inverter ready to run state after elapse of initial charging time. At momentary power failure, power of external circuit (relay circuit etc.), which controls the inverter, decreases as well, and run command may be turned off. Therefore, when the inverter becomes at inverter ready to run state, wait 2 seconds for input of run command. When input of run command is confirmed within 2 seconds, initiate restarting according to F14 (mode selection). When there is no input of run command at run command input waiting state, momentary power failure restart mode will be released and start from normal starting frequency. Therefore, input run command within 2 seconds after auto-restarting or hold run command by off-delay timer or mechanical latch relay.

In case of F02=0 (run command from keypad and rotation direction command determined by terminal), it operates in the same way as above. For rotation direction fixed mode (F02 = 2, 3), run command is held within the inverter, therefore, it restarts immediately at inverter ready to run state.



- Note
- At auto-restarting, inverters waits 2 seconds for input of run command, however, if allowable momentary power failure time (H16) is elapsed after the state is judged as power failure, the state of run command input waiting for 2 seconds will be canceled and normal starting operation is performed.
- When coast to a stop command "BX" is entered during power failure, momentary power failure restart waiting state is released and return to normal run mode, and when run command is inputted, start from normal starting frequency.
- Detection of momentary power failure within the inverter is performed by detecting DC link bus voltage drop of the inverter. With the structure in which a magnetic contactor is equipped on the output side of the inverter, there will be no operation power of the magnetic contactor at momentary power failure and the magnetic contactor becomes at open state. When the magnetic contactor becomes open, connection of inverter and motor is released and load of the inverter is shutdown. Therefore, it becomes difficult to decrease DC link bus voltage of the inverter and it may not be judged as a momentary power failure. If this is the case, momentary power failure restart will not be performed normal. As a countermeasure against this case, by connecting auxiliary contact signal of the magnetic contactor to the interlock signal "IL" it is possible to detect momentary power failure without fail. Function code E01 to E05 Data = 22

Terminal command "IL"	Meaning
OFF	No momentary power failure has occurred.
ON	A momentary power failure has occurred. (Restart after a momentary power failure enabled)

When motor speed decreases during momentary power failure, and when restarting from frequency of before momentary power failure after power is recovered (auto-restarting), current limiter becomes active and output frequency of the inverter decreases automatically. When output frequency and motor rotation speed synchronize, the speed is accelerated up to the original output frequency. Refer to the figure below. However, it is necessary to enable instantaneous overcurrent limiting (H12 = 1) to bring in synchronization of the motor.



· Auto-restarting after momentary power failure "IPF"

During momentary power failure auto-restarting "IPF" signal is turned on until returning to original frequency after auto-restarting after momentary power failure occurred. When "IPF": is turned ON, motor speed decreases, therefore, take necessary measures. (

Restart mode after momentary power failure (Basic operation: With auto-searching setting)

Auto-searching is not performed normally if there is residual voltage of the motor.

Therefore, it is necessary to secure the time until residual voltage runs out.

Restart mode after momentary power failure secures the necessary time with function code H46 starting mode (auto search delay time 2). Even if starting conditions are satisfied, inverter does not start unless auto-search delay time elapses after inverter goes into OFF state. Inverter starts after elapse of auto-searching delay time.



- When operating auto-searching, it is necessary to perform auto-tuning in advance.
 - When the estimated speed exceeds the maximum frequency or the upper limit frequency, the inverter disables auto search and starts running the motor with the maximum frequency or the upper limit frequency, whichever is lower.
 - During auto search, if an overcurrent or overvoltage trip occurs, the inverter will restart the auto search.
 - Use 60 Hz or below for auto-searching

Note

- Note that auto search may not fully provide the performance depending on load conditions, motor parameters, wiring length, and other external factors.
- When output circuit filter OFL-DD-2, -4 is equipped on the output side of the inverter, auto-searching must be disabled. Use OFL-DD-DA type.
- If using permanent magnetic type synchronous motors to restart following a momentary power interruption, do not set d67 = 0.

Restart mode after momentary power failure (Allowable momentary power failure time) (H16)

Sets the maximum time from when momentary power failure (undervoltage level) occurs until restart (setting range: 0.0 to 30.0 s). Set coast to a stop time which is allowable for machine and equipment. Momentary power failure restart operation should be performed within the specified time, however, if the set time is exceeded, the inverter judges the state as a power shut down, and then operates as powering on again without performing momentary power failure restart operation.



When allowable momentary power failure time (H16) is set to "999", momentary power failure restart is performed until DC link bus voltage decreases by momentary power failure restart allowance voltage (100 V for 400 V class), however, if the voltage becomes at or below the momentary power failure allowance voltage, the state is judged as a power shut down. As a result, the inverter operates as powering ON again without performing momentary power failure restart operating.

Power supply voltage	Allowance voltage of momentary power failure restart
400V	100V

Note

The time until voltage decreases to the momentary power failure restart allowance voltage from undervoltage differs greatly depending on the inverter capacity and with/without option.

Restart mode after momentary power failure (Restart timer) (H13) (Exclusive to V/f control for IM)

H13 set the time until restart is performed after momentary power failure occurred. (At auto-searching setting, use H46 (auto search holding time 2)).

Restarting at the state when residual voltage of the motor is high, inrush current becomes greater or temporarily becomes at regeneration state, and overcurrent alarm may occur. For security reason, in order to restart after residual voltage is reduced to some extent, adjust H13. Even if auto-restarted, restart cannot be performed until the holding time (H13) elapses.



Factory default: At the factory default state, setting is performed so that it is appropriate to the standard motor (refer to "5.2.3 Factory default value per applicable electric motor capacitance"). Basically, there is no need to modify the default setting. However, when problems occur due to the long holding time or decrease in flow rate of pump becomes significant, change to about half of the standard value and make sure that alarm etc. will not occur.

Restart Mode after Momentary Power Failure (H14)(Exclusive to V/f control for IM)

At momentary power failure restart operation, when inverter output frequency and motor rotation speed does not synchronize, overcurrent occurs and current limiter will operate. when current limit is detected, automatically decrease the output frequency and synchronize with the motor rotation speed. H14 sets the slope of lowering output frequency (frequency lowering rate in Hz/s).

H14 data	Output frequency lowering operation
0.00	Decrease by the selected deceleration time.
0.01 to 100.00 (Hz/s)	Decrease by the lowering rate that is set by H14.
999	Depending on the PI regulator of current limiting processing (PI constant is fixed value within the inverter), the rate will decrease.

Note

When frequency lowering rate is increased, regeneration operation is performed at the moment when output frequency of the inverter and rotation speed of inverter synchronize, and overvoltage trip may occur. When frequency lowering rate is reduced, the time until output frequency of the inverter and motor rotation speed synchronize (current limiting operation) becomes longer, and protection operation of inverter overload may be activated.

Restart mode after momentary power failure (Continuous running level) (H15) Continued operation at the momentary power failure (P, I) (H92, H93)

• Trip after momentary deceleration is stopped

When trip after deceleration stopped is selected (F14 = 2), at momentary power failure restart operation (Mode selection), momentary power failure occurs while operating the inverter, and deceleration stop control starts when DC link bus voltage of the inverter becomes at or drops below the continuous running level.

Adjust voltage level of DC link bus to start deceleration stop control by H15.

Under decelerate-to-stop control, the inverter decelerates its output frequency keeping the DC link bus voltage constant using a PI regulator.

P (proportional) and I (integral) components of the PI regulator are specified by H92 and H93, respectively.

For normal inverter operation, it is not necessary to modify data of H15, H92 or H93.

Continue to run

When momentary power failure restart operation (Continue to run) is selected (F14 = 3) at momentary power failure restart (operation selection), momentary power failure occurs while operating the inverter and continue to run control starts when DC link bus voltage of the inverter becomes at or drops below the continue to run level.

Adjust continue to run level to start continue to run control by H15.

Under the continue to run control, the inverter continues to run keeping the DC link bus voltage constant using the PI regulator.

P (proportional) and I (integral) components of the PI regulator are specified by H92 and H93, respectively. For normal inverter operation, it is not necessary to modify data of H15, H92 or H93.



	Alpha (α)		
Power supply group	FRN0060F2E-4G or below	FRN0075F2E-4G or above	
400 V	10 V	20 V	

Note Even if "Deceleration stop control" or "Continue to run", is selected, the inverter may not be able to perform the function when the inertia of the load is small or the load is heavy, due to undervoltage caused by the control delay. In such a case, when "Deceleration stop control" is selected, the inverter allows the motor to coast to a stop; when "Continue to run" is selected, the inverter saves the output frequency being applied when the undervoltage alarm occurs and perform momentary power failure restart operation.

When the input power voltage for the inverter is high, setting the continue to run level high makes the control more stable even if the inertia of the load is relatively small. Raising the continuous running level too high, however, might cause the continue to run control activated even during normal operation.

When the input power voltage for the inverter is extremely low, continue to run control might be activated even during normal operation, at the beginning of acceleration or at an abrupt change in load. To avoid this, lower the continuous running level. Lowering it too low, however, might cause undervoltage that results from voltage drop due to the control delay.

Before you change the continuous running level, make sure that the continuous running control will be performed properly, by considering the fluctuations of the load and the input voltage.

F15, F16 Frequency limiter (Upper limit), Frequency limiter (Lower limit) Related function codes: H63 Lower limit Limiter (Mode selection)

Frequency limiter (Upper limit) (Lower limit) (F15, F16)

F15 and F16 specify the upper and lower limits of the output frequency or reference frequency, respectively.

Frequency Limiter			Object to which the limit is applied	
Frequency	limiter (Upper)	F15	Output frequency	
Frequency limiter (Lower) F16		F16	Reference frequency	
Note	When the limit is appli control may cause an limit level.	is applied to the reference frequency or reference speed, delayed responses o use an overshoot or undershoot, and the frequency may temporarily go beyond		

• Data setting range: 0.0 to 120.0 (Hz)

■ Low Limiter (Mode selection) (H63)

H63 specifies the operation to be carried out when the reference frequency drops below the low level specified by F16, as follows:

H63 data	Action
0	The output frequency will be held at the low level specified by F16.
1	The inverter decelerates to stop the motor.

Refer to the figure below.



Note

- When changing the frequency limiter (Upper) (F15) in order to raise the reference frequency, be sure to change the maximum frequency (F03) accordingly.
- Set each function code related to operation frequency so that the relationship among data becomes the following magnitude relationship.
 - F15>F16, F15>F23, F15>F25
 - F03>F16

However, F23 is the starting frequency, and F25 is stop frequency

If any wrong data is specified for these function codes, the inverter may not run the motor at the desired speed, or cannot start it normally.



Refer to the description of function code F01 to find the details of bias (Frequency setting 1) setting.

F20 to F22	DC braking1 (Starting frequency, braking level, braking time)
H95	DC braking (Braking response mode)
H195	DC braking (Braking timer at the startup)

These function codes specify the DC braking that prevents motor 1 from running by inertia during decelerate-to-stop operation.

If the motor enters a decelerate-to-stop operation by turning OFF the run command or by decreasing the reference frequency below the stop frequency, the DC braking starts when output frequency reached the DC braking starting frequency. Set braking starting frequency (F20), braking level (F21), and braking time (F22) to start DC braking when deceleration is stopped.

Setting the braking time to "0.00" (F22 = 0) disables the DC braking.

By H195, it is possible to perform DC braking when starting up inverter. By doing so, it is efficient for preventing from falling down when the brake is released, and prompt torque startup when starting up.

Braking starting frequency (F20)

F20 specifies the frequency at which the DC braking starts its operation during motor decelerate-to-stop state.

• Data setting range: 0.0 to 60.0 (Hz)

Braking level (F21)

F21 specifies the output current level to be applied when the DC braking is activated. The function code data should be set, assuming the rated output current of the inverter as 100%, in increments of 1%.

• 0 to 80%

Braking time (F22)

F22 specifies the braking period that activates DC braking.

• Data setting range: 0.00 (Disable), 0.01 to 30.00 (s)

Braking response mode (H95)

H95 data	Characteristics	Note
0	Slow response. Slows the rising edge of the current, thereby preventing reverse rotation at the start of DC braking.	Insufficient braking torque may result at the start of DC braking.
1	Quick response. Quickens the rising edge of the current, thereby accelerating the build-up of the braking torque.	Reverse rotation may result depending on the moment of inertia of the mechanical load and the coupling mechanism.

H95 specifies the DC braking response mode.



Tip It is also possible to input DC braking command "DCBRK" by using an external digital input signal as the terminal command. As long as the DCBRK is ON, the inverter performs DC braking, regardless of the braking time specified by F22.

(Refer to function code E01 to E05 Data =13 to find the details of "DCBRK")

Turning the "DCBRK" ON even when the inverter is in a stopped state activates the DC braking. This feature allows the motor to be excited before starting, resulting in smoother acceleration (quicker build-up of acceleration torque) (under V/f control).

Depending on the timing of the activation of "DCBRK", alarm of overvoltage or overcurrent occurs.



In general, specify data of function code F20 at a value close to the rated slip frequency of motor. If an extremely high value is set, control may become unstable and an overvoltage alarm may result in some cases.

The DC braking function of the inverter does not provide any holding mechanism.

Injuries could occur.

Braking timer at the startup (H195)

When starting up inverter by run command, it is possible to start by operating DC braking.

This is particularly useful in applications such as hoists and elevators where the inverter runs at low speed braking mode after starting up, preventing loads from falling.

• Data setting range: 0.00: No DC braking at the start up 0.01 to 30.00 (s)



F23 to F25 Starting frequency 1, Starting frequency 1 (Holding time) and Stop frequency

Under V/f control

At the startup of an inverter, the initial output frequency is equal to the starting frequency. The inverter stops its output when the output frequency reaches the stop frequency. Set the starting frequency to a level at which the motor can generate enough torque for startup. Generally, set the rated slip frequency of the motor as the starting frequency.

Specifying the holding time for the starting frequency compensates for the delay time for the establishment of a magnetic flux in the motor; specifying that for the stop frequency stabilizes the motor speed at the stop of the inverter.





Starting frequency 1 (F23)

F23 specifies the starting frequency at the startup of an inverter.

 Data setting range: 0.0 to 60.0 (Hz) Under V/f control, even if the start frequency is set at 0.0 Hz, the inverter starts its output at 0.1 Hz.

Starting frequency 1 (Holding time) (F24)

F24 specifies the holding time for the starting frequency 1.

Data setting range: 0.00 to 10.00 (s)

Stop frequency (F25)

F25 specifies the stop frequency at the stop of the inverter.

 Data setting range: 0.0 to 60.0 (Hz) Under V/f control, even if the stop frequency is set at 0.0 Hz, the inverter stops its output at 0.1 Hz.



If the starting frequency is lower than the stop frequency, the inverter does not output any power as long as the reference frequency does not exceed the stop frequency.

F26, F27

Motor Sound (Carrier frequency, Tone) Related function codes: H98 Protection/Maintenance function (Mode selection)

Motor Sound (Carrier frequency) (F26)

Adjust carrier frequency. By changing carrier frequency, it is possible to reduce an audible noise generated by the motor or electromagnetic noise from the inverter itself, and to decrease a leakage current from the main output (secondary) wiring.

Item	Characteristics		
Carrier frequency	Low	to	High
Motor sound noise emission	High	\leftrightarrow	Low
Motor temperature (due to harmonics components)	High	\leftrightarrow	Low
Ripples in output current waveform	Large	\leftrightarrow	Small
Leakage current	Low	\leftrightarrow	High
Electromagnetic noise emission	Low	\leftrightarrow	High
Inverter loss	Low	\leftrightarrow	High

Setting range of carrier frequency is as follows.

Model and Modes	Carrier frequency
FRN0002 to 0045F2E-4G	0.75 to 16 kHz
FRN0060 to 0150F2E-4G	0.75 to 10 kHz
FRN0176F2E-4G or above	0.75 to 6 kHz

Note Specifying a carrier frequency that is too low will cause the output current waveform to have a large amount of ripple. As a result, the motor loss increases, causing the motor temperature to rise. Furthermore, the large amount of ripple tends to cause a current limiting alarm. When the carrier frequency is set to 1 kHz or lower, therefore, reduce the load so that the inverter output current comes to be 80% or less of the rated current.

When a high carrier frequency is specified, the temperature of the inverter may rise due to the ambient temperature rise or an increase of the load. If it happens, the inverter automatically decreases the carrier frequency to prevent the inverter overload ($\Box'_{L} L'$). With consideration for motor noise, the automatic reduction of carrier frequency can be disabled. Refer to the description of H98.

Running a PMSM at low carrier frequency may overheat the permanent magnet due to the output current harmonics, resulting in demagnetization. When decreasing the carrier frequency setting, therefore, be sure to check the allowable carrier frequency of the motor.

When using a Fuji standard PMSM with the rated load, decrease the carrier frequency. Setting a high carrier frequency decreases not only the harmonic components of the output current but also the allowed continuous running inverter output current.

Motor Sound (Tone) (F27)

F27 changes the motor running sound tone (only for motors under V/f control). This setting is effective when the carrier frequency specified by function code F26 is 7 kHz or lower. Changing the tone level may reduce the high and harsh running noise from the motor.

Note

If the tone level is set too high, the output current may become unstable, or mechanical vibration and noise may increase. Also, this function code may not be very effective for certain types of motor.

F27 data	Function	
0	Disable (Level 0)	
1	Enable (Level 1)	
2	Enable (Level 2)	
3	Enable (Level 3)	

F29 to F35

Terminal [FM1], [FM2] (Mode selection, Output gain, Function selection, Pulse rate)

These function codes allow outputting monitor data such as output frequency and output current to terminals [FM1], [FM2] as analog DC voltage, current, and pulse ([FM1] only). In addition, voltage and current output level on terminals [FM1], [FM2] is adjustable.



When switching voltage, current, and pulse, it is necessary to switch both mode selection function code and switch on the PCB.

There is no pulse output function for terminal [FM2]

Terminal	Mode selection function	Gain	Function	Pulse rate	Switch
[FM1]	F29	F30	F31	F33	SW5
[FM2]	F32	F34	F35	None	SW7

Mode selection (F29, F32)

F29 and F32 select output form of terminals [FM1], [FM2]. Accordingly ,change the switches SW5, SW7 on the control PCB.

For details of the switches on the control PCB, refer to Chapter 12 "SPECIFICATIONS."

F29 data	Terminal [FM1] output form	Control PCB switch (SW5)	
0	Voltage output (0 to +10 VDC)	FMV side	
1	Current output (4 to 20 mA DC)		
2	Current output (0 to 20mA DC)	- FMI side	
3	Pulse output	FMP side	

F32 data	Terminal [FM2] Output form	Control PCB switch (SW7)
0	Voltage output (0 to +10 VDC)	FMV side
1	Current output (4 to 20 mA DC)	
2	Current output (0 to 20mA DC)	FIVII Side

Note

The output current is not isolated from analog input, and does not have an isolated power supply.

Therefore, if an electrical potential relationship between the inverter and peripheral equipment has been established, e.g., by connecting an analog input, cascade connection of a current output device is not available.

Keep the optimum connection wire length.

■ Output gain (F30, F34)

F30, F34 allows you to adjust the output voltage within the range of 0 to 300%.



■ Function selection (F31, F35)

F31, F35 specify which data is monitored at the output terminals [FM1], [FM2].

F31/F35 data	[FMA] output	Data	Definition of monitor amount 100%
0	Output frequency 1 (PM: Speed command value)	Output frequency of the inverter	Maximum frequency (F03)
1	Output frequency 2 (PM: Speed estimated value)	Output frequency of the inverter	Maximum frequency (F03)
2	Output current	Output current (RMS) of the inverter	Twice the inverter rated current (Inverter rated output current depending on F80 setting)
3	Output voltage	Output voltage (RMS) of the inverter	400 V class: 500 V
4	Output torque	Motor shaft torque	Twice the rated motor torque
5	Load factor	Load factor (Equivalent to the indication of the load meter)	Twice the rated motor load
6	Input power	Input power of the inverter	Twice the rated output power (Inverter rated output power depending on F80)
7	PID feedback value	Feedback value under PID control	100% of the feedback amount
8	Estimated speed	Estimated speed under vector control without speed sensor	Maximum speed as 100%
9	DC link bus voltage	DC link bus voltage of the inverter	400 V class: 1000 V
10	Universal AO	Command from communication (RS-485 communication user manual)	20,000/100%
13	Motor output	Motor output (kW)	Twice the rated motor output (P02/A16 setting value)
14	Calibration (+)	For meter calibration Full scale output	Always full scale (equivalent to 100%) Output
15	PID command (SV)	Command value under PID control	PID command 100%
16	PID output (MV)	Output level of the PID processor under PID control (Frequency command)	Maximum frequency (F03)
18	Inverter heat sink temperature	Heat sink detection temperature of inverter	200°C/100%

F31/F35 data	[FMA] output	Data	Definition of monitor amount 100%
20	Reference frequency	Reference frequency	Maximum frequency (F03) / 100%
60	External PID control1 feedback value (EPID1-PV)	External PID control1 feedback value	100% / 100%
61	External PID control1 command (EPID1-SV)	External PID control1 command	100% / 100%
65	External PID control1 output (EPID1-OUT)	External PID control1 output	Maximum frequency (F03) / 100%
111	Customizable logic output signal 1	Enable only at analog output	100% / 100%
112	Customizable logic output signal 2	Enable only at analog output	100% / 100%
113	Customizable logic output signal 3	Enable only at analog output	100% / 100%
114	Customizable logic output signal 4	Enable only at analog output	100% / 100%
115	Customizable logic output signal 5	Enable only at analog output	100% / 100%
116	Customizable logic output signal 6	Enable only at analog output	100% / 100%
117	Customizable logic output signal 7	Enable only at analog output	100% / 100%
118	Customizable logic output signal 8	Enable only at analog output	100% / 100%
119	Customizable logic output signal 9	Enable only at analog output	100% / 100%
120	Customizable logic output signal 10	Enable only at analog output 100% / 100%	

Pulse rate (F33)

F33 specifies the pulse rate at which the output of the monitored item selected reaches 100%, in accordance with the modes of the pulse counter to be connected.

• Data setting range: 25 to 32000 (pulse/s)

Pulse output waveform







F37

Load Selection/Auto Torque Boost/Auto Energy Saving Operation 1 Related function codes: F09 Torque boost 1

F37 specifies V/f pattern, torque boost type, and auto energy saving operation in accordance with the characteristics of the load.

F37 data	V/f characteristics	Torque boost	Auto Energy-saving Operation	Applicable load
0	Variable torque V/f pattern	By F09 torque		Variable torque load (General-purpose fan and pumps)
1		DOOSI	Disabled	Constant torque load
2	Linear V/f pattern	Auto torque Boost		Constant torque load (To be selected if a motor may be over-excited at no load)
3	Variable torque V/f pattern	By F09 torque	Enabled	Variable torque load (General-purpose fan and pumps)
4		DOOST		Constant torque load
5	Linear V/f pattern	Auto torque Boost		Constant torque load (To be selected if a motor may be over-excited at no load)



If a required "load torque + acceleration toque" is 50% or more of the rated torque, it is recommended to select the linear V/f pattern. Factory defaults are set to linear V/f pattern.

V/f characteristics

The FRENIC-eHVAC series of inverters offer a variety of V/f patterns and torque boosts, which include V/f patterns suitable for variable torque load such as general fans and pumps and for constant torque load (including special pumps requiring high starting torque). Two types of torque boosts are available: manual and automatic.



When the variable torque V/f pattern is selected (F37 = 0 or 3), the output voltage may be low at a low frequency zone, resulting in insufficient output torque, depending on the characteristics of the motor and load. In such a case, it is recommended to increase the output voltage at the low frequency zone using the non-linear V/f pattern.

Recommended value: H50 = 1/10 of the base frequency H51 = 1/10 of the voltage at base frequency



Torque boost

Tip

Manual torque boost by F09 (Manual adjustment)

• Data setting range: 0.0 to 20.0 (%), (100%/base frequency voltage)

In torque boost using F09, constant voltage is added to the basic V/f pattern, regardless of the load. To secure a sufficient starting torque, manually adjust the output voltage to optimally match the motor and its load by using F09. Specify an appropriate level that guarantees smooth Startup and yet does not cause over-excitation at no or light load.

Torque boost using F09 ensures high driving stability since the output voltage remains constant regardless of the load fluctuation.

Specify the function code F09 data in percentage to the base frequency voltage. At factory shipment, boost amount with which approx. 100% of starting torque can be assured, is specified.

- Note
 Specifying a high torque boost level will generate a high torque, but may cause overcurrent due to over-excitation at no load. If you continue to drive the motor, it may overheat. To avoid such a situation, adjust torque boost to an appropriate level.
 - When the non-linear V/f pattern and the torque boost are used together, the torque boost takes effect below the frequency on the non-linear V/f pattern's point.



Output voltage (V)

Auto torque boost

This function automatically optimizes the output voltage to fit the motor with its load. Under light load, auto torque boost decreases the output voltage to prevent the motor from over-excitation. Under heavy load, it increases the output voltage to increase the output torque of the motor.

Note

This function controls in accordance with motor characteristics. Therefore, set the base frequency 1 (F04), rated voltage at base frequency 1 (F05), and other pertinent motor parameters (P01 through P03 and P06 through P99) in line with the motor capacity and characteristics, or else perform auto-tuning (P04).

• When a special motor is driven or the load does not have sufficient rigidity, the maximum torque might decrease or the motor operation might become unstable. In such cases, do not use auto torque boost but choose manual torque boost using F09 (F37 = 0 or 1).

F40, F41	Torque limiter 1 (Driving), Torque limiter 1 (Braking)	
	Related function codes:	
	E16, E17 Torque limiter 2 (Driving), Torque limiter 2 (Braking)	
	H76 Torque control (Braking) (Frequency rising limit for braking)	

Under V/f control (F42=0)

If the inverter output torque exceeds the specified levels of the torque limiters (F40, F41, E16, E17), the inverter controls the output frequency and limits the output torque for preventing a stall.

To use the torque limiters, it is necessary to configure the function codes listed in Table 5.3-5.

Note In braking, the inverter increases the output frequency to limit the output torque. Depending on the conditions during operation, the output frequency could dangerously increase. H76 (Frequency rising limit for braking) is provided to limit the increasing frequency component.

Function code	Name	V/f control	Remarks
F40	Torque limiter 1 (Driving)	Y	
F41	Torque limiter 1 (Braking)	Y	
E16	Torque limiter 2 (Driving)	Y	
E17	Torque limiter 2 (Braking)	Y	
H76	Torque limiter (Frequency rising limit for braking)	Y	

Table 5.3-5	Related function codes

Torque limit control mode

Torque limit is performed by limiting torque current flowing across the motor.

The graph below shows the relationship between the torque and the output frequency at the constant torque current limit.



■ Torque limiter (F40, F41, E16, E17) Data setting range: 20 to 150%; 999 (Disable)

These function codes specify the operation level at which the torque limiters become activated, as the percentage of the motor rated torque.

Function code	Name	Torque limit feature
F40 Torque limiter 1 (Driving)		Driving torque current limiter 1
F41	Torque limiter 1 (Braking)	Braking torque current limiter 1
E16	Torque limiter 2 (Driving)	Driving torque current limiter 2
E17	Torque limiter 2 (Braking)	Braking torque current limiter 2

Note Although the setting range of the torque is 150%, the torque limiter determined by the overload current of the unit internally limits the torque current output. Therefore, the torque current output is automatically limited at a value lower than 150%, the maximum setting value.

■ Torque limiter levels specified via communications link (S10, S11)

The torque limiter levels can be changed via the communications link. Communication dedicated codes S10, S11 interlock with the function codes F40, F41.

Switching torque limiters

The torque limiters can be switched by the function code setting and the terminal command "TL2/TL1" (Select torque limiter level 2/1) assigned to any of the digital input terminals. To assign the Torque limiter 2/Torque limiter 1, "TL2/TL1" set Data = 14 in function codes from E01 to E05. If no "TL2/TL1" is assigned, torque limiter levels 1-1 and 1-2 (F40 and F41) take effect by default.





■ Torque limiter (Braking) (Frequency rising limit for braking) (H76) Data setting range: 0.0 to 120.0 (Hz)

H76 specifies the rising limit of the frequency in limiting torque for braking. The Factory defaults are 5.0 Hz. If the increasing frequency during braking reaches the limit value, the torque limiters no longer function, resulting in an overvoltage trip. Such a problem may be avoided by increasing the setting value of H76.

Note

The torque limiter and current limiter are very similar in function. If both are activated concurrently, they may conflict with each other and cause hunting. Avoid concurrent activation of these limiters.

Under vector control without speed sensor nor pole position sensor (PMSM) (F42=15)

When a PMSM is driven under vector control without speed sensor nor pole position sensor, the torque limiters are used like as IM driven under vector control without speed sensor.



When switching control target motor and control method with the function code F42, the Factory defaults are also switched.

The factory default for PMSM is 150%.

Function code	Name	Vector control	Remarks	
F40	Torque limiter 1 (Driving)	Y	Factory defaults are "150%"	
F41	Torque limiter 1 (Braking)	Y	(F42=15)	
E16	Torque limiter 2 (Driving)	Y	Factory defaults are "999"	
E17	Torque limiter 2 (Braking)	Y		

Table 5.3-6 Related function codes

F42

Drive control selection 1

F42 specifies the motor drive control.

F42 data	Control mode	Basic control	Speed feedback	Speed control
0	V/f control for induction motor without slip compensation	V/f control	Disable	Frequency control
15	Vector control for synchronous motor without speed sensor nor pole position sensor	Vector control	Estimated speed	Speed control with automatic speed regulator (ASR)

■ V/f control for induction motor without slip compensation (F42=0)

Under this control, the inverter controls an induction motor with the voltage and frequency according to the V/f pattern specified by function codes.

■ Vector control for synchronous motor without speed sensor nor pole position sensor (F42=15)

This control estimates the motor speed based on the inverter's output voltage and current, and uses the estimated speed for speed control. It also decomposes the motor drive current into the exciting and torque current components, and controls each of those components as vectors. No PG (pulse generator) interface card is required. It is possible to obtain the desired response by adjusting the control constants (PI constants) using the speed regulator (PI controller).



When changing function code F42 to data 15 "Vector control for synchronous motor without speed sensor nor pole position sensor" by the keypad, then the inverter automatically updates data of F03, F04, F05 and others.

Control parameters which are initialized when the control method F42 is changed

When control method (F42) is switched between synchronous motor and induction motor, the data of related function codes are also switched to the default value. See the table below.

Function code	Switch F42 between 0 and 15	Change P02	H03=2 with F42=0	H03=2 with F42=15
F03	Y	N	N	N
F04	Y	N	Ν	Y
F05	Y	N	Ν	Y
F06	Y	N	N	Y
F10	Ν	N	N	Y
F11	Y	N	Ν	Y
F12	Y	N	Ν	Y
F15	Y	N	Ν	Ν
F23	Y	N	N	N
F26	Y	N	Ν	Ν
F40, F41	Y	N	Ν	Ν
E50	Y	N	Ν	Ν
P01	Y	N	Y	Y
P02	Ν	N	Ν	Ν
P03	Y	Y	Y	Y
P06 to P08	Ν	Y	Y	Y
P30	Ν	Y	Y	Y
P60 to P64	Ν	Y	Y	Y
P65	Ν	Y	Y	Y
P74	Ν	Y	Y	Y
P83	Ν	Y	Y	Y
P84	Ν	Y	Y	Y
P85	Ν	Y	Y	Y
P87 to P89	Ν	Y	Y	Y
P90	Ν	Y	Y	Y
P99	Y	N	Ν	Ν
H46	Ν	Y	Y	Y
d01 to d04	Y	N	Ν	Ν

Y: Switched N: Not switched

F43, F44

Current limiter (Mode selection and Level) Related function codes: H12 Instantaneous overcurrent limiting (Mode selection)

When the output current of the inverter exceeds the level specified by the current limiter (F44), the inverter automatically manages its output frequency to prevent a stall and limits the output current. According to limit value based on Inverter's rated current, the default setting of the current limiter is 130% for HND/ND mode. If overload current, higher than the current limiter level, flows instantaneously so that the output frequency decrease due to the current limiter causes a problem, consider to increase the current limiter level.

The current limiter mode should be also selected with F43. If F43 = 1, the current limiter is enabled only during constant speed operation. If F43 = 2, it is enabled during both of acceleration and constant speed operation. Choose F43 = 1 if you need to run the inverter at full capability during acceleration and to limit the output current during constant speed operation.

Mode selection (F43)

F43 selects the motor running state in which the current limiter becomes active.

E42 data	Running states that enable the current limiter			
F43 Uala	During acceleration	During constant speed	During deceleration	
0	Disabled	Disabled	Disabled	
1 Disabled		Action	Disabled	
2	Action	Action	Disabled	

Level (F44)

F44 specifies the operation level at which the output current limiter becomes activated, as a ratio of the inverter rating.

 Data setting range: 20 to 150 (%) of rated current of the inverter (Inverter's rated current changes according to the setting value of function code F80.)

■ Instantaneous overcurrent limiting (Mode selection) (H12)

H12 specifies whether the inverter invokes the current limit processing or enters the overcurrent trip when its output current exceeds the instantaneous overcurrent limiting level. Under the current limit processing, the inverter immediately turns OFF its output gate to suppress the further current increase and continues to control the output frequency.

H12 data	Function
0	Disable (An overcurrent trip occurs at the instantaneous overcurrent limiting level.)
1	Enable (An instantaneous overcurrent limiting operation is activated)

If any problem could occur when the motor torque temporarily drops during current limiting processing, it is necessary to cause an overcurrent trip (H12 = 0) and actuate a mechanical brake at the same time.

Note • Since the current limit operation with F43 and F44 is performed by software, it may cause a delay in control. If you need a quick response current limiting, also enable the instantaneous overcurrent limiting with H12.

- If an excessive load is applied when the current limiter operation level is set extremely low, the inverter will rapidly lower its output frequency. This may cause an overvoltage trip or dangerous turnover of the motor rotation due to undershooting. Depending on the load, extremely short acceleration time may activate the current limiting to suppress the increase of the inverter output frequency, causing hunting (undesirable oscillation of the system) or activating the inverter overvoltage trip (alarm *I*⁽¹⁾/₂). When specifying the acceleration time, therefore, you need to take into account machinery characteristics and moment of inertia of the load.
- The torque limiter and current limiter are very similar in function. If both are activated concurrently, they may conflict with each other and cause hunting. Avoid concurrent activation of these limiters.
 - Vector control with speed sensor itself contains the current control system, so it disables the current limiter specified by F43 and F44, as well as automatically disabling the instantaneous overcurrent limiting (specified by H12). Accordingly, the inverter causes an overcurrent trip when its output current exceeds the instantaneous overcurrent limiting level.

F50 to F52

Electronic thermal overload protection for braking resistor (Discharging capability, Allowable average loss and Braking resistance value)

These function codes specify the electronic thermal overload protection feature for the braking resistor.

Set the discharging capability, allowable average loss and resistance to F50, F51 and F52, respectively. These values are determined by the inverter and braking resistor models. For the discharging capability, allowable average loss and resistance, refer to Chapter 11 "11.8.4 Specifications."

The values listed in the tables are for standard models and 10% ED models of the braking resistors which Fuji Electric provides. When using a braking resistor of any other manufacturer, confirm the corresponding values with the manufacturer and set the function codes accordingly.

Set 0.00 to F52 when replacing from FRENIC-Multi.



Depending on the thermal characteristics of the braking resistor, the electronic thermal overload protection feature may act so that the inverter issues the overheat protection alarm $\Box_{\Box}^{\prime} \Box_{\Box}^{\prime} + e^{-1}$ even if the actual temperature rise is not large enough. If this happens, review the relationship between the performance index of the braking resistor and settings of related function codes.



Using the standard models of braking resistor or using the braking unit and braking resistor together can output temperature detection signal for overheat. Assign terminal command THR ("Enable external alarm trip") to any of digital input terminals [X1] to [X5], [FWD] and [REV] and connect that terminal and its common terminal to braking resistor's terminals 2 and 1.

<u>Calculating the discharging capability and allowable average loss of the braking resistor and configuring</u> the function code data

When using any non-Fuji braking resistor, inquire to the resistor manufacturer about the resistor rating and then configure the related function codes.

The calculation procedures for the discharging capability and allowable average loss of the braking resistor differ depending on the application of the braking load as shown below.

<Applying braking load during deceleration>

In usual deceleration, the braking load decreases as the speed slows down. In the deceleration with constant torque, the braking load decreases in proportion to the speed.

Use Expressions (1) and (3) given below.

Applying braking load during running at a constant speed

Different from during deceleration, in applications where the braking load is externally applied during running at a constant speed, the braking load is constant.

Use Expressions (2) and (4) given below.



→ (Braking time)

Braking load (kW)



→(Braking time)

<Applying braking load during deceleration>

<Applying braking load during running at a constant speed>
■ Discharging capability (F50)

The discharging capability refers to kWs allowance for a single braking cycle. It can be calculated from breaking

F50 data	Function
1 to 9000	1 to 9000 (kWs)
OFF	Disable the electronic thermal overload protection

Discharging capability (kWs) =
$$\frac{\text{Braking time (s) } \times \text{Motor rated capacity (kW)}}{2}$$
(1)

Discharging capability (kWs) = Braking time (s) x Motor rated capacity (kW) (2)

■ Allowable average loss (F51)

Allowance average loss is the resistor capacitor that enables continuous operation of motor. It can be calculated from ED (%) and motor capacity (kW).

F51 data	Function
0.001 to 99.99	0.001 to 99.99 (kW)
	9/ED/9/)

Allowable average loss (kWs) =
$$\frac{\frac{\frac{76 \text{ED}(76)}{100}}{2} \times \text{Motor rated capacity (kW)}}{2}$$
(3)

Allowable average loss (kWs) =
$$\frac{\% ED(\%)}{100}$$
 × Motor rated capacity (kW) (4)

Braking resistance value (F52)

F52 specifies the resistance of the braking resistor.

F52 data	Function			
0.00	Braking resistor protection method by FRENIC-Multi series method (Resistance not required)			
0.01 to 999	0.01 to 999 (Ω)			

5.3.2 E codes (Extension terminal functions)

Related function codes: Terminal E98 [FWD] function Terminal E99 [REV] function	E01 to E05	Terminals [X1] to [X5] function		
			Related function codes:	Terminal E98 [FWD] function Terminal E99 [REV] function

E01 to E05, E98 and E99 assign commands to general-purpose, programmable, digital input terminals, [X1] to [X5], [FWD], and [REV].

These function codes can also switch the logic system between normal and negative to define how the inverter logic interprets the ON or OFF state of each terminal. The factory default setting is normal logic system "Active ON." Functions assigned to digital input terminals [X1] to [X5], [FWD] and [REV] are as shown below. Descriptions that follow are given in normal logic system. Each signal has been described at data allocation order. However, the signal is related has been described together. Refer to the function codes in the "Related function codes" column, if any.

The FRENIC-eHVAC runs under "V/f: V/f control or "PM SLV: vector control without speed sensor nor pole position sensor for permanent magnet synchronous motor." Some terminal commands assigned apply exclusively to the specific drive control, which is indicated by letters Y (Applicable) and N (Not applicable) in the "Control mode" column in the table given below.

- Run commands (e.g., Run forward "FWD"), stop commands (e.g., Coast to a stop "BX"), and frequency change commands can be assigned to digital input terminals. Depending on the state of digital input terminals, modifying a single function code setting may cause abrupt start of operation or significant change of the speed. Ensure safety before modifying the function code settings.
- Functions for switching run or frequency command sources (such as "SS1, SS2, SS4, SS8", "Hz2/Hz1", "Hz/PID", "IVS" and "LE") can be assigned to the digital input terminals. Switching these signals may cause a sudden motor start or an abrupt change in speed depending on the condition.

An accident or physical injury may result.

Data				Control	mode	Deleted for etim
Active ON	Active OFF	Terminal commands assigned	Symbol	V/f	PM SLV	codes
0	1000		"SS1"	Y	Y	
1	1001	Select multistep frequency	"SS2"	Y	Y	005 to 010
2	1002	(1 to 15 steps)	"SS4"	Y	Y	C05 to C19
3	1003		"SS8"	Y	Y	
4	1004	Select ACC/DEC time (2 steps)	"RT1"	Y	Y	F07, F08,
5	1005	Select ACC/DEC time (4 steps)	"RT2"	Y	Y	E10 to E15
6	1006	Select 3-wire operation	"HLD"	Y	Y	F02
7	1007	Coast to a stop command	"BX"	Y	Y	—
8	1008	Reset alarm	"RST"	Y	Y	—
1009	9	External alarm	"THR"	Y	Y	—
11	1011	Select frequency setting 2/1	"Hz2/Hz1"	Y	Y	F01, C30
13	-	DC braking command	"DCBRK"	Y	Ν	F20 to F22
14	1014	Select torque limit 2/ Torque limit 1	"TL2/TL1"	Y	Y	F40, F41 E16, E17
15	_	Switch to commercial power (50Hz)	"SW50"	Y	Ν	—
16	_	Switch to commercial power (60Hz)	"SW60"	Y	Ν	—
17	1017	UP command	"UP"	Y	Y	Frequency
18	1018	DOWN command	"DOWN"	Y	Y	setting: F01, C30 PID command: J02
19	1019	Allow function code editing (Data change enabled)	"WE-KP"	Y	Y	F00
20	1020	Cancel PID control	"Hz/PID"	Y	Υ	J01 to J19, J57 to J62

Data				Control	mode	Delete d function	
Active ON	Active OFF	Terminal commands assigned	Symbol	V/f	PM SLV	Related function codes	
21	1021	Switch normal/inverse operation	"IVS"	Y	Y	C53, J01	
22	1022	Interlock	"IL"	Y	Y	F14	
24	1024	Select link operation (RS-485, BUS option)	"LE"	Y	Y	H30, y98	
25	1025	Universal DI	"U-DI"	Y	Y	—	
26	1026	Select auto search for idling motor speed at starting	"STM"	Y	Y	H09, d67	
1030	30	Force to stop	"STOP"	Y	Y	F07, H56	
33	1033	Reset PID integral and differential terms	"PID-RST"	Y	Y	J01 to J19, J57	
34	1034	Hold PID integral term	"PID-HLD"	Y	Y	to J62	
35	1035	Select local (keypad) command	"LOC"	Y	Y	(See Section 3.3.6)	
38	1038	Run enable	"RE"	Y	Y	-	
39	_	Dew condensation prevention	"DWP"	Y	Y	J21	
40	_	Enable integrated sequence to switch to commercial power (50Hz)	"ISW50"	Y	N	J22	
41	_	Enable integrated sequence to switch to commercial power (60Hz)	"ISW60"	Y	N	J22	
48	_	Pulse train input (Only for X5 terminal (E05))	"PIN"	Y	Y	F01, C30 d62,	
49	1049	Pulse train sign (Other than X5 terminal (E01 to E04))	"SIGN"	Y	Y	d63	
50	1050	Clear running motor regular switching time	"MCLR"	Y	Y	-	
72	1072	Count the run time of commercial power-driven motor 1	"CRUN-M1"	Y	Ν	H44,H94	
78	1078	Select speed control parameter 1	"MPRM1"	Ν	Ν	d01 to d08	
80	1080	Cancel customizable logic	"CLC"	Y	Y	E01 toE05, U81	
81	1081	Clear all customizable logic timers	"CLTC"	Y	Y	to U90	
82	1082	Cancel anti-regenerative control	"AR-CCL"	Y	Y	H69	
87	1087	Run command 2/ 1	"FR2/FR1"	Y	Y	-	
88	_	Run forward / stop 2	"FWD2"	Y	Y	-	
89	_	Run reverse / stop 2	"REV2"	Y	Y	-	
98	_	Run forward (Exclusively assigned to [FWD] and [REV] terminals by E98 and E99)	"FWD"	Y	Y	500	
99	_	Run reverse (Exclusively assigned to [FWD] and [REV] terminals by E98 and E99)	"REV"	Y	Y	FU2	
100	_	No function assigned	"NONE"	Y	Y	U81 to U90	
149	1149	Switch pump control	"PCHG"	Y	Y		
150	1150	Enable master motor drive in mutual operation	"MEN0"	Y	Y		
151	1151	Enable pump control motor 1 to be driven	"MEN1"	Y	Y		
152	1152	Enable pump control motor 2 to be driven	"MEN2"	Y	Y	J401 to J493	
153	1153	Enable pump control motor 3 to be driven	"MEN3"	Y	Y		
154	1154	Enable pump control motor 4 to be driven	"MEN4"	Y	Y		
171	1171	PID control multistage command 1	"PID-SS1"	Y	Y	1426 to 1428	
172	1172	PID control multistage command 2	"PID-SS2"	Y	Y	J130 to J138	

Da	Data			Control	mode	Deleted function
Active ON	Active OFF	Terminal commands assigned	Symbol	V/f	PM SLV	codes
181	1181	External PID1 multistage command 1	"EPID-SS1"	Y	Y	
182	1182	External PID1 multistage command 2	"EPID-SS2"	Y	Y	
201	1201	External PID1 ON command	"EPID1-ON"	Y	Y	
202	1202	External PID1 Cancel	"%EPID1"	Y	Y	J501 to J553
203	1203	External PID1 Switch normal/inverse operation	"EPID1-IVS"	Y	Y	
204	1204	External PID1 reset integral and differential omponents	"EPID1-RST"	Y	Y	
205	1205	External PID1 hold integral component	"EPID1-HLD"	Y	Y	



Negative logic (Active OFF) command cannot be assigned to the functions marked with "-" in the "Active OFF" column.

The "External alarm" (data = 1009) and "Force to stop" (data = 1030) are fail-safe terminal commands. In the case of "External alarm" when data = 1009, "Active ON" (alarm is triggered when ON); when data = 9, "Active OFF" (alarm is triggered when OFF).

Terminal function assignment and data setting

■ Select multistep frequency – "SS1", "SS2", "SS4", and "SS8" (Function code data = 0, 1, 2, and 3)

The combination of the ON/OFF states of digital input signals "SS1", "SS2", "SS4" and "SS8" selects one of 16 different frequency commands defined beforehand by 15 function codes C05 to C19 (Multistep frequency 1 to 15). With this, the inverter can drive the motor at 16 different preset frequencies. (

■ Select ACC/DEC time – "RT1" and "RT2" (Function code data = 4 and 5)

These terminal commands switch between ACC/DEC time 1 to 4 (F07, F08 and E10 through E15).

(Functions codes F07 and F08)

■ Select 3-wire operation – "HLD" (Function code data = 6)

Turning this terminal command ON self-holds the forward "FWD", reverse "REV", run command, to enable 3-wire inverter operation. (

■ Coast to a stop command -- "BX" (Function code data = 7)

Turning "BX" ON immediately shuts down the inverter output. The motor coasts to a stop, without issuing any alarm.

Reset alarm – "RST" (Function code data = 8)

Turning this terminal command ON clears the ALM state--alarm output (for any alarm). Turning it OFF erases the alarm display and clears the alarm hold state. When you turn the "RST" command ON, keep it ON for 10 ms or more. This command should be kept OFF for the normal inverter operation.



■ External alarm – "THR" (Function code data = 9)

Turning this terminal command OFF immediately shuts down the inverter output (so that the motor coasts to a stop), displays the alarm $\square \square \square$, and issues the alarm output (for any alarm) ALM. The THR command is self-held, and is reset when an alarm reset takes place.

Tip Use this alarm trip command from external equipment when you have to immediately shut down the inverter output in the event of an abnormal situation in peripheral equipment.

■ Select frequency setting 2/1 – "Hz2/Hz1" (Function code data = 11)

Turning this terminal command ON and OFF switches the frequency command source between frequency setting 1 (F01) and frequency setting 2 (C30). (Function code F01)

■ DC braking command – "DCBRK" (Function code data = 13)

This terminal command gives the inverter a DC braking command through the inverter's digital input. (Requirements for DC braking must be satisfied.) (

■ Select torque limit 2/1 – "TL2/TL1" (Function code data = 14)

This terminal command switches between torque limiter 1 (F40 and F41) and torque limiter 2-1, 2-2 (E16 and E17). (

■ Switch to commercial power for 50 Hz or 60 Hz – "SW50" and "SW60" (Function code data = 15 and 16)

When an external sequence switches the motor drive power from the commercial line to the inverter, the terminal command SW50 or SW60 enables the inverter to start running the motor with the current commercial power frequency, regardless of settings of the reference/output frequency in the inverter. A running motor driven by commercial power is carried on into inverter operation. This command helps you smoothly switch the motor drive power source from the commercial power to the inverter power.

For details, refer to the table below, "Operation timing scheme", "Example of Sequence Circuit" and "Example of Operation Time Scheme" on the following pages.

Terminal command assigned	Action		
Switch to commercial power for 50 Hz "SW50"	Starts at 50 Hz.	Note Do not concurrently assign both	
Switch to commercial power for 60 Hz "SW60"	Starts at 60 Hz.	SW50 and SW60.	

<Operation timing scheme>

• When the motor speed remains almost the same during coast-to-stop:



• When the motor speed decreases significantly during coast-to-stop (with the current limiter activated)



Note

- Secure more than 0.1 second after turning ON the "Switch to commercial power" signal before turning ON a run command.
- Secure more than 0.2 second of an overlapping period with both the "Switch to commercial power" signal and run command being ON.
- If an alarm has been issued or BX has been ON when the motor drive source is switched from the commercial power to the inverter, the inverter will not be started at the commercial power frequency and will remain OFF. After the alarm has been reset or "BX" turned OFF, operation at the frequency of the commercial power will not be continued, and the inverter will be started at the ordinary starting frequency.
- If you wish to switch the motor drive source from the commercial line to the inverter, be sure to turn "BX" OFF before the "Switch to commercial power" signal is turned OFF.
- When switching the motor drive source from the inverter to commercial power, adjust the inverter's
 reference frequency at or slightly higher than that of the commercial power frequency beforehand,
 taking into consideration the motor speed down during the coast-to-stop period produced by
 switching.
- Note that when the motor drive source is switched from the inverter to the commercial power, a high
 inrush current will be generated, because the phase of the commercial power usually does not match
 the motor speed at the switching. Make sure that the power supply and all the peripheral equipment
 are capable of withstanding this inrush current.
- If you have enabled "Restart mode after momentary power failure" (F14 = 3, 4, or 5), keep "BX" ON during commercial power driven operation to prevent the inverter from restarting after a momentary power failure.

<Example of Sequence Circuit>





Note 1) Emergency switch

Manual switch provided for the event that the motor drive source cannot be switched normally to the commercial power due to a serious problem of the inverter

Note 2) When any alarm has occurred inside the inverter, the motor drive source will automatically be switched to the commercial power.



<Example of Operation Time Scheme>

"UP" (Increase output frequency) and "DOWN" (Decrease output frequency) commands -- UP and DOWN (Function code data = 17 and 18)

- Frequency command: Turning the terminal command "UP" or "DOWN" ON causes the output frequency to increase or decrease, respectively, within the range from 0 Hz to the maximum frequency. (I Function code F01 data = 7)
- PID command: Turning the terminal command "UP" or "DOWN" ON causes the PID command value to increase or decrease, respectively, within the range from 0 to 100%.
 (III) Function code J02 (data= 3)

■ Allow function code editing – "WE-KP" (Function code data = 19)

Turning the terminal command "WE-KP" OFF protects function code data from accidentally getting changed by pressing the keys on the keypad. Only when this terminal command is ON, you can change function code data from the keypad. (

Cancel PID control – "Hz/PID" (Function code data = 20)

Turning this terminal command "Hz/PID" ON disables PID control. If the PID control is disabled with this command, the inverter runs the motor with the reference frequency manually set by any of the multistep frequency, keypad, analog input, etc.

Terminal command "Hz/PID"	Function
OFF	Enable PID control
ON	Disable PID control (Enable manual settings)

	E		104	1- 140	157	1- 100	
be	Function	codes	JU1	to J19	, 157	to Jo2	1

■ Switch normal/inverse operation – "IVS" (Function code data = 21)

This terminal command switches the output frequency control between normal (proportional to the input value) and inverse in analog frequency setting or under PID process control. To select the inverse operation, turn the IVS ON.



Tip The normal/inverse switching operation is useful for air-conditioners that require switching between cooling and heating. In cooling, the <u>speed</u> of the fan motor <u>(output frequency of the inverter)</u> is increased to <u>lower the temperature</u>. In heating, the <u>speed</u> of the fan motor <u>(output frequency of the inverter)</u> is reduced to <u>lower the temperature</u>. This switching is realized by the IVS.

When the inverter is driven by an external analog frequency setting sources (terminals [12] and [C1] (C1 function) and [C1] (V2 function)):

Switching normal/inverse operation can apply only to the analog frequency command sources (terminals [12] and [C1] (C1 function) and [C1] (V2 function)) in frequency setting 1 (F01) and does not affect frequency setting 2 (C30) or UP/DOWN control. As shown below, the combination of the "Selection of normal/inverse operation for frequency setting 1" (C53) and the terminal command "IVS" determines the final operation.

C53 data	Terminal command "IVS"	Action
0: Normal operation	OFF	Normal
0: Normal operation	ON	Inverse
1: Inverse operation	OFF	Inverse
1: Inverse operation	ON	Normal

• When process control is performed by the PID processor integrated in the inverter:

The terminal command Hz/PID ("Cancel PID control") can switch PID control between enabled (process is to be controlled by the PID processor) and disabled (process is to be controlled by the manual frequency setting). In either case, the combination of the "PID control" (J01) or "Selection of normal/inverse operation for frequency setting 1" (C53) and the terminal command IVS determines the final operation as listed Table 5.3-7 and Table 5.3-8.

Table 5.3-7When PID control is enabled:

The normal/inverse operation selection for the PID processor output (reference frequency) is as follows.

PID control (Mode selection) (J01)	Terminal command "IVS"	Action
1. Enable (normal anaration)	OFF	Normal
1: Enable (normal operation)	ON	Inverse
2. Enchle (inverse execution)	OFF	Inverse
2: Enable (inverse operation)	ON	Normal

Table 5.3-8 When PID control is disabled:

The normal/inverse operation selection for the manual reference frequency is as follows.

Selection of normal/inverse operation for frequency setting 1 (C53)	Terminal command "IVS"	Action
0: Normal operation	-	Normal
1: Inverse operation	-	Inverse

Note When process control is performed by the PID control facility integrated in the inverter, the "IVS" is used to switch the PID processor output (reference frequency) between normal and inverse, and has no effect on any normal/inverse operation selection of the manual frequency setting.

(Function codes J01 to J19, J57 to J62)

Interlock – "IL" (Function code data = 22)

In a configuration where a magnetic contactor (MC) is installed in the power output (secondary) circuit of the inverter, the momentary power failure detection feature provided inside the inverter may not be able to accurately detect a momentary power failure by itself. Using a digital signal input with the interlock command IL assures the accurate detection. (

Terminal command "IL"	Meaning
OFF	No momentary power failure has occurred.
ON	A momentary power failure has occurred. (Restart after a momentary power failure enabled)

■ Select link operation (RS-485, BUS option) – "LE" (Function code data = 24)

Turning this terminal command "LE" ON gives priority to frequency commands or run commands received via the RS-485 communications link (H30) or the fieldbus option (y98). No LE assignment is functionally equivalent to the "LE" being ON. (

■ Universal DI -- "U-DI" (Function code data = 25)

Universal DI "U-DI" assigned to digital input terminals allow to monitor signals from peripheral equipment connected to those inputs from an upper controller via an RS-485 or fieldbus communications link. Input terminals assigned to "U-DI" are simply monitored and do not operate the inverter.

For an access to universal DI via the RS-485 or fieldbus communications link, refer to their respective Instruction Manuals.

■ Select auto search for idling motor speed at starting – "STM" (Function code data = 26)

This digital terminal command determines, at the start of operation, whether or not to search for idling motor speed and follow it. (

■ Force to stop – "STOP" (Function code data = 30)

Turning this terminal command "STOP" OFF causes the motor to decelerate to a stop in accordance with the H56 data (Deceleration time for forced stop). After the motor stops, the inverter enters the alarm state with the alarm $\mathcal{E}-\mathcal{E}$ displayed. (\square Function code F07)

Reset PID integral and differential terms – "PID-RST" (Function code data = 33)

Turning this terminal command "PID-RST" ON resets the integral and differential components of the PID processor. (
Function codes J01 to J19, J23, J24, J57 to J62)

■ Hold PID integral term – "PID-HLD" (Function code data = 34)

Turning this terminal command "PID-HLD" ON holds the integral components of the PID processor. (III) Function codes J01 to J19, J23, J24, J57 to J62)

■ Select local (keypad) command – "LOC" (Function code data = 35)

This terminal command "LOC" switches the sources of run and frequency commands between remote and local.

For details of switching between remote and local modes, refer to Chapter 3 "3.3.6 Remote and local modes."

■ Enable run commands – "RE" (Function code data = 38)

Once this terminal command is assigned to any digital input terminal, the inverter no longer starts running with a run command only. Upon receipt of a run command, the inverter gets ready to run and outputs an "AX2" signal ("Run command entered").

Entering an "I	RE" signal	("Enable run	commands")	when the	inverter i	s readv f	for running star	ts the inverter to run.
		\						

Input		Output	
Run command (e.g., FWD)	Enable run commands <i>RE</i>	Run command entered AX2	Inverter status
OFF	OFF	OFF	Stopped
OFF	ON	OFF	Stopped
ON	OFF	ON	Stopped
ON	ON	ON	Running

Typical operation sequence of RE

- (1) A run command "FWD" is given to the inverter.
- (2) When the inverter gets ready for running, it outputs an "AX2" signal ("Run command entered").
- (3) Upon receipt of the "AX2", the upper equipment gets ready to operate the peripherals (e.g., opening a damper).
- (4) Upon completion of preparation of the peripherals, the upper equipment gives an "RE" signal ("Enable run command") to the inverter.
- (5) Upon receipt of the "RE", the inverter starts running.

■ Dew condensation prevention – "DWP" (Function code data = 39)

By turning ON dew condensation prevention "DWP" with the inverter stopped, DC current flows, and the motor temperature is raised to prevent dew condensation. (

Enable integrated sequence to switch to commercial power for 50 Hz and 60 Hz – "ISW50" and "ISW60" (Function code data = 40 and 41)

With the terminal command *ISW50* or *ISW60* assigned, the inverter controls the magnetic contactor that switches the motor drive source between the commercial power and the inverter output according to the integrated sequence.

This control is effective when not only *ISW50* or *ISW60** has been assigned to the input terminal but also the *SW88* and SW52-2 signals have been assigned to the output terminals. (It is not essential to assign the *SW52-1* signal.)

- The *ISW50* or *ISW60* should be selected depending upon the frequency of the commercial power; the former for 50 Hz and the latter for 60 Hz.
- For details about *SW88* and *SW52-2* ("Switch motor drive source between commercial power and inverter output"), refer to E20 to E22, E24, E27.

For details of these commands, refer to the circuit diagrams and timing schemes on the following pages.

Terminal command assigned	Operation (Switching from commercial power to inverter)
<i>ISW50</i> Enable integrated sequence to switch to commercial power (50 Hz)	Start at 50 Hz.
<i>ISW60</i> Enable integrated sequence to switch to commercial power (60 Hz)	Start at 60 Hz.

Note Do not assign both *ISW50* and *ISW60* at the same time. Doing so cannot guarantee the result.





Configuration of Control Circuit

Summary	of Operation
---------	--------------

Input		Output (Status signal and magnetic contactor)			Inverter		
<i>ISW50</i> or <i>ISW60</i>	Run command	SW52-1SW52-252-152-2		SW88 88	operation		
OFF	ON	OFF	055	ON	OFF		
(Commercial power)	OFF		OFF OFF	OFF			
ON	ON	ON					ON
(Inverter)	OFF		ON	ON OFF	OFF		

Timing Scheme

Switching from inverter operation to commercial-power operation $\textit{ISW50/ISW60}: \text{ON} \rightarrow \text{OFF}$

- (1) The inverter output is shut OFF immediately (Power gate IGBT OFF)
- (2) The inverter primary circuit SW52-1 and the inverter secondary side SW52-2 are turned OFF immediately.
- (3) If a run command is present after an elapse of t1 (0.2 sec + time specified by H13), the commercial power circuit **SW88** is turned ON.

Switching from commercial-power operation to inverter operation $\textit{ISW50/ISW60}: \mathsf{OFF} \rightarrow \mathsf{ON}$

- (1) The inverter primary circuit SW52-1 is turned ON immediately.
- (2) The commercial power circuit SW88 is turned OFF immediately.
- (3) After an elapse of t2 (0.2 sec + time required for the main circuit to get ready) from when **SW52-1** is turned ON, the inverter secondary circuit **SW52-2** is turned ON.
- (4) After an elapse of t3 (0.2 sec + time specified by H13) from when SW52-2 is turned ON, the inverter harmonizes once the motor that has been freed from the commercial power to the commercial power frequency. Then the motor returns to the operation driven by the inverter.



- t1: 0.2 sec + Time specified by H13 (Restart mode after momentary power failure)
- t2: 0.2 sec + Time required for the main circuit to get ready
- t3: 0.2 sec + Time specified by H13 (Restart mode after momentary power failure)

Selection of Commercial Power Switching Sequence

J22 specifies whether or not to automatically switch to commercial-power operation when an inverter alarm occurs.

Data for J22	Sequence (upon occurrence of an alarm)
0	Keep inverter-operation (Stop due to alarm.)
1	Automatically switch to commercial-power operation

• The sequence operates normally also even when **SW52-1** is not used and the main power of the inverter is supplied at all times.

- Using **SW52-1** requires connecting the input terminals [R0] and [T0] for an auxiliary control power. Without the connection, turning **SW52-1** OFF loses also the control power.
- The sequence operates normally even if an alarm occurs in the inverter except when the inverter itself is broken. Therefore, for a critical facility, be sure to install an emergency switching circuit outside the inverter.
- Turning ON both the magnetic contactor MC (88) at the commercial-power side and the MC (52-2) at the inverter output side at the same time supplies main power mistakenly from the output (secondary) side of the inverter, which may damage the inverter. To prevent it, be sure to set up an interlocking logic outside the inverter.

Examples of Sequence Circuits

1) Standard sequence







 Sequence with an emergency switching function --Part 2 (Automatic switching by the alarm output issued by the inverter)



Pulse train input – "PIN" (Only for X5 terminal (E05)) (Function code data = 48), Pulse train sign – "SIGN" (For all terminal except X5 terminal (E05)) (Function code data = 49)

Assigning the command "PIN" to digital input terminal [X5] enables the frequency command by the pulse train input. Assigning the command "SIGN" to one of the digital input terminals except [X5] enables the pulse train sign input to specify the polarity of frequency command. (

■ Clear running motor regular switching time – "MCLR" (Function code data = 50)

Turning the MCLR ON clears the regular switching time of the running motor. (Refer to J436.)

■ Count the run time of commercial power-driven motor-1 – "CRUN-M1" (Function code data = 72)

This terminal command enables the inverter to count the cumulative run time of motor-1 even when it is driven by commercial power (not by the inverter).

When the "CRUN-M1" is ON, the inverter judges that the motor-1 is driven by commercial power, respectively, and counts the run time of the corresponding motor. (

■ Select speed control parameter 1 – "MPRM1" (Function code data = 78)

The combination of the ON/OFF states of digital input signal "MPRM1" selects one of 2 different level speed control parameter sets for vector control PMSM. (PFunction codes d01 to d08)

Input signal	Speed control parameter
"MPRM1"	Speed control parameter
OFF	Speed control parameter sets 1 : d01~d08
ON	Speed control parameter sets 2 : A43~A50

Cancel customizable logic – "CLC" (Function code data = 80), Clear all customizable logic timers – "CLTC" (Function code data = 81)

Terminal command "CLC" stops the operation of customizable logic. Terminal command "CLTC" clears all customizable logic timers. (

■ Cancel anti-regenerative control – "AR-CCL" (Function code data = 82)

Terminal command "AR-CCL" ON disables anti-regenerative control. (

Run command 2/1 – "FR2"/"FR1" (Function code data = 87), Run forward 2 – "FWD2" (Function code data = 88), Run reverse 2 – "REV2" (Function code data = 89)

The FR2/FR1 switches between the run command source selected by Run command (FWD and REV) and the one selected by Run command 2 (FWD2 and REV2)

	Run command expedient		
[FR2/FR1] Link disable		Link enable	
OFF	By F02	S06 : FWD/REV	
ON	[FWD2], [REV2]	S06 : FWD2/REV2	

■ Run forward – "FWD" (Function code data = 98)

Turning this terminal command ON runs the motor in the forward direction; turning it OFF decelerates it to stop.



This terminal command "FWD" can be assigned only to E98 or E99.

Run reverse – "REV" (Function code data = 99)

Turning this terminal command "REV" ON runs the motor in the reverse direction; turning it OFF decelerates it to stop.



This terminal command "REV" can be assigned only to E98 or E99.

No function assigned – "NONE" (Function code data = 100)

It allows the inverter to run unaffected by ON/OFF of signals. It is used when a signal is externally input using customizable logic. It is also used to temporarily disable a terminal function.

Switch pump control – "PCHG" (Function code data = 149)

Turning the PCHG ON enables the pump control switching signal to switch the motor regularly. This command is available only when J401 (Pump control mode selection) = any of 1 through 3, 11 through 13, and 52. (EFunction code J401.)

■ Enable master motor drive in mutual operation – "MEN0" (Function code data = 150)

Turning the MEN0 ON enables the master motor to be driven in mutual operation. Turning it OFF disables the master motor to stop it. If no MEN0 is assigned, the master motor is capable of being driven. (

■ Enable pump control motor 1 to 4 to be driven – "MEN1" to "MEN4" (Function code data = 151 to 154)

Turning the MEN1 to MEN8 ON enables the corresponding motors to be driven under pump control. Turning them OFF prohibits the motors from being driven. If MEN1 to MEN8 are not assigned, those motors are capable of being driven. In mutual operation, slave inverters 1 and 2 correspond to MEN1 and MEN2, respectively. (

■ PID control multistage command 1, 2 – "PID-SS1", "PID-SS2" (Function code data = 171, 172)

"PID-SS1" and "PID-SS2" can be used to select 4 different PID commands. (III Function codes J136 to J138)

External PID multistep command – "EPID-SS1", "EPID-SS2" (Function code data = 181, 182)

Turning the "EPID-SS1" and "EPID-SS2" ON/OFF selectively switches the external PID multistep commands (preset by J551 through J553) in three steps. (

■ External PID control 1 ON command – "EPID1-ON" (Function code data = 201)

Turning the EPID1-ON ON enables external PID control 1. (Function codes J501.)

■ Cancel external PID control 1 – "%/EPID1 "(Function code data = 202)

Turning the %/EPID1 ON switches from external PID control 1 to manual commands (running at the frequency selected from the keypad or analog input). (

Terminal command "%/EPID1"	Function
OFF	Enable external PID control 1
ON	Disable external PID control 1 (Enable manual commands)

■ Switch normal/inverse operation under external PID control 1 – "EPID1-IVS" (Function code data = 203)

The "EPID1-IVS" switches the output signal of external PID control 1 between normal and inverse operations.



■ Reset external PID1 integral and differential components – "EPID1-RST" (Function code data = 204)

Turning the "EPID1-RST" ON resets the integral and differential terms of the PID processor of external PID control 1.(Department of the PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of external PID processor of ex

■ Hold external PID1 integral component – "EPID1-HLD" (Function code data = 205)

When the "EPID1-HLD" is ON, the inverter holds the integral term of the PID processor of external PID control 1. (III) Function codes J501 through J553.)

E10 to E15	Acceleration time 2 to 4, Deceleration time 2 to 4	(Refer to F07)

Refer to the description of F07.

E16, E17	Torque limiter 2 (driving), 2 (braking)	(Refer to F40)
----------	---	----------------

For the torque limiter 2 (driving) and 2 (braking) settings, refer to the description of F40.

E20 to E22Terminals [Y1] function to [Y3] functionE24Terminal [Y5A/C] function (Relay output)E27Terminal [30A/B/C] function (Relay output)

E20 through E22, E24 and E27 assign output signals to general-purpose, programmable output terminals, [Y1], [Y2], [Y3], [Y5A/C], and [30A/B/C]. These function codes can also switch the logic system between normal and negative to define how the inverter interprets the ON or OFF state of each terminal. The factory default setting is normal logic system "Active ON."

Terminals [Y1], [Y2] and [Y3] are transistor outputs and terminals [Y5A/C] and [30A/B/C] are contact outputs. In normal logic, if an alarm occurs, the relay will be energized so that [30A] and [30C] will be closed, and [30B] and [30C] opened. In negative logic, the relay will be de-energized so that [30A] and [30C] will be opened, and [30B] and [30C] closed. This may be useful for the implementation of failsafe power systems.

- When negative logic is employed, output signal is OFF(active) while the inverter is powered OFF. To avoid causing system malfunctions by this, interlock these signals to keep them ON using an external power supply. Furthermore, the validity of these output signals is not guaranteed for approximately 1.5 seconds (for FRN0060F2E-4G or below) or 3 seconds (for FRN0075F2E-4G or above) after power-ON, so introduce such a mechanism that masks them during the transient period.
 - Terminals [Y5A/C] and [30A/B/C] use mechanical contacts. They cannot stand frequent ON/OFF switching. Where frequent ON/OFF switching is anticipated (for example, by using frequency arrival signal), use transistor outputs [Y1] to [Y3] instead.

The service life of a relay is approximately 200,000 times if it is switched ON and OFF at one-second intervals. For signals expected to be turned ON/OFF frequently, use terminals [Y1] to [Y3] for output.

The tables given on the following pages list functions that can be assigned to terminals [Y1], [Y2], [Y3], [Y5A/C] and [30A/B/C]. The descriptions are, in principle, arranged in the numerical order of assigned data. However, the signal is related has been described together. Refer to the function codes or signals in the "Related function codes/signals (data)" column, if any.

Da	ata	<u>-</u>		Co m	ntrol ode	Related function
Active ON	Active OFF	ierminal commands assigned	Symbol	V/f	PM SLV	signals (data)
0	1000	Inverter running	"RUN"	Y	Y	—
1	1001	Frequency (speed) arrival	"FAR"	Y	Y	<u>E30</u>
2	1002	Frequency (speed) detected	"FDT"	Y	Y	<u>E31, E32</u>
3	1003	Undervoltage detected (Inverter stopped)	"LU"	Y	Y	—
5	1005	Inverter output limiting	"IOL"	Y	Y	—
6	1006	Auto-restarting after momentary power failure	"IPF"	Y	Y	<u>F14</u>
7	1007	Motor overload early warning	"OL"	Υ	Y	<u>E34</u> , F10, F12
8	1008	Keypad operation enabled	"KP"	Υ	Y	—
10	1010	Inverter ready to run	"RDY"	Y	Y	—
11	_	Switch motor drive source between commercial power and inverter output (For MC on commercial line)	"SW88"	Y	N	E01 to E05
12	_	Switch motor drive source between commercial power and inverter output (For secondary side)	"SW52-2"	Y	N	"ISW50"(40) "ISW60"(41)
13	_	Switch motor drive source between commercial power and inverter output (For primary side)	"SW52-1"	Y	N	J22
15	1015	Switch MC on the input power lines	"AX"	Y	Y	—
16	1016	Pattern operation stage transition	"TU"	Y	Y	
17	1017	Pattern operation cycle completed	"TO"	Y	Y	
18	1018	Pattern operation stage No. 1	"STG1"	Y	Y	C21 to C28
19	1019	Pattern operation stage No. 2	"STG2"	Y	Y	
20	1020	Pattern operation stage No. 4	"STG4"	Υ	Y	
25	1025	Cooling fan in operation	"FAN"	Y	Y	<u>H06</u>
26	1026	Auto-resetting	"TRY"	Y	Y	<u>H04, H05</u>
27	1027	Universal DO	"U-DO"	Y	Y	—
28	1028	Heat sink overheat early warning	"OH"	Y	Y	_

Explanations of each function are given in normal logic system "Active ON."

Data		-	0	Coi ma	ntrol ode	Related function
Active ON	Active OFF	lerminal commands assigned	Symbol	V/f	PM SLV	codes/ Related signals (data)
30	1030	Lifetime alarm	"LIFE"	Y	Y	<u>H42</u>
33	1033	Reference loss detected	"REF OFF"	Y	Y	<u>E65</u>
35	1035	Inverter outputting	"RUN2"	Y	Y	RUN (0)
36	1036	Overload prevention controlling	"OLP"	Y	Y	<u>H70</u>
37	1037	Current detected	"ID"	Y	Y	<u>E34,</u> E35, E37,
41	1041	Low current detected	"IDL"	Y	Y	E38, E55, E56
42	1042	PID alarm	"PID-ALM"	Y	Y	<u>J11 to J13</u>
43	1043	Under PID control	"PID-CTL"	Υ	Y	J01
44	1044	Under sleep mode of PID control	"PID-STP"	Y	Y	<u>J08, J09</u>
45	1045	Low torque detected	"U-TL"	Υ	Y	<u>E80, E81</u>
52	1052	Running forward	"FRUN"	Y	Y	
53	1053	Running reverse	"RRUN"	Y	Y	
54	1054	Under remote mode	"RMT"	Y	Y	(Refer to Section 3.3.6)
55	1055	Run command entered	"AX2"	Υ	Y	
56	1056	Motor overheat detected by thermistor	"THM"	Y	Y	<u>H26</u> , H27
59	1059	Terminal [C1] (C1 function)wire break detected	"C1OFF"	Y	Y	_
68	1068	Motor regular switching early warning	"MCHG"	Y	Y	J401 to J493
69	1069	Pump control output limit signal	"MLIM"	Y	Y	J401 to J493
76	1076	Speed deviation excess	"PG-ERR"	Ν	Ν	<u>d21 to d23</u>
77	1077	Low DC link bus voltage detection	"U-EDC"	Υ	Y	<u>E76</u>
79	1079	During deceleration in momentary power failure	"IPF2"	Υ	Y	<u>F14, F15</u>
84	1084	Maintenance timer counted up	"MNT"	Υ	Y	<u>H44</u> , H78, H79
87	1087	Frequency arrival and frequency detected	"FARFDT"	Y	Y	<u>E30, E31, E32</u>
88	1088	Auxiliary motor drive signal	"AUX_L"	Υ	Y	
98	1098	Light alarm	"L-ALM"	Y	Y	<u>H81, H82</u>
99	1099	Alarm output (for any alarm)	"ALM"	Y	Y	
111 to 120	1111 to 1120	Customizable logic output signal 1 to 10	"CLO1" to "CLO10"	Y	Y	U71 to U75, U81 to U90
160	1160	Motor 1 being driven by inverter	"M1_I"	Y	Y	
161	1161	Motor 1 being driven by commercial power	"M1_L"	Y	Y	
162	1162	Motor 2 being driven by inverter	"M2_I"	Y	Y	
163	1163	Motor 2 being driven by commercial power	"M2_L"	Υ	Y	
164	1164	Motor 3 being driven by inverter	"M3_I"	Υ	Y	
165	1165	Motor 3 being driven by commercial power	"M3_L"	Υ	Y	
167	1167	Motor 4 being driven by inverter	"M4_L"	Υ	Y	1404 45 1400
180	1180	In mutual operation	"M-RUN"	Υ	Y	J401 to J493
181	1181	Alarm in mutual operation	"M-ALM"	Y	Y	
211	1211	Under external PID1 control	"EPID1-CTL"	Y	Y	
212	1212	External PID1 output	"EPID1-OUT"	Y	Y	
213	1213	Running under external PID1	"EPID1-RUN"	Y	Y	
214	1214	External PID1 alarm	"EPV1-ALM"	Y	Y	
215	1215	External PID1 feedback error	"EPV1-OFF"	Y	Y	



Any negative logic (Active OFF) command cannot be assigned to the functions marked with "-" in the "Active OFF" column.

Inverter running – "RUN" (Function code data = 0), Inverter outputting – "RUN2" (Function code data = 35)

These output signals tell the external equipment that the inverter is running at a starting frequency or higher. If assigned in negative logic (Active OFF), these signals can be used to tell the "Inverter being stopped" state.

Output signal	Basic function	Remarks
RUN	These signals come ON when the inverter is running. Under V/f control: These signals come ON if the	Goes OFF even during DC braking.
RUN2	inverter output frequency exceeds the starting frequency, and go OFF if it drops below the stop frequency. The "RUN" signal can also be used as a "Speed valid" signal.	Comes ON even during DC braking, pre-excitation, zero speed control.

■ Frequency (speed) arrival- "FAR" (Function code data = 1)

These output signals come ON when the difference between the output frequency (detected speed) and reference frequency (reference speed) comes within the frequency arrival hysteresis width specified by E30. (IPFunction code E30)

■ Frequency (speed) detected – "FDT" (Function code data = 2)

These output signal FDT come ON when the output frequency (detected speed) exceeds the frequency detection level specified by E31, E36 or E54, respectively, and go OFF when the output frequency (detected speed) drops below the "Frequency detection level (E31, E36 or E54) - Hysteresis width (E32)."

(Function codes E31 and E32)

Undervoltage detected (Inverter stopped) – "LU" (Function code data = 3)

This output signal comes ON when the DC link bus voltage of the inverter drops below the specified undervoltage level. When this signal is ON, the inverter cannot run even if a run command is given. It goes OFF when the voltage exceeds the level.

■ Inverter output limiting – "IOL" (Function code data = 5)

The output signal IOL comes ON when the inverter is limiting the output frequency by activating any of the following actions (minimum width of the output signal: 100 ms).

- Torque limiting (F40, F41, E16 and E17, Maximum internal value)
- Current limiting by software (F43 and F44)
- Instantaneous overcurrent limiting by hardware (H12 = 1)
- Automatic deceleration (Anti-regenerative control) (H69)

Note When the "IOL" is ON, it may mean that the output frequency may have deviated from the reference frequency because of the limiting functions above.

■ Auto-restarting after momentary power failure – "IPF" (Function code data = 6)

This output signal is ON either during continuous running after a momentary power failure or during the period after the inverter detects an undervoltage condition and shuts down the output until restart has been completed (the output has reached the reference frequency). (

■ Motor overload early warning – "OL" (Function code data = 7)

The OL signal is used to detect a symptom of an overload condition (alarm code \mathcal{L}_{L}^{\prime} /) of the motor so that the user can take an appropriate action before the alarm actually happens. (\square Function code E34)

■ Keypad operation enabled – "KP" (Function code data = 8)

This output signal comes ON when the (1) / (1) keys are specified as the run command source.

■ Inverter ready to run – "RDY" (Function code data = 10)

This output signal comes ON when the inverter becomes ready to run by completing hardware preparation (such as initial charging of DC link bus capacitors and initialization of the control circuit) and no protective functions are activated.

Switch motor drive source between commercial power and inverter output – "SW88", "SW52-2" and "SW52-1" (Function code data = 11, 12, and 13)

Assigning these output signals to transistor output terminals [Y1], [Y2], [Y3] and [Y5A/C] enables the terminal command "ISW50" or "ISW60" that controls the magnetic contactor for switching the motor drive source between the commercial power and the inverter output according to the integrated sequence. (\square Function code E01 through E07 (data = 40 and 41).)

Switch MC on the input power lines – "AX" (Function code data = 15)

In response to a run command FWD, this output signal controls the magnetic contactor on the commercial-power supply side. It comes ON when the inverter receives a run command. It goes OFF after the motor decelerates to stop with a stop command received. This signal immediately goes OFF upon receipt of a coast-to-stop command or when an alarm occurs.

"AX" can be selected where there is control power such as with FRN0045F2E-4G or above.



Pattern operation stage No. 1 – "STG1" (Function code data = 18), Pattern operation stage No. 2 – "STG2" (Function code data = 19), Pattern operation stage No. 4 – "STG4" (Function code data = 20)

Outputs the stage (operation process) currently performed during pattern operation.

	Output terminal signal				
Operation pattern stage No.	STG1	STG2	STG4		
Stage 1	ON	OFF	OFF		
Stage 2	OFF	ON	OFF		
Stage 3	ON	ON	OFF		
Stage 4	OFF	OFF	ON		
Stage 5	ON	OFF	ON		
Stage 6	OFF	ON	ON		
Stage 7	ON	ON	ON		

■ Cooling fan in operation – "FAN" (Function code data = 25)

With the cooling fan ON/OFF control enabled (H06 = 1), this output signal is ON when the cooling fan is in operation, and OFF when it is stopped. This signal can be used to make the cooling system of peripheral equipment interlocked for an ON/OFF control. (\square Function code H06)

■ Auto-resetting – "TRY" (Function code data = 26)

This output signal comes ON when auto resetting (resetting alarms automatically) is in progress. (

■ Universal DO -- "U-DO" (Function code data = 27)

Assigning this output signal to an inverter's output terminal and connecting the terminal to a digital input terminal of peripheral equipment, allows an upper controller to send commands to the peripheral equipment via the RS-485 or the fieldbus communications link. The universal DO can be used as an output signal independent of the inverter operation.

For the procedure for access to Universal DO via the RS-485 or fieldbus communications link, refer to the respective instruction manual.

■ Heat sink overheat early warning – "OH" (Function code data = 28)

This output signal is used to issue a heat sink overheat early warning that enables you to take a corrective action before an overheat trip 2 + 1 actually happens.

ON at [(Overheat trip (27 + 1) temperature) – 5°C (41°F)] or higher

OFF at [(Overheat trip (パイ /) temperature) - 8°C (46°F)] or lower

This signal comes ON also when the internal air circulation DC fan (FRN0176F2E-4G or above for 400 V class series) is locked.

■ Lifetime alarm – "LIFE" (Function code data = 30)

This output signal comes ON when it is judged that the service life of any one of capacitors (DC link bus capacitors or electrolytic capacitors on the printed circuit boards) or cooling fan has expired. This signal should be used as a guide for replacement of the capacitors and cooling fan. If this signal comes ON, use the specified maintenance procedure to check the service life of these parts and determine whether the parts should be replaced or not.

(Function code H42)

This signal comes ON also when the internal air circulation DC fan (FRN0176F2E-4G or above for 400 V class series) is locked.

Reference loss detected – "REF OFF" (Function code data = 33)

This output signal comes ON when an analog input used as a frequency command source is in a reference loss state (as specified by E65) due to a wire break or a weak connection. This signal goes OFF when the normal operation under the analog input is resumed. (

■ Overload prevention controlling – "OLP" (Function code data = 36)

This output signal comes ON when overload prevention control is activated. (The minimum ON-duration is 100 ms.) (

■ Current detected – "ID" (Function code data = 37)

When the inverter output current exceeds the level specified by E34 for the period specified by E35, the ID signal turns ON, respectively. (The minimum ON-duration is 100 ms.)

(Function code E34)

■ Low current detected – "IDL" (Function code data = 41)

When the inverter output current falls to or below the level specified by E34 for the period specified by E35, the IDL signal turns ON, respectively. (The minimum ON-duration is 100 ms.) (III) Function code E34)

■ PID alarm – "PID-ALM" (Function code data = 42)

Assigning this output signal enables PID control to output absolute-value alarm or deviation alarm.

(Function codes J11 to J13)

Under PID control – "PID-CTL" (Function code data = 43)

This output signal comes ON when PID control is enabled ("Cancel PID control" (Hz/PID) = OFF) and a run command is ON. (Function code J01)

Note

When PID control is enabled, the inverter may stop due to the slow flowrate stopping function or other reasons. If that happens, the "PID-CTL" signal remains ON. As long as the "PID-CTL" signal is ON, PID control is effective, so the inverter may abruptly resume its operation, depending on the feedback value in PID control.

When PID control is enabled, even if the inverter stops its output during operation because of sensor signals or other reasons, operation will resume automatically. Design your machinery so that safety is ensured even in such cases.

Otherwise an accident could occur.

Under sleep mode of PID control – "PID-STP" (Function code data = 44)

This output signal is ON when the inverter is in a stopped state due to the slow flowrate stopping function under PID control.) (Function codes J15 to J17, J23 J24)

Low torque detected – "U-TL" (Function code data = 45)

This output signal comes ON when the torque value calculated by the inverter or torque command drops below the level specified by E80 (Low torque detection (Level)) for the period specified by E81 (Low torque detection (Timer)). (minimum width of the output signal: 100 ms) (Function codes E80, E81)

Running forward – "FRUN" (Function code data = 52) Running reverse – "RRUN" (Function code data = 53)

Output signal	Assigned data	Running forward	Running reverse	Inverter stopped
"FRUN"	52	ON	OFF	OFF
"RRUN"	53	OFF	ON	OFF

Under remote mode – "RMT" (Function code data = 54)

This output signal comes ON when the inverter switches from local to remote mode.

For details of switching between remote and local modes, refer to Chapter 3 "3.3.6 Remote and local modes."

Run command entered – "AX2" (Function code data = 55)

This output signal comes ON the moment the inverter is ready to run after receipt of a run command.

 \square Refer to E01 through E07, Function code data = 38.

Motor overheat detected by thermistor – "THM" (Function code data = 56)

When the PTC thermistor on the motor detects an overheat, the inverter turns this signal ON and continues to run, without entering the alarm *U*/-// state. This feature applies only when H26 data is set to "2."

(Function codes H26 and H27)

Terminal [C1] (C1 function)wire break detected – "C1OFF" (Function code data = 59)

This output signal comes ON when the inverter detects that the input current to terminal [C1] (C1 function) drops below 2 mA interpreting it as the terminal [C1] wire broken.

Motor regular switching early warning - "MCHG" (Function code data = 68)

This outputs a motor regular switching early warning signal. (Function codes J437)

Pump control output limit signal – "MLIM" (Function code data = 69)

When the pump control mode selection is enabled (J401 \neq 0), all of the enabled motors are to be driven. With all motors being driven, if the motor increase judgment is established by the motor increase judgment (Judgment frequency) (J450) and (Duration time) (J451), the inverter issues an "MLIM" signal.

This signal detects the discharge rate (pressure) remaining low due to pump pipe rupture. etc.

Speed deviation excess detected -- "PG-ERR" (Function code data = 76)

This output signal comes ON when the inverter detects a speed deviation excess error with the d23 (speed deviation excess error processing) data being set to "0: Continue to run," in which the inverter does not enter the alarm state. (I Function codes d21 through d23.)

■ Low DC link bus voltage detection – "U-EDC" (Function code data = 77)

This output signal comes ON when the DC intermediate voltage drops below E76 (DC link bus low-voltage detection level), and it goes OFF when the DC intermediate voltage exceeds E76. (

■ During decelerating at momentary power failure – "IPF2" (Function code data = 79)

When F14 data is set to 2 or 3, this output signal comes ON when the DC intermediate voltage drops below H15 (Continue to run level) and continue to run control starts. When the power returns and the DC intermediate voltage becomes "at least 10 V higher than the voltage specified by H15," the signal goes OFF.

Even when F14 data is set to 4 or 5, the signal comes ON when the DC intermediate voltage drops below the undervoltage level, and it goes OFF when the DC intermediate voltage becomes "at least 10 V higher than the undervoltage level." (

■ Maintenance timer counted up – "MNT" (Function code data = 84)

Once the inverter's cumulative run time or the startup times for the motor 1 exceeds the previously specified count, this output signal comes ON. (

■ Frequency arrival AND frequency detected – "FARFDT" (Function code data = 87)

The FARFDT, which is an ANDed signal of FAR and FDT, comes ON when both signal conditions are met.

(Function codes E30 to E32)

■ Auxiliary motor drive signal – "AUX_L" (Function code data = 88)

This output signal comes ON when all motors enabled by MEN1 to MEN4 (Enable pump control motor 1 to 4 to be driven) are running and the frequency of inverter-driven motors reaches the frequency operation level of the auxiliary motor (J465).

When the frequency of inverter-driven motors drops below the hysteresis width of the auxiliary motor (J466), this signal goes OFF.

When PID control is disabled (J01 = 0) or pump control is disabled (J401 = 0), this output signal is OFF. (\square Function codes J465 to J469.)

■ Light alarm – "L-ALM" (Function code data = 98)

This output signal comes ON when a light alarm occurs. (Function codes H81 and H82)

■ Alarm output (for any alarm) – "ALM" (Function code data = 99)

This output signal comes ON if any of the protective functions is activated and the inverter enters Alarm mode.

■ Customizable logic output signal 1 to 10 – "CLO1" to "CLO10" (Function code data =111 to 120)

Outputs the result of customizable logic operation. (

■ Motor 1 to Motor 3 being driven by inverter – "M1_I" to "M3_I" (Function code data = 160, 162, and 164)

These signals are used to find inverter-driven motors in pump operation. Assign these signals for motors to be driven by the inverter when the "inverter drive motor floating system" (J401 = 2 or 12) or the "inverter drive motor floating + commercial power-driven motor system" (J401 = 3 or 13) is selected. (\square Function code J401.)

Motor 1 to Motor 4 being driven by commercial power -- M1_L to M4_L (Function code data = 161, 163, 165, and 167)

These signals are used to find motors being driven by commercial power in pump operation. Assign these signals for motors to be driven by commercial power when the "inverter drive motor fixed system" (J401 = 1), the "inverter drive motor floating system" (J401 = 2 or 12), or the "inverter drive motor floating + commercial power-driven motor system" (J401 = 3 or 13) is selected. (\Box Function code J401.)

■ In mutual operation – "M-RUN" (Function code data = 180)

This output signal comes ON when two or more motors are running in mutual operation (J401 = 52 or 54). (\Box Function code J401 through J404.)

Alarm in mutual operation – "M-ALM" (Function code data = 181)

This output signal comes ON when two or more motors are stopped due to alarm in mutual operation (J401 = 52 or 54). (\Box Function code J401 through J404.)

Under external PID1 control – "EPID1-CTL" (Function code data = 211)

This signal comes ON when external PID control is selected, respectively. (L Function code J501.)

External PID1 output -- EPID1-OUT (Function code data = 212)

This signal is duty output of external PID control. (Function code J501).

Running under external PID1 – "EPID1-RUN" (Function code data = 213)

This signal comes ON when external PID is activated. (Function code J501).

External PID1 alarm – "EPV1-ALM" (Function code data = 214)

This signal comes ON when external PID1 alarms occur with external PID control selected. (Function code J521, J522, J524.)

External PID1 feedback error – "EPV1-OFF" (Function code data = 215)

This signal comes ON when a feedback (PV) level error occurs when external PID control is selected. (

E30	Frequency arrival detection width (Detection width)	
-----	---	--

E30 specifies the detection level for the Frequency (speed) arrival signal "FAR".

Output signal	E20 to E22, E24, E27 assigned data	Operating condition 1	Operating condition 2
"FAR"	1	The signals come ON when the difference between the output frequency (estimated/actual speed) and the reference frequency (reference speed) comes within the frequency arrival width specified by E30.	FAR always goes OFF when the run command is OFF or the reference speed is "0".

• Data setting range: E30: 0.0 to 10.0 (Hz)

The operation timings of each signal are as shown below.



Figure 5.3-9







Figure 5.3-11

E31, E32

Frequency detection (level and hysteresis width)

When the output frequency exceeds the frequency detection level specified by E31, the "Frequency (speed) detection signal" comes ON; when it drops below the "Frequency detection level minus Hysteresis width specified by E32," it goes OFF.

The following three settings are available.

		E20 to E22,	Operation level	Hysteresis width
Name	Output signal	E24, E27 assigned data	Range: 0.0 to	Range: 0.0 to
		abolghod dala	120.0 Hz	120.0 Hz
Frequency detection	"FDT"	2	E31	E32



E34, E35Overload early warning/Current detection (level and timer)E37, E38Low current detection (level and timer)

These function codes define the detection level and time for the Motor overload early warning "OL", Current detected "ID", and Low current detected "IDL" output signals.

Output	E20 to E22, Detection level 7 E24, E27		Timer	Motor characteristics	Thermal time constant
signal	Assigned data	Range: See below	Range: 0.01 to 600.00 s	Range: See below	Range: 0.5 to 75.0 min
"OL"	7	E34	—	F10	F12
"ID"	37	E34	E35		
"IDL"	41	E37	E38		—

· Data setting range

Detection level: 0.00 (Disable), 1 to 150% of inverter rated current

Motor characteristics 1: Enable (For a general-purpose motor with shaft-driven cooling fan)

2: Enable (For an inverter-driven motor, non-ventilated motor, or motor with separately powered cooling fan)

Motor overload early warning signal – "OL"

The OL signal is used to detect a symptom of an overload condition (alarm code \mathcal{J}_{-}^{\prime} /) of the motor so that the user can take an appropriate action before the alarm actually happens. The OL signal turns ON when the inverter output current exceeds the level specified by E34. In typical cases, set E34 data to 80 to 90% against F11 data (Electronic thermal overload protection for motor 1, Overload detection level). Set the temperature characteristics of the motor with electronic thermal (motor characteristics selection, thermal time constant).

■ Current detected – "ID"

When the inverter output current exceeds the level specified by E34 for the period specified by E35, the ID signal turns ON, respectively. When the output current drops below 90% of the specified detection level, the ID turns OFF. (The minimum ON-duration is 100 ms.)



■ Low current detected – "IDL"

This signal turns ON when the output current drops below the level specified by E37 (Low current detection, Level) for the period specified by E38 (Timer). When the output current exceeds the "Low current detection level plus 5% of the inverter rated current," it goes OFF. (The minimum ON-duration is 100 ms.)



E42 LED display filter

Excluding speed monitor (when E43 = 0), E42 specifies a filter time constant to be applied for displaying the output frequency, output current and other running status monitored on the LED monitor on the keypad. If the display varies unstably so as to be hard to read due to load fluctuation or other causes, increase this filter time constant.

• Data setting range: 0.0 to 5.0 (s)

E43	LED monitor (Item selection)
	Related function code: E48 LED monitor (speed monitor item)

E43 specifies the running status item to be monitored and displayed on the LED monitor. Specifying the speed monitor with E43 provides a choice of speed-monitoring formats selectable with E48 (LED monitor).

Monitor item		Display sample on the LED monitor	LED indication	Unit	Meaning of displayed value	E43 data
Spe	ed monitor	Function co indicators.	ode E48 specifies	s what to	be displayed on the LED monitor and LED	0
	Output frequency 1 (PM: Speed command value)	50.DD	■Hz□A□kW	Hz	Indicated value = Output frequency (Hz)	(E48 = 0)
	Output frequency 2 (PM: Speed estimated value)	<i>50.00</i>	■Hz□A□kW	Hz	Indicated value = Output frequency (Hz)	(E48 = 1)
	Reference frequency	50.00	■Hz□A□kW	Hz	Indicated value = Reference frequency (Hz)	(E48 = 2)
	Motor rotation speed	<i>1500</i>	■Hz∎A□kW	min ⁻¹	Indicatedvalue = Output frequency(Hz) $\times \frac{120}{P01}$	(E48 = 3)
	Load rotation speed	300,0	■Hz∎A□kW	min ⁻¹	Indicated value = Output frequency (Hz) \times E50	(E48 = 4)
	Speed (%)	50.0	□Hz□A□kW	%	$Indicatedvalue = \frac{Outputfrequency(Hz)}{Maximumfrequency} \times 100$	(E48 = 7)
Output current		12.34	□Hz∎A□kW	А	Current output from the inverter in RMS	3
Output voltage		נומכ	□Hz□A□kW	V	Output voltage (RMS) of the inverter	4
Calculated torque		50	□Hz□A□kW	%	Motor output torque in % (Calculated value)	8
Input power		10.25	□Hz□A ■ kW	kW	Input power to the inverter	9
PID	process command	ום.חם.	□Hz□A□kW	-	PID command and its feedback converted into	10
PID	feedback value	<i>9.00</i> .	□Hz□A□kW	-	physical quantities of the object to be controlled (e.g. temperature)	12
PIC	output	וביבה.	□Hz□A□kW	%	PID output in % as the maximum frequency (F03) being at 100%	14
Loa	d factor	50L	□Hz□A□kW	%	Load factor of the motor in % as the rated output being at 100%	15
Mo	or output	<i>9.8</i> 5	□Hz□A ■ kW	kW	Motor output in kW	16
Ana mo	alog signal input nitor	82.00	□Hz□A□kW	-	An analog input to the inverter in a format suitable for a desired scale.	17
Inp	ut watt-hour	נססו	□Hz□A□kW	kWh	$Indicatedvalue = \frac{Inputwatt - hour(kWh)}{100}$	25
Ext con valu	ernal PID1 process nmand (final) (physical ue)	12.00.	□Hz□A□kW	-	External PID1 control command value or PID feedback value converted into physical quantities	60
External PID1 feedback value (physical value)		<i>9.00</i> .	□Hz□A□kW	-	of the object to be controlled and then displayed.	61
Ext	ernal PID1 output (%)	82.00	□Hz□A□kW	%	External PID1 control output displayed as percentage with maximum output frequency (F03) being 100%.	62
Ext con	ernal PID1 manual nmand (%)	82.00	□Hz□A□kW	%	External PID1 control command value displayed as percentage with maximum output frequency (F03) being 100%.	63

■ Illuminated, □ Not illuminated

E44 LED

LED monitor (display when stopped)

E44 specifies whether the specified value (data = 0) or the output value (data = 1) will be displayed on the LED monitor of the keypad when the inverter is stopped. The monitored item depends on the E48 (LED monitor, Speed monitor item) setting as shown below.

E48 data	Monitorod itom	Inverter stopped		
E40 Uala	Monitored item	E44 = 0 Specified value	E44 = 1 Output value	
0	Output frequency 1 (PM: Speed command value)	Reference frequency	Output frequency 1 (PM: Speed command value)	
1	Output frequency 2 (PM: Speed estimated value)	Reference frequency	Output frequency 2 (PM: Speed estimated value)	
2	Reference frequency	Reference frequency	Reference frequency	
3	Motor rotation speed	Reference motor rotation speed	Motor rotation speed	
4	Load rotation speed	Reference load rotation speed	Load rotation speed	
7	Speed (%)	Reference display speed	Display Speed	

E48

LED monitor (speed monitor item)

(refer to E43)

For details about LED Monitor (Speed monitor item), refer to the description of E43.

E50 Display coefficient for speed monitor

E50 specifies the coefficient that is used when the load shaft speed or line speed is displayed on the LED monitor. (Refer to the description of E43.)

Load shaft speed $[min^{-1}] = (E50: Display coefficient for speed monitor) \times (Output frequency Hz)$

Line speed [m/min] = (E50: Display coefficient for speed monitor) × (Output frequency Hz)

• Data setting range: 0.01 to 200.00

E51

Display coefficient for "Input watt-hour data"

E51 specifies a display coefficient (multiplication factor) for displaying the input watt-hour data $(5_{-} / 2)$ in a part of maintenance information on the keypad.

Input watt-hour data = Display coefficient (E51 data) × Input watt-hour (100kWh)

• Data setting range: 0.000 (cancel/reset) 0.001 to 9999



Setting E51 data to 0.000 clears the input watt-hour and its data to "0." After clearing, be sure to restore E51 data to the previous value; otherwise, input watt-hour data will not be accumulated.

E52 Keypad (Menu display mode)

E52 data	Menu display mode	Menus to be displayed	
0	Function code data editing mode	Menus #0, #1 and #7	
1	Function code data check mode	Menus #2 and #7	
2	Full-menu mode	Menus #0 through #7	

E52 provides a choice of three menu display modes for the standard keypad as listed below.

E52 specifies the menus to be displayed on the standard keypad. There are eight menus as shown in the table below.

Menu #	LED monitor shows:	Function	Display content
0	D. FnE	Quick setup	Quick setup function code
1	1. F	Data setting F to o	F to o group function code
2	2. rEP	Data check	Modified function code
3	3. oPE	Operation monitor	Operation status indication
4	40	I/O check	DIO, AIO status indication
5	S. CHE	Maintenance	Maintenance information indication
6	5. AL	Alarm information	Alarm information indication
7	יציק, ב	Data copy	Data copy function (only optional keypad)

For details of each menu item, refer to Chapter 3 "OPERATION USING THE KEYPAD."

E59 Terminal [C1] function selection (C1 function//V2 function)

Specifies whether terminal [C1] is used with current input +4 to +20 mA/0 to 20 mA or voltage input 0 to +10 V. In addition, switch SW7 on the interface board must be switched.

E59 data	Input form	Switch SW7
0	Current input: 4 to 20 mA/0 to 20 mA (C1 function)	C1
1	Voltage input: 0 to 10 V (V2 function)	V2

(Note When using terminal [C1] as a PTC thermistor input, specify E59 = 0.

For using terminal [C1] for the C1, V2 or PTC function, switching as shown below is necessary.

Terminal [C1]	SW3	SW4	E59	H26	C40
For use of C1 function (4 to 20 mA)	C1	AI	0	0	0,10
For use of C1 function (0 to 20 mA)	C1	AI	0	0	1, 11
For use of V2 function (0 to +10 V)	V2	AI	1	0	Does not matter
For use of PTC function	C1	PTC	Does not matter	1,2	Does not matter

For details about SW3 and SW4, refer to Chapter 2, Section 2.2.8.

Failure to correctly switch as shown above may cause a wrong analog input value, possibly leading to unexpected operation of the inverter.

Injuries may occur.

Failure may occur.

E61 to E63 Terminals [12], [C1] (C1 function), [C1] (V2 function) (extended function)

Select the functions of terminals [12], [C1] (C1 function) and [C1] (V2 function).

There is no need to set up these terminals if they are to be used for frequency command sources.

E61, E62, E63 data	Function	Description	
0	None	_	
1	Auxiliary frequency command 1	Auxiliary frequency input to be added to the reference frequency given by frequency setting 1 (F01). Will not be added to any other reference frequency given by frequency setting 2 and multistep frequency commands, etc. 100%/full scale	
2	Auxiliary frequency command 2	Auxiliary frequency input to be added to all frequency commands. Will be added to frequency command 1, frequency command 2, multistep frequency commands, etc. 100%/full scale	
3	PID process command	Inputs command sources such as temperature and pressure under PID control. You also need to set function code J02. 100%/full scale	
5	PID feedback value	Inputs feedback values such as temperature and pressure under PID control. 100%/full scale	
20	Analog signal input monitor	By inputting analog signals from various sensors such as the temperature sensors in air conditioners to the inverter, you can monitor the state of external devices via the communications link. By using an appropriate display coefficient, you can also have various values to be converted into physical quantities such as temperature and pressure before they are displayed. 100%/full scale	
41	External PID process command	Inputs command values such as temperature and pressure for external PID control. 100%/full scale	
42	External PID feedback value	Inputs feedback such as temperature and pressure for external PID control. 100%/full scale	
43	External PID manual command (%)	Inputs manual command values such as temperature and pressure for external PID control. 100%/full scale	



If these terminals have been set up to have the same data, E61 is given priority. For E62 and E63, only the terminal selected with E59 is enabled.

E64

Saving of digital reference frequency

E64 specifies how to save the reference frequency specified in digital format by the \odot/\odot keys on the keypad as shown below.

E64 data	Function
0	The reference frequency will be automatically saved when the main power is turned OFF. At the next power-on, the reference frequency at the time of the previous power-off applies.
1	Saving by pressing 💮 key. Pressing the 🕽 key saves the reference frequency. If the control power is turned OFF without pressing the [image] key, the data will be lost. At the next power-ON, the inverter uses the reference frequency saved the 🚔 key was pressed.

E65 Reference lo

Reference loss detection (continuous running frequency)

When the analog frequency command (setting through terminal [12], [C1] (C1 function) or [C1] (V2 function) has dropped below 10% of the reference frequency within 400 ms, the inverter presumes that the analog frequency command wire has been broken and continues its operation at the frequency determined by the ratio specified by E65 to the reference frequency. And "REF OFF" signal comes on.

(Function codes E20 to E22, E24 and E27, data = 33)

When the frequency command level (in voltage or current) returns to a level higher than that specified by E65, the inverter presumes that the broken wire has been fixed and continues to run following the frequency command.



In the diagram above, f1 is the level of the analog frequency command sampled at any given time. The sampling is repeated at regular intervals to continually monitor the wiring connection of the analog frequency command.

Data setting range:0 (Decelerate to stop) 20 to 120 % 999 (Disable)

Note

Avoid an abrupt voltage or current change for the analog frequency command. An abrupt change may be interpreted as a wire break.

Setting E65 data at "999" (Disable) allows the REF OFF signal ("Reference loss detected") to be issued, but does not allow the reference frequency to change. (The inverter runs at the analog frequency command as specified.)

When E65 = "0" or "999," the reference frequency level at which the broken wire is recognized as fixed is "f1 \times 0.2."

When E65 = "100" (%) or higher, the reference frequency level at which the wire is recognized as fixed is "f1 \times 1."

The reference loss detection is not affected by the setting of analog input adjustment (filter time constants: C33, C38, and C43).

E76 DC link bus low

DC link bus low-voltage detection level

"U-EDC" signal comes ON when the DC intermediate voltage drops below E76 (DC link bus low-voltage detection level), and it goes OFF when the DC intermediate voltage exceeds E76.

(Function codes E20 to E22, E24 and E27, data = 77)
E80, E81 Torque detection 2/low torque detection (level and timer)

E80 specifies the operation level and E81 specifies the timer, for the output signal "U-TL".

In the inverter's low frequency operation, as a substantial error in torque calculation occurs, no low torque can be detected within the operation range at less than 20% of the base frequency (F04). (In this case, the result of recognition before entering this operation range is retained.) The U-TL signal goes off when the inverter is stopped.

Since the motor parameters are used in the calculation of torque, it is recommended that auto-tuning be applied by function code P04 to achieve higher accuracy.

Output signal	Assigned data	Detection level	Timer	
	Assigned data	Range: 0 to 300%	Range: 0.01 to 600.00 s	
"U-TL"	45	E80	E81	

■ Low torque detected – "U-TL"

This output signal comes ON when the torque value calculated by the inverter or torque command drops below the level specified by E80 (Low torque detection (Level)) for the period specified by E81 (Low torque detection (Timer)). The signal turns OFF when the calculated torque exceeds "the level specified by E80 or E80 plus 5% of the motor rated torque." (The minimum ON-duration is 100 ms.)





For details, refer to the descriptions of E01 to E05.

5.3.3 C codes (Control functions)

C01 to C04 Jump frequency 1, 2 and 3, Jump frequency (Skip width)

These function codes enable the inverter to jump over three different points on the output frequency in order to skip resonance caused by the motor speed and natural frequency of the driven machinery (load).

- While increasing the reference frequency, the moment the reference frequency reaches the bottom of the jump frequency band, the inverter keeps the output at that bottom frequency. When the reference frequency exceeds the upper limit of the jump frequency band, the internal reference frequency takes on the value of the reference frequency. When decreasing the reference frequency, the situation will be reversed. Refer to the left figure below.
- When more than two jump frequency bands overlap, the inverter actually takes the lowest frequency within the overlapped bands as the bottom frequency and the highest as the upper limit. Refer to the right figure below.



■ Jump frequency 1, 2 and 3 (C01, C02 and C03)

Specify the center of the jump frequency band.

• Data setting range: 0.0 to 120.0 (Hz) (Setting to 0.0 results in no jump frequency band.)

■ Jump frequency skip width (C04)

Specify the jump frequency skip width.

• Data setting range: 0.0 to 30.0 (Hz) (Setting to 0.0 results in no jump frequency band.)

C05 to C19 Multistep frequency 1 to 15

■ These function codes specify 15 frequencies required for driving the motor at frequencies 1 to 15.

Turning terminal commands "SS1", "SS2", "SS4" and "SS8" ON/OFF selectively switches the reference frequency of the inverter in 15 steps. To use this features, you need to assign "SS1", "SS2", "SS4" and "SS8" ("Select multistep frequency") to the digital input terminals with E01 to E05 (data = 0, 1, 2, and 3).

■ Multistep frequency 1 to 15 (C05 through C19)

• Data setting range: 0.00 to 120.0 (Hz)

The combination of "SS1", "SS2", "SS4" and "SS8" and the selected frequencies is as follows.

"SS8"	"SS4"	"SS2"	"SS1"	Selected frequency command	
OFF	OFF	OFF	OFF	Other than multistep frequency*	
OFF	OFF	OFF	ON	C05 (Multistep frequency 1)	
OFF	OFF	ON	OFF	C06 (Multistep frequency 2)	
OFF	OFF	ON	ON	C07 (Multistep frequency 3)	
OFF	ON	OFF	OFF	C08 (Multistep frequency 4)	
OFF	ON	OFF	ON	C09 (Multistep frequency 5)	
OFF	ON	ON	OFF	C10 (Multistep frequency 6)	
OFF	ON	ON	ON	C11 (Multistep frequency 7)	
ON	OFF	OFF	OFF	C12 (Multistep frequency 8)	
ON	OFF	OFF	ON	C13 (Multistep frequency 9)	
ON	OFF	ON	OFF	C14 (Multistep frequency 10)	
ON	OFF	ON	ON	C15 (Multistep frequency 11)	
ON	ON	OFF	OFF	C16 (Multistep frequency 12)	
ON	ON	OFF	ON	C17 (Multistep frequency 13)	
ON	ON	ON	OFF	C18 (Multistep frequency 14)	
ON	ON	ON	ON	C19 (Multistep frequency 15)	

* "Other than multistep frequency" includes frequency setting 1 (F01), frequency setting 2 (C30) and other frequency command sources except multistep frequency commands.

C21 C22 to C28

Pattern operation mode selection Stage 1 to 7

Pattern operation is a function of automatic operation according to the predefined run time, rotational direction, acceleration/deceleration time and reference frequency.

When using this function, set the frequency setting (F01) to 10 (pattern operation).

The following operation patterns are available:

C21:Setting	Operation pattern
0	Pattern operation performed for one cycle and stopped after the cycle.
1	Pattern operation repeatedly performed and immediately stopped with a stop command
2	Pattern operation performed for one cycle and operation continued at the reference frequency after the cycle.



■ C22 to C28 Stage 1 to Stage 7

Specify the run time for Stage 1 to Stage 7.

Press the 📾 key three times for each function code to set the following three data.

Setting	Description							
1st	Specifies the ru	Specifies the run time between 0.0 and 3600 s.						
2nd	2nd: Specifies	2nd: Specifies the rotational direction F (forward) or r (reverse)						
3rd	3rd: Specifies t 1: F07/F08	3rd: Specifies the acceleration/deceleration time between 1 and 4.1: F07/F082: E10/E113: E12/E134: E14/E15						

If the 🕮 key is pressed to exit the function code before the three data are specified by pressing the 🚔 key three times, no data are updated.

For any unused stage, specify 0.0 as the run time. The stage is skipped and the next stage becomes ready for setting.

Reference frequency

Multistep frequencies 1 to 7 are assigned to the reference frequency of Stage 1 to 7.

C21 (Mode selection)	Stage No.	Run time	Rotational direction	Acceleration/deceler ation time	Operation (reference)	
		Setting value	Setting value	Setting value	nequency	
	Stage 1	60.0	F	2	C05 Multistep frequency 1	
0	Stage 2	100	F	1	C06 Multistep frequency 2	
	Stage 3	65.5	r	4	C07 Multistep frequency 3	
	Stage 4	55.0	r	3	C08 Multistep frequency 4	
	Stage 5	50.0	F	2	C09 Multistep frequency 5	
	Stage 6	72.0	F	4	C10 Multistep frequency 6	
	Stage 7	35.0	F	2	C11 Multistep frequency 7	

Example of pattern operation setting

The figure below illustrates the operation.



F08 Deceleration time 1 setting is used as deceleration time for deceleration to stop after the completion of one cycle.

◆ To run or stop, use input from the we key of the keypad or by switching the control terminal. When using the keypad, press the we key to run. Press the we key to suspend the progression of stages. Press the we key again to resume operation according to the stages from the point where it was suspended. For alarm stop, press the we key to reset the inverter protective functions. Then press the we key. The suspended progression of the cycle resumes. If a need arises for operation from the first stage "C22 (Stage 1 runtime)" and "C82 (Stage 1 rotational direction and acceleration/deceleration time)" during operation, input a stop command and press the key.

When operation from the first stage is necessary after an alarm stop, press the is key for resetting the protective functions and press the key again. For operation with input terminals, use of the "RST" terminal (set "8 (Active ON)" or "1008 (Active OFF)" for any of E01 to E05) function the same way.

- Pattern operation can be started by either a forward run command (specify F02 = 2 and press the weight key, or specify F02 = 1 and turn the FWD terminal ON) or reverse run command (specify F02 = 3 and press the weight key, or specify F02 = 1 and turn the REV terminal ON). However, the rotational direction is as specified by C82 to C88 regardless the operation is started by a forward run command or reverse run command.
 - If using FWD or REV terminal, please use the alternate-type switch because it is not self-holding.

When pattern operation is started by specifying C21 = 0 and turning the FWD (REV) terminal ON, the motor stops after the completion of the last stage even if the FWD (REV) terminal is kept turned ON. In this case, modifying the value for F01 or C30 or switching the control terminal "Hz2/Hz1" ON/OFF without turning the FWD (REV) terminal OFF causes the operation to be immediately resumed according to the reference frequency after the change.

An accident or physical injury may result.

C30

Frequency setting 2

(refer to F01)

For details of frequency setting 2, refer to the description of F01.

Analog input adjustment (terminal [12])
(offset, gain, filter time constant, gain base point, polarity)
Analog input adjustment (terminal [C1] C1 function)
(offset, gain, filter time constant, gain base point, range/polarity)
Analog input adjustment (terminal [C1] V2 function)
(offset, gain, filter time constant, gain base point, polarity)
(refer to F01 for frequency setting)
Bias (for PID, frequency command 2 (terminal [12])) (bias, bias base point) (refer to F01)

C61, C62	Bias (for PID, frequency command 2 (terminal [C1]) (C1 function))
	(bias, bias base point)(refer to F01)
C67, C68	Bias (for PID, frequency command 2 (terminal [C1]) (V2 function))
	(bias, bias base point)(refer to F01)

You can adjust the gain, bias, polarity, filter time constant and offset which are applied to analog inputs (voltage inputs to terminals [12] and [C1] (V2 function) and current input to terminal [C1] (C1 function)).

Input terminal	Input rongo	Bias		Gain		Delerity	Filter time	Offeet
	input lange	Bias	Base point	Gain	Base point	Folanty	constant	Oliset
[12]	0 to +10 V, -10 to +10 V	C55	C56	C32	C34	C35	C33	C31
[C1] (C1)	4 to 20 mA, 0 to 20 mA	C61	C62	C37	C39	C40	C38	C36
[C1] (V2)	0 to +10 V	C67	C68	C42	C44	C45	C43	C41

Adjustable items for analog inputs (excluding those for frequency command 1)

■ Offset (C31, C36, C41)

C31, C36 or C41 configures an offset for an analog voltage/current input.

• Data setting range: -5.0 to +5.0 (%)

■ Filter time constant (C33, C38, C43)

C33, C38, and C43 provide the filter time constants for the voltage and current of the analog input. The larger the time constant, the slower the response. Specify the proper filter time constant taking into account the response speed of the machine (load). If the input voltage fluctuates due to line noises, increase the time constant.

• Data setting range: 0.00 to 5.00 (s)

Polarity Terminal [12] (C35)

C35 and C45 configure the input range for analog input voltage.

C35 data	Modes for terminal inputs
0	-10 to +10 V
1	0 to +10 V (negative value of voltage is regarded as 0 V)

Polarity [C1] (V2 function) (C45)

C45 data	Modes for terminal inputs
0	0 to +10 V When the bias is specified to be a negative value, makes a point lower than 0 effective as a negative value.
1	0 to +10 V (factory default) When the bias is specified to be a negative value, limits a point lower than 0 to 0.





Note To input bipolar analog voltage (0 to ±10 VDC) to terminal [12], set C35 data to "0." Setting C35 data to "1" enables only the voltage range from 0 to +10 VDC and interprets the negative polarity input from 0 to -10 VDC as 0 V.

■ Terminal [C1] (C1 function) range / polarity selection(C40)

Selects the range of current input terminal [C1](C1 function).

C40 data	Terminal input range	When specified bias is negative		
0	4 to 20 mA (factory default)	Limite a point lower than 0 to 0		
1	0 to 20 mA	Limits a point lower than 0 to 0.		
10	4 to 20 mA	Makes a point lower than 0 effective as a negative		
11	0 to 20mA	value.		

For using terminal [C1] for the C1, V2 or PTC function, it is necessary to make the settings as shown below.

Terminal [C1]	SW3	SW4	E59	H26	C40
For use of C1 function (4 to 20 mA)	C1	AI	0	0	0, 10
For use of C1 function (0 to 20 mA)	C1	AI	0	0	1, 11
For use of V2 function (0 to +10V)	V2	AI	1	0	Does not matter
For use of PTC function	C1	PTC	Does not matter	1, 2	Does not matter

For details about SW3 and SW4, refer to Chapter 2, Section 2.2.8.

Expected operation may not be obtained if the settings above are not switched correctly. Use sufficient caution.

Gain/bias



These are biases and bias base points used for PID command, PID feedback, frequency command 2 and analog monitor. For details, refer to the description of F01 and J01.

Bias (C55, C61, C67)

• Data setting range: -100.00 to 100.00 (%)

Bias base point (C56, C62, C68)

• Data setting range: 0.00 to 100.00 (%)

Specifying the bias as a negative value allows an input to be specified as bipolar for a unipolar analog input. By setting C40 data to 10 or 11 for terminal [C1] (C1 function) or C45 data to 1 for terminal [C1] (V2 function), an input value for an analog input equal to or lower than 0 point is specified to have negative polarity.

Refer to the description of F01.

C53

Selection of normal/inverse operation (frequency setting 1)

Switches between the between normal and inverse operation of frequency setting 1 (F01) .

For details, refer to E01 through E05 (data = 21) for the terminal command IVS ("■ Switch normal/inverse operation – "IVS"").

C58	Analog input adjustment (for analog monitor (terminal [12])) (Display unit)
C64	Analog input adjustment (for analog monitor (terminal [C1])) (C1 function) (Display unit)
C70	Analog input adjustment (for analog monitor (terminal [C1])) (V2 function) (Display unit)

The units for the respective analog inputs can be displayed when a multi-function keypad (TP-A1-E2C) is used. Set these codes to use for command and feedback values of the PID control and the analog input monitor. Use the multi-function keypad to display the SV and PV values of the PID control and the analog input monitor on the main and sub-monitors. Indications are given in the specified units.

C58, C64, C70	Unit	C58, C64, C70	Unit	C58, C64, C70	Unit
_	—	23	L/s (flowrate)	45	mmHg (pressure)
1	No unit	24	L/min (flowrate)	46	Psi (pressure)
2	%	25	L/h (flowrate)	47	mWG (pressure)
4	r/min	40	Pa (pressure)	48	inWG (pressure)
7	kW	41	kPa (pressure)	60	K (temperature)
20	m ³ /s (flowrate)	42	MPa (pressure)	61	°C (temperature)
21	m ³ /min (flowrate)	43	mbar (pressure)	62	°F (temperature)
22	m ³ /h (flowrate)	44	bar (pressure)	80	ppm (concentration)

C59, C60	Analog input adjustment (terminal [12]) (Maximum scale, Minimum scale)
C65, C66	Analog input adjustment (terminal [C1] (C1 function)) (Maximum scale, Minimum scale)
C71, C72	Analog input adjustment (terminal [C1] (V2 function)) (Maximum scale, Minimum scale)

Values of the analog input monitor (terminals [12] and [C1] (C1 and V2 functions) can be converted into easily recognizable physical quantities for display. This function can also be used for PID feedback and PID command values.

• Data setting range: (maximum scale and minimum scale) -999.00 to 0.00 to 9990.00



5.3.4 P codes (Motor 1 parameters)

To use the integrated automatic control functions such as auto torque boost, torque calculation monitoring, auto energy saving operation, torque limiter, automatic deceleration (anti-regenerative control), and auto search for idling motor speed, it is necessary to build a motor model in the inverter by specifying proper motor parameters including the motor capacity and rated current.

The FRENIC-eHVAC, provides built-in motor parameters for Fuji standard motors 8-series. To use these Fuji motors, it is enough to specify motor parameters for P99 (Motor 1 selection). If the cabling between the inverter and the motor is long (generally, 20 m (66 ft) or longer) or a reactor is inserted between the motor and the inverter, however, the apparent motor parameters are different from the actual ones, so auto-tuning or other adjustments are necessary.

For the auto-tuning procedure, refer to the FRENIC-eHVAC Instruction Manual, Chapter 4 "TEST RUN PROCEDURE."

When using a motor made by other manufacturers or a Fuji non-standard motor, obtain the datasheet of the motor and specify the motor parameters manually or perform auto-tuning.

P01

Motor 1 (No. of poles)

P01 specifies the number of poles of the motor. Enter the value given on the nameplate of the motor. This setting is used to display the motor speed on the LED monitor and to control the speed (refer to E43). The following expression is used for the conversion.

Motor rotational speed $(min^{-1}) = 120/No.of$ poles x Frequency (Hz)

- Data setting range: 2 to 22 (poles)
- P02

Motor 1 (Rated capacity)

P02 specifies the rated capacity of the motor. Enter the rated value given on the nameplate of the motor.

P02 data	Unit	Function
0.01 to 1000	kW	When P99 (Motor 1 selection) = 0, 4, 20 or 21
0.01 to 1000	HP	When P99 (Motor 1 selection) = 1

When accessing P02 with the keypad, take into account that the P02 data automatically updates data of P03, P06 through P08, P53 and H46.

P03

Motor 1 (Rated current)

P03 specifies the rated current of the motor. Enter the rated value given on the nameplate of the motor.

• Data setting range: 0.00 to 2000 (A)

P04 Motor 1 (Auto-tuning)

The inverter automatically detects the motor parameters and saves them in its internal memory. Basically, it is not necessary to perform tuning when a Fuji standard motor is used with a standard connection with the inverter.

There are two types of auto-tuning as listed below. Select the appropriate one considering the limitations in your equipment and control mode.

P04 data	Auto-tuning	Action	Motor parameters to be tuned		
0	Disable	—		—	
			IM	Primary resistance (%R1) Leakage reactance (%X)	(P07) (P08)
1	Tune the motor while it is stopped	Tunes while the motor is stopped.	РМ	Armature resistance d-axis inductance q-axis inductance	(P60) (P61) (P62)
		After tuning the motor in a	IM	No-load current Primary resistance (%R1) Leakage reactance (%X)	(P84, P88) (P06) (P07) (P08)
2	Tune the motor while it is rotating.	stopped state, retunes it running at 50% of the base frequency.	РМ	Armature resistance d-axis inductance q-axis inductance Reserved	(P60) (P61) (P62) (P84, P88)

For details of auto-tuning, refer to Chapter 4 "TEST RUN PROCEDURE."

Note In any of the following cases, perform auto-tuning since the motor parameters are different from those of Fuji standard motors so that the best performance cannot be obtained under some conditions.

- The motor to be driven is a non-Fuji motor or a non-standard motor.
- Cabling between the motor and the inverter is long. (Generally, 20 m (66 ft) or longer)
- A reactor is inserted between the motor and the inverter.

Other applicable cases

Functions whose performance is affected by the motor parameters

Function	Related function codes (representative)
Auto torque boost	F37
Output torque monitor	F31, F35
Load factor monitor	F31, F35
Auto energy saving operation	F37
Torque limit control	F40
Anti-regenerative control (Automatic deceleration)	H69
Auto search	H09
Low torque detection	E80 to E81

P06 to P08 Motor 1 (No-load current, %R1 and %X)

P06 through P08 specify no-load current, %R1 and %X, respectively. Obtain the appropriate values from the test report of the motor or by calling the manufacturer of the motor. Performing auto-tuning automatically sets these parameters.

- No-load current: Input the value obtained from the motor manufacturer.
- %R1: Enter the value calculated by the following expression.

$$\%$$
R1= $\frac{$ R1+CableR1}{V/(\sqrt{3} \times I)}×100(%)

R1: Primary resistance of the motor (Ω)

Cable R1: Resistance of the output cable (Ω)

V: Rated voltage of the motor (V)

I: Rated current of the motor (A)

• %X: Enter the value calculated by the following expression.

$$%X = \frac{X1 + X2 \times XM / (X2 + XM) + CableX}{V / (\sqrt{3} \times 1)} \times 100(\%)$$

X1: Primary leakage reactance of the motor (Ω)

X2: Secondary leakage reactance of the motor (converted to primary) (Ω)

XM: Exciting reactance of the motor (Ω)

Cable X: Reactance of the output cable (Ω)

V: Rated voltage of the motor (V)

I: Rated current of the motor (A)

Note For reactance, use the value at the base frequency (F04).

P30	PMSM drive Motor 1 (Magnetic pole position detection mode)
	Related function codes:
	P74:PMSM Motor 1 (Reference current at starting)
	P87:PMSM Motor 1 (Reference current for polarity discrimination)

P30 specifies the magnetic pole position detection mode. Select the appropriate mode that matches the PMSM to be used.

Data for P30	Function	Remarks
0: Pull-in by current	No magnet pole position detection is made. At the start of driving the motor, the inverter supplies current specified by P74 to pull in the magnetic pole position. In this position detection mode, the motor may rotate slightly in the direction opposite to the commanded direction depending upon the current motor shaft position.	Ι
1: For IPMSM (Interior permanent magnet synchronous motor)	The inverter starts the motor with the magnetic pole position detection suitable for IPMSM. The reference current for polarity discrimination specified by P87 applies. Usually it is not necessary to change the factory default.	_
2: For SPMSM (Surface permanent magnet synchronous motor)	The inverter starts the motor with the magnetic pole position detection suitable for SPMSM.	_
3: Pull-in by current for IPMSM (Interior permanent magnet synchronous motor)	The inverter starts the motor with the magnetic pole position detection suitable for IPMSM causing no magnetic saturation. In this position detection mode, the motor may rotate slightly in the direction opposite to the commanded direction depending upon the current motor shaft position.	-

Tip The reference current for polarity discrimination specified by P87 applies. Usually it is not necessary to change the factory default.

Note During the magnetic pole position pull-in operation or the magnetic pole position detection, the motor cannot generate enough torque. When applying to the application which needs torque at start, engage the mechanical brake by using brake signal *BRKS* until magnetic pole position pull-in operation is completed. (III) Function code E20)

P60 to P64

PMSM Motor 1 (Armature resistance, d-axis inductance, q-axis inductance, Induced voltage, and Iron loss)

P60 through P64 specify the armature resistance, d-axis inductance, q-axis inductance, induced voltage and iron loss of the motor, respectively.

The combination of P99 (Motor 1 selection) and P02 (Motor 1 rated capacity) data determines the standard value. Basically, there is no need to modify the setting.



These are the control parameter for PMSMs. Normally, it is not necessary to change the data of these function codes.

P74

PMSM Motor 1 (Reference current at starting)

Refer to P30.

P83, P84, P86, P88, P89 PMSM Motor 1 (Reserved)

These function codes are displayed, but they are reserved for particular manufacturers. Unless otherwise specified, do not access these function codes.

PMSM Motor 1 (Overcurrent protection level)

A PMSM has a current limit to prevent demagnetization of permanent magnet. If a current exceeding that limit flows through the motor, it weakens the magnet force of permanent magnet so that the motor does not get the desired characteristics.

To prevent it, P90 specifies the overcurrent protection level. If a current flows exceeding the level, the inverter causes an overcurrent protection alarm $\Box c$ /, $\Box c c$ or $\Box c c$.

P99	Motor 1 selection	

P99 specifies the motor type to be used.

P99 data	Function
0	Motor characteristics 0 (Fuji standard IM, 8-series)
1	Motor characteristics 1 (HP rating IMs)
4	Other IMs
20	Other PMSMs
21	Motor characteristics PM (Fuji standard PMSM, GNB-series)

To select the motor drive control or to run the inverter with the integrated automatic control functions such as auto torque boost and torque calculation monitoring, it is necessary to specify the motor parameters correctly.

First select the motor type with P99 from Fuji standard motors 8-series, set P02 (capacity) and then initialize the motor parameters with H03. This process automatically configures the related motor parameters (P01, P03, P06 through P08, P53 and H46).

The data of F09 (Torque boost 1), H13 (Restart mode after momentary power failure (Restart time)), and F11 (Electronic thermal overload protection for motor 1 (Overload detection level)) depends on the motor capacity, but the process stated above does not change them. Specify and adjust the data during a test run if needed.

5.3.5 H codes (High performance functions)

H02, H03	Data initialization (Method, Target)
	Related function codes: H193,H194 User initialization data (Save, Protect)

Initialize all function code data to the factory defaults. The motor parameters are also initialized.

To change the H02/H03 data, it is necessary to press the 10^{10} + 10^{10} keys (simultaneous keying).

H03 data	Function
0	Disable initialization (Settings manually made by the user will be retained.)
1	Initialize all function codes (initialization in accordance with function code H02 setting)
2	Initialize motor 1 parameters in accordance with P02 (Rated capacity) and P99 (Motor 1 selection)
11	Limited initialization (initialization other than communications function codes): Communication can be continued after initialization.
12	Limited initialization (initialization of customizable logic function U codes only)

• When all function codes are initialized, select the initialization method in advance with function code H02.

Selection of H02		Initialization method when 1 is set to H03
Data=0	Fuji standard initial value	Initialize all function codes with the Fuji Electric standard factory defaults.
Data=1	User initial value	Initialize the value with the user setting value saved by H194. If the user initial value is not saved, initialize it with Fuji standard initial value (H02=0).

For saving the user initial value, refer to items in function codes H193 and H194.

•	To initialize the motor	parameters,	set the re	elated funct	tion codes a	s follows.
---	-------------------------	-------------	------------	--------------	--------------	------------

Stop	ltom	Dete	Function code
Step	item	Data	1st motor
(1)	Motor selection	Selects the motor type	P99
(2)	Motor (rated capacity)	Sets the motor capacity (kW)	P02
(3)	Data initialization	Initialize motor parameters	H03 = 2
Function code data to be initialized Please refer to the F42 when using PMSM drive (F42=15)		ed ing PMSM drive (F42=15)	P01, P03, P06 to P08, P30, P60 to P65, P74,P83 to P90, H46

• Upon completion of the initialization, the H03 data reverts to "0" (factory default).

• If P02/A16 data is set to a value other than the standard nominal applied motor rating, data initialization with H03 internally converts the specified value parameters values to the standard nominal applied motor rating. (See "5.2.4 Motor constant.")

• Motor parameters to be initialized are for motors listed below under V/f control. When the base frequency, rated voltage, and the number of poles are different from those of the listed motors, or when non-Fuji motors or non-standard motors are used, change the rated current data to that printed on the motor nameplate.

	Motor selection	V/f control data
Data = 0 or 4	Fuji standard motors, 8-series	4 poles 400 V/50 Hz
Data = 1	HP rating motors	4 poles 460 V/60 Hz

Note When accessing P02 with the keypad, take into account that the P02 data automatically updates data of P03, P06 through P08, P53 and H46. Also, when accessing function code A16 for the 2nd motor, data of related function codes for each are automatically updated.

H193,	
H194	

User initial value (save, protection)

Relevant function code: Initialization of H02 and H03 data (initial value selection and target)

The value can be saved in the non-volatile memory in the inverter so that customers may use the setting value changed from the Fuji Electric standard factory default value as the initial value for inverter initialization.

The setting value saved and protected here can be selected as the user initial value for initialization with function code H03. When this function is used, set H02 data=1.

If initialization is performed without saved/protected setting data, it is initialized to the Fuji Electric standard factory default regardless of the H02 value.

For data initialization, refer to function codes H02 and H03.

To save the user setting value, set 1 (saved as the user initial value) to function code H02 in advance. In addition, function code H194 must be set to 0 (save enable).

H02 data	H194 data	Function when 1 is set to H193
0	Optional	User setting value is not saved.
1	0 : Save enable	User setting value is saved.
	1 : Protected (save disable)	User setting value is not saved.

User initial value save procedures

- (1) Set all function codes and determine the user setting value for initialization.
- (2) Set H02=1 and H194=0.
- (3) Set H193=1. The user setting value is saved.
- (4) Set H194=1. The user setting value is protected.
- When the setting value of the function code has already saved by H193 and the step of H193 is repeated again, the saved data is overwritten. Be careful for error operation. To prevent overwriting by error, it is recommended to protect the data with H194 data=1 after saving.

H04, H05 Auto-reset (Times and reset interval)

H04 and H05 specify the auto-reset function that makes the inverter automatically attempt to reset the tripped state and restart without issuing an alarm output (for any alarm) even if any protective function subject to reset is activated and the inverter enters the forced-to-stop state (tripped state). If the protective function is activated in excess of the times specified by H04, the inverter will issue an alarm output (for any alarm) and not attempt to auto-reset the tripped state.

Protective function	LED monitor displays:	Protective function	LED monitor displays:
Overcurrent protection	DE 1, DE2, DE3	Braking resistor overheat	daH
Overvoltage protection	OLI I, OLIZ, OLIZ	Motor overload	OL I, OLZ
Heat sink overheat	DH I	Inverter overload	OLU
Inverter internal overheat	0H3	Step-out/ Magnetic pole position detection failure	Erd
Motor overheat	<u>ר</u> ואין		

Listed below are the protective functions subject to auto-reset.

Number of reset times (H04)

H04 specifies the number of reset times for the inverter to automatically attempt to escape the tripped state. When H04 = 0, the auto-reset function will not be activated.

• Data setting range: 0 (Disable), 1 to 20 (times)

If the "auto-reset" function has been specified, the inverter may automatically restart and run the motor stopped due to a trip fault, depending on the cause of the tripping. Design the machinery so that human body and peripheral equipment safety is ensured even when the auto-resetting succeeds.

Otherwise an accident could occur.

Reset interval (H05)

• Data setting range: 0.5 to 20.0 (s)

H05 specifies the reset interval time between the time when the inverter enters the tripped state and the time when it issues the reset command to attempt to auto-reset the state. Refer to "Operation timing scheme" below.

<Operation timing scheme>

• In the figure below, normal operation restarts in the 4-th retry.



• In the figure below, the inverter failed to restart normal operation within the number of reset times specified by H04 (in this case, 3 times (H04 = 3)), and issued the alarm output (for any alarm) ALM.



• The auto-reset operation can be monitored from the external equipment by assigning the digital output signal TRY to any of the programmable, output terminals [Y1], [Y2], [Y3], [Y5A/C] or [30A/B/C] by setting E20 to E22, E24 or E27 respectively (data = 26).

Cooling fan ON/OFF control

To prolong the service life of the cooling fan and reduce fan noise during running, the cooling fan stops when the temperature inside the inverter drops below a certain level while the inverter stops. However, since frequent switching of the cooling fan shortens its service life, the cooling fan keeps running for at least 10 minutes once started.

H06 specifies whether to keep running the cooling fan all the time or to enable ON/OFF control.

H06 data	Function
0	Disable (Always in operation)
1	Enable (ON/OFF controllable)

■ Cooling fan in operation -- FAN (E20 to E22, E24 and E27, data = 25)

With the cooling fan ON/OFF control enabled (H06 = 1), this output signal is ON when the cooling fan is in operation, and OFF when it is stopped. This signal can be used to make the cooling system of peripheral equipment interlocked for an ON/OFF control

H07

H06

Curve acceleration/ deceleration

(refer to F07)

For details, refer to the description of F07.

H08	Rotational direction	on limitation			
-----	----------------------	---------------	--	--	--

H08 inhibits the motor from running in an unexpected rotational direction due to miss-operation of run commands, miss-polarization of frequency commands, or other mistakes.

H08 data	Function
0	Disable
1	Enable (Reverse rotation inhibited)
2	Enable (Forward rotation inhibited)

H09, d67	Starting mode (Auto search)
	Related function codes: H49 (Starting mode, auto search delay time 1) H46 (Starting mode, auto search delay time 2)

Specify the mode for auto search without stopping the idling motor. The mode can be specified for each restart after momentary power failure and each start of normal operation. The starting mode can be switched by assigning "STM" to a general-purpose digital input signal. If it is not assigned, "STM" is regarded to be OFF. (Data = 26)

■ H09/d67 (Starting mode, auto search) and terminal command "STM" ("Enable auto search for idling motor speed at starting")

The combination of H09 data and the "STM" status determines whether to perform the auto search as listed below.

Function code	Drive control	Factory default
H09 V/f control (F42 = 0)		0: Disable
d67 Vector control for synchronous motor without pole position sensor nor speed sensor (F42 = 15)		2: Enable

H09/d67 data	Enable auto search for idling motor speed at starting "STM"	Auto search for idling motor speed at starting			
		Restart mode after momentary power failure (F14 = 3 to 5)	For normal startup		
0: DisableOFF1: EnableOFF2: EnableOFF		Disable	Disable		
		Enable	Disable		
		Enable	Enable		
—	ON	Enable	Enable		

When "STM" is ON, auto search for idling motor speed at starting is enabled regardless of the H09/d67 setting. (
Function codes E01 to E05, data =26)

Auto search for idling motor speed to follow

Starting the inverter (with a run command ON, BX OFF, auto-reset, etc.) with STM being ON searches for the idling motor speed for a maximum of 1.2 seconds to run the idling motor without stopping it. After completion of the auto search, the inverter accelerates the motor up to the reference frequency according to the frequency command and the preset acceleration time.



■ Starting mode (auto search delay time 1) (H49)

• Data setting range: 0.0 to 10.0 (s)

Auto search does not function normally when performed with the residual voltage remaining in the motor.

Accordingly, time to allow the residual voltage to disappear must be ensured.

When operation is started by turning a run command ON, auto search is started after the period specified with the starting mode (auto search delay time 1) (H49) has elapsed. When switching between two inverters for controlling one motor and if the motor is coasting to stop at the time of switching to start by auto search, by specifying H49 eliminates the need for timing the run command.

Starting mode (auto search delay time 2) (H46)

• Data setting range: 0.1 to 20.0 (s)

At the restart after a momentary power failure, at the start by turning the terminal command "BX" ("Coast to a stop") OFF and ON, or at the restart by auto-reset, the inverter applies the delay time specified by H46. The inverter will not start unless the time specified by H46 has elapsed, even if the starting conditions are satisfied. The inverter starts after the auto search delay time has elapsed.



Under auto search control, the inverter searches the motor speed with the voltage applied at the motor start and the current flowing in the motor, based on the model built with the motor parameters. Therefore, the search is greatly influenced by the residual voltage in the motor.

H46 is available for motor 1 only. At factory shipment, H46 data is preset to a correct value according to the motor capacity for the general-purpose motor, and basically there is no need to modify the data.

Depending on the motor characteristics, however, it may take time for residual voltage to disappear (due to the secondary thermal time constant of the motor). In such a case, the inverter starts the motor with the residual voltage remaining, which will cause an error in the speed search and may result in occurrence of an inrush current or an overvoltage alarm.

If it happens, increase the value of H46 data and remove the influence of residual voltage.

(If possible, it is recommended to set the value around two times as large as the factory default value allowing a margin.)



- Be sure to auto-tune the inverter preceding the start of auto search for the idling motor speed.
- When the estimated speed exceeds the maximum frequency or the upper limit frequency, the inverter disables auto search and starts running the motor with the maximum frequency or the upper limit frequency, whichever is lower.
- During auto search, if an overcurrent or overvoltage trip occurs, the inverter restarts the suspended auto search.
- Perform auto search at 60 Hz or below.



Note that auto search may not fully provide the performance depending on load conditions, motor parameters, wiring length, and other external factors.

H11 Deceleration mode

H11 specifies the deceleration mode to be applied when a run command is turned OFF.

H11 data	Action
0	Normal deceleration
1	The inverter immediately shuts down its output, so the motor stops according to the inertia of the motor and machinery (load) and their kinetic energy losses.

Note

When reducing the reference frequency, the inverter decelerates the motor according to the deceleration commands even if H11 = 1 (Coast-to-stop).

H12	Instantaneous overcurrent limiting (Mode selection)	(refer to F43)

Refer to the descriptions of F43 and F44.

H13, H14 H15, H16	Restart mode after momentary power failure (Restart time, frequency fall rate) Restart mode after momentary power failure (Continue to run level, allowable	
	momentary power failure time) (refer to F14)

For how to set these function codes (Restart time, Frequency fall rate, Continue to run level and Allowable momentary power failure time), refer to the description of F14.

H26, H27	Thermistor (for motor) (Mode selection and level)
· ·	

These function codes specify the PTC (Positive Temperature Coefficient) thermistor embedded in the motor. The thermistor is used to protect the motor from overheating or output an alarm signal.

■ Thermistor (for motor) (mode selection) (H26)

H26 selects the function operation mode (protection or alarm) for the PTC thermistor as shown below.

H26 data	Action	
0	Disable	
1	When the voltage sensed by PTC thermistor exceeds the detection level, motor protective function (alarm $27/2$) is triggered, causing the inverter to enter an alarm stop state.	
2	When the voltage sensed by the PTC thermistor exceeds the detection level, a motor alarm signal is output but the inverter continues running.	
	You need to assign the "Motor overheat detected by thermistor" signal ("THM") to one of the digital output terminals beforehand, by which a temperature alarm condition is indicated to the peripheral equipment (E20 to E22, E24 and E27, data = 56).	

If H26 data is set to "1" or "2" (PTC thermistor), the inverter monitors the voltage sensed by PTC thermistor and protects the motor even when the 2nd motor is selected.

■ Thermistor (for motor) (level) (H27)

H27 specifies the detection level (expressed in voltage) for the temperature sensed by the PTC thermistor.

• Data setting range: 0.00 to 5.00 (V)

The alarm temperature at which the overheat protection becomes activated depends on the characteristics of the PTC thermistor. The internal resistance of the thermistor will significantly change at the alarm temperature. The detection level (voltage) is specified based on the change of the internal resistance.



Figure 5.3-12

Suppose that the internal resistance of the PTC thermistor at the alarm temperature is Rp, the detection level (voltage) V_{v2} is calculated by the expression below. Set the value of V_{v2} to function code H27.

$$V_{V2} = \frac{R_p}{1000 + 5 \times R_p} \times 10.5(V)$$

Connect the PTC thermistor as shown below. The voltage obtained by dividing the input voltage on terminal [C1] with a set of internal resistors is compared with the detection level voltage specified by H27.







When using the terminal [C1] for PTC thermistor input, also set SW4 on the control printed circuit board to the PTC side. For details, refer to Chapter 2, Section 2.2.8.

H30

Communication link function (Mode selection) Related function codes: y98 bus link function (mode selection)

Using the RS-485 communications link, or fieldbus (option) allows you to issue frequency commands and run commands from a computer or PLC at a remote location, as well as monitor the inverter running information and the function code data. It is possible to sets the source that specifies the frequency and run commands with H30 and y98. H30 and y98 set the sources that specify RS-485 communications and fieldbus respectively.



Table 5.3-9 Command sources selectable

Command sources	Data
Inverter itself	Sources except RS-485 communications link and fieldbus
	Frequency setting source: Specified by F01/C30, or multistep frequency command
	Operation method source: Via the keypad or digital input terminals selected by F02
Via RS-485 communications link (port 1)	Via the standard RJ-45 port used for connecting a keypad
Via RS-485 communications link (port 2)	Terminals DX+ and DX-
Via fieldbus(option)	Via fieldbus (DeviceNet, PROFIBUS DP, etc.)

Table 5.3-10	Command sources	s specified by H30	(Communications	link function,	Mode selection)
--------------	-----------------	--------------------	-----------------	----------------	-----------------

H30 data Frequency command		Run command source
0	Inverter itself (F01/C30)	Inverter itself (F02)
1	RS-485 communications link (port 1)	Inverter itself (F02)
2	Inverter itself (F01/C30)	RS-485 communications link (port 1)
3	RS-485 communications link (port 1)	RS-485 communications link (port 1)
4	RS-485 communications link (port 2)	Inverter itself (F02)
5	RS-485 communications link (port 2)	RS-485 communications link (port 1)
6	Inverter itself (F01/C30)	RS-485 communications link (port 2)
7	RS-485 communications link (port 1)	RS-485 communications link (port 2)
8	RS-485 communications link (port 2)	RS-485 communications link (port 2)

y98 data	Frequency command	Run command source
0	Follow H30 data	Follow H30 data
1	Via fieldbus (option)	Follow H30 data
2	Follow H30 data	Via fieldbus (option)
3	Via fieldbus (option)	Via fieldbus (option)

Table 5.3-11 Command sources specified by y98 (Bus link function, Mode selection)

Table 5.3-12H30 and y98 settings by combination of sources

		Frequency command			
		Inverter itself	Via RS-485 communications link port 1	Via RS-485 communications link port 2	Via fieldbus (option)
Run command source	Inverter itself	H30 = 0 y98 = 0	H30 = 1 y98 = 0	H30 = 4 y98 = 0	H30 = 0 (1, 4) y98 = 1
	Via RS-485 communications link (port 1)	H30 = 2 y98 = 0	H30 = 3 y98 = 0	H30 = 5 y98 = 0	H30 = 2 (3, 5) y98 = 1
	Via RS-485 communications link (port 2)	H30 = 6 y98 = 0	H30 = 7 y98 = 0	H30 = 8 y98 = 0	H30 = 6 (7, 8) y98 = 1
	Via fieldbus (option)	H30 = 0 (2, 6) y98 = 2	H30 = 1 (3, 7) y98 = 2	H30 = 4 (5, 8) y98 = 2	H30 = 0 (1 to 8) y98 = 3

For details, refer to the RS-485 Communication User's Manual, the Field Bus (Option) Instruction Manual or Chapter 9.

 When the terminal command "LE" ("Select link operation (RS-485, BUS option)") is assigned to a digital input terminal, turning "LE" ON makes the settings of H30 and y98 enabled. When LE is OFF, those settings are disabled so that both frequency commands and run commands specified from the inverter itself take control. (Function codes E01 to E05, data = 24)

No "LE" assignment is functionally equivalent to the "LE" being ON.

H42, H43,	Capacitance of DC link bus capacitor, Cumulative run time of cooling fan	
H48	Cumulative run time of capacitors on printed circuit boards	
	Related function codes: H47 Initial capacitance of DC link bus capacitor H98 Protection/maintenance function	

■ Life prediction function

The inverter has the life prediction function for some parts which measures the discharging time or counts the voltage applied time, etc. The function allows you to monitor the current lifetime state on the LED monitor and judge whether those parts are approaching the end of their service life. The life prediction function can also issue early warning signals if the lifetime alarm command LIFE is assigned to any of the digital output terminals by any of E20 to E22, E24 and E27.

The predicted values should be used only as a guide since the actual service life is influenced by the surrounding temperature and other usage environments.

Object of life prediction	Prediction function	End-of-life criteria	Prediction timing	On the LED monitor	
DC link bus capacitor	Calculating the capacitance of DC link bus capacitor Measures the discharging time of the DC link bus capacitor when the main power is shut down and calculates the capacitance.	85% or lower of the initial capacitance at shipment (See "[1] Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment" on page 5-142.)	At periodic inspection H98 bit3 = 0	<i>5_05</i> (Capacitance)	
		85% or lower of the reference capacitance under ordinary operating conditions at the user site (See "[2] Measuring the capacitance of DC link bus capacitor under ordinary operating conditions at power shutdown" on page 5-143.)	During ordinary operation H98 bit3 = 1	<i>5_05</i> (Capacitance)	
	ON-time counting of DC link bus capacitor Counts the time elapsed when the voltage is applied to the DC link bus capacitor, while correcting it according to the capacitance measured above.	Exceeding 87,600 hours (10 years) (ND mode: 61,320 hours (7 years))	During ordinary operation	$5_2 = -25$ (Elapsed time) $5_2 = -7$ (Remaining hours)	
Electrolytic capacitors on printed circuit boards	Counts the time elapsed when the voltage is applied to the capacitors, while correcting it according to the surrounding temperature.	Exceeding 87,600 hours (10 years) (ND mode: 61,320 hours (7 years))	During ordinary operation	5_ <i>D</i> 5 (Cumulative run time)	
Cooling fans Counts the run time of the cooling fans.		Exceeding 87,600 hours (10 years) (ND mode: 61,320 hours (7 years))	During ordinary operation	5_07 (Cumulative run time)	

■ Capacitance of DC link bus capacitor (H42)

Calculating the capacitance of DC link bus capacitor

- The discharging time of the DC link bus capacitor depends largely on the inverter's internal load conditions, e.g. options attached or ON/OFF of digital I/O signals. If actual load conditions are so different from the ones at which the initial/reference capacitance is measured that the measurement result falls out of the accuracy level required, then the inverter does not perform measuring.
- The capacitance measuring conditions at shipment are extremely restricted, e.g., all input terminals being OFF in order to stabilize the load and measure the capacitance accurately. Those conditions are, therefore, different from the actual operating conditions in almost all cases. If the actual operating conditions are the same as those at shipment, shutting down the inverter power automatically measures the discharging time; however, if they are different, no automatic measurement is performed. To perform it, put those conditions back to the factory default ones and shut down the inverter. For the measuring procedure, see "[1] Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment" on page 5-142.
- To measure the capacitance of the DC link bus capacitor under ordinary operating conditions when the power is turned OFF, it is necessary to set up the load conditions for ordinary operation and measure the reference capacitance (initial setting) when the inverter is introduced. For the reference capacitance setup procedure, see "[2] Measuring the capacitance of DC link bus capacitor under ordinary operating conditions at power shutdown" on page 5-143. Performing the setup procedure automatically detects and saves the measuring conditions of the DC link bus capacitor.

Setting bit 3 of H98 data to 0 restores the inverter to the measurement in comparison with the initial capacitance measured at shipment.



When the inverter uses an auxiliary control power input, the load conditions widely differ so that the discharging time cannot be accurately measured. In this case, measuring of the discharging time can be disabled with the function code H98 (Bit 4 = 0) for preventing unintended measuring. (For details, refer to H98.)

ON-time counting of DC link bus capacitor

 In a machine system where the inverter main power is rarely shut down, the inverter does not measure the discharging time. For such an inverter, the ON-time counting is provided. If the capacitance measurement is made, the inverter corrects the ON-time according to the capacitance measured. The ON-time counting result can be represented as "elapsed time" and "remaining time" before the end of life.

[1] Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment

When bit 3 of H98 data is 0, the measuring procedure given below measures the capacitance of DC link bus capacitor in comparison with initial one at shipment when the power is turned OFF. The measuring result can be displayed on the keypad as a ratio (%) to the initial capacitance.

- -----Capacitance measuring procedure-----
- 1) To ensure validity in the comparative measurement, put the condition of the inverter back to the state at factory shipment.
 - Remove the option card (if already in use) from the inverter.
 - In case another inverter is connected via the DC link bus to the P(+) and N(-) terminals of the main circuit, disconnect the wires. (You do not need to disconnect a DC reactor (optional), if any.)
 - Disconnect power wires for the auxiliary input to the control circuit (R0, T0).
 - In case the standard keypad has been replaced with an optional multi-function keypad TP-A1 after the purchase, put back the original standard keypad.
 - Turn OFF all the digital input signals fed to terminals [FWD], [REV], and [X1] through [X5] of the control circuit
 - · If a potentiometer is connected to terminal [13], disconnect it.
 - · If an external apparatus is attached to terminal [PLC], disconnect it.
 - Ensure that transistor output signals ([Y1], [Y2], and [Y3]) and relay output signals ([Y5A/C] and [30A/B/C]) will not be turned ON.
 - Disable the RS-485 communications links.

Note If negative logic is specified for the transistor output and relay output signals, they are considered ON when the inverter is not running. Specify positive logic for them.

- Keep the surrounding temperature within 25 ±10°C.
- 2) Turn ON the main circuit power.
- 3) Confirm that the cooling fan is rotating and the inverter is in stopped state.
- 4) Turn OFF the main circuit power.
- 5) The inverter automatically starts the measurement of the capacitance of the DC link bus capacitor. Make sure that "...." appears on the LED monitor.

Note If "...." does not appear on the LED monitor, the measurement has not started. Check the conditions listed in 1).

- 6) After "...." has disappeared from the LED monitor, turn ON the main circuit power again.
- Select Menu #5 "Maintenance Information" in Programming mode and note the reading (relative capacitance (%) of the DC link bus capacitor).

[2] Measuring the capacitance of DC link bus capacitor under ordinary operating conditions at power shutdown

When bit 3 of H98 data is 1, the inverter automatically measures the capacitance of the DC link bus capacitor under ordinary operating conditions when the power is turned OFF. This measurement requires setting up the load conditions for ordinary operation and measuring the reference capacitance when the inverter is introduced to the practical operation, using the setup procedure given below.

Function code	Name	Data
H42	Capacitance of DC link bus capacitor	 Capacitance of DC link bus capacitor (measured value)
		 Start of initial capacitance measuring mode under ordinary operating conditions (0000)
		Measurement failure (0001)
H47	Initial capacitance of DC link bus capacitor	 Initial capacitance of DC link bus capacitor (measured value)
		 Start of initial capacitance measuring mode under ordinary operating conditions (0000)
		Measurement failure (0001)

When replacing parts, clear or modify the H42 and H47 data. For details, refer to the maintenance related documents.

------Reference capacitance setup procedure------

- 1) Set function code H98 (Protection/maintenance function) to enable the user to specify the judgment criteria for the service life of the DC link bus capacitor (Bit 3 = 1) (refer to function code H98).
- 2) Turn OFF all run commands.
- 3) Make the inverter ready to be turned OFF under ordinary operating conditions.
- 4) Set both function codes H42 (Capacitance of DC link bus capacitor) and H47 (Initial capacitance of DC link bus capacitor) to "0000".
- 5) Turn OFF the inverter, and the following operations are automatically performed.

The inverter measures the discharging time of the DC link bus capacitor and saves the result in function code H47 (Initial capacitance of DC link bus capacitor).

The conditions under which the measurement has been conducted will be automatically collected and saved. During the measurement, "...." will appear on the LED monitor.

6) Turn ON the inverter again.

Confirm that H42 (Capacitance of DC link bus capacitor) and H47 (Initial capacitance of DC link bus capacitor) hold right values. Shift to Menu #5 "Maintenance Information" and confirm that the relative capacitance (ratio to full capacitance) is 100%.

Note If the measurement has failed, "0001" is entered into both H42 and H47. Remove the factor of the failure and conduct the measurement again.

Hereafter, each time the inverter is turned OFF, it automatically measures the discharging time of the DC link bus capacitor if the above conditions are met. Periodically check the relative capacitance of the DC link bus capacitor (%) with Menu #5 "Maintenance Information" in Programming mode.

Note The condition given above tends to produce a rather large measurement error. If this mode gives you a lifetime alarm, set H98 (Protection/maintenance function) back to the default setting (Bit 3 (Select life judgment threshold of DC link bus capacitor) = 0) and conduct the measurement under the condition at the time of factory shipment.

Cumulative run time of capacitors on printed circuit boards (H48)

Function code	Name	Data
H48	Cumulative run time of capacitors on printed circuit boards	Displays the cumulative run time of capacitor on the printed circuit board in units of ten hours. • Data setting range: 0 to 9999 (0 to 99990 hours)

When replacing capacitors on printed circuit boards, clearing or modifying H48 data is required. For details, refer to the maintenance related documents.

Cumulative run time of cooling fan (H43)

Function code	Name	Data
H43	Cumulative run time of cooling fan	Displays the cumulative run time of cooling fan in units of ten hours.
		Data setting range: 0 to 9999 (0 to 99990 hours)

When replacing the cooling fan, clearing or modifying H43 data is required. For details, refer to the maintenance related documents.

H44		Startup count for motor 1
-----	--	---------------------------

H44 counts the number of inverter startups and displays it in hexadecimal format. Check the displayed number on the maintenance screen of the keypad, and use it as a guide for maintenance timing for parts such as belts. To start the counting over again, e.g. after a belt replacement, set the H44 data to "0000."

H45	Mock alarm
	Related function codes: H97 (Clear alarm data)

H45 causes the inverter to generate a mock alarm in order to check whether external sequences function correctly at the time of machine setup. Setting the H45 data to "1" displays mock alarm \mathcal{E}_{r-r} on the LED monitor. It also issues alarm output (for any alarm) "ALM" (if assigned to a digital output terminal by any of E20 to E22, E24 and E27).

Accessing the H45 data requires simultaneous keying of the 100 key + \bigcirc key. After that, the H45 data automatically reverts to "0," allowing you to reset the alarm.

Same as other alarms that could occur when running the inverter, the inverter saves mock alarm data, enabling you to confirm the mock alarm status.

To clear the mock alarm data, use H97. (Accessing the H97 data requires simultaneous keying of the m key + key.) H97 data automatically returns to "0" after clearing the alarm data.

Tip A mock alarm can be issued also by simultaneous keying of the 🞰 key + 😹 key on the keypad for 5 seconds or more.

H46 Starting mode (Auto search delay time 2) (refer to H0	(refer to H09)
---	----------------

For details, refer to the description of H09.



For details, refer to the description of H42.

H49	Starting mode (Auto search delay time 1)	(refer to H09)

For details, refer to the description of H09.

H50, H51	Non-linear V/f 1 (Frequency and voltage)	(refer to F04)
H52, H53	Non-linear V/f 2 (Frequency and voltage)	

For details, refer to the description of F04.

H56	Deceleration time for forced stop	(refer to F07)
-----	-----------------------------------	----------------

For details, refer to the description of F07.

H63	Low limiter (Mode selection)	(refer to F15)

For details, refer to the description of F15.

H64 Low limiter (Lower limiting frequency)
--

H64 specifies the lower limit of frequency to be applied when the current limiter, torque limiter, or overload prevention control is activated. Normally, it is not necessary to change this data.

• Data setting range: 0.0 to 60.0 (Hz)

H69

Anti-regenerative control (Mode selection) Related function codes: H76 (Torque limiter) (Frequency rising limit for braking)

Enable the automatic deceleration (anti-regenerative control) with this function code. In the inverter not equipped with a PWM converter or braking unit, if the regenerative energy returned exceeds the inverter's braking capability, an overvoltage trip occurs. Turning digital input "AR-CCL" ON cancels anti-regenerative control.

(Function codes E01 to E05, data = 82)

If anti-regenerative control is selected, the output frequency is controlled to suppress the regenerative energy for avoiding an overvoltage trip.

	Function		
H69	Control mode	Force-to-stop with actual deceleration time exceeding three times the specified one	AR-CCL
0	Disable automatic deceleration	_	OFF
2	Torque limit control	Enable	OFF
3	DC link bus voltage control	Enable	OFF
4	Torque limit control	Disable	OFF
5	DC link bus voltage control	Disable	OFF
_	Disable automatic deceleration	—	ON

FRENIC-eHVAC is equipped with two control modes: torque limiter and DC link bus voltage control. Understand the features of the respective modes and select the appropriate one.

Control mode	Control operation	Operation mode	Characteristics
Torque limiter (H69 = 2, 4)	Controls the output frequency so that the braking torque is approximately 0.	Enabled during acceleration, constant speed operation and deceleration.	Features high response and makes less prone to overvoltage trips under impact load.
DC link bus voltage control (H69 = 3, 5)	Controls the output frequency so that the DC link bus voltage is decreased when it exceeds the limit level.	Enabled only during deceleration Disabled during constant speed operation	Regenerative capability of the inverter will be maximum use. Deceleration time will be shorter than the torque limit control.

■ Torque limiter (Frequency rising limit for braking) (H76)

• Data setting range: 0.0 to 120.0 (Hz)

With the torque limiter, the inverter increases the output frequency to limit the output torque. Excessive increase of the output frequency may cause danger, and therefore the frequency increment limit for braking (H76) is provided. This prevents the output frequency from increasing to exceed the "reference frequency + H76." If the limit is reached, however, anti-regenerative control is restricted and an overvoltage trip may occur. Increasing the frequency increment limit for braking improves the anti-regenerative capability.

If a run command is turned OFF, the anti-regenerative control causes the frequency to increase and operation may not stop depending on the load conditions. For safety, a function is provided in which the anti-regenerative control is forced to be disabled if the actual deceleration time becomes three times the deceleration time currently selected forcing the operation to stop. The function can be enabled/disabled by the setting of H69.



- The deceleration time may be automatically increased by anti-regenerative control.
- Disable the anti-regenerative control when a braking unit is connected. Otherwise, the anti-regenerative control may be activated at the same time as the operation of the braking unit, resulting in a deceleration time not in accordance with the setting.
- An excessively short deceleration time causes the DC link bus voltage of the inverter to rise too fast for the anti-regenerative control to function. In that case, specify a longer deceleration time.

H70 Overload prevention control

Specifies the rate of decrease of the output frequency of overload prevention control. Before the inverter generates a heat sink overheat or overload trip (alarm $\Box \vdash \prime$ or $\Box \vdash \prime \prime$), the output frequency of the inverter is decreased for avoiding a trip. This is applied when operation is required to continue in a system in which the load decreases as the output frequency decreases, such as a pump.

H70 data	Function
0.00	Uses the deceleration time currently selected (F08, E11, E13, E15, etc.).
0.01 to 100.0	Decelerates at a deceleration rate of 0.01 to 100.0 (Hz/s).
999	Cancel overload prevention control

■ Overload prevention controlling – "OLP" (E20 to E22, E24 and E27, data = 36)

Outputs "OLP", which is a signal that turns ON during overload prevention control, in order to inform that the overload prevention control has been activated and the output frequency has changed.

Note

No effect can be expected in a system in which the load does not decrease even if the output frequency decreases. Do not use this function.

H71

Deceleration characteristic

Enable hard braking control with this function code.

During motor deceleration, if the regenerative energy returned exceeds the inverter's braking capability, an overvoltage trip occurs. When hard braking control is selected, the motor loss is increased and the deceleration torque is increased during motor deceleration.

H71 data	Function
0	Disable
1	Action



This function suppresses the torque during deceleration and is not effective if braking load is applied. When anti-regenerative control of the torque limiter is enabled (H69 = 2, 4), the deceleration characteristic is disabled.

Main power shutdown detection (Mode selection)

This function monitors the AC input power supply of the inverter to see if the AC input power supply (main circuit power) is established and prevents inverter operation when the main circuit power is not established.

Available FRN0045F2E-4G or above.

H72 data	Function
0	Disables main circuit power cutoff detection
1	Enables main circuit power cutoff detection

With power supply via a PWM converter or DC link bus, there is no AC input. When the data for H72 is "1," the inverter cannot operate. Change the data for H72 to "0."

Note For single-phase supply, consult your Fuji Electric representatives.

H72

H76

Torque limiter (Braking) (Frequency rising limiter for braking)

(refer to H69)

For details, refer to the description of H69.

1177	Opensional life of DO limb have appreciate (Dependenciate of the s)
H//	Service life of DC, link bus capacitor (Remaining time)

Indicates the time remaining (in units of ten hours) before the end of service life of the DC link bus capacitor. Transfer the DC link bus capacitor life data when replacing the printed circuit board.

• Data setting range: 0 to 8760 (in units of 10 hours 0 to 87,600 hours)

H78	Maintenance interval (M1)
H94	Cumulative motor run time 1

Specify the maintenance interval in hours with the maintenance interval (M1) (H78). Specify in units of 10 hours. Up to 9999 x 10 hours can be specified.

• Data setting range: 0 (disable), 1 to 9999 (in units of 10 hours)

■ Maintenance timer counted up – "MNT" (E20 to E22, E24 and E27, data = 84)

When the cumulative motor run time 1 (H94) reaches the value specified by the maintenance interval (H78), the inverter outputs the maintenance timer signal "MNT".

Cumulative motor run time 1 (H94)

The cumulative run time of the motor can be indicated by keypad operation. It can be used for management of the machinery or maintenance. Specifying an arbitrary time for the cumulative motor run time 1 (H94) allows an arbitrary value to be specified for the cumulative motor run time. It can be replaced with the initial data to use as a guide for the replacement of machine parts or inverter. Setting "0" allows the cumulative motor run time to be reset.

<For half yearly maintenance>

Cumulative motor run time (H94)



Note

If the maintenance interval is reached, set a new value in H78 and press the 🛞 key to reset the output signal and restart measurement.

This function is exclusively applied to the 1st motor.

Count the run time of commercial power-driven motor 1 – "CRUN-M1" (E01 to E05, data = 72)

Even when a motor is driven by commercial power, not by the inverter, it is possible to count the cumulative motor run time 1 (H94) by detecting the ON/OFF state of the auxiliary contact of the magnetic contactor for switching to the commercial power line.

Note Check the cumulative motor run time with 5_2^2 on Menu #5 "Maintenance Information" of the keypad.

H79

Preset startup count for maintenance (M1) Related function codes: H44 Startup count for motor 1

H79 specifies the number of inverter startup times to determine the next maintenance timing, e.g., for replacement of a belt.

Set the H79 and H44 data in hexadecimal. The maximum setting count is 65,535 (FFFF in hexadecimal.)

• Data setting range: OFF (disable), 0001 to FFFF (hexadecimal)

■ Maintenance timer counted up – "MNT" (E20 to E22, E24 and E27, data = 84)

When the startup counter for motor 1 (H44) reaches the number specified by H79 (Preset startup count for maintenance (M1)), the inverter outputs the maintenance timer signal "MNT" (if assigned to any digital terminal with any to E20 to E22, E24 and E27) to inform the user of the need of the maintenance of the machinery.

< Maintenance every 1,000 times of startups >





If the startup counter reaches the specified value, set a new value for the next maintenance in H79 and press the key to reset the output signal and restart counting.

This function is exclusively applied to the 1st motor.

H80 Output current fluctuation damping gain for motor 1

The inverter output current driving the motor may fluctuate due to the motor characteristics and/or backlash in the machinery (load). Modifying the H80 data adjusts the controls in order to suppress such fluctuation. However, as incorrect setting of this gain may cause larger current fluctuation, do not modify the default setting unless it is necessary.

• Data setting range: 0.00 to 1.00

H81, H82 Light alarm selection 1 and 2

The table below lists alarms selectable as "light alarm."

Code	Name	Description
DH I	Heat sink overheat	Heat sink temperature increased to the trip level.
DHZ	Enable external alarm trip	An error that has occurred in peripheral equipment turned the external alarm signal THR ON.
OH3	Inverter internal overheat	The temperature inside the inverter abnormally has increased.
השם	Braking resistor overheat	Estimated temperature of the coil in the braking resistor exceeded the allowable level.
	Overload of motor 1	Motor temperature calculated with the inverter output current reached the trip level.
E4	Option communications error	Communications error between the inverter and an option.
E-5	Option error	An option judged that an error occurred.
E-8 E-P	RS-485 communications error (COM port 1, 2)	RS-485 communications error in COM ports 1 or 2.
EaF	PID feedback wire break	The PID feedback signal wire(s) is broken.
FAL	Detect DC fan lock	Failure of the air circulation DC fan inside the inverter
ΞL	Motor overload early warning	Early warning before a motor overload
<u>D</u> H	Heat sink overheat early warning	Early warning before a heat sink overheat trip
L 1/F	Lifetime alarm	It is judged that the service life of any one of the capacitors (DC link bus capacitors or electrolytic capacitors on the printed circuit boards) or cooling fan has expired. Or, failure of the air circulation DC fan inside the inverter.
r-EF	Reference loss	Analog frequency command was lost.
ר ום	PID alarm	Warning related to PID control (absolute-value alarm or deviation alarm)
LITL	Low output torque detection	Output torque drops below the low torque detection level for the specified period.
PE	PTC thermistor activated	The PTC thermistor on the motor detected a high temperature.
rTE	Machine life (Cumulative run time)	The motor cumulative run time reached the specified level.
הי <u>ר</u> י	Machine life (Number of startups)	Number of startups reached the specified level.

Set data for selecting "light alarms" in hexadecimal. For details on how to select the codes, see the next page.

• Data setting range: 0000 to FFFF (hexadecimal)
Selecting light alarm factors

To set and display the light alarm factors in hexadecimal format, each light alarm factor has been assigned to bits 0 to 15 as listed in Table 5.3-13 and Table 5.3-14. Set the bit that corresponds to the desired light alarm factor to "1." Table 5.3-15 shows the relationship between each of the light alarm factor assignments and the LED monitor display.

Table 5.3-16 gives the conversion table from 4-bit binary to hexadecimal.

 Table 5.3-13
 Light Alarm Selection 1 (H81), Bit Assignment of Selectable Factors

Bit	Code	Data	Bit	Code	Data
15	OH5	Charging resistor overheat	7	—	—
14	—	—	6	—	
13	E-P	RS-485 communications error (COM port 2)	5	OL /	Overload of motor 1
12	E-8	RS-485 communications error (COM port 1)	4	dbH	Braking resistor overheat
11	E-5	Option error	3	—	—
10	E-4	Option communications error	2	OH3	Inverter internal overheat
9	_	—	1		External alarm
8	_	_	0	ו אום	Heat sink overheat

Table 5.3-14 Light Alarm Selection 2 (H82), Bit Assignment of Selectable Factors

Bit	Code	Data	Bit	Code	Data
15	—	—	7	Ĺ "Ē	Lifetime alarm
14	—	—	6	DH	Heat sink overheat early warning
13	[ה]	Inverter life (Number of startups)	5	DL	Motor overload early warning
12	-FE	Inverter life (Cumulative run time)	4	FAL	Detect DC fan lock
11	F[-[-	PTC thermistor activated	3	EoF	PID feedback wire break
10	<u> </u> [_]	Low output torque detection	2	—	—
9	P d	PID alarm	1	_	
8	rEF	Reference loss	0	_	—

Table 5.3-15	Display	of Liaht	Alarm	Factor
		••• <u> </u>		

(Example) Light alarm factors "RS-485 communications error (COM port 2)," "RS-485 communications error (COM port 1)," "Option communications error," "Overload of motor 1" and "Heat sink overheat" are selected by H81.

	LED No.	LED 4				LED 3			LED 2				LED 1				
	Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	Code			E-P	Er8	Er-5	Er-4	_	_	-	I	OL I	dbH		OH3	OH2	ОН І
	Binary	0	0	1	1	0	1	0	0	0	0	1	0	0	0	0	1
indication	Hexadecimal * Refer to Table 5.3-16	3					4			2				/			
Sample in	Hexadecimal on the LED monitor										LED1						

Hexadecimal expression

A 4-bit binary number can be expressed in hexadecimal format (hexadecimal digit). The table below shows the correspondence between the two notations.

Binary			Hexadecimal	Binary				Hexadecimal	
0	0	0	0	D	1	0	0	0	8
0	0	0	1	/	1	0	0	1	3
0	0	1	0	2	1	0	1	0	R
0	0	1	1	Ē	1	0	1	1	6
0	1	0	0	4	1	1	0	0	Ĺ
0	1	0	1	5	1	1	0	1	ď
0	1	1	0	6	1	1	1	0	E
0	1	1	1	7	1	1	1	1	F

 Table 5.3-16
 Binary and Hexadecimal Conversion

When H26 = 1 (PTC (The inverter immediately trips with 2HH displayed)), if the PTC thermistor is activated, the inverter stops without displaying I-al, blinking the KEYPAD CONTROL LED, or outputting L-ALM signal, regardless of the assignment of bit 11 (PTC thermistor activated) by H82 (Light Alarm Selection 2).

■ Light alarm – "L-ALM" (E20 to E22, E24 and E27, data = 98)

This output signal "L-ALM" comes ON when a light alarm occurs.

H89

Electronic thermal overload protection for motor – data retention

When the electronic thermal overload protection for motor is used, whether to clear the cumulative value of the thermal by inverter power-off or retain the value after power-off can be specified.

Data for H89	Function		
0	Clears cumulative value of thermal by inverter power-off.		
1	Retains cumulative value of thermal after inverter power-off (factory default).		

H86, H90	Reserved for particular manufacturers	
----------	---------------------------------------	--

H86 and H90 are reserved for particular manufacturers. Unless otherwise specified, do not access these function codes.

H91	PID feedback wire break detection	

Using the terminal [C1] (C1 function) (current input) for PID feedback signal enables wire break detection and alarm $(\mathcal{L}_{\Box}\mathcal{F})$ issuance. H91 specifies whether the wire break detection is enabled, or the duration of detection. (The inverter judges an input current to the terminal [C1] below 2 mA as a wire break.)

This function does not work unless C40 is set to 0.

- Data setting range: 0.0 (Disable wire break detection)
 - 0.1 to 60.0 s (Detect wire break and issue $L_{O}/$ alarm within the time)

H92, H93		Continuous running at the momentary power failure (P, I)	(refer to F14)
----------	--	--	----------------

Refer to the description of F14.

H94

Cumulative motor run time 1

(refer to H78)

Refer to the description of H78.

H95	DC braking (Braking response mode)	(refer to F20 to F22)

Refer to the descriptions of F20 through F22.

STOP key priority/Start check function

H96 specifies a functional combination of " STOP key priority" and "Start check function" as listed below.

H96 data	STOP key priority	Start check function
0	Disable	Disable
1	Enable	Disable
2	Disable	Enable
3	Enable	Enable

■ STOP key priority

Even when run commands are entered from the digital input terminals or via the RS-485 communications link (link operation), pressing the ror key forces the inverter to decelerate and stop the motor. After that, $\pounds - \pounds$ appears on the LED monitor.

Start check function

For safety, this function checks whether any run command has been turned ON or not in each of the following situations. If one has been turned ON, the inverter does not start up but displays alarm code $\mathcal{E}_{\mathcal{T}}\mathcal{L}$ on the LED monitor.

- When the power to the inverter is turned ON.
- When the 💼 key is pressed to release an alarm status or when the digital input terminal command "RST" ("Reset alarm") is turned ON.
- When the run command source is switched by a digital input terminal command such as "LE" ("Enable communications link via RS-485 or fieldbus") or "LOC" ("Select local (keypad) operation").

H97	Clear alarm data	
		Related function codes: H45 Mock alarm

H97 clears alarm data (alarm history and relevant information) stored in the inverter.

To clear alarm data, simultaneous keying of " \mathfrak{m} key + \bigcirc key" is required.

H97 data	Function	
0	Disable	
1	Enable (Setting "1" clears alarm data and then returns to "0.")	

Protection/Maintenance function (Mode selection)

H98 specifies whether to enable or disable automatic lowering of carrier frequency, input phase loss protection, output phase loss protection, judgment threshold on the life of DC link bus capacitor, judgment on the life of DC link bus capacitor, DC fan lock detection and braking transistor error detection by setting a bit combination.

Automatic lowering of carrier frequency (Bit 0)

This function should be used for critical machinery that requires keeping the inverter running. Even if a heat sink overheat or overload occurs due to excessive load, abnormal surrounding temperature, or cooling system failure, enabling this function lowers the carrier frequency to avoid tripping ($\Box H$, $\Box H \exists$ or $\Box L U$). Note that enabling this function results in increased motor noise.

Input phase loss protection (/ ריו) (Bit 1)

This function detects the voltage unbalance between the phases and phase loss of 3-phase power supply. And an alarm displays $\frac{1}{2}$ π to stop the inverter when it detects.



H98

In configurations where only a light load is driven or a DC reactor is connected, phase loss or line-to-line voltage unbalance may not be detected because of the relatively small stress on the apparatus connected to the main circuit.

Output phase loss protection (2PL) (Bit 2)

Upon detection of output phase loss while the inverter is running, this feature stops the inverter and displays an alarm $2P_{\perp}$.



Where a magnetic contactor is installed in the inverter output circuit, if the magnetic contactor goes OFF during operation, all the phases will be lost. In such a case, this protection function does not work.

Judgment threshold on the life of DC link bus capacitor (Bit 3)

Bit 3 is used to select the threshold for judging the life of the DC link bus capacitor between the factory default setting and a user-defined setting.

Note Before specifying a user-defined threshold, measure and confirm the reference level in advance. (
Function code H42)

Judgment on the life of DC link bus capacitor (Bit 4)

Whether the DC link bus capacitor has reached its life is judged by measuring the discharging time after power OFF. The discharging time is determined by the capacitance of the DC link bus capacitor and the load inside the inverter. Therefore, if the load inside the inverter fluctuates significantly, the discharging time cannot be accurately measured. As a result, it may be mistakenly determined that the DC link bus capacitor has reached the end of its life. To avoid such an error, you can disable the judgment based on the discharging time. (Even if it is disabled, the judgment based on the "ON-time counting" while the voltage is applied to the DC link bus capacitor is performed.)

For details about the life prediction function, refer to H42.

Since load may fluctuate significantly in the cases described below, disable the judgment on the life during operation even in user-defined setting mode. During periodical maintenance, either conduct the measurement with the judgment enabled under appropriate conditions or conduct the measurement under the operating conditions matching the actual ones.

- Auxiliary input for control power is used.
- · An option card is used.
- Another inverter or equipment such as a PWM converter is connected to terminals of the DC link bus.

Reserve (bit 5)

Braking transistor error detection (Bit 6) (dbR FRN0060F2E-4G or below)

Upon detection of a built-in braking transistor error, this feature stops the inverter and displays an alarm $\Box \Box \neg \neg$. Set data of this bit to "0" when the inverter does not use a braking transistor and there is no need of entering an alarm state.

To set data of function code H98, assign the setting of each function to each bit and then convert the 8-bit binary to the decimal number. Refer to the assignment of each function to each bit and a conversion example below.

Bit	Function	Data = 0	Data = 1	Factory default
Bit 0	Lower the carrier frequency automatically	Disable	Enable	1: Enable
Bit 1	Detect input phase loss	Continue to run	Enter alarm processing	1: Enter alarm processing
Bit 2	Detect output phase loss	Continue to run	Enter alarm processing	0: Continue to run
Bit 3	Select life judgment threshold of DC link bus capacitor	Factory default	User-defined setting	0: Factory default
Bit 4	Judge the life of DC link bus capacitor	Disable	Enable	1: Enable
Bit 5	reserve	Enter alarm processing	Continue to run	0: Enter alarm processing
Bit 6	Detect braking transistor breakdown	Continue to run	Enter alarm processing	0: Continue to run

Decimal and binary conversion

Decimal = Bit 6×2^{6} + Bit 5×2^{5} + Bit 4×2^{4} + Bit 3×2^{3} + Bit 2×2^{2} + Bit 1×2^{1} + Bit 0×2^{0}

= Bit 7 x 128 + Bit 6 x 64 + Bit 5 x 32 + Bit 4 x 16 + Bit 3 x 8 + Bit 2 x 4 + Bit 1 x 2 + Bit 0 x 1

- = 64 + 0 × 32 + 1 × 16 + 0 × 8 + 0 × 4 + 1 × 2 + 1 × 1
- = 16 + 2 + 1
- = 19

H99,	Password 2 setting/check
H197, H198	User password 1 (selection of protective operation, setting check)
H199	User password protection valid

The password function is the function to hide the function code entirely/partially which is set for the inverter. When this function is used, perform correct settings after familiarizing yourself with the following details. If incorrect settings are made, the function code cannot be changed or checked. An alarm may also occur and the inverter may stop. Perform the operation carefully.



If the objective is to prevent inadvertent rewriting of the setting value from the touch panel, it is recommended to use the data protective function with function code F00 rather than the password function. For details of the data protection, refer to the items in F00.



- Note If an incorrect password setting value is entered and you failed to decode the password, the password protection state cannot be released. In addition, failure to decode the password consecutively 5 times results in minor failure $\frac{1}{2} \frac{1}{2}$.
- Note To prevent the password decoding by an ill-disposed third party, failure to decode the password for the specified number of times results in $\angle \Box^{\perp}$ alarm, which disables the inverter operation. Therefore, it is recommended to decode the password during stop of the system. If it is necessary to decode the password during operation, perform decoding carefully.
- We are not able to know the passwords set by customers. If you have forgotten the password setting value, the only way to decode the password is initialization of the function code. Set and control the password carefully.

Password 1 (Rewrite disable protection)

Function code setting values excluding some codes can be protected as rewrite disable.

Select the target function code which is protected by H197 and set the password (hexadecimal 4 digits) with function code H198. When function code H199 is set to 1, password 1 protective status (rewrite disable protection) is active.

Function code	Name	Remarks	
H197	Protection operation selection	 0: Displays all function codes, however, changes are prohibited. 1: Only function codes applicable to quick setup can be displayed or changed. 2: Only function codes for customize logic settings are hidden, and changes are prohibited. 	
H198	Set/verify	0000 to FFFF	
H199	Protection enable	0: Disable 1: Protect	

Temporary decoding of password 1 (rewrite disable protection)

When password 1 protective status is shown and the same value as the password set for function code H198 is entered in H198, password 1 protective status is temporarily released and the function code setting value can be rewritten.

If password 2 is set at the same time, it is necessary to decode password 2 with H99 in advance.



Figure 5.3-14 Relation chart of password 1 protection status

Password 2 (Read/write disable protection)

Setting values of all function codes not by selecting function code H197 can be protected as read disable and rewrite disable. (Exceptionally, partial function codes are not protected.)

Set the password with function code H99 and set function code H199 to 1. Password 2 protective status (read/write disable protection) is active.

The function code of read/write disable does not allow writing of the setting value to the inverter with a remote touch panel, multi-function touch panel or external device using serial communication, or reading of the setting value.

■ Temporary decoding of password 2 (read/write disable protection)

When password 2 protective status is shown and the same value as the password (hexadecimal 4 digits) set for function code H99 is entered in H99, password 2 protective status is temporarily decoded and the function code value can be read and it can be displayed on the touch panel.

If password 1 protection (rewrite disable protection) is also set, the function code can be rewritten by temporarily decoding password 1 protective status continuously.

Failure of temporary decoding of passwords 1 and 2

In password 1 protective status or password 2 protective status, if the password value entered in function code H198 or H99 is incorrect when trying to temporarily cancel the protective status, temporary decoding is disabled.

In both function codes H198 and H99, 5 consecutive failures of password input result in minor failure $\angle -\beta \angle$.



Figure 5.3-15 Relation chart of password 2 protection status

Note In our factory default status, passwords are not provided excluding special products. Therefore, if the password set for H198 or H99 is unknown or forgotten, we do not answer or inform you of the password or its decoding method from protective status.

For this reason, set and control the password at your own risk. If a password is set at the delivery of the product and its decoding is required, please contact the dealer you purchased or the unit manufacturer. (We are not able to know the passwords set by customers.)

Setting passwords 1 and 2 with multi-function touch panel and temporary decoding

Setting or temporary decoding of passwords 1 and 2 using the multi-function touch panel is performed by the special menu on the multi-function touch panel. Therefore, function codes H99, H198 and H199 are not displayed on the function code list of the function code setting menu or function code check menu on the multi-function touch panel (H197 is displayed).

For the special password menu of the multi-function touch panel, refer to the instruction manual of the multi-function touch panel.

Allows the adjustment of the level when anti-regenerative control by torque limiter is performed with H69 = 2, 4. Basically, there is no need to modify the setting.

Data for H114	Function
0.0 to 50.0%	Adjusted level: Increasing the value increases the frequency operation.
999	Standard level

H193,H194 User initialization data (Save, Protect) Related function code: H

Refer to H02, H03.

|--|

DC braking can be activated at startup. For details, refer to the description of F21.

H197,H198	User password 1 (selection of protective operation, se	etting check)
H199	User password protection valid	Related function code: H99

Refer to H99.

5.3.6 A codes (Motor 2 parameters)

FRENIC-eHVAC has two sets of speed control parameter. They can be selected by "MPRM1" signals. For the description of speed control parameters, refer to function code d01.

Name		Speed control parameter sets	
		set1	set2
Speed control	(Speed command filter)	d01	A43
	(Speed detection filter)	d02	A44
	(P gain)	d03	A45
	(Integral time)	d04	A46

■ Select speed control parameter 1 – "MPRM1" (E01 to E05 data = 78)

The combination of the ON/OFF states of digital input signals "MPRM1" selects one between 2 different speed control parameter sets .

input signals	Selected speed control parameter set	
"MPRM1"		
OFF	d01 to d04 speed control parameter set1	
ON A43 to A50 speed control parameter set2		

5.3.7 J codes (Applied functions)

J01 PID control (Mode selection)

Under PID control, the inverter detects the state of a control target object with a sensor or similar device and compares it with the commanded value (e.g., temperature control command). If there is any deviation between them, PID control operates so as to minimize it. That is, it is a closed loop feedback system that matches a controlled variable (feedback amount).

PID control expands the application area of the inverter to process control (e.g., flow control, pressure control, and temperature control).

If PID control is enabled (J01 = 1 or 2), the frequency control of the inverter is switched from the drive frequency command generator block to the PID command generator block.

■ Mode Selection (J01)

J01 selects the PID control mode.

J01 data	Function
0	Disable
1	Process control (normal operation)
2	Process control (inverse operation)

<PID process control block diagram>



- Using J01 allows switching between normal and inverse operations for the PID control output, so you can specify an increase/decrease of the motor rotating speed depending on the difference (error component) between the commanded (input) and feedback amounts, making it possible to apply the inverter to air conditioners. The terminal command IVS can also switch operation between normal and inverse.
- For details about the switching of normal/inverse operation, refer to the description of "■ Switch normal/inverse operation "IVS"" (E01 to E05, data = 21).

J02	PID Control (Remote command)	
	Related function code	J105: PID control (Display unit) J106: PID control (Maximum scale) J107: PID control (Minimum scale) J136 to J138: PID control multistep command 1 to 3

J02 sets the source that specifies the command value (SV) under PID control.

J02 data	Function
0	Keypad Specify the PID command by using the \oslash / \oslash keys on the keypad.
1	PID command 1 (Analog input: Terminals [12], [C1] (C1 function), [C1] (V2 function)) Voltage input to the terminal [12] (0 to ±10 VDC, 100% PID command/ ±10 VDC) Current input to the terminal [C1] (C1 function) (4 to 20 mA DC, 100% PID command/ 20 mA DC) Voltage input to the terminal [C1] (V2 function) (0 to +10 VDC, 100% PID command/ +10 VDC)
3	Terminal command UP/DOWN Using the "UP" or "DOWN" command in conjunction with PID minimum scale to maximum scale (specified by J106 and J107) with which the command value is converted into a physical quantity, etc., you can specify 0 to 100% of the PID command.
4	Command via communications link Use function code S13 to specify the PID command by communications. The transmission data of 20000d (decimal) is equal to 100% (maximum set point value) of the PID command.

[1] PID command with the \bigcirc / \bigcirc keys on the keypad (J02 = 0, factory default)

Using the \bigcirc / \bigcirc keys on the keypad in conjunction with PID minimum / maximum scale (specified by J106 and J107), you can specify 0 to 100% of the PID command in an easy-to-understand, converted command format.

For details of operation, refer to Chapter 3 "3.3.5 Setting up PID commands from the keypad."

[2] PID command by analog inputs (J02 = 1)

When any analog input (voltage input to terminals [12] and [C1] (V2 function), or current input to terminal [C1] (C1 function)) for PID command 1 (J02 = 1) is used, it is possible to arbitrary specify the PID command by multiplying by the gain and adding the bias. The polarity can be selected and the filter time constant and offset can be adjusted. In addition to J02 setting, it is necessary to select PID process command 1 for analog input (specified by any of E61 to E63, function code data = 3). For details, refer to the descriptions of E61 to E63.

	Input range	Bias		Gain		Delerity	Filter	Offeet
input terminar	input range	Bias	Base point	Gain	Base point	Polarity	Filler	Oliset
[12]	0 to +10V, -10 to +10V	C55	C56	C32	C34	C35	C33	C31
[C1] (C1)	4 to 20mA, 0 to 20mA	C61	C62	C37	C39	C40	C38	C36
[C1] (V2)	0 to +10V	C67	C68	C42	C44	C45	C43	C41

 Table 5.3-17
 Adjustable elements of PID command

Offset (C31, C36, C41)

C31, C36 or C41 configure the offset for an analog voltage/current input.

■ Filter (C33, C38, C43)

C33, C38, and C43 provide the filter time constants for the voltage and current of the analog input. The larger the setting of time constant is, the slower the response is. Specify the proper filter time constant taking into account the response speed of the machine (load). If an analog input signal fluctuates due to line noises, increase the filter time constant.

■ Polarity selection for terminal [12] (C35)

C35 configures the input range for analog input voltage of terminal [12].

C35 data	Modes for terminal inputs	
0	-10 to +10V	
1	0 to +10 V(negative value of voltage is regarded as 0 V)	

■ Range / polarity selection for terminal [C1] (C1 function) (C40)

C40 configures the input range for analog input current of terminal [C1] (C1 function).

C40 data	Range of terminal inputs	Handling when a bias value is configured as minus	
0	4 to 20 mA (Factory default)		
1	0 to 20 mA	Limits any value lower than 0 to 0.	
10	4 to 20 mA	Enchlos any value lawer than 0 on minus value	
11	0 to 20 mA	Enables any value lower than 0 as minus value.	

Polarity selection for terminal [C1] (V2 function) (C45)

C45 configures the input range for analog input voltage of terminal [C1] (V2 function).

C45 data	Modes for terminal inputs	When bias is specified to be negative
0	0 to +10V	Makes a value lower than 0 effective as a negative value.
1	0 to +10V (factory default)	Limits a value lower than 0 to 0.

Gain and bias



(Example) In order to allocate for the range of 0 to 100% to the range of 1 to 5 V at terminal [12], set as follows.



[3] PID command with UP/DOWN control (J02 = 3)

When UP/DOWN control is selected as a PID speed command, turning the terminal command "UP" or "DOWN" ON causes the PID set point value to change within the range from minimum scale to maximum scale.

The PID set point value can be specified in physical quantity units (such as temperature or pressure) with the minimum scale (J106) and maximum scale (J107).

To select UP/DOWN control as a PID set point value, the "UP" and "DOWN" should be assigned to the digital input terminals [X1] to [X5]. (Function codes E01 to E05 data = 17, 18)

"UP"	"DOWN"	Action		
Data = 17	Data = 18			
OFF	OFF	Retain PID set point value.		
ON	OFF	Increase PID set point value at a rate between 0.1%/0.1 s and 1%/0.1 s.		
OFF	ON	Decrease PID set point value at a rate between 0.1%/0.1 s and 1%/0.1 s.		
ON	ON	Retain PID set point value.		



The inverter internally holds the PID command value set by UP/DOWN control and applies the held value at the next restart (including powering ON).

[4] PID command via communications link (J02 = 4)

Use function code S13 to specify the PID command by communications. The transmission data of 20000 (decimal) is equivalent to 100% (maximum set point value) of the PID command. For details of the communications format, refer to the RS-485 Communication User's Manual.



Other than the remote command selection by J02, the PID multistep commands 1, 2 or 3 (specified by J106, J137 or J138, respectively) selected by the PID multistep commands "PID-SS1" and "PID-SS2" can also be used as preset set point values for the PID command.

Selecting Feedback Terminals

For feedback control, determine the connection terminal according to the type of the sensor output.

- If the sensor is a current output type, use the current input terminal [C1] (C1 function) of the inverter.
- If the sensor is a voltage output type, use the voltage input terminal [12] of the inverter, or switch over the terminal [C1] (V2 function) to the voltage input terminal and use it.
- For details, refer to the descriptions of E61 to E63.

<Application example: Process control> (for air conditioners, fans and pumps)

The operating range for PID process control is internally controlled as 0% through 100%. For the given feedback input, determine the operating range to be controlled by means of gain adjustment.

Example: When the external sensor has the output range of 1 to 5 V:

- Use terminal [12] as the input terminal in voltage.
- Set the gain (C32 for analog input adjustment) to 200% in order to make 5V of the maximum output of the external sensor to be 100% of input scale.

For the input specification of terminal 12, 0-10V is equivalent to 0-100%. Therefore the gain has to be set 200% (= $10 \text{ V} / 5 \text{ V} \times 100$). Note also that any bias setting does not apply to feedback control.



PID display coefficient and Monitoring

To monitor the PID command and its feedback value, set the scale to convert the values into easy-to-understand physical quantities such as temperature. The display unit is invalid on the standard keypad (TP-M2). The display unit is used with the multi-function keypad (TP-A1-E2C).

	Display unit	Maximum scale	Minimum scale
Terminal [12]	C58	C59	C60
Terminal [C1] (C1)	C64	C65	C66
Terminal [C1] (V2)	C70	C71	C72

Refer to function codes C59, C60, C65, C66, C71 and C72 for details on scales, and to E43 for details on monitoring.

Display unit (J105)

J105 can select the display units for monitoring PID feedback value with the multi-function keypad (TP-A1-E2C). Setting "0" selects the factory default unit for the PID feedback value.

J105	Display unit	J105	Display unit	J105	Display unit
0	* (Factory default)	23	L/s (flow)	45	mmHg (pressure)
1	No unit	24	L/min (flow)	46	Psi (pressure)
2	%	25	L/h (flow)	47	mWG (pressure)
4	r/min	40	Pa (pressure)	48	inWG (pressure)
7	kW	41	kPa (pressure)	60	K (temperature)
20	m³/s (flow)	42	MPa (pressure)	61	°C (temperature)
21	m ³ /min (flow) 43		mbar (pressure)	62	°F (temperature)
22	m³/h (flow)	m ³ /h (flow) 44		80	ppm (density)

* The unit and scale for feedback values are used.

■ Maximum scale/minimum scale (J106, J107)

The PID control values can be converted to a physical quantity that is easy to recognize and displayed accordingly. Set the maximum scale "PID command value/ display for 100% of a PID feedback value" with J106 and the minimum scale "PID command value/ display for 0% of a PID feedback value" with J107

The displayed value is determined as follows:

Display value = (PID command value (%)) / 100 * (Max. scale - Min. scale) + Min. scale

• Data setting range: (Max. scale and min. scale) -999.00 to 0.00 to 9990.00

■ PID multistep command 1 to 3 (J136, J137 and J138)

A PID command value can be given by the PID multistep command and selected by digital inputs programmed with "PID-SS1" and "PID-SS2" functions. Assign the digital input terminals with "PID-SS1" and "PID-SS2" (III) Function codes E01 to E05, data =171 and 172 respectively).

PID-SS2	PID-SS1	PID multistep command	
OFF	OFF	Not selected	
OFF	ON	J136: PID multistep command 1 setting range: -999.0 to 0.00 to 9990	
ON	OFF	J137: PID multistep command 2 setting range: -999.0 to 0.00 to 9990	
ON	ON	J138: PID multistep command 3 setting range: -999.0 to 0.00 to 9990	

J03 to J06 PID Control P (Gain), I (Integral time), D (Differential time), Feedback filter

P gain (J03)

J03 specifies the proportional gain for the PID processor.

• Data setting range: 0.000 to 30.000 (times)

P (Proportional) action

An operation in which the MV (manipulated value: output frequency) is proportional to the deviation is called P action, which outputs the MV in proportion to deviation. However, P action alone cannot eliminate deviation.

Gain is data that determines the system response level against the deviation in P action. An increase in gain speeds up response, but an excessive gain may oscillate the inverter output. A decrease in gain delays response, but it stabilizes the inverter output.



■ I integral time (J04)

J04 specifies the integral time for the PID processor.

• Data setting range: 0.0 to 3600.0 (s)

0.0 indicates that the integral component is ineffective

I (Integral) action

An operation in which the change rate of the MV (manipulated value: output frequency) is proportional to the integral value of deviation is called I action, which outputs the MV that integrates the deviation. Therefore, I action is effective in bringing the feedback value close to the commanded value. For the system whose deviation rapidly changes, however, this action cannot make it respond quickly.

The effectiveness of I action is expressed by integral time as parameter, that is J04 data. The longer the integral time, the slower the response. The reaction to the external disturbance also becomes slow. The shorter the integral time, the faster the response. Setting too short integral time, however, makes the inverter output tend to oscillate against the external disturbance.



■ D differential time (J05)

J05 specifies the differential time for the PID processor.

• Data setting range: 0.00 to 600.00 (s)

0.00 indicates that the differential component is ineffective.

D (Differential) action

An operation in which the MV (manipulated value: output frequency) is proportional to the differential value of the deviation is called D action, which outputs the MV that differentiates the deviation. D action makes the inverter quickly respond to a rapid change of deviation.

The effectiveness of D action is expressed by differential time as parameter, that is J05 data. Setting a long differential time will quickly suppress oscillation caused by P action when a deviation occurs. Too long differential time makes the inverter output oscillation more. Setting short differential time will weakens the suppression effect when the deviation occurs.



The combined uses of P, I, and D actions are described below.

(1) PI control

PI control, which is a combination of P and I actions, is generally used to minimize the remaining deviation caused by P action. PI control always acts to minimize the deviation even if a commanded value changes or external disturbance steadily occurs. However, the longer the integral time of I action, the slower the system response to quick-changed control. P action can be used alone for loads with very large part of integral components.

(2) PD control

In PD control, the moment that a deviation occurs, the control rapidly generates greater MV (manipulated value: output frequency) than that generated by D action alone, to suppress the deviation increase. When the deviation becomes small, the behavior of P action becomes small. A load including the integral component in the controlled system may oscillate due to the action of the integral component if P action alone is applied. In such a case, use PD control to reduce the oscillation caused by P action, for keeping the system stable. That is, PD control is applied to a system that does not contain any damping actions in its process.

(3) PID control

PID control is implemented by combining P action with the deviation suppression of I action and the oscillation suppression of D action. PID control features minimal control deviation, high precision and high stability. In particular, PID control is effective to a system that has a long response time to the occurrence of deviation.

Follow the procedure below to set data to PID control function codes.

It is highly recommended that you adjust the PID control value while monitoring the system response waveform of the PID feedback with an oscilloscope or equivalent. Repeat the following procedure to determine the optimal solution for each system.

- Increase the data of J03 (PID control P (Gain)) within the range where the feedback signal does not oscillate.
- Decrease the data of J04 (PID control I (Integral time)) within the range where the feedback signal does not oscillate.
- Increase the data of J05 (PID control D (Differential time)) within the range where the feedback signal does not
 oscillate.

The method for refining the system response from the waveforms is shown below.

 Suppressing overshoot Increase the data of J04 (Integral time) and decrease that of J05 (Differential time).



Quick stabilizing (Moderate overshoot is allowable.)
 Decrease the data of J03 (Gain) and increase that of J05 (Differential time).



3) Suppressing oscillation whose period is longer than the integral time specified by J04 Increase the data of J04 (Integral time).



4) Suppressing oscillation whose period is approximately the same as the time specified by J05 (Differential time)

Decrease the data of J05 (Differential time).

Decrease the data of J03 (Gain), if the oscillation cannot be suppressed even though the differential time is set at 0 sec.



■ Feedback filter (J06)

J06 specifies the time constant of the filter for feedback signals under PID control.

- Data setting range: 0.0 to 900.0 (s)
- This setting is used to stabilize the PID control loop. Setting a too long time constant makes the system response slow.

J10 PID Control (Anti-reset windup)

J10 suppresses overshoot in control with the PID processor. As long as the error between the feedback and the PID command is beyond the preset range, the integrator holds its value and does not perform integration operation.

• Data setting range: 0 to 200 (%)



J11 to J13 PID Control (Select warning output, Upper limit of warning (AH) and Lower limit of warning (AL))

The inverter can output two types of warning signals (caused by process command value or PID error value) associated with PID control if the digital output signal "PID-ALM" is assigned to any of the programmable, output terminals with any of E20 to E22, E24 and E27 (data = 42).

J11 specifies the warning output types. J12 and J13 each specify the upper and lower limits for warnings.

■ PID Control (Select warning output) (J11)

J11 specifies one of the following alarms available.

J11 data	Alarm	Data
0	Warning caused by process command value	While PV < AL or AH < PV, "PID-ALM" is ON PID control (lower level alarm (AL)) (J13) PID control (upper level alarm (AH)) (J12) PID control (upper level alarm (AH))
1	Warning caused by process command value with hold	Same as above (with Hold)
2	Warning caused by process command value with latch	Same as above (with Latch)
3	Warning caused by process command value with hold and latch	Same as above (with Hold and Latch)
4	Warning caused by PID error value	While PV < SV - AL or SV + AH < PV, "PID-ALM" is ON. PID control (lower level alarm (AL)) (J13) PID control (upper level alarm (AH)) (J12) PID feedback value (PV) PID command value (SV)
5	Warning caused by PID error value with hold	Same as above (with Hold)
6	Warning caused by PID error value with latch	Same as above (with Latch)
7	Warning caused by PID error value with hold and latch	Same as above (with Hold and Latch)

Hold: During the power-on sequence, the alarm output is kept OFF (disabled) even when the monitored quantity is within the alarm range. Once it goes out of the alarm range, and comes into the alarm range again, the alarm is enabled.

Latch: Once the monitored quantity comes into the alarm range and the alarm is turned ON, the alarm will remain ON even if it goes out of the alarm range. To release the latch, perform a reset by using the Rey on keypad or turning the terminal command RST ON. Resetting can be done by the same way as resetting an alarm.

■ PID Control (Upper limit of warning (AH)) (J12)

J12 specifies the upper limit of warning (AH) in percentage (%) of the feedback value.

■ PID Control (Lower limit of warning (AL)) (J13)

J13 specifies the lower limit of warning (AL) in percentage (%) of the feedback value.

Note The value displayed (%) is the ratio of the upper/lower limit to the full scale (10 V or 20 mA) of the feedback amount (in the case of a gain of 100%).

Upper limit of warning (AH) and lower limit of warning (AL) also apply to the following alarms.

A la 199	Data	How to handle the warning		
Alarm		Select warning output (J11)	Data setting	
Upper limit (process command)	ON when AH < PV	Warning caused by process command	AL = 0	
Lower limit (process command)	ON when PV < AL		AH = 100%	
Upper limit (PID error value)	ON when SV + AH < PV	Warning caused by PID error value	AL = 100%	
Lower limit (PID error value)	ON when PV < SV - AL		AH = 100%	
Upper/lower limit (PID error value)	ON when SV - PV > AL		AL = AH	
Upper/lower range limit (PID error value)	ON when SV - AL < PV < SV + AL	Warning caused by PID error value	A penative logic	
Upper/lower range limit (process command)	ON when AL < PV < AH	Warning caused by process command	signal should be assigned to	
Upper/lower range limit (PID error value)	ON when SV - AL < PV < SV + AH	Warning caused by PID error value	"PID-ALM".	

J15 J16 J17	PID control (Sleep frequency) PID control (Sleep timer) PID control (Wakeup frequency) PID control (Wakeup lawel of PID error)
J23	PID control (Wakeup level of PID error)
J24	PID control (Wakeup timer)

Sleep function (J15 to J17, J23, J24)

J15 to J17 configure the sleep function in pump control, a function that stops the inverter when the discharge pressure increases, causing the volume of water to decrease.

When the discharge pressure has increased, decreasing the reference frequency (output of the PID processor) below the sleep level (J15) for the period specified sleep timer (J16), the inverter decelerates to stop, while PID control itself continues to operate. When the discharge pressure decreases, increasing the reference frequency (output of the PID processor) above the wakeup frequency (J17), the inverter resumes operation.

The restarting conditions can be adjusted with J23 and J24.

■ PID control (Sleep frequency) (J15)

J15 specifies the frequency which triggers slow flowrate stop of inverter.

■ PID control (Sleep timer) (J16)

J16 specifies the period from when the PID output drops below the frequency specified by J15 until the inverter starts deceleration to stop.

■ PID control (Wakeup frequency) (J17)

J17 specifies the wakeup frequency. Set J17 to a frequency higher than the sleep frequency (J15). If the specified wakeup frequency is lower than the sleep frequency, the sleep frequency is ignored; the sleep function is triggered when the output of the PID processor drops below the specified wakeup frequency.

Assignment of "PID-STP" ("Under sleep mode of PID control") (E20 to E22, E24 and E27, data = 44)

"PID-STP" ("Under sleep mode of PID control") is ON when the inverter is in a stopped state due to the sleep function under PID control. PID-STP should be assigned if it is necessary to output a signal to indicate that the inverter is stopped.

For the sleep function, see the chart below.



■ PID control (Wakeup level of PID error) (J23)

■ PID control (Wakeup timer) (J24)

When both of the two conditions below are satisfied (AND), the inverter is restarted.

- The discharge pressure has decreased, increasing the frequency (output of the PID processor) to or above the wakeup frequency (J17) and the wakeup timer (J24) has elapsed.
- The absolute error of the PV (feedback value) against to the SV (command value) is equal to or higher than the wakeup level of PID error (J23), and the wakeup time (J24) has elapsed.



J18, J19

PID Control (Upper limit of PID process output, Lower limit of PID process output)

The upper and lower limiters can be specified to the PID output, exclusively used for PID control. The settings are ignored when PID cancel "Hz/PID" is enabled and the inverter is operated at the reference frequency previously specified. (\square Function codes E01 to E05 data = 20)

■ PID Control (Upper limit of PID process output) (J18)

J18 specifies the upper limit of the PID processor output limiter in %. If the value of "999" is specified to J18, the setting of the frequency limiter (Upper) (F15) will serve as the upper limit.

■ PID Control (Lower limit of PID process output) (J19)

J19 specifies the lower limit of the PID processor output limiter in %. If the value of "999" is specified to J19, the setting of the frequency limiter (Lower) (F16) will serve as the lower limit.

J21 **Dew condensation Prevention**

With the inverter stopped, dew condensation can be prevented by applying DC current at fixed intervals to raise the motor temperature.

If using the dew condensation prevention function, it is necessary to assign dew condensation prevention "DWP" to the general-purpose digital input terminal. (\square Function code data = 39)

Enabling conditions

Turn ON dew condensation prevention "DWP" while the inverter is stopped to enable and start the dew condensation prevention function.

Dew condensation prevention

The current flowing to the motor is based on DC braking (braking level) (F21), and duty control is performed based on the dew condensation prevention duty (J21) ratio with respect to DC braking (time) (F22).



(F21)

Figure 5.3-17 Dew condensation prevention operation

```
J105 to J107
                 PID control (Display unit, Maximum scale, Minimum scale)
```

Refer to the description of J02.

J136 to J138

PID control 1 (PID multistep command 1 to 3)

For details, refer to the description of J02.

[5] Pump control

Applying the FRENIC-eHVAC to a water supply system configured with two or more pumps combined with a header enables the FRENIC-eHVAC to control those pumps for operating the water supply system with optimum electric power.

Cascade control and mutual operation control are available for controlling two or more pumps. Understanding the features of each control and selecting the appropriate control allows the FRENIC-eHVAC to provide high economic efficiency.

Control	Features
J401 = 1 or 11	A single FRENIC-eHVAC drives a maximum of 5 pump motors.
Cascade control	No. of pumps driven by inverter at variable speed: 1 (fixed)
(Inverter drive motor	No. of commercial power-driven pumps: 4 max. (fixed)
fixed system)	No. of auxiliary pumps (commercial power-driven): 1 (fixed)
	No. of magnetic contactors required: "No. of commercial power- driven pumps x 1"
	Pressure fluctuation at the time of adding/subtracting pumps: Large
	When J401 = 1, adding/subtracting pumps is judged with the ID controller output.
	When J401 = 11, adding/subtracting pumps is judged with the output frequency.
J401 = 2 or 12	A single FRENIC-eHVAC drives a maximum of 3 pump motors.
Cascade control	No. of pumps driven by inverter at variable speed: 1 (floating)
(Inverter drive motor	No. of commercial power-driven pumps: 2 max. (floating)
noaling system)	No. of auxiliary pumps (commercial power-driven): 1 (fixed)
	No. of magnetic contactors required: "No. of inverter drive pumps floating x 2 + 1 (for auxiliary pump)"
	Pressure fluctuation at the time of adding/subtracting pumps: Small
	When J401 = 2, adding/subtracting pumps is judged with the ID controller output.
	When J401 = 12, adding/subtracting pumps is judged with the output frequency.
J401 = 3 or 13	A single FRENIC-eHVAC drives a maximum of 5 pump motors.
Cascade control	No. of pumps driven by inverter at variable speed: 1 (floating)
(Inverter drive motor	No. of commercial power-driven pumps: 2 max. (floating)
power-driven motor system)	No. of auxiliary pumps (commercial power-driven): 1 (fixed)
	No. of magnetic contactors required: "No. of inverter drive pumps floating x 2 + 1 (for auxiliary pump)"
	Pressure fluctuation at the time of adding/subtracting pumps: Small
	No. of magnetic contactor ON/OFF times: Small
	When J401 = 3, adding/subtracting pumps is judged with the ID controller output.
	When J401 = 13, adding/subtracting pumps is judged with the output frequency.
J401 = 52	Number of pumps controllable: 4 max.
Mutual operation control	All pumps driven by inverter at variable speed (The same number of inverters is required.)
(Communications-	All FRENIC-eHVAC units to be linked via RS-485
linked inverter drive	No magnetic contactor required.
motor floating system)	Start/stop sequence cycles under PID control.
J401 = 54	Number of pumps controllable: 4 max.
Mutual operation control	All pumps driven by inverter at variable speed (The same number of inverters is required.)
(Communications-	All FRENIC-eHVAC units to be linked via RS-485
linked all motors	No magnetic contactor required.
control system)	All pumps operated at the same speed simultaneously.
	Closed-loop cycling pumps managing not pressure control but flowrate control, which provides large energy saving effect.

Details of each control are given on the following pages.

■ J401 = 1 or 11 Cascade control (Inverter drive motor fixed system)

Configure such a pump drive system that drives a particular pump (M0 in the configuration figure given below) with the FRENIC-eHVAC and drives other pumps (M1 to M4) with commercial power by turning magnetic contactors ON with the digital output signals issued by the FRENIC-eHVAC.

The FRENIC-eHVAC drives the M0 under PID control. If the frequency rises due to a PV signal level drop to satisfy the pump adding conditions, the FRENIC-eHVAC outputs pump start signals to turn the magnetic contactors ON, thereby starting commercial power-driven pumps successively. After starting all pumps, the inverter can further drive a single auxiliary pump (MA).

If the PV signal level rises and the frequency of the inverter-driven pump drops to satisfy the pump subtracting conditions, the FRENIC-eHVAC cancels pump start signals to turn the magnetic contactors OFF, thereby stopping commercial power-driven pumps successively.

The number of start signal lines available on the FRENIC-eHVAC is a total of three transistor output lines and two relay output lines in a standard configuration, so the FRENIC-eHVAC can control a total of five pumps (one pump driven by inverter at variable speed and four commercial power-driven pumps) in a standard configuration.

The advantage of this system is low cost since the number of controllable pumps is large and the number of magnetic contactors is one per pump. The disadvantage is large pressure fluctuation since adding/subtracting of pumps targets commercial power-driven pumps.

The start/stop sequence of commercial power-driven pumps is changeable so that the operating time of pumps can be averaged.

< Maximum number connection configuration of inverter drive motor fixed system (J401 = 1) >



Figure 5.3-18

< Operation timing scheme of inverter drive motor fixed system (J401 = 1) >



Figure 5.3-19



< Function code configuration required for the inverter drive motor fixed system >

(1) Function codes to be configured

Configuring the following function codes as listed below activates the inverter drive motor fixed system under cascade control.

Function code	Name	Data	Description
J401	Pump control mode selection	1, 11: Inverter drive motor fixed system	
J01 to J138	PID control 1	Depends on each code setting	These function codes configure PID control in accordance with the system design.
E20 to E22, E24,E27	[Y1] to [Y3], [Y5A/C] [30A/B/C]	 88: <i>AUX_L</i> (Auxiliary motor drive signal) 161, 163, 165, 167: <i>M1_L</i> to <i>M4_L</i> (Motor 1 to 4 being driven by commercial power) 	These function codes assign commercial drive start signals to the output terminals according to the number of commercial power-driven pumps. For a maximum configuration, the optional relay output card is required. AUX_L is a drive signal for auxiliary pump.
J411 to J414	Motor 1 to Motor 4 mode selection	1: Enable	These function codes configure motor modes according to the number of commercial power-driven pumps. Only motors enabled can be control targets.

(2) Function codes recommended to be configured

Function code	Name	Data	Description
J425	Motor switching procedure	1: Equal operating time	This function code automatically adjusts the start/stop sequence of commercial power-driven pumps to equalize the operating times of pumps.

(3) Function codes for individual adjustments

Configure the following function codes as needed.

Function code	Name	Data	Description
J450	Motor increase judgment (Judgment frequency)	0 to 120 Hz, 999: Depends on J18	This function code adjusts the motor adding conditions. If the frequency of the inverter-driven pump exceeds the setting of J450 and keeps it for the
J451	Motor increase judgment (Duration time)	0.00 to 3600 s	setting of J451, commercial power-driven motor adding conditions are met. The default is that if the frequency reaches the setting of J18 (PID upper limiter), the adding conditions are immediately met.
J452	Motor decrease judgment (Judgment frequency)	0 to 120 Hz, 999: Depends on J19	This function code adjusts the motor subtracting conditions. If the frequency of the inverter-driven pump drops below the setting of J452 and keeps it for the
J453	Motor decrease judgment (Duration time)	0.00 to 3600 s	setting of J453, commercial power-driven motor subtracting conditions are met. The default is that if the frequency reaches the setting of J19 (PID lower limiter), the subtracting conditions are immediately met.
J461	Motor increase/ decrease switching judgment non-responsive area width	0.0: Disable 0.1 to 50.0%	If the deviation between SV and PV values is less than the setting of J461, no increase/ decrease judgment is made.

Function code	Name	Data	Description
J455	Motor increase switching time (Deceleration time)	0.01 to 3600 s, 0.00: Depends on F08	This function code adjusts the sequence to apply at the time of adding motors. If the adding conditions of commercial power-driven pumps are met, the inverter decelerates according to the
J456	Motor increase switching level	0 to 100%	setting of J455. If the inverter decelerates to the setting of J456, it turns the commercial power-driven pump start signal ON. After that, the
J457	Motor increase PID control start frequency	0 to 120 Hz, 999: Depends on J452	inverter continues to decelerate. When it reaches the setting of J457, it restarts PID control. J456 is a percentage within the PID control range
			The initial speed decelerates according to the deceleration time selected. When it drops to the PID lower limit frequency, the start signal comes ON.
J458	Motor decrease switching time (Acceleration time)	0.00 to 3600 s, 0.00: Depends on F07	This function code adjusts the sequence to apply at the time of motor decrease. If the subtracting conditions of commercial power-driven pumps are met, the inverter accelerates according to the
J459	Motor decrease switching level	0 to 100% 999: Depends on J456	setting of J458. If the inverter accelerates to the setting of J459, it turns the commercial power-driven pump start signal ON. After that, the inverter continues to accelerate. When it reaches
J460	Motor decrease PID control start frequency	0 to 120 Hz, 999: Depends on J450	the setting of J460, it restarts PID control. J459 is a percentage within the PID control range (lower to upper limits). The initial speed accelerates according to the acceleration time selected. When it rises to the PID upper limit frequency, the start signal comes
J430	Stop of commercial power-driven motors	 0: Stop commercial power-driven motors 1: Stop commercial power-driven motors only when an inverter alarm occurs 2: Continue to run 	This function code specifies whether to stop commercial power-driven motors when an inverter run command is turned OFF or the inverter stops due to an alarm. Regardless of this setting, entering a coast-to-stop command BX stops all commercial power-driven pumps. The initial setting is that inverter stop conditions satisfied stops commercial power-driven pumps.
J436	Motor regular switching time	0.1 to 720.0 h	If feedback signals are kept stabilized, commercial power-driven pumps are not added or subtracted so that a particular pump is driven for a long time. Specifying the time to this function code forcibly adds or subtracts pumps if no adding or subtracting occurs for the specified time.
E01 to E05	[X1] to [X5]	151 to 154: MEN1 to MEN4 Pump control motor 1 to 4	These function codes individually separate pumps from the inverter drive motor fixed system with external signals. Only pumps whose MEN signals are ON are subject to this system.
J465	Auxiliary motor (Frequency operation level)	0.1 to 120 Hz 0.0: Disable	When all pumps subject to this system are operating and the inverter output exceeds the setting of J465, the auxiliary pump start signal
J466	Auxiliary motor (Hysteresis width)	0.0 to 120 Hz	comes ON. If the inverter decelerates from the setting of J465 by the setting of J466, the auxiliary pump start signal goes OFF.

J401 = 2 or 12 Cascade control (Inverter drive motor floating system)

To switch a maximum of three pumps between inverter drive and commercial power drive by a single FRENIC-eHVAC, configure two magnetic contactors per pump.

The FRENIC-eHVAC drives the first pump at variable speed under PID control. If the frequency rises due to a PV signal level drop to satisfy the pump adding conditions, the FRENIC-eHVAC switches the inverter-driven pump to commercial power drive and drives the newly added pump. After starting all pumps, the inverter can further drive a single auxiliary pump (MA). If the PV signal level rises and the frequency of the inverter-driven pump drops to satisfy the pump subtracting conditions, the FRENIC-eHVAC cancels start signals of the pumps being driven by commercial power, thereby stopping them successively. At the time of decreasing pumps, the FRENIC-eHVAC continues to drive the last added pump.

In this system, each of pumps to be controlled requires two signal lines for inverter drive and commercial power drive. To operate the pump drive system in a maximum configuration, an auxiliary pump start signal line is further required.

The number of start signal lines available on the FRENIC-eHVAC is a total of three transistor output lines and two relay output lines in a standard configuration, so the FRENIC-eHVAC can control a total of two pumps in a standard configuration.

To operate the pump drive system using three pumps, it is necessary to add the optional relay output card (OPC-F2-RY) to the FRENIC-eHVAC. It can add three relay output lines.

The advantage of this system is that the operating times of pumps can be averaged since the FRENIC-eHVAC cycles through pump motors.

■ J401 = 3 or 13 Cascade control (Inverter drive motor fixed + commercial power-driven motor system)

This system is the same as the inverter drive motor floating system in the basic configuration, except that it fixes the inverter drive pump according to the slow flowrate unit and switches the inverter drive pump when the system is started at the next time.

The advantage of this system is that the ON/OFF times of the magnetic contactors can be reduced. Therefore, this system is suitable for clean water supply systems repeating slow flowrate stops frequently.

< Maximum number connection configuration of inverter drive motor floating system >



< Operation timing scheme of inverter drive motor floating system (J401 = 2) >



Figure 5.3-22

< Operation timing scheme of inverter drive motor floating + commercial power-driven motor system (J401 = 3) >



Figure 5.3-23



Figure 5.3-24



Figure 5.3-25

< Function code configuration required for the inverter drive motor floating system and the inverter drive motor floating + commercial power-driven motor system >

(1) Function codes to be configured

Function code	Name	Data	Description
J401	Pump control mode selection	 2: Inverter drive motor floating system 3: Inverter drive motor floating + commercial power-driven motor system 	
J01 to J138	PID control 1	Depends on each code setting	These function codes configure PID control in accordance with the system design.
E20 to E22, E24, E27	[Y1] to [Y3], [Y5A/C] [30A/B/C]	 88: AUX_L (Auxiliary motor drive signal) 160 to 164: M1_I to M3_I (Motor 1 to 4 being driven by inverter) 161 to 165: M1_L to M3_L (Motor 1 to 3 being driven by commercial power) 	These function codes assign inverter drive start signals and commercial drive start signals to the output terminals according to the number of pumps. For a maximum configuration, the optional relay output card is required. AUX_L is a drive signal for auxiliary pump.
J411 to J413	Motor 1 to Motor 3 mode selection	1: Enable	These function codes configure motor modes according to the number of pumps. Only motors enabled can be control targets.

(2) Function codes recommended to be configured

Function code	Name	Data	Description
J425	Motor switching procedure	1: Equal operating time	This function code automatically adjusts the start/stop sequence of commercial power-driven pumps to equalize the operating times of pumps.

(3) Function codes for individual adjustments

Configure the following function codes as needed.

Function code	Name	Data	Description
J450	Motor increase judgment (Judgment frequency)	0 to 120 Hz 999: Depends on J18	This function code adjusts the motor adding conditions. If the frequency of the inverter-driven pump exceeds the setting of J450 and keeps it for the
J451	Motor increase judgment (Duration time)	0.00 to 3600 s	setting of J451, commercial power-driven motor adding conditions are met. The default is that if the frequency reaches the setting of J18 (PID upper limiter), the adding conditions are immediately met.
J452	Motor decrease judgment (Judgment frequency)	0 to 120 Hz 999: Depends on J19	This function code adjusts the motor subtracting conditions. If the frequency of the inverter-driven pump drops below the setting of J452 and keeps it for the
J453	Motor decrease judgment (Duration time)	0.00 to 3600 s	setting of J453, commercial power-driven motor subtracting conditions are met. The default is that if the frequency reaches the setting of J19 (PID lower limiter), the subtracting conditions are immediately met.
Function code	Name	Data	Description
---------------	--	---	---
J461	Motor increase/ decrease switching judgment non-responsive area width	0.1 to 50.0% 0.0: Disable	If the deviation between SV and PV values is less than the setting of J461, no increase/ decrease judgment is made.
J454	Contact restart time when switching the motor	0.01 to 2.00 s	Taking into account the contactor delay at the time of adding motors, the start of an inverter output can be delayed. Adjust this value when the inverter trips due to a contactor delay.
J455	Motor increase switching time (Deceleration time)	0.00 to 3600 s 0.00: Depends on F08	This function code adjusts the sequence to apply at the time of adding motors. If the adding conditions of commercial power-driven pumps are met, the inverter decelerates according to the
J456	Motor increase switching level	0 to 100%	setting of J455. If the inverter decelerates to the setting of J456, it turns the commercial power-driven pump start signal ON. After that, the
J457	Motor increase PID control start frequency	0 to 120 Hz 999: Depends on J452	 inverter continues to decelerate. When it reaches the setting of J457, it restarts PID control. J456 is a percentage within the PID control range (lower to upper limits). The initial speed decelerates according to the deceleration time selected. When it drops to the PID lower limit frequency, the start signal comes ON.
J458	Motor decrease switching time (Acceleration time)	0.00 to 3600 0.00: Depends on F07	This function code adjusts the sequence to apply at the time of motor decrease. If the subtracting conditions of commercial power-driven pumps are met, the inverter accelerates according to the
J459	Motor decrease switching level	0 to 100%	setting of J458. If the inverter accelerates to the setting of J459, it turns the commercial power-driven pump start signal ON. After that, the
J460	Motor decrease PID control start frequency	0 to 120 Hz 999: Depends on J450	 inverter continues to accelerate. When it reaches the setting of J460, it restarts PID control. J459 is a percentage within the PID control range (lower to upper limits). The initial speed accelerates according to the acceleration time selected. When it rises to the PID upper limit frequency, the start signal comes ON.
J430	Stop of commercial power-driven motors	 0: Stop commercial power-driven motors 1: Stop commercial power-driven motors only when an inverter alarm occurs 2: Continue to run 	This function code specifies whether to stop commercial power-driven motors when an inverter run command is turned OFF or the inverter stops due to an alarm. Regardless of this setting, entering a coast-to-stop command BX stops all commercial power-driven pumps. The initial setting is that inverter stop conditions satisfied stops commercial power-driven pumps.
J436	Motor regular switching time	0.1 to 720.0 h	If feedback signals are kept stabilized, commercial power-driven pumps are not added or subtracted so that a particular pump is driven for a long time. Specifying the time to this function code forcibly adds or subtracts pumps if no adding or subtracting occurs for the specified time.

Function code	Name	Data	Description
E01 to E05	[X1] to [X5]	151 to 155: <i>MEN1</i> to <i>MEN3</i> Pump control motor 1 to 3	These function codes individually separate pumps from the inverter drive motor fixed system with external signals. Only pumps whose <i>MEN</i> signals are ON are subject to this system.
J465 J466	Auxiliary motor (Frequency operation level) Auxiliary motor	0.1 to 120 Hz 0.0: Disable 0.0 to 120 Hz	When all pumps subject to this system are operating and the inverter output exceeds the setting of J465, the auxiliary pump start signal comes ON. If the inverter decelerates from the setting of J465
	width)		by the setting of J466, the auxiliary pump start signal goes OFF.
J467 J468 J469	Auxiliary motor (PV operation level, Connection timer, Interrupting timer	0.00 to 9999.0 0.00 to 2.00 s 0.00 to 2.00 s	When an inverter drive motor is switched in the inverter drive motor floating system, the pressure may decreases. If it happens, run the auxiliary motor to compensate the pressure decrease. For details, refer to the description of function codes given later.

Each function code is detailed separately.

■ J401 = 52 Mutual operation control (Communications-linked inverter drive motor floating system)

This system controls up to three pumps which are individually connected with the FRENIC-AQUA units in multidrop connection via RS-485.

The FRENIC-AQUA specified as a master performs PID control and sends run commands and frequency commands to other two slaves.

If the frequency rises due to a PV signal level drop to satisfy the pump adding conditions, the second inverter is started. After the start of a total of three inverters, the master can output a start signal to drive an auxiliary pump. The start/stop sequence of pumps cycles.

Even if the master stops due to an alarm, the slaves can continue running.

The advantage of this system is very small pressure fluctuation at the time of adding/subtracting pumps and small load to piping since all pumps are driven by inverters. The disadvantage is high cost since each pump requires an inverter.

■ J401 = 54 Mutual operation control (Communications-linked all motors simultaneous PID control system)

This system is configured in the same way as the communications-link inverter drive motor floating system except that all motors are driven under PID control with the same frequency at the same time.

Even if an alarm occurs, the remaining inverters continue to run. If the pressure is insufficient, the inverter outputs a start signal to an auxiliary pump to add one pump.

The advantage of this system is that driving two or more pumps under PID control at the same time can deliver water with low power for optimum watt hour in the cooling water cycling system managing the flowrate.

< Maximum number connection configuration of mutual operation (J401 = 52 or 54) >



Figure 5.3-26



< Operation timing scheme of communications-linked inverter-drive motor floating system >

Figure 5.3-27

Communications-linked inverter-driven motor floating system (J401 = 52)



Figure 5.3-28

FUNCTION CODES

Chap 5

< Function code configuration required for the communications-linked inverter drive motor floating system and communications-linked all motors simultaneous PID control system >

(1) Function codes to be configured (Different between master and slaves)

For master

Function code	Name	Data	Description
J401	Pump control mode selection	52: Communications- linked inverter drive motor floating system	
		54: Communications- linked all motors simultaneous PID control system	
J01 to J138	PID control 1	Depends on each code setting	These function codes configure PID control in accordance with the system design.
J403	Number of slaves	1 to 3	
y20	RS-485 communication 2	50: Communications link pump control protocol	

For slaves

Function code	Name	Data	Description
J401	Pump control mode selection	 52: Communications- linked inverter drive motor floating system 54: Communications- linked all motors simultaneous PID 	
		control system	
H30	Communications link function	8: Frequency command (RS-485) and run command (RS-485)	Ready to receive run commands and frequency command.
J402	Communication master/slave selection	1: Communication slave inverter	
y11	Station address	1 to 3	
y20	RS-485 communication 2	50: Communications link pump control protocol	

(2) Function codes recommended to be configured

Function code	Name	Data	Description
J425	Motor switching procedure	1: Equal operating time	This function code automatically adjusts the start/stop sequence of commercial power-driven pumps to equalize the operating times of pumps.

(3) Function codes for individual adjustments

Configure the following function codes as needed. No configuration is required for all motors simultaneous PID control system.

Function code	Name	Data	Description
J450	Motor increase judgment (Judgment	0 to 120 Hz 999: Depends on J18	This function code adjusts the motor adding conditions.
J451	frequency) Motor increase judgment (Duration time)	0.00 to 3600 s	exceeds the setting of J450 and keeps it for the setting of J451, commercial power-driven motor adding conditions are met. The default is that if the frequency reaches the setting of J18 (PID upper limiter), the adding conditions are immediately met.
J452	Motor decrease judgment (Judgment frequency)	0 to 120 Hz 999: Depends on J19	This function code adjusts the motor subtracting conditions. If the frequency of the inverter-driven pump drops below the setting of J452 and keeps it for
J453	Motor decrease judgment (Duration time)	0.00 to 3600 s	the setting of J453, commercial power-driven motor subtracting conditions are met. The default is that if the frequency reaches the setting of J19 (PID lower limiter), the subtracting conditions are immediately met.
J461	Motor increase/decrease switching judgment non-responsive area width	0.1 to 50.0% 0.0: Disable	If the deviation between SV and PV values is less than the setting of J461, no increase/ decrease judgment is made.
J436	Motor regular switching time	0.1 to 720.0 h	If feedback signals are kept stabilized, commercial power-driven pumps are not added or subtracted so that a particular pump is driven for a long time. Specifying the time to this function code forcibly adds or subtracts pumps if no adding or subtracting occurs for the specified time.

Each function code is detailed separately.

Pump Control Mode Selection

E01 to E05 Terminals X1 to X5 (Function selection) E20 to 22, E24 Terminals Y1 to Y3, Y5A/C (Function selection) E27 Terminal 30A/B/C (Ry output) H13 Restart Mode after Momentary Power Failure (Restart time) J01 PID Control (Mode selection)

J401 selects the pump control mode.

- Data setting range: 0 to 54

Data for J401	Function	Description
0	Disable	Pump quantity control (switching motor) is not performed.
1	Enable (Inverter drive motor fixed system)	Perform cascade control in the inverter drive motor fixed system. Adding/subtracting pumps is judged with the PID processor output.
2	Enable (Inverter drive motor floating system)	Perform cascade control in the inverter drive motor floating system. Adding/subtracting pumps is judged with the PID processor output.
3	Enable (Inverter drive motor floating + commercial power-driven motor system)	Perform cascade control in the inverter drive motor floating + commercial power-driven system. Adding/subtracting pumps is judged with the PID processor output.
11	Enable (Inverter drive motor fixed system)	Perform cascade control in the inverter drive motor fixed system. Adding/subtracting pumps is judged with the output frequency.
12	Enable (Inverter drive motor floating system)	Perform cascade control in the inverter drive motor floating system. Adding/subtracting pumps is judged with the output frequency.
13	Enable (Inverter drive motor floating + commercial power-driven motor system)	Perform cascade control in the inverter drive motor floating + commercial power-driven system. Adding/subtracting pumps is judged with the output frequency.
52	Enable (Communications- linked inverter drive motor floating system)	Perform mutual operation control in the communications- linked inverter drive motor floating system.
54	Enable (Communications- linked all motors simultaneous PID control system)	Perform mutual operation control in the communications- linked all motors simultaneous PID control system.

Note • The default setting cannot be modified during operation.

• When performing pump control, specify the pump control mode selection (J401), PID control 1 (mode selection) (J01).

• During mutual operation, if the slave unit generates an alarm (SLA: slave alarm), the master unit generates a "light alarm."

Functions for different J401 operating formats

Some functions are disabled, depending on the J401 operating format. The chart below indicates whether functions are enabled or disabled.

Function code	Pump	J401: Pump control operation mode selection				
	1, 11	2, 12	3, 13	52	54	
J01 to J138			Y			
Communication master/slave selection (J402)		Ν		Ň	Y	
Number of slave units (J403)		Ν		Ň	Y	
Master input transmission selection (J404)		Ν		Ň	Y	
Motors 1 to 4 drive selection (J411 to J414)		Y		1	N	
Motor switching sequence (J425)		Ň	Y		Ν	
Stop of commercial power-driven motors (J430)		Y		1	N	
Motor fixed-period switch (J435 to J437)		Y			Ν	
Motor increase judgment (J450, J451)	Y				Ν	
Motor decrease judgment (J452, J453)	gment (J452, J453) Y				Ν	
Motor switching time contact wait period (J454)	N Y N			N		
Motor increase switching time (deceleration time) (J455)	Y N Y N			N		
Motor increase switching level (J456)	Y N Y N			N		
Motor increase PID control start frequency (J457)	Y N Y N			N		
Motor decrease switching time (acceleration time) (J458)	Y N Y N			N		
Motor decrease switching level (J459)	Y	Ν	Y	Ν		
Motor decrease PID control start frequency (J460)	Y	Y N Y N			N	
Motor increase/decrease judgment dead zone (J461)	Y			Ν		
Abnormal unit judgment time (J462) N			Y	Ν		
Auxiliary motor (J465 to J467) Y						
Auxiliary motor (J468, J469) N Y N				Ν	Ν	

Y: Enabled, N: Disabled

J402

Communication Master/Slave Selection

J402 defines inverters as a master or slave in mutual operation. This function code only needs to be set during mutual operation. Set the inverter used as the master unit to "0," and the inverter used as the slave unit to "1."

- Data setting range: 0, 1
 - 0: Master inverter
 - 1: Slave inverter

J403

Number of slaves

J403 specifies the number of slave inverters in mutual operation. This function code only needs to be set during mutual operation. (This is required only for master, not for slave.)

- Data setting range: 1 to 3

J404

Master Input Permeation Selection

During mutual operation, the input terminals for making these settings on the slave units (X1 to X5, FWD, REV), the master unit terminal input information is reflected via the master unit operation command (S06). As a result, terminal input on the master unit allows simultaneous terminal input on the slave unit. As terminal input on the master unit is also input on the slave unit, the same settings are applied to the master and slave for terminals X1 to X5, FWD, REV (function selection) (E01 to E05, E98, E99).

- Data setting range: 0 to 007F (hexadecimal display)

7	6	5	4	3	2	1	0
0	X5	X4	X3	X2	X1	REV	FWD

(All bits are 1, and master unit input information reflection is enabled.)

(Example)

If master units X1, X2 and X4 are reflected in slave unit 1 and master units X4 and X5 are reflected in slave unit 2

The setting for slave unit 1 is 0010 1100 (binary) = 2C (hexadecimal), so J404 = 002C, and the setting for slave unit 2 is 0110 0000 (binary) = 60 (hexadecimal), to J404 = 0060.

When *FWD* and *REV* are set on J404, do not set function codes: E98 and E99 for terminals *FWD* and *REV* for both the master and slave to *FWD*, *REV*, *FWD2* and *REV2*. While number of terminals in operation for the master unit is (F02 = 1) and the run command is entered, the run command remains entered on the slave unit, so the slave unit will not operate as commanded by the master unit pump control commands.

J411 to J414 Motor 1 Mode Selection to Motor 4 Mode Selection

For motor mode selection, select the motor operation subject to pump control. When specifying "2" with forced drive (forced commercial power drive) ON, the pump commercial power driving signal can be output regardless of run command. This function code only needs to be set during cascade operation.

Data for J411 to J414	Function	
0	Disable (off at all times)	
1	Enable	
2	Forced drive ON (forced commercial power drive)	

Note

Forced drive ON (forced commercial power drive) is a function to turn on the relay output forcibly to
connect the motor to the commercial power supply. Thus, even if the run command is off, turn on the
relay output to drive the motor by commercial power.

Pump control drive motor permission commands 1 to 4 of pump control motor ("MEN1" to "MEN4")

As mode selection of pump control motors, there are pump control drive motor permission commands 1 to 8 ("MEN1" to "MEN8") by terminal input. A combination of the pump control drive motor permission command and the motor mode selection enables motor degradation. Degradation is a state in which the system is under operation continually with only the corresponding motor stopped.

< Action block diagram of pump control drive motor permission command >



PID control action

In the inverter-driven motor floating system (J401 = 2), the following state (1) or (2) is developed depending on the setting of motor mode selection (J411 to J414).

(1) Driving of all motors are not permitted

When driving of all motors is not permitted (pump control drive motor permission commands 1 to 4 = OFF ("MEN1" to "MEN4") or the motors are set to disable with motor mode selection (J411 to J414), PID control will not start because no motors can control the pump.

(2) All motors are driven by commercial power forcibly

On changing all motors from forced commercial power drive state to enable state (" $2 \Rightarrow 1$ " for J411 to J414) with the run command turned ON, motor increase/decrease judgment will be performed immediately based on the PID control.

J425 Motor Swit

Motor Switching Procedure

In pump control, two or more motors are operated while switching them. When increasing or decreasing the number of operating motors, specify the motors to be driven and the motors to be stopped in the motor switching procedure (J425). This allows cumulative run time for each motor to be equalized.

Data for J425	Function					
0	Fixing procedure <when increases="" motors="" number="" of="" the=""> The number increases successively in order of increasing the motor number. (motor 1 \Rightarrow motor 2, motor 3)</when>					
	<when decreases="" motors="" number="" of="" the=""> The number decreases successively in order of decreasing the motor number. (motor 3 \Rightarrow motor 2, motor 1)</when>					
	Equal operating time (Cumulative run time of each motor is equalized.)					
1	<when increases="" motors="" number="" of="" the=""> Of the motors that are not running, turn on the motor having the shortest operating time.</when>					
	<when decreases="" motors="" number="" of="" the=""> Of the motors that are running, turn off the motor having the longest operating time.</when>					
	Fixing procedure (Switching the motor at slow flowrate stop)					
2	Mode selection is the same when J425 is configured to 0. However, the drive motor switches to the subsequent motor not only when motors are increased, but also during slow flowrate stop.					
	Equal operating time (Switching the motor at slow flowrate stop)					
3	The operation is the same as when J425 =1 is selected. However, the drive motor switches to the motor with least operating time not only when motors are increased, but also during slow flowrate stop.					

J430

Stop of Commercial Power-driven Motors J411 to J418 (Motor mode selection)

J430 specifies whether to stop commercial power-driven motors when an inverter run command is turned OFF or the inverter stops due to an alarm under cascade control.

Data for	Turner of stars	Desci	ription
J430	Type of stop	Inverter-driven motor	Commercial power-driven motor
0	When run command is turned offThe motor will decelerate and stop. Inverter drive motor signals ("M1_I" to "M3_I") are turned off in concurrence with inverter output stop.		Motor commercial power driving signals ("M1_L" to "M4_L") are turned off at a time as soon as the inverter stops the output.
0	When alarmOutput to the motor is stopped and motor inverter drive signals ("M1_I" to "M3_I") are turned off.		Motor commercial power driving signals ("M1_L" to "M4_L") are turned off at a time as soon as the inverter stops the output.
1	When run command is turned off	The motor will decelerate and stop. Inverter drive motor signals ("M1_I" to "M3_I") are turned off in concurrence with inverter output stop.	Operation is continued.
	When alarm is generated	Output to the motor is stopped and motor inverter drive signals ("M1_I" to "M3_I") are turned off.	Motor commercial power driving signals ("M1_L" to "M4_L") are turned off at a time as soon as the inverter stops the output.
2	When run command is turned off	The motor will decelerate and stop. Inverter drive motor signals ("M1_I" to "M3_I") are turned off in concurrence with inverter output stop.	Operation is continued.
2	When alarm is generated	Output to the motor is stopped and inverter drive motor signals ("M1_I" to "M3_I") are turned off.	Operation is continued.

Chap 5 FUNCTION CODES



Commercial power-driven motors (including forced on motor) can be stopped in the following methods.

- (1) When turning off commercial power-driven motors individually
 - Set motor mode selection to disable (J411 to J418 = 0).
 - Turn off the pump control motor drive permission command ("MEN1" to "MEN4").
- $(2) \qquad \mbox{When turning off commercial power-driven motors at a time}$
 - Set pump control to disable (J401 = 0 or J01 = 0).
 - Perform BX input.

The above-mentioned function codes (J401, J01) cannot be changed during operation.

J435 J436	Motor Regular Switching Mode Selection Motor Regular Switching Time
J437	Motor Regular Switching Signal Output Time
	J401 (Pump Control Mode Selection)
	J411 to J414 (Motor Mode Selection)
	J425 (Motor Operating Time Procedure)
	J454 (Contactor Restart Time during Motor Switching)
	J458 (Motor Decrease Switching Time (Acceleration time))
	J480 to J484 (Operating Time Cumulative Run Time)

When the number of motors under operation remains unchanged for a period of the motor regular switching time (J436), switch one motor under operation to another motor under suspension. This allows to equalize the operating time of the pump connected to each motor.

■ Motor regular switching mode selection (J435)

When the inverter drive motor floating system (J401 = 2) or inverter drive motor floating + commercial power-driven motor system (J401 = 3), communication link inverter floating method (J401 = 52) is specified in pump control mode selection, if the number of motors under operation remains unchanged switching, specifies the motor.

When the inverter drive motor fixed system (J401 = 1) is specified in pump control mode selection, commercial drive motors will be subject to switching. (Same as when J435 is configured to 2.)

Data for J435	Description
1	Inverter-driven motors are subject to switching during cascade operation. During mutual operation, PID controlled units are subject to switching.
2	During cascade operation, commercial drive motors are subject to switching. During mutual operation, units in highest frequency operation are subject to switching.
3	During cascade operation, all motors (inverter-driven motors /commercial power-driven motors) are subject to switching. During mutual operation, all motors (PID controlled units/units in highest frequency operation) are subject to switching.

Motor regular switching time (J436)

The time for judging the regular switching operation of the motor is specified on a 0.1-hour basis. If the period specified for regular motor switching (J436) elapses without any change in the number of motors in operation, regular motor switching is performed.

- Data setting range: 0.0, 0.1 to 720.0 h, 999

Data for J436	Description
0.0	Disabled
0.1 to 720.0 h	Enable: Switching time
999	Enable: Switching time fixed to three minutes

Motor regular switching signal output time (J437)

Motor regular switching signal output time (duration time) is specified. After a lapse of motor regular switching time (J436), switching forecast signal "MCHG" is output and switching operation is implemented.

- Data setting range: 0.00 to 600.00 second



Furthermore, the motors in which forced on (forced commercial power drive) (J411 to J414 = 2) is selected in motor mode selection shall not be subject to motor operating time switching.

Motors subject to motor operating time switching

After the number of motors remains unchanged for motor operating time switching time (J436), switching operation will be implemented on the following motors.

Motor regular switching time (J436)	Description		
0.0	Motor regular switching operation is not implemented.		
	After the number of motors under operation remains unchanged for a period specified in the motor regular switching time (J436), motor regular switching operation will be implemented. The motor under operation with the maximum cumulative run time is stopped and then the motor under suspension with the minimum cumulative run time is driven. However, when the motor subject to stop has a shorter (or the same) cumulative run time than the motor subject to operation, no switching will be implemented. When there are two or more motors in which the maximum cumulative run time is the same with the minimum cumulative run time, the motor with smaller motor number will be subject to switching		
	Pump control mode selection (J401)	Motor regular switching mode selection (J435)	Motor subject to switching during operation
	1: Fixed system	-	Commercial drive motor
	2: Floating system 3: Floating + commercial	1: Subject to commercial power-driven pump	Commercial drive motor
0.1 to 720.0 h	power-driven motor system	2: Subject to inverter-driven pump	Inverter drive motor
		3: Subject to all pumps	Inverter drive motor Commercial drive motor
	52: Communication link inverter floating method	1. Subject to commercial drive pumps	Unit in highest-frequency operation
		2. Subject to inverter drive pumps	PID-controlled unit
		3. Subject to all pumps	PID-controlled unit Unit in highest-frequency operation
	54: Method in which all communication links simultaneously controlled by PID	Regular motor switching not performed.	
999	Switching operation is implemented as in the case with motor regular time switching function operation (J436 = 0.1 to 720.0 h) However, operating motor switching operation will be implemented after the number of motors under operation remains unchanged for three minutes. This setting is a function used for operation check upon start-up of the inverter		

■ Cancel regular switching operation

Operating time is counted during which there are no changes in the number of motors. When this count reaches the specified motor operation switching time (J436), regular switching occurs. Clearing this count by changing the regular switching time clearing command "MCLR" from ON to OFF cancels this regular switching. While the switching warning signal "MCHG" is being output, the regular switching time clearing command "MCLR" can be turned from ON to OFF to cancel regular switching.



 When the motor regular switching time clearing command "MCLR" remains tuned on continually, the time in which the number of operating motors remains unchanged is always cleared, which prevents motor regular switching from running.

Regular switching via input terminal

Even if there are no changes in the number of motors and the specified motor operation switching time (J436) is not reached, changing the pump control switching command "PCHG" from ON to OFF allows regular switching to be performed. In this case, the count of the time during which the number of motors in operation remains unchanged is cleared.

J450 J451	Motor Increase Judgment	(Judgment frequency) (Duration time)	
J452 J453	Motor Decrease Judgment	(Judgment frequency) (Duration time)	

During cascade operation (J401 = 1, 2, 3) or during communication link inverter floating method (J401 = 52) in mutual operation, changes in the number of motors are implemented when the motor increase/decrease judgment (duration time) (J451/J453) has elapsed over the inverter operation frequency (PID output (MV)) higher or lower the motor increase/decrease judgment (judgment frequency) (J450/J452).

When J401 = 11, 12 or 13, the judgment uses the actual output frequency instead of MV.

- Note
- When the deviation between the PID command value (SV value) and the PID feedback value is within the non-responsive area, switching operations are not performed based on the motor change judgment.
 - When the deviation between the PID command value (SV value) and the PID feedback value is
 negative, the number of motors is not increased based on the motor increase judgment. When the
 deviation between the PID command value (SV value) and the PID feedback value is positive, the
 number of motors is not decreased based on the motor decrease judgment.

< Action block diagram of upper and lower limiters >



Motor increase judgment (Judgment frequency) (J450)

Motor increase judgment frequency is specified.

Data for J450	Description
0 to 120 Hz	Motor increase judgment frequency
999	Depends on the PID control (PID output limiter upper limit) (J18)

Motor increase judgment (Duration time) (J451)

The duration time of motor increase judgment frequency is specified.

- Data setting range: 0.00 to 3600 s

Motor decrease judgment (Judgment frequency) (J452)

Motor decrease judgment frequency is specified.

Data for J452	Description	
0 to 120 Hz	Motor decrease judgment frequency	
999	Depends on the PID control (PID output limiter upper limit) (J19)	

Motor decrease judgment (Duration time) (J453)

The duration time of motor decrease judgment frequency is specified.

- Data setting range: 0.00 to 3600.00 s

J454

Contactor Restart Time when Switching the Motor

Contactor restart time during motor switching (J454)

In the inverter drive motor floating system (J401 = 2, 12) and inverter drive motor floating + commercial power-driven motor system (J401 = 3, 13), the motors are operated by delaying starting inverter-driven motors or commercial power-driven motors when the number of motors is increased or regular switching is implemented. The delay time (relay or contactor activation delay time) is specified.

- Data setting range: 0.01 to 2.00 s

J455 J456 J457 Motor Increase Switching Time (Deceleration time) Motor Increase Switching Level Motor Increase PID Control Start Frequency

Motor increase switching time (Deceleration time) (J455)

When the number of motors increases in the inverter drive motor fixed system (J401 = 1, 11) or the inverter drive motor floating + commercial power-driven motor system (J401 = 3, 13), the inverter-driven motor is slowed down during the motor increase switching time (deceleration time) (J455), and after the commercial power-driven motor is driven the output frequency reaches the motor increase PID start frequency (J457), and deceleration stops. At this point, PID control recommences, and the inverter-driven motor operates with the PID control MV frequency.

Data for J455	Description
0.01 to 3600.00 s	The deceleration time of the inverter-driven motor before commercial power-driven motor is driven with motor increase judgment.
0.00	Depend on F08 (Deceleration time 1). When RT1 is ON, the time depends on E11 (Deceleration time 2)

Motor increase switching level (J456)

When the number of motors increases in the inverter drive motor fixed system (J40 = 1, 11) or the inverter drive motor floating + commercial power-driven motor system (J401 = 3, 13), if the output frequency of the inverter driven motor is below the motor increase switching level (J456), the contactors for the increased units is turned ON.

- Data setting range: 0 to 100%

Switching frequency [Hz] = (J456/100%) × (J18 - J19) + J19

Note: J18: PID control 1 (PID output limiter upper limit), J19: PID control 1 (PID output limiter lower limit)

Motor increase PID control start frequency (J457)

When the number of motors increases in the inverter drive motor fixed system (J401 = 1, 11) or the inverter drive motor floating + commercial power-driven motor system (J401 = 3, 13), the frequency is set to create PID control.

Data for J457	Description
0 to 120 Hz	PID control start frequency after driving the commercial power-driven motor with motor increase judgment
999	The motor decrease judgment (judgment frequency) (J452) depends on the motor increase PID control start frequency.

J458	Motor Decrease Switching Time (Acceleration time)
J459	Motor Decrease Switching Level
J460	Motor Decrease PID Control Start Frequency
J460	Motor Decrease PID Control Start Frequency

Motor decrease switching time (Acceleration time) (J458)

During motor decrease during cascade operation, the inverter-driven motor is accelerated at motor deceleration switching time (acceleration time) (J458). After the commercial driven motor is interrupted, acceleration stops when output frequency reaches the motor decrease PID start frequency (J460). At this point, PID control recommences, and the inverter-driven motor operates with the PID control MV frequency.

Data for J458	Description
0.01 to 3600.00 s	The acceleration time of inverter-driven motor before stopping the commercial power-driven motor with motor decrease judgment.
0.00	F07: Depends on acceleration time 1 (When RT1 is turned ON, E10: acceleration time 2)

Motor decrease switching level (J459)

When motors are decreased ruing cascade operation, if the output frequency of the inverter-driven motor is above that of the motor decrease switching level (J459), the contacts for the decreased units are turned OFF.

Data for J459	Description
0 to 100%	The inverter-driven motor frequency level when the commercial power-driven motor is stopped with motor decrease judgment.
999	The motor increase switching level (J456) depends on the motor decrease switching level (J459).

Switching frequency [Hz] = (J459/100%) × (J19) - J18) + J19

Motor decrease PID control start frequency (J460)

When motors are decreased ruing cascade operation, the PID control start frequency is specified.

Data for J460	Description
0 to 120 Hz	The PID control start frequency after the commercial power-driven motor is stopped with motor decrease judgment.
999	Depends on the motor increase judgment (judgment frequency) (J450)

J461

Motor Increase/Decrease Switching Judgment Non-responsive Area Width

In the PID control, no motor increase/decrease judgment will be performed as long as the deviation between the PID command value (SV value) and the PID feedback value is less than the specified value.

Data for J461	Description
0.1 to 50.0%	Deviation between PID command value (SV value) and PID feedback value, assuming 100% of PID feedback full scale.
0.0	Disable (Always perform motor increase/decrease judgment)

J462 Failure Inverter Judgment Time

In the communications-linked inverter drive motor floating system (J401 = 52), if PID control comes to be at the hold state in the inverter running under PID control due to the limiter (e.g., current limit), then it is judged whether to exclude the PID control inverter.

If any other ready-to-run inverter exists in the system and the failure inverter judgment time (J462) has elapsed, the current PID control inverter will be switched to the other one.

This switching does not involve increase/decrease of inverters or regular switching even if their conditions are met.

If J462 = OFF, no switching occurs. During auto search for idling motor speed, no PID control inverter will be switched even if PID control comes to be at the hold state.

- Data setting range: OFF, 0.5 to 600.0 s

J463 PID control start frequency

After inputting a run command, the motor accelerates without performing PID control until the frequency set in J463 is reached. PID control is started after the value set in J463 is reached.

Data for J463	Description	
0	Disable	
1 to 120 Hz	Start frequency	
999	Depends on J19	

J465	Auxiliary Motor	(Frequency operation level)	
J466		(Hysteresis width)	

When all the set motors are under operation, the output frequency (for cascade operation: inverter-driven motor output frequency; for mutual operation: output frequency of units during PID control) reaches the auxiliary motor (frequency operation level) (J465), the auxiliary motor drive signal "AUX_L" is turned on and output. When the frequency is lowered below the auxiliary motor (frequency operation level) by more than the auxiliary motor (hysteresis width) (J466), the auxiliary motor drive signal "AUX_L" is turned OFF. However, when the configuration is set to disable (J01 = 0) in PID mode selection, or the configuration is set to disable (J401 = 0) in the pump control mode selection, the auxiliary motor drive signal "AUX_L" is turned OFF at all time.



■ Auxiliary motor (frequency operation level) (J465)

The frequency for determining the auxiliary motor drive is specified. When the frequency of the inverter-driven motor exceeds this value, the auxiliary motor is driven.

When the configuration is set to 0.0, the frequency at the frequency detection operation level (E31) is specified.

- Data setting range: OFF, 0.1 to 120.0 Hz

Auxiliary motor (hysteresis width) (J466)

The frequency width for determining the auxiliary motor stop is specified. When the frequency is lowered below the auxiliary motor (frequency operation level) (J465) by more than this value, the auxiliary motor is stopped.

When the configuration is set to 0.0, the frequency detection hysteresis width (E32) is specified.

- Data setting range: 0.0 to 120.0 Hz

J467	Auxiliary Motor	(PV operation level)	
J408		(Connection timer)	
J469		(Interrupting timer)	

For the inverter drive motor floating system (J401 = 2, 12) in the pump control mode selection, the inverter-driven motor is allowed to free-run before increasing the number of motors. The auxiliary motor is driven to control the pressure variation during a time period until the motor is commercial power-driven (contactor restart time during motor switching (J454)). Furthermore, when the number of motors is decreased, the auxiliary motor is not driven. The timing to drive and stop the auxiliary motor is determined by the connection level and the interrupting level. This judgment is implemented continually for a given period of time after allowing the inverter-driven motor to free-run. This period of time is ten times the larger value of the contactor restart time during motor switching (J454) or the auxiliary motor (connection timer) (J468).



J480 to J484 Motor Cumulative Run Time (Motor 0 to 4)

In the pump control, each motor cumulative run time (J480 to J484) is cumulated. The motor cumulative run time can be used for maintenance plan.

The motor cumulative run time is counted when the gate is turned ON and the dew condensation prevention function is not operated.

This is counted even during commercial operation due to the output signal, "M□_L" from the inverter.

The cumulative run time is cumulated in the range from 0 to 65,535 hours and reset to zero as it exceeds 65,535 hours, and then the time is cumulated continually. For the display of cumulative run time, 1 hour is displayed as 1 hours in the keypad.

The cumulative run time can be specified to any value from the keypad. The initial time of replacing machine parts or inverter can be specified to any value.

The chart below indicates cumulative operating times and corresponding motor numbers for each pump control mode selection (J401) setting.

Everetien ende		Pump control mode selection (J401)		
	Function code	1, 11	2, 3, 12, 13	52, 54
J480	Cumulative operating time (Motor 0)	Inverter drive motor	-	Master unit
J481	Cumulative operating time (Motor 1)	M1_L motor	M1_I and M1_L motor	Slave unit 1
J482	Cumulative operating time (Motor 2)	M2_L motor	M2_I and M2_L motor	Slave unit 2
J483	Cumulative operating time (Motor 3)	M3_L motor	M3_I and M3_L motor	Slave unit 3
J484	Cumulative operating time (Motor 4)	M4_L motor	-	-

J490	Y terminal ON Maximum Cumulation Count (Y1 Y2 Y3)
J491	(Y5A/C)
J492	(30A/B/C)
J493	(Y6RY to Y8RY)

Y terminal output and relay output option ON/OFF cumulation count can be monitored. This serves as a guide for the operating life of each relay. The cumulation count stops when 1 million is reached. Furthermore, the relay time can be reset by the user by clearing the relay ON cumulation count and using the keypad. This is operational only when cascade operation is enabled (J401 = 1, 2, 3, 11, 12, 13). The count is stored in units of 16 when the power is off, so the maximum deviation is 16 each time the power is turned off.

Note • The relay ON maximum cumulation count (J490 to J493) is resettable by keypad operation.

■ Y terminal ON maximum cumulation count (Y1 Y2 Y3) (J490)

The larger of the cumulation counts of Y terminal outputs (E20, E21, and E22) ON of inverter main body is displayed. The display of "1.000" indicates 1000 times.

Relay ON cumulation count (Y5A /C) (J491)

The cumulation count of Y5A/C relay outputs (E24) ON of inverter main body is displayed. The display of "1.000" indicates 1000 times.

Relay ON cumulation count (30A/B/C) (J492)

The cumulation count of 30A/B/C relay outputs (E27) ON of inverter main body is displayed. The display of "1.000" indicates 1000 times.

■ Relay ON maximum cumulation count (Y6RY to Y8RY) (J493)

The larger of the relay ON cumulation counts on the relay output option (OPC-F2-RY) is displayed. The display of "1.000" indicates 1000 times.

Output terminals	Lifetime of contacts	Capacity of contacts
Transistor outputs (Y1, Y2, Y3)	Depends upon the specifications of the relay to be connected.	-
Relay outputs	200000 times	250 VAC 0.3A
(Y5A/C, 30A/B/C)	(when turned ON/OFF at one-second intervals)	48 VDC 0.5A
Relay output option	200000 times	250 VAC 0.3A
OPC-F2-RY	(when turned ON/OFF at one-second intervals)	48 VDC 0.5A

J501

External PID Control 1 (Mode selection)

Apart from PID control specified by J01, the inverter has three channels of PID control to control external devices such as dampers and valves so that no external PID controllers are required.

Under PID control, the inverter detects the state of a control target object with a sensor or the similar device and compares it with the commanded value (e.g., temperature control command). If there is any deviation between them, PID control operates to minimize it. That is, it is a closed loop feedback system that matches controlled variable (feedback amount). PID control expands the application area of the inverter to process control (e.g., flow control, pressure control, and temperature control).

Data for J501	Function	
0	Disable	
1	Enable process control (Normal operation)	
2	Enable process control (Inverse operation)	
11	Enable process control, interlocking with inverter running (Normal operation) When the output signal <i>RUN</i> ("Inverter running") is ON, the process control operates.	
12	Enable process control, interlocking with inverter running (Inverse operation) When the output signal <i>RUN</i> ("Inverter running") is ON, the process control operates.	
21	Enable process control by external digital signal (Normal operation) Turning ON the terminal command <i>EPID1-ON</i> ("External PID control 1 ON command") operates the process control.	
22	Enable process control by external digital signal (Inverse operation) Turning ON the terminal command <i>EPID1-ON</i> ("External PID control 1 ON command") operates the process control.	
31	Enable process control by external digital signal, interlocking with inverter running (Normal operation) Turning ON the terminal command <i>EPID1-ON</i> ("External PID control 1 ON command") when the output signal <i>RUN</i> ("Inverter running") is ON, the process control operates.	
32	Enable process control by external digital signal, interlocking with inverter running (Inverse operation) Turning ON the terminal command <i>EPID1-ON</i> ("External PID control 1 ON command") when the output signal <i>RUN</i> ("Inverter running") is ON, the process control operates.	

To use "External PID control 1 ON command", you need to assign the terminal command *EPID1-ON* to any of the general-purpose digital input terminals, respectively. (E01 to E05)

External PID control: "External PID control 1 ON command" *EPID1-ON* (data = 201)



If data 11, 12, 31, 32 are set, during inverter deceleration the PID control is put on hold (I item hold).
 PID control is put on hold only during decelerating to stop when the run command is OFF. PID control is not put on hold when decelerating to stop if the set frequency is changed.

J502

External PID Control 1 (Remote command selection)

J502 selects the source that specifies external PID control command 1, respectively. The table below lists the external PID control command sources.

Data for J502	External PID control command sources		
0	Keypad Specify the external PID command by using the \oslash / \oslash keys on the keypad.		
	Terminal command UPIDOWN		
3	With the <i>UP</i> and <i>DOWN</i> commands, 0 to 100% of an external PID control command value can be set as a value converted into physical quantity in terms of the display unit and scale.		
4	Command via communications link For J502, use function code S30. The transmission data of 20000 (decimal) is equal to 100% the PID command.		
51	Analog input Voltage input to terminal [12]: 0 to ±10 VDC, 100% PID command/ ±10 VDC Current input to terminal [C1] (C1 function): 4 to 20 mA DC, 100% PID command/ 20 mA DC, 0 to 20 mA DC, 100% PID command/ 20 mA DC Voltage input to the terminal [C1](V2function): 0 to 10 VDC, 100% PID command/ 10 VDC)		

(1) External PID command with the \bigcirc / \bigcirc keys on the keypad (J502, data = 0 (factory default))

With the \bigcirc / \bigcirc keys on the keypad, 0 to 100% of an external PID control command value can be set as a value converted into easy-to-understand, physical quantity in terms of the display unit and scale.

- For scale setting for terminals [12], [C1](C1 function) or [C1](V2 function), refer to function codes C59 and C60, C65 and C66, or C71 and C72, respectively.
- (2) External PID command with *UP/DOWN* control (J502, data = 3)

When the UP/DOWN control is selected as an external PID command, turning the terminal command UP or DOWN ON causes the external PID command to change between the minimum scale and maximum scale.

The PID command can be specified in mnemonic physical quantities with the display unit (J505) and scale (J506/J507).

To select the *UP/DOWN* control as an external PID command, the *UP* and *DOWN* should be assigned to the digital input terminals [X1] to [X5]. (\square E01 to E05, data = 17, 18)

UP	DOWN	Function	
Data = 17	Data = 18		
OFF	OFF	Retain the current external PID command value.	
ON	OFF	Increase external PID command value at a rate between 0.1%/0.1 s and 1%/0.1 s.	
OFF	ON	Decrease external PID command value at a rate between 0.1%/0.1 s and 1%/0.1 s.	
ON	ON	Retain the current external PID command value.	

Note Command settings via the UP/DOWN control are common to PID control 1(J02).

(3) External PID command via communications link (J502, data = 4)

Use function code S30 that specifies the communications function code. The transmission data of 20000 (decimal) is equal to 100% of the PID command.

For details of the communications format, refer to the RS-485 Communication User's Manual.

(4) External PID command by analog inputs (J502, data = 51)

When any analog input (voltage input to terminals [12] and [V2], or current input to terminal [C1]) for an external PID command is used, it is possible to arbitrary specify the PID command by multiplying the gain and adding the bias. The polarity can be selected and the filter time constant and offset can be adjusted. In addition to J502, J602 and J652 settings, it is necessary to select external PID command 1, 2 or 3 for analog input (specified by any of E61 to E63, function code data = 3). For details, refer to the descriptions of E61 to E63.

A division has a large state of DID as many	
Adjustable elements of PID comm	and

Input terminal	Input range	Bias		Gain			Filter		laput
		Bias	Base point	Gain	Base point	Polarity	time constant	Offset	range
[12]	0 to +10 V, -10 to +10 V	C55	C56	C32	C34	C35	C33	C31	-
C1	4 to 20 mA, 0 to 20 mA	C61	C62	C37	C39	-	C38	C36	C40
[C1](V2)	0 to +10 V	C67	C68	C42	C44	C45	C43	C41	-

Offset (C31, C36, C41)

C31, C36 or C41 configures an offset for an analog voltage/current input. The offset also applies to signals sent from the external equipment.

■ Filter time constant (C33, C38, C43)

C33, C38, and C43 provide the filter time constants for the voltage and current of the analog input. Choose appropriate values for the time constants considering the response speed of the machinery system, as large time constants slow down the response. If the input voltage fluctuates because of noise, specify large time constants.

Polarity (C35, C45)

C35 and C45 specify the input range for analog input voltage.

Data for C35/C45	Terminal input specifications
0	-10 to +10V With [C1] (V2 function), 0 to +10 V is converted to -100% to +100% based on the minus bias setting.
1	0 to +10V (negative value of voltage is regarded as 0 V)

■ Terminal [C1] input range selection (C40)

C40 specifies the input range for terminal [C1] (analog input current).

Data for C40	Terminal input range
0	4 to 20 mA (factory default)
1	0 to 20 mA

Gain and bias

Terminal	Action
[12]	PID command % Gain (C32) Bias (C55) Point A Point A Analog input
	base base point point (C56) (C34)
[C1](C1 function)	PID command % Gain (C37) Bias (C61) Point A Dias base point (C62) (C39) Analog input
[C1](V2 function)	PID command % Gain (C42) Bias (C67) Point A 0 Bias base base point (C68) (C44) Analog input

(Example) Mapping the range of 1 through 5 V at terminal [12] to 0 through 100% Process command



Selecting Feedback Terminals

For feedback control, determine the connection terminal according to the type of the sensor output.

- If the sensor is a current output type, use the current input terminal [C1](C1 function) of the inverter.
- If the sensor is a voltage output type, use the voltage input terminal [12] of the inverter, or switch over the terminal [C1](V2 function) to the voltage input terminal and use it.
- For details, refer to the descriptions of E61 through E63.

Application example: Process control (for air conditioners, fans and pumps)

The operating range for PID process control is internally controlled as 0% through 100%. For the given feedback input, determine the operating range to be controlled by means of gain adjustment.

(Example) When the output level of the external sensor is within the range of 1 to 5 V:

- · Use terminal [12] designed for voltage input.
- Set the gain (C32 for analog input adjustment) at 200% in order to make the maximum value (5 V) of the external sensor's output correspond to 100%. Note that the input specification for terminal [12] is 0 to 10 V corresponding to 0 to 100%; thus, a gain factor of 200% (= 10 V ÷ 5 V × 100) should be specified. Note also that any bias setting does not apply to feedback control.



(Example 1) When the output level of the external sensor is ± 7 VDC:

- Use terminal [12] since the voltage input is of bipolar.
- When the external sensor's output is of bipolar, the inverter controls the speed within the range of ±100%. To convert the output ±7 VDC to ±100%, set the gain (C32 for analog input adjustment) at 143% as calculated below.

$$\frac{10 \text{ V}}{7 \text{ V}} \approx 143\%$$



(Example 2) When the output level of the external sensor is 0 to 10 VDC:

- Use terminal [12] designed for voltage input.
- When the external sensor's output is of unipolar, the inverter controls the speed within the range of 0 to 100%.



PID Display Coefficient and Monitoring

To monitor the PID command and its feedback value, set a display unit, maximum scale, and minimum scale to convert the values into easy-to-understand physical quantities (such as temperature).

•	Function code of a	display unit,	maximum sc	ale, and	minimum	scale, fo	or each terminal
---	--------------------	---------------	------------	----------	---------	-----------	------------------

	Display unit	Maximum scale	Minimum scale
Terminal [12]	C58	C59	C60
Terminal C1	C64	C65	C66
Terminal [C1](V2)	C70	C71	C72

For the monitor, refer to function code K10.

External PID Control 1 (Display unit)

J505 selects a display unit for external PID control 1.

J505

Under external PID control, the external PID command setting value (SV), feedback value (PV), manipulated value (MV) and others can be monitored on the keypad. For these values, select the display units.

For the setting procedure of the monitor display, refer to Chapter 5, Section 5.5.1 "Monitoring the running status."

Note When external PID control is to be performed with the same unit and scale as for feedback values, the J505 settings need not be changed. (Factory default: In accordance with the unit and scale used for feedback values)

Configure the J505 to use different unit and scale from feedback values.

Data for J505	Display unit	Data for J505	Display unit	Data for J505	Display unit
0	(Factory default)*	23	L/s (flowrate)	45	mmHg (pressure)
1	No unit	24	L/min (flowrate)	46	Psi (pressure)
2	%	25	L/h (flowrate)	47	mWG (pressure)
4	r/min	40	Pa (pressure)	48	inWG (pressure)
7	kW	41	kPa (pressure)	60	K (temperature)
20	m ³ /s (flowrate)	42	MPa (pressure)	61	°C (temperature)
21	m ³ /min (flowrate)	43	mbar (pressure)	62	°F (temperature)
22	m ³ /h (flowrate)	44	bar (pressure)	80	ppm (density)

* In accordance with the unit and scale used for feedback values

For feedback value selection, see function codes E61 to E63.

The table below lists function codes to be used for setting a unit and scale for feedback values.

	Display unit	Maximum scale	Minimum scale
Terminal [12]	C58	C59	C60
Terminal [C1](C1 function)	C64	C65	C66
Terminal [V2](V2 function)	C70	C71	C72

J506, J507

External PID Control 1 (Maximum scale, Minimum scale)

J506/J507 specify the maximum/minimum scale for external PID control 1.

Set the maximum scale "External PID command value / Display value at 100% of external PID feedback value" with J506, and the minimum scale "External PID command value / Display value at 0% of external PID feedback value" with J507.

Display values are calculated with the following expression.

Display value = (External PID control value (%)) / 100 x (Maximum scale - Minimum scale) + Minimum scale

- Data setting range: (Maximum scale and minimum scale) -999 to 0.00 to 9990



Note

When external PID control is to be performed with the same unit and scale as for feedback values, the J506 or J507 settings need not be changed. (Factory default: In accordance with the unit and scale used for feedback values. Refer to J505.)

Configure the J506 and J507 to use different unit and scale from feedback values.

J510	External PID Control 1 P (Gain)	
J511	I (Integral time)	
J512	D (Differential time)	
J513	(Feedback filter)	

The table below lists function codes to be used for setting the P (gain), I (integral time), D (differential time) and feedback filter for external PID controls.

	P (gain)	l (integral time)	D (differential time)	Feedback filter
External PID control 1	J510	J511	J512	J513

For details of P action, I action, D action, as well as their coordinated controls and adjusting method, see the description of J10, J11, and J12. Note that the P (gain) of External PID (J510) correspond to J10. Also, I (integral time) (J511) correspond to J11, and the D (differential time) (J512) correspond to J12.

P gain (J510)

J510 specifies the gain for the external PID processor.

- Data setting range: 0.000 to 30.000 (times), 999: ON/OFF control

ON/OFF control

Setting the P gain (J510) to "999" enables ON/OFF control. If the feedback value (PV) exceeds the threshold value "Command setting value SV + Hysteresis width (J515)," the manipulated value (MV) switches between two positions 0% and 100%.

 Normal operation Reverse operation Manipulated value (MV) J515 J515 J515 J515 Manipulated value (MV) ON ON 100% 100% OFF OFF 0% 0% Feedback value (PV) Feedback value (PV) Command value (SV) Command value (SV)

I integral time (J511)

J511 specifies the integral time for the external PID processor.

- Data setting range: 0.0 to 3600.0 (s) 0.0 means that the integral component is ineffective.

D differential time (J512)

J512 specifies the differential time for the external PID processor.

- Data setting range: 0.00 to 600.00 (s) 0.00 means that the differential component is ineffective.

Feedback filter (J513)

J513 specifies the time constant of the filter for feedback signals under the external PID control.

- Data setting range: 0.0 to 900.0 (s)
- This setting is used to stabilize the PID control loop. Setting too long a time constant makes the system response slow.

J514 External PID Control 1 (Anti-reset wind-up)

J514 suppresses overshoot under external PID control 1 using an external PID processor. As long as the deviation between the PID command and its feedback is out of the preset range, the integrator holds its value and does not perform integration operation.

- Data setting range: 0.00, 0.01 to 9990 (The setting range is restricted by the maximum scale and minimum scale.)



J515	External PID Control 1 (ON/OFF control hysteresis width)	
J212	External PID Control 1 (ON/OFF control hysteresis width)	

J515 specifies the hysteresis width for ON/OFF control under external PID control 1 in a physical quantity.

Setting the P gain (J510) to "999" enables ON/OFF control. If the feedback value (PV) exceeds the threshold value "Command setting value SV + Hysteresis width (J515)," the manipulated value (MV) switches between two positions 0% and 100%.

- Data setting range: 0.00 to 9990 (The setting range is restricted by the maximum scale and minimum scale.)
 - Normal operation Reverse operation Manipulated value J515 I J515 J515 J515 Manipulated value (MV) (MV) ON ON 100% 100% OFF OFF 0% 0% Feedback value (PV) Feedback value (PV) Command value (SV) Command value (SV)

5-220



External PID Control 1 (Proportional operation output convergent value)

Exclusively for external PID control, this setting value can be added to the external PID output. J516 sets external PID controls 1 respectively.

- Data setting range: 0 to 150 (%)



Also, by disabling I (integral time) and D (differential time) to enable only P (gain) and this value, the following comparison is possible.



J517

External PID Control 1 (Proportional cycle)

J517 specifies the output cycle (Tc) of pulse outputs under output duty control for external PID control 1.

- Data setting range: 1 to 150 (s)



The ON and OFF times are calculated by the following expressions.

ON time = Output cycle (Tc) x Manipulated value (MV) / 100 OFF time = Output cycle (Tc) - ON time

(Example) If output cycle (Tc) = 60 s, MV = 35%

ON time = 60 s x 35% / 100 = 21 s OFF time = 60 s -21 s = 39 s

To use the proportional cycle, it is necessary to assign *EPID1-OUT* to any of digital output terminals as duty control output with any of E20 to E22, E24 and E27.

- External PID control 1: EPID1-OUT (E20 to E24 and E27, data = 212)

J518	
J519	
J520	

External PID Control 1 (Upper limit of PID process output) (Lower limit of PID process output) (Upper and lower limits)

J518/J519/J520 defines the upper and lower limiters for the external PID output, which exclusively apply to external PID control 1.

When external PID control is cancelled with %/EPID1 and manual command is used to operate, the upper and lower limiters are effective.

E01 to E05, data = 202 (%/*EPID1*)

■ PID Control 1 (Upper limit of PID process output) (J518)

- Data setting range: -10 to 110 (%)

J518 specifies the upper limit of the external PID processor output limiter in %.

■ PID Control 1 (Lower limit of PID process output) (J519)

- Data setting range: -10 to 110 (%)

J519 specifies the lower limit of the external PID processor output limiter in %.

■ PID Control 1 (Upper and lower limits) (J520)

J520 specifies the upper and lower limits of the external PID processor output limiter.

Data for J520	PID output limiter		
	Upper limit	Lower limit	
0	J518	J519	
1	J518 data or above \Rightarrow 110%	Less than J519 data $ \Rightarrow $ -10%	
J521	External PID Control 1	(Alarm output selection)	
------	------------------------	--------------------------	
J522		(Upper level alarm (AH))	
J524		(Lower level alarm (AL))	

J521/J522/J524 define two types of alarm signals (absolute-value and deviation alarms) that the inverter can output for external PID control 1.

To use the alarm output, it is necessary to assign *EPV1-ALM* to any of digital output terminals as duty control output with any of E20 to E22, E24 and E27. To generate a light alarm, the following digital output signals can be extracted without setting the light alarm selection 4 (H184). For details of light alarms, see the description of function codes H181 to H184.

- External PID control 1: EPV1-ALM (E20 to E23, E24 and E27, data = 214)

J521 specifies the alarm output types. J522 and J524 specify the upper and lower limits for alarms.

■ PID control 1 (Alarm output selection) (J521)

J521 specifies one of the following alarms available.

Data for J521	Alarm	Description
0	Absolute-value alarm (PV)	While PV < AL or AH < PV, EPV1-ALM is ON.
		PID control (Lower level alarm (AL)) (J524) PID control (Upper level alarm (AH)) (J522) PID feedback (PV)
1	Absolute-value alarm (PV) (with Hold)	Same as above (with Hold)
2	Absolute-value alarm (PV) (with Latch)	Same as above (with Latch)
3	Absolute-value alarm (PV) (with Hold and Latch)	Same as above (with Hold and Latch)
4	Deviation alarm (PV)	While PV < SV - AL or SV + AH < PV, EPV1-ALM is ON. PID control (Lower level alarm (AL)) (J524) PID command value (SV) PID command
5	Deviation alarm (PV) (with Hold)	Same as above (with Hold)
6	Deviation alarm (PV) (with Latch)	Same as above (with Latch)
7	Deviation alarm (PV) (with Hold and Latch)	Same as above (with Hold and Latch)
8	Absolute-value alarm (SV)	While SV < AL or AH < SV, EPV1-ALM is ON. PID control (Lower level alarm (AL)) (J524) PID control (J522) PID feedback (PV) PID feedback

Data for J521	Alarm	Description
9	Absolute-value alarm (SV) (with Hold)	Same as above (with Hold)
10	Absolute-value alarm (SV) (with Latch)	Same as above (with Latch)
11	Absolute-value alarm (SV) (with Hold and Latch)	Same as above (with Hold and Latch)
12	Absolute-value alarm (MV)	While MV < AL or AH < MV, EPV1-ALM is ON. PID control (Lower level alarm (AL)) (J524) PID control (Upper level alarm (AH))
13	Absolute-value alarm (MV) (with Hold)	Same as above (with Hold)
14	Absolute-value alarm (MV) (with Latch)	Same as above (with Latch)
15	Absolute-value alarm (MV) (with Hold and Latch)	Same as above (with Hold and Latch)

SV: Process command value, PV: Feedback value, MV: Manipulated value

- Hold: During the power-on sequence, the alarm output is kept OFF (disabled) even when the monitored quantity is within the alarm range. Once it goes out of the alarm range, and comes into the alarm range again, the alarm is enabled.
- Latch: Once the monitored quantity comes into the alarm range and the alarm is turned ON, the alarm will remain ON even if it goes out of the alarm range. To release the latch, perform a reset by using the terminal command *RST* ON. Resetting can be done by the same way as resetting an alarm.

External PID control 1 (Upper level alarm (AH) (J522)

J522 specifies the upper limit (AH) for alarms in a physical quantity.

- Data setting range: OFF: Disable, -999.00 to 0.00 to 9990.00

The physical quantity is dependent on the display unit and maximum/minimum scale specified by the following function codes.

	Display unit	Maximum scale	Minimum scale
External PID control 1	J505	J506	J507

External PID control 1 (Lower level alarm (AL) (J524)

J524 specifies the lower limit (AL) for alarms in a physical quantity. The physical quantity is dependent on the display unit and maximum/minimum scale specified by the function codes listed above.

- Data setting range: OFF: Disable, -999.00 to 0.00 to 9990.00

Upper level alarm (AH) and lower level alarm (AL) also apply to the following alarms.

Alorm	Departmen	How to handle the alarm:		
Alaim	Description	Select alarm output (J521)	Parameter setting	
Upper limit (absolute)	ON when AH < PV ON when AH < SV ON when AH < MV	Absolute-value alarm	AL = 0	
Lower limit (absolute)	ON when PV < AL ON when SV < AL ON when MV < AL		AH = 100%	
Upper limit (deviation)	ON when SV + AH < PV	Deviation alarm	AL = 100%	
Lower limit (deviation)	ON when PV < SV - AL		AH = 100%	
Upper/lower limit (deviation)	ON when SV - PV > AL		AL = AH	
Upper/lower range limit (deviation)	ON when SV - AL < PV < SV + AL	Deviation alarm	A negative logic signal should be assigned to	
Upper/lower range limit (absolute)	ON when AL < PV < AH ON when AL < SV < AH ON when AL < MV < AH	Absolute-value alarm	EPV1-ALM	
Upper/lower range limit (deviation)	ON when SV - AL < PV < SV + AH	Deviation alarm		

J527
J529
J530
J531

External PID Control 1 (Feedback error detection mode) (Feedback error upper-limit) (Feedback error lower-limit) (Feedback error detection time)

Under external PID control, the inverter can detect abnormal feedback values (PV).

In the case of external PID control 1, if the error level of a PV signal (Upper limit: J529, Lower limit: J53) is kept for the feedback error detection time (J531), the inverter regards it as an error, then stops or continues running according to the mode specified by J527.

	Feedback error detection mode	Feedback error upper limit	Feedback error lower limit	Error detection time
External PID control 1	J527	J529	J530	J531

External PID control 1 (Feedback error detection mode) (J527)

J527 specifies the error processing to be performed if a feedback error occurs.

- Data setting range: 0 to 2

Data for J527	Error processing
0	Disable: Turn ON the following output signal and continue to run. EPV1-OFF for external PID control 1
1	Enable: Coast to a stop (PVA trip)
2	Enable: Decelerate to a stop and cause a PVA trip.

Feedback errors can be monitored from the external equipment by assigning the digital output signal *EPV1-OFF*, to any of the output terminals [Y1] to [Y3], [Y5A/C], and [30A/B/C] with any of E20 through E22, E24 and E27.

- External PID control 1: *EPV1-OFF* (E20 to E22, E24 and E27, data = 215)

External PID control 1 (Feedback error lower-limit) (J529)

J529 specifies the upper limit for feedback errors in a physical quantity.

- Data setting range: -999.00 to 0.00 to 999.00, Auto = 105%

The physical quantity is dependent on the display unit and maximum/minimum scale specified by the following function codes.

	Display unit	Maximum scale	Minimum scale
External PID control 1	J505	J506	J507

External PID control 1 (Feedback error lower-limit) (J530)

J530 specifies the lower limit for feedback errors in a physical quantity. The physical quantity is dependent on the display unit and maximum/minimum scale specified by the function codes listed above.

- Data setting range: -999.00 to 0.00 to 999.00, 999: -5%

External PID control 1 (Feedback error detection time) (J531)

J531 specifies the feedback error detection time for the upper-limit (J529) and lower-limit (J530). If the detection time has elapsed after a feedback error occurred, the inverter regards it as an error.

- Data setting range: 0 to 300.0 (s)

J540

External PID Control 1

(Manual command)

External PID control 1 (Manual command) (J540)

J540 specifies the source that specifies a manual command to apply when external PID command is canceled.

Data for J540	Manual command sources
0	Keypad
_	Specify the external PID command by using the \circlearrowright / \circlearrowright keys on the keypad.
0	Keypad (Balanceless-bumpless)
0	Specify the external PID command by using the \oslash / \oslash keys on the keypad.
	External PID command 1 (Analog input: Terminals [12], [C1](C1 function) and [C1](V2 function)
51	Function codes E61 to E63 (terminal [12], C1, [C1](V2) Extended function selection): Data = 43
	Voltage input to terminal [12] (0 to \pm 10 VDC, 100% PID command/ \pm 10 VDC)
	Current input to terminal [C1](C1 function) (4 to 20 mA DC, 100% PID command/ 20 mA DC)
	(0 to 20 mA DC, 100% PID command/ 20 mA DC)
	Voltage input to the terminal [C1](V2 function) (0 to \pm 10 VDC, 100% PID command/ \pm 10 VDC)

To cancel external PID controls, assign digital input signals **%/EPID1** to digital input terminals with E01 to E05 (data = 202) beforehand.

J551 J552	External PID Multistep Command	(Multistep command 1) (Multistep command 2)
J553		(Multistep command 3)

J551, J552 and J553 define an external PID control command as a preset value (3 steps).

External PID multistep command (Multistep command 1 to 3) (J551, J552, J553)

J551/J552/J553 specifies a multistep command in a physical quantity.

- Data setting range: -999.00 to 0.00 to 9990.00
- External PID command

EPID-SS2	EPID-SS1	Command
OFF	OFF	Command by J502
OFF	ON	J551 (Multistep 1)
ON	OFF	J552 (Multistep 2)
ON	ON	J553 (Multistep 3)

The physical quantity is dependent on the display unit and maximum/minimum scale specified by the following function codes.

	Display unit	Maximum scale	Minimum scale	
External PID control 1	J505	J506	J507	

Note: Factory default value is set at J505, J605, J655=0 (according to the PID control 1 feedback value unit/scale).

5.3.8 d codes (Applied functions 2)

[1] Speed control (Vector control without speed sensor nor pole position sensor for PMSM)

d01/A43	Speed control 1, and 2	(Speed command filter)	
d02/A44		(Speed detection filter)	
d03/A45		P (Gain)	
d04/A46		I (Integral time)	
		Related function code:	d25:ASR switching

These function codes are used to set up the speed control for vector control without speed sensor nor pole position sensor for PMSM.

Block diagram of the speed control algorithm



■ Speed command filter (d01/A43)

d01 specifies the time constant determining the first order delay of the speed command filter.

• Data setting range: 0.000 to 5.000 (s)

Modify this data when an excessive overshoot occurs against the change of the reference speed.

Increasing the filter time constant stabilizes the reference speed and reduces overshoot against the change of the reference speed, but it slows the response speed of the inverter.

■ Speed detection filter (d02/A44)

d02 specifies the time constant determining the first order delay of the speed detection filter.

• Data setting range: 0.000 to 0.100 (s)

Modify this data when the control target (machinery) is oscillatory due to deflection of a drive belt or other causes so that ripples (oscillatory components) are superimposed on the detected speed, causing hunting (undesirable oscillation of the system) and blocking the PI processor gain from increasing (resulting in a slow response speed of the inverter).

Increasing the time constant stabilizes the detected speed and allows to raise the PI processor gain even with ripples superimposed on the detected speed. However, speed detection itself is delayed, resulting in a slower speed response, larger overshoot, or hunting.

P(Gain) (d03/A45), I(integral time) (d04/A46)

d03 and d04 specify the gain and integral time of the speed regulator (PI processor), respectively.

- Data setting range: (d03) 0.1 to 200.0 (times)
 - (d04) 0.001 to 9.999 (s), 999 (Cancel integral term)

<u>P(Gain)</u>

Definition of "P gain = 1.0" is that the torque command is 100% (100% torque output of each inverter capacity) when the speed deviation (reference speed – detected speed) is 100% (equivalent to the maximum speed).

Determine the P gain according to moment of inertia of machinery loaded to the motor output shaft. Larger moment of inertia needs larger P gain to keep the flat response during whole operation.

Specifying a larger P gain improves the quickness of control response, but may cause a motor speed overshooting or hunting (undesirable oscillation of the system). Moreover, mechanical resonance or vibration sound on the machine or motor could occur due to excessively amplified noise. If it happens, decreasing P gain will reduce the amplitude of the resonance/vibration. A too small P gain results in a slow inverter response and a speed fluctuation in low frequency, which may prolong the time required for stabilizing the motor speed.

I(Integral time)

Specifying a shorter integral time shortens the time needed to compensate the speed deviation, resulting in quick response in speed. Specify a short integral time if quick arrival to the target speed is necessary and a slight overshooting in the control is allowed; specify a long time if any overshooting is not allowed and taking longer time is allowed.

If a mechanical resonance occurs and the sound from the motor or gears is abnormal, setting a longer integral time can transfer the resonance point to the low frequency zone and suppress the resonance in the high frequency zone.

■ Select speed control parameter 1 – "MPRM1" (E01 toE05 data = 78)

The combination of the ON/OFF states of digital input signals "MPRM1" selects one between 4 different speed control parameter sets.

■ ASR switching time (d25)

Speed control parameters switching by "MPRM1" and "MPRM2" signals is possible even during motor drive operation. For example, speed control P (Gain) and I (Integral time) listed can be switched. Switching these parameters during operation may cause an abrupt change of torque and result in a mechanical shock, depending on the driving condition of the load. To reduce such a mechanical shock, the inverter decreases the abrupt torque change using the ramp function of ASR switching time (d25).

• Data setting range: 0.000 to 1.000 (s)

(Refer to d01)

d21, d22 d23

Speed deviation excess detected (Hysteresis width, detection timer) Speed deviation excess detected processing

These function codes specify the detection levels of the speed deviation excess detected signal "PG-ERR".

Speed deviation excess detected signal "PG-ERR" (E20 to E22, E24, and E27, data = 76)

- Hysteresis width (d21), Detection timer (d22) and PG error processing (d23))

• Data setting range: (d21) 0.0 to 50.0 (%), in (%) of the maximum speed (d22) 0.00 to 10.00 (s)

(d23) 0 to 2

If the speed regulator's deviation (between the reference speed and estimated one) is out of the specified range (d21) for the period specified by d22, the inverter judges it as a PG error.

d23 defines the detection condition (and exception), processing after error detection, and hysteresis width as listed below.

d23	Function	Detection condition (and exception)	Processing after error detection	Hysteresis width for error detection
0	Continue to run 1	When the inverter cannot follow the reference speed (even after soft-starting) due to a heavy overload or similar, so that the detected speed is less than the reference speed, the inverter does not interpret this situation as a Speed deviation excess detected.	The inverter outputs the Speed deviation excess detected signal " PG-ERR " and continues to run.	Hysteresis width = d21, which is constant, even if the speed command is above the base frequency
1	Stop running with alarm 1		The inverter initiates a motor coast to stop, with the $\mathcal{E} - \mathcal{E}$ alarm. It also outputs the Speed deviation excess detected	(FU4).
2	Stop running with alarm 2	No exception.	signal " PG-ERR ".	

Enabling an operation limiting function such as the torque limit will increase the deviation caused by a Note huge gap between the reference speed and detected one. In this case, the inverter may trip interpreting this situation as a PG error, depending on the running state. To avoid this incident, set the d23 data to "0" (Continue to run) to prevent the inverter from tripping even if any of those limiting functions is activated.

d25

ASR switching time

Refer to the description of d01.

d32, d33

Speed limits / Over speed level 1 and 2

Under speed control, the over speed detection levels are specified with 120% of these function codes.

- Forward overspeed level = Maximum frequency 1 (F03) × Speed limit 1 (d32) × 120 (%)
- Reverse overspeed level = Maximum frequency 1 (F03) × Speed limit 2 (d33) × 120 (%)
- Data setting range: (d32,d33) 0 to 110 (%)

d35	Over speed detection level
u35	Over speed detection lever

Setting d35 data to "999(factory default)" causes the inverter to issue an over speed alarm if either of the above conditions are satisfied.

or

Motor speed = 200 Hz (120Hz at [ND] mode) × (d32 or d33) × 120(%)

d35 specifies the over speed detection level by percentage of the maximum frequency (F03/A01).

• Over speed level = Maximum frequency 1 (F03/A01) × d35

d51 d55, d69,	Reserved for particular manufacturers
d79, d91 to d92, d99	

These function codes are reserved for particular manufacturers. Unless otherwise specified, do not access these function codes.

d61 to d63	Command (Pulse train input) (Filter time constant, Pulse scaling factor 1 and Pulse scaling factor 2) (Refer to F01.)

Refer to the description of the function code F01 for details on the pulse rate input.

d67

PMSM starting mode (Auto search)

Refer to the description of the function code H09 for details on the PMSM starting mode.

5.3.9 U codes (Customizable logic operation)

The customizable logic function allows the user to form a logic or operation circuit for digital/analog input/output signals, customize those signals arbitrarily, and configure a simple relay sequence inside the inverter. In the customizable logic, one step (component), depending on the type, is composed of:

- (1) Digital 2 inputs, digital 1 output + logical operation (including timer)
- (2) Analog 2 inputs, analog 1 output/digital 1 output + numerical operation
- (3) Analog 1 input, digital 1 input, analog 1 output + numerical operation, logical operation

and a total of 200 steps can be used to configure a sequence.

Modes

Item		Modes	
Terminal command	Digital 2 inputs	Analog 2 inputs	Analog 1 input Digital 1 input
Operation block	Logical operation, counter, etc.: 13 types Timer: 5 types	Numerical operation, comparator, limiter, etc.: 25 types	Selector, hold, etc.: 12 types
Output signal	Digital 1 output	Analog 1 output/ Digital 1 output	Analog 1 output
Number of steps	200 steps		
Customizable logic output signal	10 outputs		
Customizable logic processing time	2 ms (max. 10 steps), 5 ms (max. 50 steps), 10 ms (max. 100 steps), 20ms (max. 200 steps) Can be selected with a function code.		
Customizable logic cancellation command "CLC"	Allows to stop all the customizable logic operations by assigning "CLC" to a general-purpose input terminal and turning it ON. It is used when you want to deactivate the customizable logic temporarily.		
Customizable logic timer cancellation command "CLTC"	Resets the timer, counter and all the previous values used in customizable logic by assigning "CLTC" to a general-purpose input terminal and turning it ON. It is used when a customizable logic is changed or if you want to synchronize it with external sequence.		

Note If you use the customizable logic cancellation command and customizable logic timer cancellation command, the inverter can unintentionally start because the speed command is unmasked, depending on the structure of the customizable logic. Be sure to turn OFF the operation command to turn it ON.

A physical injury may result.

A damage may result.



Mode selection function codes for enabling customizable logic can be modified during operation but the customizable logic output may become temporarily unstable due to the setting modification. Therefore, since unexpected operation can be performed, change the settings if possible when the inverter is stopped.

A physical injury may result.

A damage may result.

U00	Customizable logic (Mode selection)
U01 to U70	Customizable logic: Step 1 to 14 (Mode setting)
U71 to U80	Customizable logic: Output signal 1 to 10 (Output selection)
U81 to U90	Customizable logic: Output signal 1 to 10 (Function selection)
U91	Customizable logic: Timer monitor (Step selection)
U92 to U97	Customizable logic: The coefficients of the approximate formula
U100	Customizable logic: Task process cycle setting
U101 to U106	Customizable logic: Operating point 1 to 3
U107	Customizable logic: Auto calculation of the coefficients of the approximate formula
U121 to U140	Customizable logic: User parameter 1 to 20
U171 to U175	Customizable logic: Storage area 1 to 5
U190 to U195	Customizable logic: Step 15 to 200 setting

■ Customizable Logic (Mode selection) (U00)

U00 specifies whether to enable the sequence configured with the customizable logic function or disable it to run the inverter only via its input terminals or others.

U00 data	Function
0	Disable
1	Enable (Customizable logic operation)

The EEL alarm occurs when changing U00 from 1 to 0 during operation.

■ Customizable Logic (Mode Setting) (U01 to U70, U190 to U195)

In the customizable logic, the steps are categorized in the following three types:

[Input: digital] Block selection (U01, U06, U11, etc.) = 1 to 1999



[Input: analog] Block selection (U01, U06, U11, etc.) = 2001 to 3999

Input 1 (analog) O Operation Input 2 (analog) O Output (analog/digital)

[Input: digital, analog] Block selection (U01, U06, U11, etc.) = 4001 to 5999



The function code settings for each step are as follows:

• Step 1 to 14

Step No.	Block selection	Input 1	Input 2	Function 1	Function 2	Output Note)
Step 1	U01	U02	U03	U04	U05	"SO01"
	= 1 to 1999	Digital input 1	Digital input 2	Time setting	Not required	Digital output
	= 2001 to 3999	Analog input 1	Analog input 2	Value 1	Value 2	Analog/digital output
	= 4001 to 6999	Analog input 1	Digital input 2	Value 1	Value 2	Analog output
Step 2	U06	U07	U08	U09	U10	"SO02"
Step 3	U11	U12	U13	U14	U15	"SO03"
Step 4	U16	U17	U18	U19	U20	"SO04"
Step 5	U21	U22	U23	U24	U25	"SO05"
Step 6	U26	U27	U28	U29	U30	"SO06"
Step 7	U31	U32	U33	U34	U35	"SO07"
Step 8	U36	U37	U38	U39	U40	"SO08"
Step 9	U41	U42	U43	U44	U45	"SO09"
Step 10	U46	U47	U48	U49	U50	"SO10"
Step 11	U51	U52	U53	U54	U55`	"SO11"
Step 12	U56	U57	U58	U59	U60	"SO12"
Step 13	U61	U62	U63	U64	U65	"SO13"
Step 14	U66	U67	U68	U69	U70	"SO14"

Note) Output is not a function code. It indicates the output signal symbol.

• Step 15 to 200

Specify a step number in U190, and set the block selection, input 1, input 2, function 1, function 2 in U191 to U195 respectively.

Step No.	U190	Block selection	Input 1	Input 2	Function 1	Function 2	Output
Step 15	15						"SO15"
Step 16	16						"SO16"
		U191	U192	U193	U194	U195	
Step 199	199						"SO199"
Step 200	200						"SO200"

[Input: digital] Block function code setting

Block selection (U01 etc.) (Digital)

Any of the following items can be selected as a logic function block (with general-purpose timer): The data can be logically inverted by adding 1000.

Data	Logic function block	Description
0	No function assigned	Output is always OFF.
10	Through output + General-purpose timer (No timer)	Only a general-purpose timer. No logic function block exists.
11	(On-delay timer)	Turning the input signal ON starts the on-delay timer. When the period specified by the timer has elapsed, the output signal turns ON. Turning the input signal OFF turns the output signal OFF.
12	(Off-delay timer)	Turning the input signal ON turns the output signal ON.
		Turning the input signal OFF starts the off-delay timer. When the period specified by the timer has elapsed, the output signal turns OFF.
13	(One-shot pulse output)	Turning the input signal ON issues a one-shot pulse whose length is specified by the timer.
14	(Retriggerable timer)	Turning the input signal ON issues a one-shot pulse whose length is specified by the timer.
		If the input signal is turned ON again during the preceding one-shot pulse length, however, the logic function block issues another one-shot pulse.
15	(Pulse train output)	If the input signal turns ON, the logic function block issues ON and OFF pulses (whose lengths are specified by the timer) alternately and repeatedly. This function is used to flash a luminescent device.
20 to 25	Logical AND + General-purpose timer	AND function with 2 inputs and 1 output, plus general-purpose timer.
30 to 35	Logical OR + General-purpose timer	OR function with 2 inputs and 1 output, plus general-purpose timer.
40 to 45	Logical XOR + General-purpose timer	XOR function with 2 inputs and 1 output, plus general-purpose timer.
50 to 55	Set priority flip-flop + General-purpose timer	Set priority flip-flop with 2 inputs and 1 output, plus general-purpose timer.
60 to 65	Reset priority flip-flop + General-purpose timer	Reset priority flip-flop with 2 inputs and 1 output, plus general-purpose timer.
70, 72, 73	Rising edge detector + General-purpose timer	Rising edge detector with 1 input and 1 output, plus general-purpose timer.
		This detects the rising edge of an input signal and outputs the ON signal for 5 ms (*1).
80, 82, 83	Falling edge detector + General-purpose timer	Falling edge detector with 1 input and 1 output, plus general-purpose timer.
		This detects the falling edge of an input signal and outputs the ON signal for 5 ms (*1).
90, 92, 93	Rising & falling edges detector +	Rising and falling edge detector with 1 input and 1 output, plus general-purpose timer.
	General-purpose timer	This detects both the falling and rising edges of an input signal and outputs the ON signal for 5 ms (*1).

*1: Equals the task cycle: 2 ms for a task cycle of 2 ms, 5 ms for 5 ms, 10 ms for 10 ms, and 20 ms for 20 ms.

Data	Logic function block	Description
100 to 105	Hold + General-purpose timer	Hold function of previous values of 2 inputs and 1 output, plus general-purpose timer.
		If the hold control signal is OFF, the logic function block outputs input signals; if it is ON, the logic function block retains the previous values of input signals.
110	Increment counter	Increment counter with reset input.
		By the rising edge of the input signal, the logic function block increments the counter value by one. When the counter value reaches the target one, the output signal turns ON.
		Turning the reset signal ON resets the counter to zero.
120	Decrement counter	Decrement counter with reset input.
		By the rising edge of the input signal, the logic function block decrements the counter value by one. When the counter value reaches zero, the output signal turns ON.
		Turning the reset signal ON resets the counter to the initial value.
130	Timer with reset input	Timer output with reset input.
		If the input signal turns ON, the output signal turns ON and the timer starts. When the period specified by the timer has elapsed, the output signal turns OFF, regardless of the input signal state.
		Turning the reset signal ON resets the current timer value to zero and turns the output OFF.

The data can be logically inverted by adding 1000.

The block diagrams for individual functions are given below.

(Data=1□) Through output



(Data=2□) Logical AND



(Data=3□) Logical OR



(Data=4□) Logical XOR



(Data=6□) Reset priority flip-flop



General-purpose timer Input 1 S Q Input 2 Input 2

(Data=5□) Set priority flip-flop

Input 1	Input 2	Previous output	Output	Remarks
OFF	OFF	OFF	OFF	Hold previous value
011		ON	ON	
	ON	-	OFF	
ON	-	_	ON	Set priority

Input 1	Input 2	Previous output	Output	Remarks
OFF	OFF	OFF	OFF	Hold previous value
		ON	ON	
_	ON	_	OFF	Reset priority
ON	OFF	-	ON	

(Data=7□) Rising edge detector



(Data=8□) Falling edge detector



(Data=9□) Rising & falling edges detector



(Data=10□) Hold





(Data=110) Increment counter



(Data=120) Decrement counter



(Data=130) Timer with reset input



Input 1	OFF ON	OFF	ON	OFF	ON	OFF
Input 2			OFF			ON OFF
Output	OFF ON	N OFF	ON	OFF	ON	OFF
		\land	\square			1
					/	

Timer

I I

Time setting

 \rightarrow

4

Operation of general-purpose timer(Digital)

The operation schemes for individual timers are shown below.







(End 5) Pulse train output





■ Inputs 1 and 2 (U02, U03, etc.)(Digital)

The following digital	signals are	available as	input signals.	Value in () is in	negative logic.
					,	

Data	Selectable Signals
0000 (1000) to 0099 (1099) 0160 (1160) to 0215 (1215)	General-purpose output signals Same as the ones specified by E20, e.g., "RUN" (Inverter running), FAR (Frequency (speed) arrival signal), "FDT" (Frequency (speed) detected), "LU" (Undervoltage detected (Inverter stopped)), "B/D" (Torque polarity detected) Note: 27 (Universal DO) is not available. Note: Customizable logic output signals from 111 (1111) to 120 (1120) cannot be selected.
2001 (3001)	Output of step 1 "SO01"
to	to
2200 (3200)	Output of step 200 "SO200"
4001 (5001)	Terminal X1 input signal "X1"
4002 (5002)	Terminal X2 input signal "X2"
4003 (5003)	Terminal X3 input signal "X3"
4004 (5004)	Terminal X4 input signal "X4"
4005 (5005)	Terminal X5 input signal "X5"
4010 (5010)	Terminal FWD input signal FWD
4011 (5011)	Terminal REV input signal REV
6000 (7000)	Final RUN command "FL_RUN" (ON when a run command is given)
6001 (7001)	Final FWD run command "FL_FWD" (ON when a run forward command is given)
6002 (7002)	Final REV run command "FL_REV" (ON when a run reverse command is given)
6003 (7003)	During acceleration "DACC" (ON during acceleration)
6004 (7004)	During deceleration "DDEC" (ON during deceleration)
6005 (7005)	Under anti-regenerative control "REGA" (ON under anti-regenerative control)
6007 (7007)	Alarm factor presence "ALM_ACT" (ON when there is no alarm factor)

■ Function 1 (U04 etc.)(Digital)

U05 and other related function codes specify the general-purpose timer period or the increment/decrement counter value.

Data	Function	Description
	Timer	The period is specified in seconds.
0.00 to +600	Counter value	The specified value is multiplied by 100 times. (If 0.01 is specified, it is converted to 1.)
-9990 to -0.01	—	The timer or counter value works as 0.00. (No timer)
+601 to +9990	Timer	The period is specified in seconds.

[Input: analog] Block function code setting

■ Block selection, function 1, function 2 (U01, U04, U05, etc.)(Analog)

The following items are available as operation function block.

Note that if the upper and lower limits have the same value, there are no upper and lower limits.

Block selection (U01 etc.)	Function block	Description	Function 1 (U04 etc.)	Function 2 (U05 etc.)
0	No function assigned	This function always outputs 0% (or logical "0: False"; OFF).	Not required	Not required
2001	Adder	Addition function with two inputs (input 1 and input 2).	Upper limit	Lower limit
		This function has output limiters (upper/lower) specified with two function codes.		
		The 1st function code provides upper limit value and the 2nd one provides lower limit value.		
2002	Subtracter	Subtraction function with two inputs (input 1 and input 2).	Upper limit	Lower limit
		This function has output limiters (upper/lower) specified with two function codes.		
		The 1st function code provides upper limit value and the 2nd one provides lower limit value.		
2003	Multiplier	Multiplication function with two inputs (input 1 and input 2).	Upper limit	Lower limit
		This function has output limiters (upper/lower) specified with two function codes.		
		The 1st function code provides upper limit value and the 2nd one provides lower limit value.		
2004	Divider	Division function with two inputs (input 1 and input 2). Input 1 is dividend and input 2 is divisor. This function has output limiters (upper/lower) specified with two function	Upper limit	Lower limit
		codes.		
		The 1st function code provides upper limit value and the 2nd one provides lower limit value.		
2005	Limiter	Upper and lower limit functions of single input (input 1).	Upper limit	Lower limit
		The 1st function code provides upper limit value and the 2nd one provides lower limit value.		
2006	Absolute value	Absolute value function of single input (input 1).	Upper limit	Lower limit
	of input	Negative input numbers become positive.		
		This function has output limiters (upper/lower) specified with two function codes.		
		The 1st function code provides upper limit value and the 2nd one provides lower limit value.		

Block selection (U01 etc.)	Function block	Description	Function 1 (U04 etc.)	Function 2 (U05 etc.)
2007	Inverting adder	Inverting addition function with single input (input 1). This function subtracts the input 1 to the value specified with the 1st function code, inverts the result. And furthermore, the function adds the result to the value specified with the 2nd function code and outputs the result.	Subtraction value (former)	Addition value (latter)
2008	Variable limiter	Variable limit function of single input (input 1). Input 1 provides upper limit value and input 2 provides lower limit value.	Step number	Not required
2009	Linear function	Linear function of single input (input 1). This function receives single input (input 1), calculates pre-defined first-order polynomial, and outputs the result. The 1st and 2nd function codes provide the coefficients of the polynomial. The polynomial is represented by the following formula. $y = K_A \times \chi + K_B$ The output is limited within the range between -9990 and 9990 by the internal limiter.	Factor KA -9990.0 to +9990.0	Factor KB -9990.0 to +9990.0
2051	Comparator 1	Comparison function with hysteresis. This function compares the differential value between input 1 and input 2 with the threshold value specified with the 1st function code. The 2nd function code provides hysteresis width. If the differential value is (threshold value + hysteresis width) or bigger, this function outputs logical "1: True". On the other hand, if the differential value is (threshold value - hysteresis width) or smaller, this function outputs logical "0: False".	Threshold value	Hysteresis width
2052	Comparator 2	Comparison function with hysteresis. This function compares the differential value between input 1 and input 2 with the threshold value specified with the 1st function code. The 2nd function code provides hysteresis width. If the differential value is bigger than (threshold value + hysteresis width), this function outputs logical "1: True". On the other hand If the value is smaller than (threshold value - hysteresis width), the function outputs logical "0: False".	Threshold value	Hysteresis width
2053	Comparator 3	Comparison function with hysteresis. This function compares the absolute differential value between input 1 and input 2 with the threshold value specified with the 1st function code. The 2nd function code provides hysteresis width. This function works like as comparator 1	Threshold value	Hysteresis width
2054	Comparator 4	Comparison function with hysteresis. This function compares the absolute differential value between input 1 and input 2 with the threshold value specified with the 1st function code. The 2nd function code provides hysteresis width. This function works like as comparator 2	Threshold value	Hysteresis width

Block selection (U01 etc.)	Function block	Description	Function 1 (U04 etc.)	Function 2 (U05 etc.)
2055	Comparator 5	Comparison function with hysteresis. Input 1 is the input value of this function and input 2 is not used. The 1st function code provides threshold value and the 2nd one provides hysteresis width. If input 1 is (threshold value) or bigger, this function outputs logical "1: True". On the other hand If input 1 is smaller than (threshold value - hysteresis width), this function outputs logical "0: False".	Threshold value	Hysteresis width
2056	Comparator 6	Comparison function with hysteresis. Input 1 is the input value of this function and input 2 is not used. The 1st function code provides threshold value and the 2nd one provides hysteresis width. If input 1 is (threshold value) or smaller, this function outputs logical "1: True". On the other hand If input 1 is bigger than (threshold value + hysteresis width), this function outputs logical "0: False".	Threshold value	Hysteresis width
2071	Window comparator 1	Comparison function with limits. Whether the value of the input is within a preselected range specified with two function codes determines the status of the output. Input 1 is the input value of this function and input 2 is not used. The 1st function code provides upper threshold value and the 2nd one provides lower threshold value. If input 1 is within the range (defined with two function codes), this function outputs logical "1: True". On the other hand If input 1 is outside of this range, this function outputs logical "0: False".	Upper threshold	Lower threshold
2072	Window comparator 2	Comparison function with limit. This function has the inverting logic of "Window comparator 1".	Upper threshold	Lower threshold
2101	High selector	High selector function. This function receives two inputs (input 1 and input 2), selects the higher one automatically, and outputs it. This function has output limiters (upper/lower) specified with two function codes. The 1st function code provides the upper limit value and the 2nd one provides the lower one.	Upper limit	Lower limit
2102	Low selector	Low selector function. This function receives two inputs (input 1 and input 2), selects the lower one automatically, and outputs it. This function has output limiters (upper/lower) specified with two function codes. The 1st function code provides the upper limit value and the 2nd one provides the lower one.	Upper limit	Lower limit
2103	Average of inputs	Average function. This function receives two inputs (input 1 and input 2), averages them, and outputs the result. This function has output limiters (upper/lower) specified with two function codes. The 1st function code provides the upper limit value and the 2nd one provides the lower one.	Upper limit	Lower limit

	l.			1
Block selection (U01 etc.)	Function block	Description	Function 1 (U04 etc.)	Function 2 (U05 etc.)
2151	Loading function from S13	Loading function from the function code S13 with scale conversion function. This function loads the setting value of the function code S13, maps the pre-selected range which is specified with two function codes, and outputs the result. The 1st function code provides the maximum scale value of the range and the 2nd one provides the minimum scale value of the range. The function code S13 is the PID process command value via communications in (%).	Maximum scale	Minimum scale
2201	Clip and map function	 This function receives single input (input 1), clips a pre-selected range which is specified with two function codes from it, maps 0.00 to 100.00%, and outputs the result. The 1st function code provides the upper limit value of the range and the 2nd one provides the lower limit value of the range. This function can be connected to analog outputs (8000 to 8021) only, and only two of these functions can be used. 	Upper limit	Lower limit
2202	Scale converter	Scale conversion function with single input (input 1). This function receives single input (input 1), maps an pre-selected range which is specified with two function codes, and outputs the result. The 1st function code provides the maximum scale value of the range and the 2nd one provides the minimum scale value of the range. This function can be connected to analog outputs (8000 to 8021) only, and only two of these functions can be used.	Maximum scale	Minimum scale
3001	Quadratic function	Quadratic function with limit. This function receives single input (input 1), calculates pre-defined second-order polynomial represented by the following formula, limits the value, and outputs the result.] $K_A \times (lnput1)^2 + K_B \times input1 + K_C$ The 1st function code provides the upper limit value and the 2nd one provides the lower limit value. The coefficients of the polynomial are given by the function codes U92 to U97. Either (3001) or (3002) is available to use, and only one of these functions can be used.	Upper limit	Lower limit
3002	Square root function	Square root function with limit. This function receives single input (input 1), calculates pre-defined square root function represented by the following formula, limits the value, and outputs the result. $\sqrt{\frac{\text{Input1+K}_{A}}{K_{B}}} \times K_{C}$ The 1st function code provides the upper limit value and the 2nd one provides the lower limit value. The coefficients of the polynomial are given by the function codes U92 to U97. Either (3001) or (3002) is available to use, and only one of these functions can be used.	Upper limit	Lower limit

The block diagrams for each operation function block are given below. The setting value for functions 1 and 2 is indicated with U04 and U05.

(2001) Adder







(2004) Divider



(2007) Inverting adder





(2005) Limiter



(2008) Variable limiter



(2006) Absolute value of inputs



(2009) Linear function



(2051) Comparator 1



(2052) Comparator 2



ON is prioritized when both conditions are satisfied.

(2053) Comparator 3



ON is prioritized when both conditions are satisfied.

(2054) Comparator 4



(2055) Comparator 5



(2056) Comparator 6



(2101) High selector



(2071) Window comparator 1



(2102) Low selector



(2072) Window comparator 2



(2103) Average of inputs



(2151) Loading function from S13



(2201) Clip and map function



- * Use to connect to analog output terminals.
- * The maximum number of steps used is 2.

U04

U05

×K

✓ Output

(3002) Square root function

|Input1+K_A

 K_B

(3001) Quadratic function



* The maximum number of steps used is 1 for either (3001) or (3002).

Input 1

Input 2

(2202) Scale converter



- For input 1 signal selection, only settings 8000 to 8085 can be used.
- * The maximum number of steps used is 2.

■ Inputs 1 and 2 (U02, U03, etc.)(Analog)

The following signals are available as analog input signals.

Data	Selectable Signals
8000 to 8065	General-purpose analog output signal (same as signals selected in F31 and F35: output frequency 1, output current, output torque, Input power, DC link bus voltage, etc.) Example: For output frequency 1, maximum frequency (100%) is input as 100.00. Example: For output current, 200% of the inverter rated current is input 100.00. Note: 10 (Universal AO) is not available.
2001 to 2200	Output of step 1 to 200 "SO01" to "SO200"
9001	Analog 12 terminal input signal [12]
9002	Analog C1 terminal input signal [C1] (C1 function)
9003	Analog C1 terminal input signal [C1] (V2 function)
9004	Analog 32 terminal input signal [32] (on option card, OPC-AIO)
9005	Analog C2 terminal input signal [C2] (on option card, OPC-AIO)
9006	temperature detect channel 1 [PT1]
9007	temperature detect channel 2 [PT2]

■ Function 1, Function 2 (U04, U05, etc.)(Analog)

Sets the upper limit and lower limit of operation function block.

Data	Function	Description
-9990 to 0.00 to +9990	Reference value Hysteresis width Upper limit Lower limit Upper threshold Lower threshold Setting value Maximum scale Minimum scale	Setting values for the operation of the function block (selected with the corresponding function code such as U01).

■ The coefficients of the conversion functions (U92 to U97) (Analog)

Sets the factor of conversions function (3001, 3002) of operation function block.

Function code	Name	Data setting range	Factory default
U92	Mantissa of K _A	Mantissa: -9.999 to 9.999	0.000
U93	Exponent part of K _A	Exponent part: -5 to 5	0
U94	Mantissa of K_B		0.000
U95	Exponent part of K_B		0
U96	Mantissa of K_c		0.000
U97	Exponent part of K _c		0

U92 to U97 can automatically be calculated based on measured data. For details, refer to the descriptions of U101 to U107 (page 5-257).

[Input: digital, analog] Block function code setting

Lock selection, function 1, function 2 (U01, U04, U05, etc.) (digital,analog)

The following items are available as function block.

Note that if the upper and lower limits are identical, there are no upper and lower limits.

Block selection (U01 etc.)	Function block	Description	Function 1 (U04 etc.)	Function 2 (U05 etc.)
4001	Hold	Function to hold analog input 1 based on digital input 1.	Upper limit	Lower limit
4002	Inverting adder with enable	Function to reverse analog input 1 based on digital input 1.	Subtracted value (former)	Addition value (latter)
4003	Selector 1	Function to select analog input 1 and setting value based on digital input 1.	Setting value	Not required
4004	Selector 2	Function to select setting value 1/2 based on digital input 1.	Setting value 1	Setting value 2
4005	LPF (Low pass filter) with enable	Value of an analog input 1 is filtered through LPF (time constant U04) when the digital input 1 is "1". When the digital input 1 is "0", the analog input 1 is directly output. (LPF maintains the previous output value. Therefore, when the digital 1 input changes from 0 to 1, the output will be the value with the previous output value added as the initial value of LPF.) (No upper/lower limiter)	Time constant 0: No filter 0.01 to 5.00s	Fixed as 0
4006	Rate limiter with enable	Value of an analog input is limited with change rate specified in functions 1 and 2 when the digital input 1 is "1". When the digital input 1 is "0", the analog 1 input is directly output. When setting the initial value, carry out an operation with the initial value for input 1 and 0 applied to input 2. Then, reflect the result as the initial value (= previous output value) with 1 applied to input 2. During the initialization or when the CLC terminal is ON, the previous output value is cleared to 0.	Upward change rate Time taken to change 100% 0: No limit 0.01 to 600 s	Downward change rate Time taken to change 100% 0: The same change rate as function 1 0.01 to 600 s
5000	Selector 3	Function to select analog input 2 based on "SO01" to "SO200".	Step No.	Not required
5100	Selector 4	Function to select analog input 1 and "SO01" to "SO200" based on digital input 1.	Step No.	Not required
6001	Reading function codes	Function to read the content of arbitrary function code. Use the 1st function code (such as U04) to specify a function code group, and the 2nd one (such as U05) to specify the last two digits of the function code number. For the function code settings, refer to "■ Configuration of function codes" in page 5-254. Both input 1 and input 2 are not used. Data formats that can be read correctly are as follows (the values are restricted between -9990 and 9990 and, for [29], 20000 is indicated as 100%): [1], [2], [3], [4], [5], [6], [7], [8], [9], [10], [12], [22], [24], [29], [35], [37], [45], [61], [67], [68], [74], [92] and [93] Data formats other than the above cannot be read correctly. Do not use any other format.	0 to 255	0 to 99

5.3 Description of Function Codes

Block selection (U01 etc.)	Function block	Description	Function 1 (U04 etc.)	Function 2 (U05 etc.)
6002	Writing function codes	This function writes the value of input 1 to a function code (U171 to U175) on the volatile memory (RAM) when the input 2 becomes "1: True". When the input 2 becomes "0: False", this function stops to write to the function code (U171 to U175) and maintains the previous value. The value of input 1 is stored to the non-volatile memory (EEPROM) when the inverter detects undervoltage. Because the access arbitration from some steps at a time is not possible, only one step is allowed to access to the same function code in the customizable logic. If the access to the target function code from different steps at a time is executed, the alarm is	39	71 to 75
6003	Temporary change of function code	This function reflects the value of the specified function code on the volatile memory (RAM) when the input 2 becomes "0: False". On the other hand when the input 2 does not become "0: False", this function reflects the value of input 1 in the place of the function code. Refer to "■ Specific function codes" for the applicable function code on page 5-253. The value on the volatile memory (RAM) is cleared when the inverter is powered off. And the value is read from the non-volatile memory and restored when the inverter is powered on. Set the function code group (function type code) to the1st function code (U04, etc.). Set the lower 2 digits of the function code No. to the 2nd function (U05, etc.). If the specified function code (U04, U05, etc.) is not applicable one, this function outputs zero value. Because the access arbitration from some steps at a time is not possible, only one step is allowed with to access to the same function code in the customizable logic. When the function code is temporarily changed using 6003 during the customize logic operation and if the PC loader is read or copy to the touch panel is performed, the temporary changed data, not the non-volatile memory data, may be copied. Stop the customize logic before these operations.	0 to 255	0 to 99

(4001) Hold





(4003) Selector 1



(4004) Selector 2



(4005) Low pass filter with enable



ble (4006) Rate limiter with enable



(5000) Selector 3



(5100) Selector 4



(6001) Reading function codes



(6002) Writing function codes



(6003) Temporary change of function code



Output signal (Digital,analog)

In the customizable logic, outputs from steps 1 to 10 are issued to SO01 to SO200, respectively.

SO01 to SO200 differ in configuration depending upon the connection destination, as listed below. To relay those outputs to any function other than the customizable logic, route them via customizable logic outputs CL01 to CL0010.

Connection destination of each step output	Configuration	Function code
Input of customizable logic	Select one of the internal step output signals "SO01" to "SO200" in customizable logic input setting.	Such as U02 and U03
Input of inverter sequence processor (such as multistep speed "SS1"	Select one of the internal step output signals "SO01" to "SO200" to be connected to customizable logic output signals 1 to 10 ("CL01" to "CLO10").	U71 to U80
or operation command "FWD")	Select an inverter's sequence processor input function to which one of the customizable logic output signals 1 to 10 ("CL01" to "CLO10") is to be connected. (Same as in E01)	U81 to U90
Analog input (such as auxiliary frequency commands or PID process	Select one of the internal step output signals "SO01" to "SO200" to be connected to customizable logic output signals 1 to 10 ("CL01" to "CLO10").	U71 to U80
commands)	Select an analog input function to which one of the customizable logic output signals 1 to 10 ("CL01" to "CL010") is to be connected. (Same as in E61)	U81 to U90
General-purpose digital output ([Y] terminals)	Select one of the internal step output signals "SO01" to "SO200" to be connected to customizable logic output signals 1 to 10 ("CL01" to "CLO10").	U71 to U80
	To specify a general-purpose digital output function (on [Y] terminals) to which one of the customizable logic output signals 1 to 10 ("CL01" to "CLO10") is to be connected, select one of "CLO1" to "CLO10" by specifying the general-purpose digital output function on any Y terminal.	E20 to E22, E24, E27
General-purpose analog output ([FM1] terminals)	Select one of the internal step output signals "SO01" to "SO200" to be connected to customizable logic output signals 1 to 10 ("CL01" to "CLO10").	U71 to U80
	To specify a general-purpose analog output function (on [FM1] terminals) to which one of the customizable logic output signals 1 to 10 ("CL01" to "CL010") is to be connected, select one of "CL01" to "CL010" by specifying the general-purpose digital output function on any [FM1] terminal.	F31, F35

Note General-purpose digital outputs (on [Y] terminals) are updated every 5 ms. To securely output a customizable logic signal via [Y] terminals, include on- or off-delay timers in the customizable logic. Otherwise, short ON or OFF signals may not be reflected on those terminals.

Function codes	Name	Data setting range	Factory default
U71	Customizable logic output signal 1 (Output selection)	0: Disable1: Output of step 1, "SO01"	0
U72	Customizable logic output signal 2 (Output selection)	2: Output of step 2, "SO02"	0
U73	Customizable logic output signal 3 (Output selection)	199: Output of step 199, "SO199"200: Output of step 200, "SO200"	0
U74	Customizable logic output signal 4 (Output selection)		0
U75	Customizable logic output signal 5 (Output selection)		0
U76	Customizable logic output signal 6 (Output selection)		0
U77	Customizable logic output signal 7 (Output selection)		0
U78	Customizable logic output signal 8 (Output selection)		0
U79	Customizable logic output signal 9 (Output selection)		0
U80	Customizable logic output signal 10 (Output selection)		0
U81	Customizable logic output signal 1 (Function selection)	If a step output is digital The same value as E98 can be specified.	100
U82	Customizable logic output signal 2 (Function selection)	0(1000):Select multistep frequency (0 to 1 steps) "SS1" 1(1001):Select multistep frequency (0 to 3 steps) "SS2"	100
U83	Customizable logic output signal 3 (Function selection)	2(1002):Select multistep frequency (0 to 7 steps) "SS4" 3(1003):Select multistep frequency (0 to 15 steps)	100
U84	Customizable logic output signal 4 (Function selection)	4(1004): Select ACC/DEC time (2 steps) "RT1"	100
U85	Customizable logic output signal 5 (Function selection)	S(1005). Select ACC/DEC time (4 steps)KT26(1006): Enable 3-wire operation"HLD"7(1007): Coast to a stop command"BX"	100
U86	Customizable logic output signal 6 (Function selection)	8(1008):Reset alarm"RST"9(1009):Enable external alarm trip"THR"	100
U87	Customizable logic output signal 7 (Function selection)	(9=Active OFF/1009=Active ON) and so on.	100
U88	Customizable logic output signal 8 (Function selection)	 If a step output is analog 8001: Auxiliary frequency command 1 8002: Auxiliary frequency command 2 	100
U89	Customizable logic output signal 9 (Function selection)	8002: Auxiliary nequency command 2 8003: PID process command 8005: PID feedback value	100
U90	Customizable logic output signal 10 (Function selection)	8006:Ratio setting8007:Analog torque limit value A8008:Analog torque limit value B8020:Analog monitor	100

Specific function codes

The following function codes can take values on memory by using the customizable logic "Function code switch (6003)". Overwritten values are cleared with power off.

Code	Name	Code	Name
F07	Acceleration time 1	H52	Non-linear V/f 2 (Frequency)
F08	Deceleration time 1	H53	Non-linear V/f 2 (Voltage)
F15	Frequency limiter (Upper)	H57	1st S-curve acceleration range (At starting)
F16	Frequency limiter (Lower)	H58	2nd S-curve acceleration range (At arrival)
F21	DC braking 1 (Braking level)	H59	1st S-curve deceleration range (At starting)
F22	DC braking 1 (Braking time)	H60	2nd S-curve deceleration range (At arrival)
F23	Starting frequency 1	H91	PID feedback wire break detection
F24	Starting frequency 1 (Holding time)	J03	PID control P (Gain)
F25	Stop frequency	J04	PID control I (Integral time)
F40	Torque limiter 1 (Driving)	J05	PID control D (Differential time)
F41	Torque limiter 1 (Braking)	J06	PID control (Feedback filter)
F44	Current limiter (Level)	J10	PID control (Anti-reset windup)
E10	Acceleration time 2	J12	PID control (Upper limit of warning (AH))
E11	Deceleration time 2	J13	PID control (Lower limit of warning (AL))
E12	Acceleration time 3	J15	PID control (Sleep frequency)
E13	Deceleration time 3	J16	PID control (Sleep timer)
E14	Acceleration time 4	J17	PID control (Wakeup frequency)
E15	Deceleration time 4	J18	PID control (Upper limit of PID process output)
C05	Multistep frequency 1	J19	PID control (Lower limit of PID process output)
C06	Multistep frequency 2	d01	Speed control 1 (Speed command filter)
C07	Multistep frequency 3	d02	Speed control 1 (Speed detection filter)
C08	Multistep frequency 4	d03	Speed control 1 (P (Gain))
C09	Multistep frequency 5	d04	Speed control 1(I (Integral time))
H50	Non-linear V/f 1 (Frequency)	d05	Speed control 1 (FF (Gain))
H51	Non-linear V/f 1 (Voltage)		

■ Function codes for the customizable logic

Function code number	Name	Range	Minimum unit	Remarks
U121 to U140	User parameter 1 to 20	-9990.00 to 9990.00 Effective number are 3 digits.	0.01 to 10	
U171 to U175	Storage area 1 to 5	-9990.00 to 9990.00 Effective number are 3 digits.	0.01 to 10	Memorize the data when powered off.

Configuration of function codes

Set a function code group (code from the following table) to function 1 (such as U04) and set the last two digits of the function code number to function 2 (such as U05) to specify individual function codes.

Group	Co	de	Name	Group	Code		Name
F	0	00 _H	Basic function	U1	39	27 _H	For customizable logic
E	1	01 _Н	Terminal function	У	14	0E _H	Link function
С	2	02 _H	Control function	К	28	1C _Н	Touch panel function
Р	3	03н	Motor1	М	8	08н	Monitor data
Н	4	04 _H	High performance function	о	6	06 _H	Option function
H1	31	1F _H	High performance function 1	d	19	13 _Н	Applied function 2
А	5	05н	Speed control 2	U	11	0B _H	Customizable logic
J	13	$0D_H$	Applied function 1	W	15	0F _H	Monitor 2
J1	48	30 _Н	Applied function 1	Х	16	10 _Н	Alarm 1
				Z	17	11 _Н	Alarm 2

■ Task process cycle setting (U100)

U100 data	Data
0	Automatically adjusts the task cycle from 2 ms to 10 ms depending on the number of used steps. This is the factory default. It is recommended to use this value.
2	2 ms: Up to 10 steps. If it exceeds 10 steps, the customizable logic does not work.
5	5 ms: Up to 50 steps. If it exceeds 50 steps, the customizable logic does not work.
10	10 ms: Up to 100 steps. If it exceeds 100 steps, the customizable logic does not work.
20	20 ms Up to 200 steps.

Note that if it exceeds the steps defined in 2, 5 or 10, the customizable logic does not work.

Operating precautions

The customizable logics are executed within 2 ms to 20 ms (according to U100) and processed in the following procedure:

- (1) First, latch the external input signals for all the customizable logics from step 1 to 200 to maintain synchronism.
- (2) Perform logical operations sequentially from step 1 to 200.
- (3) If an output of a step is an input to the next step, outputs of step with high priority can be used in the same process.
- (4) The customizable logic simultaneously updates 10 output signals.

4	2 to 20 ms o	cycle		
Input signal latch	Logical operation Step $1 \rightarrow 2 \rightarrow 3 \cdots 200$		Simultaneous update of output signals	Input signal latch

Note that if you do not consider the process order of customizable logic when configuring a function block, the expected output may not be obtained, the operation can be slower or a hazard signal can occur, because the output signal of a step is not available until the next cycle.

Changing a functional code related to the customizable logic (U code etc.) or turning ON the customizable logic cancel signal "CLC" causes change in operation sequence depending on the setting, which may suddenly start an operation or start an unexpected action. Fully ensure it is safe before performing the operation.

An accident or physical injury may occur.

■ Customizable logic timer monitor (Step selection) (U91, X89 to X93)

The monitor function codes can be used to monitor the I/O status or timer's operation state in the customized logics.

Table 5.3-18 Selection of monitor time	Table 5.3-18	Selection	of monitor	timer
--	--------------	-----------	------------	-------

Function code	Function	Remarks	
U91	0: Monitor not active (the monitor data is 0) 1 to 200: set the step No. to monitor	The setting value is cleared to 0 when powered off.	

Monitor method	Function code	Data
Communication	X89 customizable logic (digital I/O)	Digital I/O data for the step defined in U91 (only for monitoring)
	X90 customizable logic (timer monitor)	Data of the timer/counter value for the step defined in U91 (only for monitoring)
	X91 customizable logic (analog input 1)	Analog input 1 data for the step defined in U91 (only for monitoring)
	X92 customizable logic (analog input 2)	Analog input 2 data for the step defined in U91 (only for monitoring)
	X93 customizable logic (analog output)	Analog output data for the step defined in U91 (only for monitoring)

■ Cancel customizable logic "CLC" (function codes E01 to E05 Data = 80)

Customizable logic operations can temporarily be disabled so that the inverter can be operated without the customizable logic's logical circuit and timer operation, for example during maintenance.

"CLC"	Function	
OFF	Customizable logic enabled (according to U00 setting)	
ON	Customizable logic disabled	

Note

If you turn ON the customizable logic cancellation signal "CLC", a sequence by the customizable logic is cleared, which can suddenly start operation depending on the settings. Ensure the safety and check the operation before switching the signal.

■ Clear all customizable logic timers "CLTC" (function codes E01 to E05 Data = 81)

If the CLTC terminal function is assigned to a general-purpose input terminal and this input is turn ON, all the general-purpose timers and counters in the customizable logic are reset. It is used to reset and restart the system, when, for example, the timing of external sequence cannot be consistent with internal customizable logic due to a momentary power failure.

"CLTC"	Function	
OFF	Normal operation	
ON	Resets all the general-purpose timers and counters in the customizable logic. (To reactivate it, turn it OFF again.)	

5.3.10 U1 codes (Customizable logic operation)

U101 to U106

Customizable logic (Operating point 1 (X1, Y1), Operating point 2 (X2, Y2), Operating point 3 (X3, Y3))

By using function block 3001, quadratic function $K_A \cdot x^2 + K_B \cdot x + K_C$ is calculated relative to the input signal x as shown in the following diagram, allowing the output to be obtained. Here, K_A , K_B , and K_C are coefficients, and they can be set with function codes.



Coefficients KA, KB, KC

Coefficients K_A , K_B , K_C for quadratic function $K_A \cdot x^2 + K_B \cdot x + K_C$ can be set within the following ranges.

	Setting range
Coefficient KA	-9.999×10^5 to 9.999×10^5
Coefficient KB	-9.999×10^5 to 9.999×10^5
Coefficient KC	-9.999×10^5 to 9.999×10^5

These coefficients are set using function codes U92 to U97.

Function code	Name	Setting range
U92	Coefficient KA mantissa portion	-9.999 to 9.999
U93	Coefficient KA exponent portion	-5 to 5
U94	Coefficient KB mantissa portion	-9.999 to 9.999
U95	Coefficient KB exponent portion	-5 to 5
U96	Coefficient KC mantissa portion	-9.999 to 9.999
U97	Coefficient KC exponent portion	-5 to 5

Instead of setting the coefficients individually, they can be calculated and set automatically in function codes U92 to U97, by changing U107 from 0 to 1 after setting the arbitrary three sets of operating point data P1 (X1, Y1), P2 (X2, Y2), and P3 (X3, Y3) from the above diagram in function codes U101 to U106.

Function code	Name Setting range		
U101	Operating point data P1 (X1)	-999.00 to 0.00 to 9990.00	
U102	Operating point data P1 (Y1)	-999.00 to 0.00 to 9990.00	
U103	Operating point data P2 (X2)	-999.00 to 0.00 to 9990.00	
U104	Operating point data P2 (Y2)	-999.00 to 0.00 to 9990.00	
U105	Operating point data P3 (X3)	-999.00 to 0.00 to 9990.00	
U106	Operating point data P3 (Y3)	-999.00 to 0.00 to 9990.00	
U107	Automatic calculation	0: No calculation, 1: Calculation	

U107 Auto calculation of the coefficients of the quadratic function

Set "1" to U107 in order to fit the approximate coefficients of the quadratic function (3001) $(K_A \times Input1^2 + K_B \times Input1 + K_C)$ to a characteristic represented by three operating points which are given by function codes U101 to U106. Coefficients (K_A, K_B, K_C) of the polynomial are automatically calculated and the results are stored inside the function codes U92 to U97, and U107 reverts to "0".

U107 data	Function	
0	Invalid	
1	Execute calculation (to get the coefficients (KA, KB, KC) of the following polynomial $K_A \times lnput1^2 + K_B \times lnput1 + K_C$)	

Setting examples of customizable logic

Setting example 1: Use one switch to change multiple signals

If you use one switch to change the frequency setting 2/frequency setting 1 and torque limit 2/torque limit 1 simultaneously, replace an external circuit that is conventionally needed with a customizable logic reducing the general-purpose input terminals used to a single terminal.



To configure this customizable logic, set the function codes as follows. (Timer selection) and (Timer setting) do not need to be modified if no change is made.

Function code		Setting value	Settings	Remarks	
E01)1 Terminal [X1] function		11	Select frequency command 2/1 "Hz2/Hz1"	Can be used in parallel as general-purpose input terminals
U00	Customizable Logic (Mode selection)		1	Enable	
U01	Customizable logic: Step 1	(Block selection)	10	Through output + General-purpose timer	Mode selection
U02		(Input 1)	4001	Terminal [X1] input signal X1	
U71	Customizable logic: Output signal 1	(Output selection)	1	Output of step 1, "SO01"	
U81		(Function selection)	14	Select torque limiter level 2/1 "TL2/TL1"	
Setting example 2: Bring multiple output signals in a single signal

If the general-purpose RUN signal is kept ON at restart after momentary power failure, replace an external circuit that is conventionally needed with a customizable logic sequence to reduce the general-purpose output terminals and external relays.



To configure this customizable logic, set the function codes as follows. (Timer selection) and (Timer setting) do not need to be modified if no change is made.

Function code		Setting value	Settings	Remarks	
E20	Terminal [Y1] function		111	Customizable logic output signal 1 "CL01"	
U00	Customizable Logic (Mode selection)		1	Enable	
U01	Customizable logic: Step 1	(Block selection)	30	Logical OR + General-purpose timer	Mode selection
U02		(Input 1)	0	During operation "RUN"	
U03		(Input 2)	6	Auto-restarting after momentary power failure "IPF"	
U71	Customizable logic output signal 1	(Output selection)	1	Output of step 1, "SO01"	
U81		(Function selection)	100	No function assigned "NONE"	

Setting example 3: One-shot operation

The required operation is as follows: SW-FWD or SW-REV switch is short-circuited to start the operation and the SW-STOP switch is short-circuited to stop the operation (equivalent to worker) keys/work keys on keypad), if the above operation is required, replace an external circuit that is conventionally needed with customizable the customized logic.



To configure this customizable logic, set the function codes as follows. (Timer selection) and (Timer setting) do not need to be modified if no change is made.

Function code		Setting value	Settings	Remarks	
F02	02 Operation method		1	External signal	
E01	Terminal [X1] function	ı	100	No function assigned "NONE"	
E98	Terminal [FWD] funct	ion	100	No function assigned "NONE"	
E99	Terminal [REV] functi	on	100	No function assigned "NONE"	
U00	Customizable Logic (Mode selection)	1	Enable	
U01	Customizable logic:	(Block selection)	30	Logical OR + General-purpose timer	Mode selection
U02	Step 1	(Input 1)	4011	Terminal REV input signal "SW-REV"	
U03		(Input 2)	4001	Terminal X1 input signal "SW-STOP"	
U06	Customizable logic:	(Block selection)	60	Reset priority flip-flop + General-purpose timer	Mode selection
U07	Step 2	(Input 1)	4010	Terminal FWD input signal "SW-FWD"	
U08		(Input 2)	2001	Output of step 1 "SO01"	
U11	Customizable logic:	(Block selection)	30	Logical OR + General-purpose timer	Mode selection
U12	Step 3	(Input 1)	4010	Terminal FWD input signal "SW-FWD"	
U13		(Input 2)	4001	Terminal X1 input signal "SW-STOP"	
U16	Customizable logic:	(Block selection)	60	Reset priority flip-flop + General-purpose timer	Mode selection
U17	Step 4	(Input 1)	4011	Terminal REV input signal "SW-REV"	
U18		(Input 2)	2003	Output of step 3 "SO03"	
U71	Customizable logic output signal 1	(Output selection)	2	Output of step 2 "SO02"	"FWD" command
U72	Customizable logic output signal 2		4	Output of step 4 "SO04"	"REV" command
U81	Customizable logic output signal 1	(Function selection)	98	Run forward/stop command "FWD"	
U82	Customizable logic output signal 2		99	Run reverse/stop command "REV"	

5.3.11 y codes (Link functions)

y01 to y20

RS-485 setting 1, RS-485 setting 2

System	Connection method	Function code	Equipment that can be connected
First system	Via RS-485 communication link (port 1) (RJ-45 connector to connect keypad)	y01 to y10	Standard/ optional keypad Inverter supporting loader Host equipments (upper equipments)
Second systems	Via RS-485 communications link (port 2) Via digital input terminal blocks (DX+, DX-)	y11 to y20	Host equipments (upper equipments) Other inverters at mutual operation Inverter supporting loader

In the RS-485 communication, two systems can be connected.

Overview of the equipments is given below.

- Standard /optional keypad
 Standard / optional keypad can be connected to operate and monitor the inverter.
 Regardless of the y code settings, standard / optional keypad is available.
- (2) Inverter supporting loader (FRENIC loader) Inverter supporting (monitor, function code editing, test operation) can be performed by connecting a computer with the FRENIC loader installed.
 - For the y codes setting, refer to the function codes y01 to y10.
- (3) Host equipments (upper equipments) Host equipments (upper equipments) such as PLC and controller can be connected to control and monitor the inverter. Modbus RTU* protocol, BACnet protocol or Fuji general-purpose inverter protocol can be selected for communication.
- (4) Other inverters in mutual operation

*: Modbus RTU is a protocol defined by Modicon.

Chap 5 FUNCTION CODES

For details, refer to the RS-485 Communication User's Manual.

Station addresses (y01, y11)

Set the station addresses for the RS-485 communication. The setting range depends on the protocol.

Protocol	Range	Broadcast
Modbus RTU	1 to 247	0
Protocol for loader commands	1 to 255	
Fuji general-purpose inverter	1 to 31	99
N2 protocol	1 to 255	—
BACnet	0 to 127	255

• When specifying a value out of range, no response is returned.

• The settings to use inverter supporting loader should match with the computer's settings.

■ Communications error processing (y02, y12)

Select an operation when an error occurs in the RS-485 communication.

The RS-485 errors are logical errors such as address error, parity error and framing error, transmission errors and disconnection errors (the latter specified in y08 and y18). These errors occur only when the inverter is configured to receive the operation command or frequency command via the RS-485 communication. If the operation command or frequency command is not issued via the RS-485 communication, or when the inverter is stopped, the system does not determine an error.

y02, y12 data	Function
0	Displays the RS-485 communication error ($\mathcal{E}_r - \mathcal{B}$ for y02, $\mathcal{E}_r - \mathcal{P}$ for y12), and immediately stops the operation (trip by alarm).
1	Operates for a period specified in the error process timer (y03, y13), and then displays the RS-485 communication error ($\mathcal{E}_r - \mathcal{B}$ for y02, $\mathcal{E}_r - \mathcal{P}$ for y12), and stops the operation (trip by alarm).
2	Retries the communication for a period specified in the error process timer (y03, y13), and if the communication is recovered, the operation continues. Displays the RS-485 communication error ($\mathcal{E}_{\mathcal{P}}\mathcal{B}$ for y02, $\mathcal{E}_{\mathcal{P}}\mathcal{P}$ for y12) if the communication is not recovered, and immediately stops the operation (trip by alarm).
3	Continues the operation if a communication error occurs.

For details, refer to the RS-485 Communication User's Manual.

Error process timer (y03, y13)

Sets the error process timer, as explained above for the communications error processing parameters (y02, y12). Refer also to the section of disconnection detection time (y08, y18).

• Data setting range: 0.0 to 60.0 (s)

Baud rate (y04, y14)

Sets the transmission baud rate.

• For inverter supporting loader (via RS-485): Match the value with the computer setting.

y04 and y14 data	Function
0	2400 bps
1	4800 bps
2	9600 bps
3	19200 bps
4	38400 bps

Data length selection (y05, y15)

Sets the character length.

 For inverter supporting loader (via RS-485): The value does not need to be set since it automatically becomes 8 bits. (It also applies to Modbus RTU.)

y05 and y15 data	Function
0	8 bits
1	7 bits

Parity selection (y06, y16)

Sets the parity.

• For inverter supporting loader (via RS-485): The value does not need to be set since it automatically becomes even parity.

y06 and y16 data	Function
0	No parity bit (2 bits of stop bit for Modbus RTU)
1	Even parity (1 bit of stop bit for Modbus RTU)
2	Odd parity (1 bit of stop bit for Modbus RTU)
3	No parity bit (1 bits of stop bit for Modbus RTU)

Function

Detection time from 1 to

Disconnection is not

detected.

60 (s)

Stop bit selection (y07, y17)

Sets the stop bit.

For inverter supporting loader (via RS-485): The value does not need to be set since it automatically becomes 1 bit.

For Modbus RTU: The value does not need to be set since it is automatically determined in conjunction with the parity bit (function y06, y16).

Communication time-out detection timer (y08, y18)

Sets a period from the time when the system detects communication time-out (for any reason such as disconnection in equipment that periodically access to the station within a specific time) during the operation using the RS-485 communication, until the time when the system processes the communication errors.

For details on processing communication errors, refer to y02 and y12.

Response interval time (y09, y19)

Sets a period from the time when the system receives a request from host equipment (upper equipment such as computer or PLC) until the time when it returns a response. In case of the host equipments that are slow to process the task from completed transmission to completed reception preparation, a timing can be synchronized by setting a response interval time.

Data setting range: 0.00 to 1.00 (s)





a: Processing time inside the inverter. It varies depending on the timing and command.

For details, refer to the RS-485 Communication User's Manual.

To set an inverter by the inverter supporting loader via the RS-485 communication, consider the Note performance and condition of the computer and converter (such as USB-RS-485 converter). (Some converters monitor communication status and switch transmission and reception with timer.)

Protocol selection (y10, y20)

Selects a communication protocol.

y10 and y20 data	Function
0	Modbus RTU protocol
1	FRENIC Loader protocol
2	Fuji general-purpose inverter protocol
3	N2 protocol
5	BACnet protocol
50	Mutual operation (only y20)

y07 and y17 data	Function
0	2 bits
1	1 bit

y08 and y18 data

0

1 to 60

UNCTION CODES
ц
iap 5

y95

Data clear processing for communications

If any of the communication error alarms (\mathcal{E} - \mathcal{B} , \mathcal{E} - \mathcal{P} , \mathcal{E} - \mathcal{H} , \mathcal{E} - \mathcal{L}) occurs in RS-485 or bus option, the data of communication command function codes (S codes) can automatically be cleared.

Since the frequency and operation commands are also disabled when the data is cleared, the inverter does not start unintentionally when an alarm is released.

y95 data	Function
0	When a communication error alarm occurs, the function code Sxx data is not cleared (compatible with the conventional mode).
1	When a communication error alarm occurs, the function codes S01, S05 and S19 data is cleared.
2	When a communication error alarm occurs, the bits assigned in function code S06 for operation command is cleared.
3	Clear operations of 1 and 2 above are performed.

y97

Communication data storage selection

The inverter memory (non-volatile memory) has a limited rewritable times (100 thousand to 1 million times). If the count immoderately increases, the data cannot be modified or saved, causing a memory error.

If the data should frequently be overwritten via communication, it can be written in the temporary memory instead of the non-volatile memory. This allows to save rewritable times to the non-volatile memory, which can avoid a memory error.

If y97 is set to "2", the data written in the temporary memory is stored (All Saved) in the non-volatile memory.

To change the y97 data, it is necessary to press the 10^{10} + 10^{10} keys (simultaneous keying).

y97 data	Function
0	Store into nonvolatile memory (Rewritable times are limited)
1	Write into temporary memory (Rewritable times are unlimited)
2	Store all data from temporary memory to nonvolatile memory (After storing all data, the y97 data return to 1)

For details on setting the y98 bus function (mode selection), refer to the description of H30.

y99 Loader link function (Mode selection)

Function code to switch the links to the inverter supporting loader software (FRENIC Loader). Rewriting y99 with the inverter supporting loader software (FRENIC Loader) enables the frequency command and operation command from the inverter supporting loader software (FRENIC Loader). You do not need to use the keypad since the data is rewritten from the inverter supporting loader.

If the operation command is configured to be given from the inverter supporting loader software, and if the computer starts to go out of control during the operation and a stop command from the loader software is ignored, remove the communication cable connected to the computer that runs the inverter supporting loader software, and connect the keypad to set the y99 data to 0. By setting the y99 data to 0, the operation is isolated from the inverter supporting loader software's commands, switching to the commands of inverter's own settings (such as function code H30).

v00 data	Function						
y99 dala	Frequency command	Run command source					
0	From function codes H30 and y98	From function codes H30 and y98					
1	Command issued from FRENIC loader	From function codes H30 and y98					
2	From function codes H30 and y98	Command issued from FRENIC loader					
3	Command issued from FRENIC loader	Command issued from FRENIC loader					

The y99 data is not saved in the inverter; the setting is lost and returned to 0 when powered off.



Chapter 6 TROUBLESHOOTING

This chapter describes troubleshooting procedures to be followed when the inverter malfunctions or detects an alarm or a light alarm condition. In this chapter, first check whether any alarm code or the "light alarm" indication $(\angle -\neg \neg \angle)$ is displayed or not, and then proceed to the troubleshooting items.

Contents

6.1	Prote	ctive F	unction 6-1
6.2	Befor	e Proc	eeding with Troubleshooting
6.3	lf an <i>l</i>	Alarm (Code Appears on the LED Monitor 6-3
6.3	5.1	Alarm	code list6-3
6.3	5.2	Cause	es, checks and measures of alarms
['	1]	CoF	PID feedback wire break
[2	2]	Ada A	Braking transistor broken 6-6
[:	3]	אם	Braking resistor overheat 6-6
[4	4]	EEL	Customizable logic failure 6-7
[{	5]	<i>EF</i> 0	Ground fault ······ 6-7
[6	6]	E- /	Memory error 6-7
[]	7]	6-2	Keypad communications error 6-8
[8	8]	E-3	CPU error 6-8
[9	9]	E-4	Option communications error 6-8
['	10]	E-5	Option error 6-8
['	11]	Er-5	Operation error 6-9
['	12]	<i>Er</i> - 7	Tuning error 6-9
['	13]	E-8	RS-485 communications error (Communications port 1)/
		E-P	RS-485 communications error (Communications port 2) ······6-10
['	14]	Erd	Step-out detection/detection failure of magnetic pole position at startup
['	15]	ErE	Speed inconsistency / Excessive speed deviation6-12
['	16]	ErF	Data saving error during undervoltage6-13
['	17]	ErH	Hardware error ······6-13
['	18]	<u>E</u>	Simulated failure6-13
['	19]	FLIS	DC fuse-blowing ······6-13
[2	20]	Ĺ <i>"</i> ¬	Input phase loss ······6-14
[2	21]	Loil	Password Protection6-14
[2	22]	<i>LL</i> / L	Indervoltage ······6-15
[2	23]	השמ	Instantaneous overcurrent6-16
[2	24]	<u>]</u> ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;	Cooling fin overheat

[25]	ビート・ External alarm
[26]	Inverter internal overheat 6-17
[27]	년년 Motor protection (PTC thermistor)····································
[28]	CHE Charging resistor overheat
[29]	<i>C</i> // Motor overloads 1 ······6-19
[30]	CL/ Inverter overload ····································
[31]	UPL Output phase-failure detection
[32]	<i>D5</i> Overspeed protection ····································
[33]	<i>[][[</i>] Overvoltage
[34]	PbF Charge circuit fault ·······6-22
6.4 If the	"Light Alarm" Indication ($\angle -\overrightarrow{n} \angle$) Appears on the LED Monitor
6.5 Whe	n Codes Other Than Alarm Codes and Light Alarm Indication $(\angle - \neg \neg \angle)$ are Displayed6-24
6.5.1	Abnormal motor operation ·······6-24
[1]	The motor does not rotate6-24
[2]	The motor rotates, but the speed does not increase6-26
[3]	The motor runs in the opposite direction to the command ······6-27
[4]	Speed fluctuation or current oscillation (e.g., hunting) occurs during running
	at constant speed ···································
[5]	Unpleasant noises are emitted from motor or noises fluctuate
[6]	Motor is not accelerated or decelerated according to set-up acceleration
[7]	The motor does not restart even after the power recovers
[']	from a momentary power failure
[8]	Motor generates heat abnormally6-30
[9]	The motor does not run as expected
[10]	Motor stalls during acceleration6-31
6.5.2	Problems with inverter settings6-32
[1]	Nothing appears on the LED monitor6-32
[2]	The desired menu is not displayed6-32
[3]	Display of under bars () 6-33
[4]	Display of center bars ()6-33
[5]	\angle \bigcirc Display of parenthesis6-33
[6]	Data of function codes cannot be changed6-34
[7]	Function code data are not changeable (change from link functions)6-34

6.1 **Protective Function**

In order to prevent system down or to shorten a downtime, FRENIC-eHVAC is provided with various protective functions shown in Table 6.1-1 below. The protective functions marked with an asterisk (*) in the table are disabled by factory default. Enable them according to your needs.

The protective functions include, for example, the "heavy alarm" detection function which, upon detection of an abnormal state, displays the alarm code on the LED monitor and causes the inverter to trip, the "light alarm" detection function which displays the alarm code but lets the inverter continue the current operation, and other warning signal output functions.

If any problem arises, understand the protective functions listed below and follow the procedures given in Sections 6.2 and onwards for troubleshooting.

Protective function	Description	Related function code
"Heavy alarm" detection	This function detects an abnormal state, displays the corresponding alarm code, and causes the inverter to trip. See "Table 6.3-1 Various failure detections (Heavy failure objects)" for alarm codes. For details of each alarm code, see the corresponding item in the troubleshooting in Section 6.3. The inverter retains the last four alarm codes and their factors together with their running information applied when the alarm occurred, so it can display them.	H98
"Light alarm" detection*	This function detects an abnormal state categorized as a "light alarm," displays $\angle \neg \exists \angle$ and lets the inverter continue the current operation without tripping. Details of light alarms are selectable. Selectable details (codes) are shown in "Table 6.3-1 Various failure detections (Heavy failure objects)." See Section 6.4 for the confirming method and releasing method of the light alarms.	H81 H82
Stall prevention	When the output current exceeds the current limiter level (F44) during acceleration/ deceleration or constant speed running, this function decreases the output frequency to avoid an overcurrent trip.	F44
Overload prevention control*	Before the inverter trips due to a cooling fin overheat $(\square + /)$ or inverter overload $(\square + /)$, this function decreases the output frequency of the inverter to reduce the load.	H70
Anti-regenerative control*	If regenerative energy returned exceeds the inverter's braking capability, this function automatically increases the deceleration time or controls the output frequency to avoid an overvoltage trip.	H69
Deceleration characteristics* (Improvement of braking performance)	During deceleration, this function increases the motor energy loss and decreases the regenerative energy returned to avoid an overvoltage trip $(\Box L' L')$.	H71
Reference loss detection*	This function detects a frequency reference loss (due to a broken wire, etc.), issues the alarm, and continues the inverter operation at the specified frequency.	E65
Automatic lowering of carrier frequency	Before the inverter trips due to an abnormal surrounding temperature or output current, this function automatically lowers the carrier frequency to avoid a trip.	H98
Dew condensation prevention	This function applies a direct current at regular intervals to raise the motor temperature and prevent condensation while the inverter is not in operation.	J21
Motor overload early warning*	When the inverter output current has exceeded the specified level, this function issues the "Motor overload early warning" signal before the thermal overload protection function causes the inverter to trip for motor protection (Only for the 1st motor).	E34 E35
Retry*	When the inverter has stopped because of a trip, this function allows the inverter to automatically reset and restart itself. The number of retries and the latency between stop and reset can be specified.	H04 H05
Forced stop*	Upon receipt of the "Force to stop" terminal command STOP, this function interrupts the run and other commands currently applied in order to forcedly decelerate the inverter to a stop state.	H56
Surge protection	This function protects the inverter from a surge voltage between main circuit power lines and the ground.	-
Momentary power failure protection*	 If a momentary power failure for 15 ms or longer occurs, a protective operation (inverter stop) is activated. When momentary power failure restart is selected, the inverter restarts automatically after voltage restoration within a set-up time (momentary power failure permissible time). 	F14

Table 6.1-1 Abnormal States Detectable ("Heavy Alarm" and "Light Alarm" Objects)

6.2 Before Proceeding with Troubleshooting

• If any of the protective functions has been activated, first remove the cause. Then, after checking that all run commands are set to OFF, release the alarm. If the alarm is released while any run command is set to ON, the inverter may supply the power to the motor, running the motor.

Injury may occur.

- Even though the inverter has interrupted power to the motor, if the voltage is applied to the main circuit input terminals L1/R, L2/S, L3/T, voltage may be output to inverter output terminals U, V, and W.
- Turn OFF the power and wait for at least five minutes for inverters with a capacity of FRN0060F2E-4G or below, or at least ten minutes for inverters with a capacity of FRN0075F2E-4G or above. Make sure that the LED monitor or charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC intermediate circuit voltage between the terminals P (+) and N (-) has dropped to the safe level (+25 VDC or below).

Electric shock may occur.

Follow the procedure below to solve problems.

- (1) Is wire connection correct?See Chapter 2 "2.2.1 Basic connection diagram."
- (2) Check whether an alarm code or the "light alarm" indication (I-al) is displayed on the LED monitor.
 - If an Alarm Code Appears on the LED Monitor
 To Section 6.3
 - If the "Light Alarm" Indication (∠ -戸∠) Appears on the LED Monitor To Section 6.4
 - When Codes Other Than Alarm Codes and Light Alarm Indication (∠ ¬∠) are To Section 6.5 Displayed

Abnormal motor operation

- 6.5.1 [1] The motor does not rotate
- 6.5.1 [2] The motor rotates, but the speed does not increase
- 6.5.1 [3] The motor runs in the opposite direction to the command
- 6.5.1 [4] Speed fluctuation or current oscillation (e.g., hunting) occurs during running at constant speed
- 6.5.1 [5] Unpleasant noises are emitted from motor or noises fluctuate
- 6.5.1 [6] Motor is not accelerated or decelerated according to set-up acceleration or deceleration times
- 6.5.1 [7] The motor does not restart even after the power recovers from a momentary power failure
- 6.5.1 [8] Motor generates heat abnormally
- 6.5.1 [9] The motor does not run as expected
- 6.5.1 [10] Motor stalls during acceleration

Problems with inverter settings

- 6.5.2 [1] Nothing appears on the LED monitor
- 6.5.2 [2] The desired menu is not displayed
- 6.5.2 [3] Display of under bars (____)
- 6.5.2 [4] Display of center bars (----)
- 6.5.2 [5] <u>/</u> J Display of parenthesis
- 6.5.2 [6] Data of function codes cannot be changed
- 6.5.2 [7] Function code data are not changeable (change from link functions)

If any problems persist after the above recovery procedure, contact your Fuji Electric representative.

To Section 6.5.1

To Section 6.5.2

6.3 If an Alarm Code Appears on the LED Monitor

6.3.1 Alarm code list

When an alarm is detected, check the alarm code displayed on 7-segment LED of keypad.

When one alarm code has more than one cause, alarm subcodes are provided to make it easy to identify the cause. When there is only one cause, the alarm subcode is displayed as "-" and described as "-."

- * See (Chapter 3 "3.4.6 Reading alarm information") for the method of checking the alarm codes.
- * With regard to alarm details having alarm subcodes name "For manufacturer", inform the alarm subcodes, too, when contacting Fuji Electric or requesting an inverter repair.

Alarm code	Alarm code name	Heavy failure object	Light alarm selectable	Retry object	Alarm subcode*	Alarm subcode name	Reference page
CoF	PID feedback wire break	Y	Y	_	_	_	6-6
dbA	Braking transistor broken	Y	_	_	_	_	6-6
	Braking resistor overheat	v	v	×	0	DB resistor overheat	6-6
	(FRN0060F2E-4G or below)	'		1	1	For manufacturer	0-0
EEL	Customizable logic failure	Y	—	—	_	_	—
EF	Ground fault (FRN0075F2E-4G or above)	Y	—	_	_	_	6-7
Er 1	Memory error	Y	-	_	1 to 16	For manufacturer	6-7
E-2	Keypad communications error	Y	—	_	1 to 2	For manufacturer	6-8
E-3	CPU error	Y	_	-	1 to 9000	For manufacturer	6-8
E4	Option communications error	Y	Y	_	1	For manufacturer	6-8
<i></i>	Option error	Y	Y	_	0	Time-out	6-8
					1 to 10	For manufacturer	00
	Operation error	Y	_		1	STOP key priority/forced stop (STOP terminal)	-
					2	Start check function	
					3	Start check function (when operation is permitted)	
E-6					4	Start check function (when reset is turned on)	6-9
					5	Start check function (when the power recovers in powering on)	
					6	Start check function (TP connection)	
					8 to 14	For manufacturer	

Table 6.3-1 Various failure detections (Heavy failure objects)

Alarm code	Alarm code name	Heavy failure object	Light alarm selectable	Retry object	Alarm subcode*	Alarm subcode name	Reference page										
					7	Operation command OFF during motor tuning											
					8	Forced stop during motor tuning											
					9	BX command during motor tuning											
					10	Hardware current limit during motor tuning											
					11	Occurrence of low voltage (LV) during motor tuning											
					12	Failure due to prevention of reverse rotation during motor tuning											
Er- 7	Tuning error	Y	_	_	13	Over upper limit frequency during motor tuning	6-9										
					14	Switching to commercial power during motor tuning											
					15	Occurrence of alarm during motor tuning	_										
					16	Change of run command source during motor tuning	_										
					18	Over acceleration time during motor tuning	_										
					5000 to 5065	Refer to Chapter 4 "4.8.2 Alarm Information"											
					Other than above	For manufacturer											
E-8	RS-485 communications error (Communication port 1)	Y	Y		_	_	6-10										
Erd	Step-out detection	Y	—	—	5001 to 5008	For manufacturer	6-11										
	Speed inconsistency/ excessive speed deviation		Y	Y				1	Signs of speed command and speed detection are inconsistent.								
c c		Y			Y	Y	Y	Y							3	In the case of excessive speed deviation (detected speed > speed command)	6-12
					5	Detected speed remains 0Hz irrespective of speed command.	ю-12										
							7	In the case of excessive speed deviation (detected speed < speed command)									
E-F	Data saving error during undervoltage	Y	_	_	_	_	6-13										
Er-H	Hardware error	Y	—	—	—	—	6-13										
E-P	RS-485 communications error (Communication port 2)	Y	Y		—	_	6-11										
Er-r-	Simulated failure	Y	—	—	—	—	6-13										
FuS	DC fuse-blowing	Y	-	_	—	—	6-13										
רוו ל	Input phase loss	Y	_	_	1-2	For manufacturer	6-14										
1.11		Y			1	Password 1 protection	6.4.4										
		Y			2	Password 2 protection	0-14										
		Y	_		1	Occurrence of low voltage during gate ON (F14=0)											
LU	Undervoltage			_	_	_	_	_	_	_	_	_	_	_	2	Run command ON during low voltage (F14=0, 2)	6-14
					3	LV trip on power recovery from a momentary power failure (F14=1)											
					4 to 5	For manufacturer											

Continuation of Table 6.3-1

Alarm code	Alarm code name	Heavy failure object	Light alarm selectable	Retry object	Alarm subcode*	Alarm subcode name	Reference page
DE 1 DE2 DE3	Instantaneous overcurrent	Y	_	Y	1 to 5001	For manufacturer	6-16
	O selin s fin succh set	V	v	v	6	Detection of fan stop	0.40
	Cooling fin overneat	Y	Ŷ	Ŷ	Other than above	For manufacturer	6-16
OH2	External alarm	Y	Y	—	—	-	6-17
					0	Internal air overheat	
DH3	Inverter internal overheat	Y	Y	Y	1	Charging resistor overheat	6-17
					Other than above	For manufacturer	
274	Motor protection (PTC thermistor)	Y	_	Y	_	_	6-18
0+15	Charging resistor overheat	Y	Y	Y		Ι	6-18
DL I	Motor 1 overload	Y	Y	Y	_	_	6-19
					1	IGBT protection	
DLU	Inverter overload	Y	—	Y	2	Inverter overload	6-20
					10	For manufacturer	
DPL	Output phase-failure detection	Y	_	_	1 to 10	For manufacturer	6-20
05	Overspeed protection	Y	_	_	—	_	6-21
OLI I							
OUZ	Overvoltage	Y	_	Y	1 to 12	For manufacturer	6-21
OU3							
PGF	Charger circuit fault (FRN0176F2E-4G or above)	Y	_	_	1 to 2	For manufacturer	6-22
בהר	Inverter life (Number of startups)	—	Y	_		_	
FAL	Detect DC fan lock	—	Y	_	_	_	
L "F	Lifetime alarm	-	Y	—	_	_	
1	Password protoction	v			1	Password protection 1	
				_	2	Password protection 2	
DH	Cooling fin overheat early warning	_	Y	_	—	—	
ÛL	Overload early warning	—	Y	—	_	-	6-23
Pid	PID alarm output	—	Y	—	_	—	0-23
PFC	PTC thermistor activated	_	Y	_	_	_	
r-EF	Reference command loss detected	_	Y	_	_	_	
rſE	Machine life (Cumulative motor running hours)	_	Y	_	_	_	
SL R	Rotary operation slave inverter alarm	_	Y	_	_	_	
LITL	Low torque detection	-	Y	_		_	1

Continuation of Table 6.3-1

NB) • If a control power supply voltage drops to such a level that the operation of the inverter control circuit cannot be maintained, all protective functions are automatically reset.

By OFF → ON operation of key or X terminal (assigned to RST) the protection stop state can be released. In a state that an alarm cause is not removed, however, resetting operation is not effective.

• If two or more alarms are occurring, the resetting operation remains ineffective until all the alarm causes are removed. Alarm factors not removed can be checked from the keypad.

• When assigned to light alarms, "30A/B/C" do not work.

6.3.2 Causes, checks and measures of alarms

[1] $\int_{\mathcal{O}} \mathcal{F}$ PID feedback wire break

Phenomena The signal line of PID feedback is broken.

Check and Measures				
 Check whether the PID feedback signal wires are connected correctly. Check whether the PID feedback signal wires are connected correctly. Or, tighten the related terminal screws. 				
 Check whether any contact part bites the wire sheath. 				
Check whether appropriate noise control measures have been implemented (e.g. correct grounding and routing of signal wires, communications cables, and main circuit wires).				
 Separate the signal wires from the main power wires as far as 				

[2] $db \beta$ Braking transistor broken

Phenomena Faulty operation of the braking transistor was detected.

Possible Causes	Check and Measures			
The braking transistor is broken.	Check whether resistance of the braking resistor is correct or there is a misconnection of the resistor.			
	 Consult your Fuji Electric representative for repair. 			

[3] *dbH* Braking resistor overheat

Phenomena The electronic thermal protection for the braking resistor has been activated.

Possible Causes	Check and Measures
(1) Braking load is too heavy.	Reconsider the relationship between the braking load estimated and the real load.
[Subcode: 0]	➔ Lower the real braking load.
	➔ Review the selection of the braking resistor and increase the braking capability. Modification of related function codes data (F50, F51, and F52) may be also required.
(2) Specified deceleration time is too short.	Recalculate the deceleration torque and time needed for the load currently applied, based on a moment of inertia for the load and the deceleration time.
[Subcode: 0]	→ Increase the deceleration time (F08, E11, E13, E15, and H56).
	➔ Review the selection of the braking resistor and increase the braking capability. Modification of related function codes data (F50, F51, and F52) may be also required.
(3) Incorrect setting of function	Recheck the modes of the braking resistor.
code data F50, F51, and F52.	→ Review data of function codes F50, F51, and F52, then modify them if required.
[Subcode: 0]	

Note

The inverter issues an overheat alarm of the braking resistor by monitoring the magnitude of the braking load, not by measuring its surface temperature.

When the braking resistor is used so frequently as to exceed the settings made by function codes F50, F51, and F52, therefore, the inverter issues an overheat alarm even if the surface temperature of the braking resistor does not rise. To obtain full performance of the braking resistor, configure function codes F50, F51, and F52 while actually measuring the surface temperature of the braking resistor.

[4] ELL Customizable logic failure

Phenomena A setting failure of customizable logic was detected.

Possible Causes	Check and Measures
 Setting of the selection of customizable logic operation was changed during operation. 	 Check whether the selection (Function code U00) of customizable logic operation is changed during operation. → Do not change the selection of customizable logic operation during operation to prevent a danger.

[5] *EF* Ground fault

Phenomena A ground fault current flew from the output terminal of the inverter.

Possible Causes	Check and Measures	
 Inverter output terminal(s) grounded (ground fault). 	 Disconnect the wiring from the output terminals (U, V, and W) and perform a Megger test. → Remove the grounded parts (including replacement of the wires, 	
	relay terminals and motor).	

[6] Er- / Memory error

Phenomena	Error occurred in writing th	he data to the memo	ory in the inverter.
-----------	------------------------------	---------------------	----------------------

Possible Causes	Check and Measures
(1) When writing data (especially initializing or copying data), the inverter was shut down so that the voltage to the control PCB has dropped.	 Initialize data by data initialization (H03), and check whether an alarm can be released by key after finishing the initialization. → Revert the initialized function code data to their previous settings, then restart the operation.
(2) The inverter was affected by strong electrical noise when writing data (especially initializing).	 Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of control and main circuit wires). Also, perform the same check as described in (1) above. → Implement noise control measures. Revert the initialized function code data to their previous settings, then restart the operation.
(3) The control PCB failed.	 Initialize data by data initialization (H03), and check whether an alarm continues even when the release of the alarm is attempted by key after finishing the initialization. → The control PCB (on which the CPU is mounted) is defective. Contact your Fuji Electric representative.
(4) The power was turned OFF, and the control power supply voltage dropped while saving user settings with function code H193.	 Ensure that the alarm persists even after saving user settings with function code H193, pressing the key after saving is complete, and attempting to clear the alarm. → This is a PCB error, including that for the CPU, and therefore we ask that you notify Fuji.
(5) The unit was affected by strong noise from the surrounding area while saving user settings with function code H193.	 Check noise countermeasures (grounding condition, control/main circuit wiring and installation). Furthermore, perform the same check as that for (4). → This is a PCB error, including that for the CPU, and therefore we ask that you notify Fuji.

[7] $\mathcal{E}_{\mathcal{F}_{\mathcal{C}}}$ Keypad communications error

Possible Causes	Check and Measures
(1) Broken communications cable or poor contact.	 Check continuity of the cable, contacts and connections. → Re-insert the connector firmly. → Replace the cable.
(2) Connecting many control wires hinders the front cover from being mounted, lifting the keypad.	 Check the mounting condition of the front cover. → Use wires of the recommended size (0.75 mm²) for wiring. → Change the wiring layout inside the unit so that the front cover can be mounted firmly.
(3) The inverter was affected by strong electrical noise.	 Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of communications cables and main circuit wires). → Implement noise control measures. For details, refer to Appendix A.
(4) A keypad failure occurred.	Replace the keypad with another one and check whether a communications error (∠, -, -, -) occurs. → Replace the keypad.

Phenomena A communications error occurred between the keypad and the inverter.

[8] *Er-3* CPU error

Phenomena	A CPU error (e.g.	erratic CPU o	operation) occurred	I.
-----------	-------------------	---------------	---------------------	----

Possible Causes	Check and Measures
 The inverter was affected by strong electrical noise. 	Check if appropriate noise control measures have been implemented (e.g. correct grounding and routing of signal wires, communications cables, and main circuit wires). → Implement noise control measures.
(2) The [PLC] and [CM] terminals have been shorted.	Check whether the [PLC] and [CM] terminals have been shorted.

[9] $\mathcal{E}_{r-\mathcal{Y}}$ Option communications error

Phenomena A communications error occurred between the option card and the inverter.

Possible Causes	Check and Measures
 There was a problem with the connection between the option card and the inverter. 	 Check whether the connector on the option card is properly engaged with that of the inverter. → Reload the option card into the inverter.
(2) The inverter was affected by strong electrical noise.	Check whether appropriate noise control measures have been implemented (e.g. correct grounding and routing of signal wires, communications cables, and main circuit wires). → Implement noise control measures.

[10] $\mathcal{E} - \mathcal{S}$ Option error

An error detected by the option card.

Refer to the instruction manual of the option card for details.

[11] *Er-5* Operation error

Phenomena An incorrect operation was attempted.

Possible Causes	Check and Measures
(1) we key was pressed when the we is effective (H96=1, 3).	Check whether the is key was pressed in a state that a run command is inputted via terminal block or communications.
[Subcode:1]	➔ If this was not intended, check the setting of H96.
(2) The start check function was activated when H96 = 2 or 3.	Check that any of the following operations has been performed with a run command being entered.
	Power on
[Subcode:2 to 6]	Release of alarm
	Switching to link operation command
	Review the running sequence to avoid input of a Run command when this error occurs.
	If this was not intended, check the setting of H96. Turn the run command OFF before releasing the alarm.
(3) The forced stop (digital input	Check that the forced stop "STOP" is turned off.
terminal) STOP was turned OFF.	➔ If this was not intended, check the settings of E01 through E05 for terminals [X1] through [X5].
[Subcode:1]	

[12] Er-7 Tuning error

Phenomena Auto-tuning failed.

Possible Causes	Check and Measures
 A phase was missing in the connection between the inverter and the motor. 	➔ Properly connect the motor to the inverter.
(2) V/f or the rated current of the motor was not properly set.	Check whether the data of function codes (F04, F05, H50, H51, H52, H53, P02, P03) agree with the motor modes.
(3) The wiring length between the inverter and the motor was too long.	 Check whether the wiring length between the inverter and the motor exceeds 50 m. Inverters with a small capacity are greatly affected by the wiring length. → Review, and if necessary, change the layout of the inverter and the motor to shorten the connection wire. Alternatively, minimize the wiring length without changing the layout. → Disable both auto-tuning and auto-torque boost (set data of F37 to "1").
(4) The rated capacity of the motor was significantly different from that of the inverter.	 Check whether the rated capacity of the motor is three or more ranks lower, or two or more ranks higher than that of the inverter. → Replace the inverter with one with an appropriate capacity. → Set motor constants (P06, P07, P08) manually. → Disable both auto-tuning and auto-torque boost (set data of F37 to "1").
(5) The motor was a special type such as a high-speed motor.	➔ Disable both auto-tuning and auto-torque boost (set data of F37 to "1").
(6) Tuning (P04=2) operation was performed of rotating a motor in a state that brake is applied to the motor.	 → Specify the tuning that does not involve the motor rotation (P04 = 1). → Perform the tuning (P04=2) with the motor brake released.

[13] $\mathcal{E} - \mathcal{B}$ RS-485 communications error (Communications port 1)/ $\mathcal{E} - \mathcal{P}$ RS-485 communications error (Communications port 2)

Possible Causes	Check and Measures
 Communications conditions of the inverter do not match that of the host equipment. 	Compare the settings of the function codes (y01 to y10, y11 to y20) with those of the host equipment. → Correct any settings that differ.
 (2) Even though no-response error detection time (y08, y18) has been set, communications is not performed within the specified cycle. 	 Check the host equipment. → Change the settings of host equipment software or disable the no-response error detection (y08, y18 = 0).
(3) The host equipment did not operate due to defective software, settings, or defective hardware.	 Check the host equipment (e.g., PLCs and personal computers). → Remove the cause of the equipment error.
(4) The RS-485 converter did not operate due to incorrect connections and settings, or defective hardware.	 Check the RS-485 converter (e.g., check for poor contact). → Change the various RS-485 converter settings, reconnect the wires, or replace hardware with recommended devices as appropriate.
(5) Broken communications cable or poor contact.	Check the continuity of the cables, contacts and connections.→ Replace the cable.
(6) The inverter was affected by strong electrical noise.	 Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of communications cables and main circuit wires). → Implement noise control measures. → Implement noise reduction measures on the host side. → Replace the RS-485 converter with a recommended insulated one.
(7) Terminating resistor is not properly configured.	 Check that the inverter serves as a terminating device in the network. Set terminal resistor changeover switches for RS-485 communications (SW2/SW6) correctly. In other words, turn the switch(es) to ON if required.

Phenomena A communications error occurred during RS-485 communications.

[14] *Erd* Step-out detection/detection failure of magnetic pole position at startup

Phenomena The step-out of PM motor was detected. The magnetic pole position at startup failed to be detected.

Possible Causes	Check and Measures
 Function code settings do not agree with the motor characteristics. 	 Check whether F04, F05, P01, P02, P03, P60, P61, P62, P63, P64 agree with the motor constants. → Perform auto-tuning of the inverter for every motor to be used.
(2) Magnetic pole position detection method is not appropriate.	 Confirm that the magnetic pole position detection mode matches the motor type. → Match the magnetic pole position detection mode selection (P30) to the motor type.
(3) Starting frequency (continuation time) (F24) is insufficient.	 Check whether a starting frequency (continuation time) (F24) is set optimally, after setting the magnetic pole position detection mode selection (P30) to "0" or "3." → Set a period of time during which motor can rotate by one or more revolutions. F24≥P01/2/F23 (P01: Number of poles, F23: Starting frequency)
(4) Starting torque is insufficient.	 Check the data of acceleration times (F07, E10, E12, E14) and a current command value on a start (P74). → Change the acceleration time to match the load. → Increase the current command value at startup.
(5) Load is small.	 Check the data of a reference current at starting (P74). → Decrease the reference current at starting. Set it to 80% or lower when running a motor single unit in a test run etc.

[15] $\mathcal{E} = \mathcal{E}$ Speed inconsistency / Excessive speed deviation

Phenomena An excessive deviation appears between the speed command and the detected speed.

Possible Causes	Check and Measures
 Incorrect setting of function code data. 	 Check the motor parameter "Number of poles" (P01). → Specify the P01 data in accordance with the motor to be used.
(2) Overload.	Measure the inverter output current. → Reduce the load.
	Check whether any mechanical brake is applied.→ Release the mechanical brake.
(3) The motor speed does not increase due to the current limiter operation.	 Check the data of function code F44 (Current limiter (Level)). → Change the F44 data correctly. Or, set the F43 data to "0" (Disable) if the current limiter operation is not needed.
	 Check the data of the function codes (F04, F05, P01-P08) to see if V/f is set correctly. → Match the V/f pattern setting with the motor ratings. → Change the function code data in accordance with the motor parameters.
(4) Function code settings do not match the motor characteristics.	 Confirm that P01, P02, P03, P06, P07, P08 match the motor constants. → Perform auto-tuning of the inverter, using the function code P04.
(5) Wiring to the motor is incorrect.	 Check the wiring to the motor. → Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively.
(6) The motor speed does not increase due to the torque limiter operation.	 Check the data of F40 (Torque limiter (Level)). → Change the F40 data correctly. Or, set the F40 data to "999" (Disable) if the torque limiter operation is not needed.
(7) The wire between the pulse generator (PG) and the option card is broken or incorrect.	 Check whether the pulse generator (PG) is correctly connected to the option card or any wire is broken. → Check whether the PG is connected correctly. Or, tighten the related terminal screws. → Check whether any contact part bites the wire sheath. → Replace the wire.

[16] $\mathcal{E} = \mathcal{F}$ Data saving error during undervoltage

Phenomena The inverter failed to save data such as the frequency commands and PID commands (which are specified through the keypad), or the output frequencies modified by the UP/DOWN signal commands when the power was turned OFF.

Possible Causes	Check and Measures
(1) During data saving performed when the power was turned OFF, the voltage fed to the control PCB dropped in an abnormally short period due to the rapid discharge of the DC intermediate circuit.	 Check how long it takes for the DC intermediate circuit voltage to drop to the preset voltage when the power is turned OFF. → Remove whatever is causing the rapid discharge of the DC intermediate circuit voltage. After pressing the key and releasing the alarm, return the data of the relevant function codes (such as the frequency commands and PID commands (specified through the keypad) or the output frequencies modified by the UP/DOWN signal commands) back to the original values and then restart the operation.
(2) The inverter operation was affected by strong electrical noise during data saving performed when the power was turned OFF.	 Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of control and main circuit wires). → Implement noise control measures. After pressing the key and releasing the alarm, return the data of the relevant function codes (such as the frequency commands and PID commands (specified through the keypad) or the output frequencies modified by the UP/DOWN signal commands) back to the original values and then restart the operation.
(3) The control circuit failed.	 Check if <i>E</i>₁−<i>F</i> occurs each time the power is turned ON. The control PCB (on which the CPU is mounted) is defective. Contact your Fuji Electric representative.

[17] Er-H Hardware error

Phenomena Faulty contact of the connector connecting the control and power printed circuit boards was detected.

Possible Causes	Check and Measures
 The control printed circuit board is misconnected to the power printed circuit board. 	 It is necessary to replace the power or control printed circuit board. → Contact your Fuji Electric representative.

[18] Err Simulated failure

Phenomena The LED displays the alarm E_{r-r-} .

Possible Causes	Check and Measures
 Keep is key + key key pressed for five seconds or longer. 	➔ To escape from this alarm state, press the

[19] FUS DC fuse-blowing

Phenomena The fuse inside the inverter blew.

Possible Causes	Check and Measures
 The fuse blew due to short-circuiting inside the 	Check whether there has been any excess surge or noise coming from outside.
inverter.	➔ Take measures against surges and noise.
	➔ Consult your Fuji Electric representative for repair.

[20] $\angle \pi$ Input phase loss

Phenomena Input phase loss occurred, or interphase voltage unbalance rate was large. If the auxiliary power (R0, T0) is taken from the breaker primary side (power supply side), a ", יר" alarm may occur even if there has been no phase loss.

Possible Causes	Check and Measures
 Breaks in wiring to the main power input terminals. 	 Measure the input voltage. → Repair or replace the main circuit power input wires or input devices (MCCB, MC, etc.).
(2) The screws on the main power input terminals are loosely tightened.	 Check if the screws on the main power input terminals have become loose. → Tighten the terminal screws to the recommended torque.
(3) Interphase voltage unbalance among three phases was too large.	 Measure the input voltage. → Connect an AC reactor (ACR) to lower the voltage unbalance between input phases. → Increase the inverter capacity.
(4) Overload cyclically occurred.	 Measure the ripple wave of the DC intermediate circuit voltage. → If the ripple is large, increase the inverter capacity.
(5) Single-phase voltage was input to the three-phase input inverter.	Check the inverter type.→ Apply three-phase power.

Note The input phase loss protection can be disabled with the function code H98.

[21] $\angle \Box_{\mu}^{\mu}$ Password Protection

Phenomena An incorrect user password has been entered a predetermined number of times.

Possible Causes	Check and Measures
 User password 1 or 2 has been entered incorrectly a predetermined number of times. 	 Release the alarm. → Turn the inverter OFF and ON. You have forgotten the password. → Contact your dealer or the unit manufacturer.

[22] *LU* Undervoltage

Phenomena DC intermediate circuit voltage has dropped below the undervoltage detection level.

Possible Causes	Check and Measures
(1) A momentary power failure occurred.[Subcode:1][Subcode:3]	 → Release the alarm. → If you want to restart running the motor without treating this condition as an alarm, set F14 to "3," "4," or "5," depending on the load type.
(2) The power to the inverter was switched back to ON too soon (when F14 = 1).[Subcode:2]	Check if the power to the inverter was switched back to ON while the control power was still alive. Check whether the LEDs on the keypad are lit. → Turn the power ON again after all LEDs on the keypad go off.
(3) The power supply voltage did not reach the inverter's type correct range.	 Measure the input voltage. → Increase the voltage to within the specified range.
(4) Peripheral equipment for the power circuit malfunctioned, or the connection was incorrect.	 Measure the input voltage to find which peripheral equipment malfunctioned or which connection is incorrect. → Replace any faulty peripheral equipment, or correct any incorrect connections.
(5) Any other loads connected to the same power supply has required a large starting current, causing a temporary voltage drop.	 Measure the input voltage and check the voltage fluctuation. → Reconsider the power supply system configuration.
(6) Inverter's inrush current caused the power voltage drop because the power supply transformer capacity was insufficient.	Check if the alarm occurs when a molded case circuit breaker (MCCB), earth leakage circuit breaker (ELCB) (with overcurrent protection) or magnetic contactor (MC) is turned ON. → Reconsider the capacity of the power supply transformer.

Dir Instantaneous overcurrent [23]

The inverter momentary output current exceeded the overcurrent level. Phenomena

Possible Causes	Check and Measures
 The inverter output lines were short-circuited. 	Disconnect the wiring from the inverter output terminals (U, V and W) and measure the interphase resistance of the motor wiring. Check if the resistance is too low.
	→ Remove the short-circuited part (including replacement of the wires, relay terminals and motor).
(2) Ground faults have occurred at the inverter output lines.	Disconnect the wiring from the output terminals (U, V, and W) and perform a Megger test.
	→ Remove the grounded parts (including replacement of the wires, relay terminals and motor).
(3) Overload.	Measure the motor current with a measuring device to trace the current trend. Then, use this data to judge if the trend is over the calculated load value for your system design.
	➔ If the load is too heavy, reduce it or increase the inverter capacity.
	Trace the current trend and check if there are any sudden changes in the current.
	➔ If there are any sudden changes, make the load fluctuation smaller or increase the inverter capacity.
	➔ Enable instantaneous overcurrent limiting (H12 = 1).
(4) Excessive torque boost specified. The manual torque	Check whether decreasing the torque boost (F09) decreases the output current but does not stall the motor.
boost is set if F37 = 0, 1, 3, or 4.	➔ If no stall occurs, decrease the torque boost (F09).
(5) The specified acceleration/ deceleration time was too short.	Check that the motor generates enough torque required during acceleration/deceleration. That torque is calculated from the moment of inertia of the load and the acceleration/deceleration times.
	➔ Increase the acceleration/deceleration times (F07, F08, E10 through E15).
	➔ Enable the current limiter (F43) and torque limiter (F40, F41, E16, and E17).
	→ Increase the inverter capacity.
(6) Malfunction caused by noise.	Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of control and main circuit wires).
	➔ Implement noise control measures. For details, refer to Appendix A.
	→ Enable the retry function (H04).
	→ Connect a surge absorber to magnetic contactor's coils or other solenoids (if any) causing noise.
(7) Motor is idling at start-up.	When the motor is idling at high speed, an excessive current flow during start-up.
	➔ Enable auto search (H09/d67).
(8) The [PLC] and [CM] terminals have been shorted.	Check whether the [PLC] and [CM] terminals have been shorted.

[24] $\square H$ / Cooling fin overheat

Possible Causes	Check and Measures
 The surrounding temperature exceeded the inverter's mode limit. 	 Measure the surrounding temperature. → Lower the temperature (e.g., ventilate the panel where the inverter is mounted).
(2) Ventilation paths are blocked.	 Check if there is sufficient clearance around the inverter. → Change the mounting place to ensure the clearance.
	Check if the fin is not clogged. → Clean the fin.
(3) Cooling fan's airflow volume decreased due to the service life expired or failure.	Check the cumulative run time of the cooling fan. (See Chapter 3 "3.4.5 Reading maintenance information.") → Replace the cooling fan.
[Subcode:6]	Visually check that the cooling fan rotates normally. → Replace the cooling fan.
(4) Overload.	 Measure the inverter output current. → Reduce the load. Reduce the load before reaching an overload using cooling fin overheat forecast (E01-E05)/overload forecast (E34). → Decrease the motor sound (Carrier frequency (F26)).
	➔ Enable overload prevention control (H70).

Phenomena Temperature around heat sink has risen abnormally.

[25] CHC External alarm

Phenomena External alarm was inputted (THR). (when the "Enable external alarm" signal THR has been assigned to any of digital input terminals)

Possible Causes	Check and Measures
 An alarm function of external equipment was activated. 	Check the operation of external equipment.→ Remove the cause of the alarm that occurred.
(2) Wrong connection or poor contact in external alarm signal wiring.	Check if the external alarm signal wiring is correctly connected to the terminal to which the "external alarm" has been assigned (Any of E01 to E05, E98, and E99 should be set to "9."). → Connect the external alarm signal wire correctly.
(3) Incorrect setting of function code data.	Check whether an "external alarm" is assigned to a terminal not used yet among E01 to E05, E98, E99. → Correct the assignment.
	Check whether the logic of [THR] set up at E01 to E05, E98, E99 agrees with that (positive/negative) of external signals. → Ensure the matching of the logic.

[26] [27] Inverter internal overheat

Phenomena Temperature inside the inverter has exceeded the allowable limit.

Possible Causes	Check and Measures
(1) The surrounding temperature exceeded the inverter's mode limit.[Subcode:0]	 Measure the surrounding temperature. → Lower the temperature around the inverter (e.g., ventilate the panel where the inverter is mounted).

[27] $\square H \forall$ Motor protection (PTC thermistor)

Possible Causes	Check and Measures
 The temperature around the motor exceeded the motor's mode range. 	Measure the surrounding temperature.→ Lower the temperature around the motor.
(2) Cooling system for the motor is defective.	 Check if the cooling system of the motor is operating normally. → Repair or replace the cooling system of the motor.
(3) Overload.	 Measure the inverter output current. → Reduce the load (e.g. Use the overload early warning (E34) and reduce the load before the overload protection is activated.). In winter, the load tends to increase. → Lower the temperature around the motor. → Increase the Carrier frequency (function code F26).
 (4) The activation level (H27) of the PTC thermistor for motor overheat protection was set inadequately. 	 Check the PTC thermistor modes and recalculate the detection voltage. → Modify the data of function code H27.
(5) The setting of the PTC thermistor is not adequate.	 Check thermistor Mode selection (H26, E59) and the changeover switches (SW3, SW4) of terminal [C1]. → Change the settings to E59=0, H26=1, and set SW3 to C1 side and SW4 to PTC side.
(6) Excessive torque boost specified (F09)	 Check whether decreasing the torque boost (F09*) does not stall the motor. → If no stall occurs, decrease the F09 data.
(7) The V/f pattern did not match the motor.	 Check if the base frequency (F04) and the rated voltage at base frequency (F05) match the rated values on the motor's nameplate. → Match the function code data with the values on the motor's nameplate.
(8) Incorrect setting of function code data.	 Although PTC thermistor is not used, the thermistor Mode selection (H26) is set to the operation state. → Set the H26 data to "0" (Disable).

Phenomena Temperature of the motor has risen abnormally.

[28] DHS Charging resistor overheat

Phenomena Temperature of the charging resistor inside the inverter has risen abnormally.

Possible Causes	Check and Measures
 The inverter power is turned ON and OFF frequently. 	Suppress the inverter power ON/OFF cycles. → Turn ON and OFF the inverter power once or less per 30 min.
(2) The inverter power is not turned ON and OFF frequently.	 Check that this alarm always occurs when the inverter power is turned ON. → The charging circuit of the inverter is faulty. Consult your Fuji Electric representative for repair.

[29] // Motor overloads 1

Phenomena	Electronic thermal	function for motor	overload detection	of motor1 worked.

Possible Causes	Check and Measures
 The electronic thermal characteristics do not match the motor overload characteristics. 	 Check the motor characteristics. → Review the data of related function codes P99, F10, F12. → Use an external thermal relay.
(2) Activation level for the electronic thermal protection was inadequate.	Check the continuous allowable current of the motor.→ Reconsider and change the data of function code F11.
(3) The specified acceleration/ deceleration time was too short.	 Recalculate the acceleration/deceleration torque and time needed for the load, based on the moment of inertia of the load and the acceleration/deceleration times. → Increase the acceleration/deceleration times (F07, F08, E10 to E15, and H56).
(4) Overload.	 Measure the inverter output current. → Reduce the load (e.g. Use the overload early warning (E34) and reduce the load before the overload protection is activated.). In winter, the load tends to increase.
(5) Excessive torque boost specified (F09)	 Check whether decreasing the torque boost (F09) does not stall the motor. → If no stall occurs, decrease the F09 data.

[30] $\Box L \Box$ Inverter overload

Possible Causes	Check and Measures
 The surrounding temperature exceeded the inverter's mode limit. 	 Measure the surrounding temperature. → Lower the temperature (e.g., ventilate the panel where the inverter is mounted).
(2) Excessive torque boost specified (F09)	 Check whether decreasing the torque boost (F09) does not stall the motor. → If no stall occurs, decrease the F09 data.
(3) The specified acceleration/ deceleration time was too short.	 Recalculate the acceleration/deceleration torque and time needed for the load, based on the moment of inertia of the load and the acceleration/deceleration times. → Increase the acceleration/deceleration times (F07, F08, E10 to E15).
(4) Overload.	 Measure the inverter output current. → Reduce the load (e.g. Use the overload early warning (E34) and reduce the load before the overload protection is activated.). In winter, the load tends to increase. → Decrease the Carrier frequency (function code F26). → Enable overload prevention control (H70).
(5) Ventilation paths are blocked.	 Check if there is sufficient clearance around the inverter. → Change the mounting place to ensure the clearance. Check if the fin is not clogged. → Clean the fin.
(6) Cooling fan's airflow volume decreased due to the service life expired or failure.	 Check the cumulative run time of the cooling fan. See Chapter 3 "3.4.5 Reading maintenance information." → Replace the cooling fan. Visually check that the cooling fan rotates normally. → Replace the cooling fan.
(7) The wires to the motor are too long, causing a large leakage current from them.	Measure the leakage current. → Insert an output circuit filter (OFL).

Phenomena Temperature inside inverter has risen abnormally.

[31] DPL Output phase-failure detection

Phenomena Output phase loss occurred.

Possible Causes	Check and Measures
(1) Inverter output wires are broken.	Measure the inverter output current.→ Replace the output wires.
(2) The motor winding is broken.	Measure the inverter output current. → Replace the motor.
(3) The terminal screws for inverter output were not tight enough.	 Check if any screws on the inverter output terminals have become loose. ➔ Tighten the terminal screws to the recommended torque.
(4) A single-phase motor has been connected.	➔ The inverter cannot be used. FRENIC-eHVAC has been designed for driving 3-phase induction / permanent magnet synchronous motors.

[32] $\square 5$ Overspeed protection

Phenomena Mo	otor rotated at excessive	speed (When mo	otor speed \geq (F03×1.2)).
--------------	---------------------------	----------------	-------------------------------

Possible Causes	Check and Measures
(1) Incorrect setting of function code data.	 Check the motor parameter "Number of poles" setting (P01). → Specify the P01 data in accordance with the motor to be used.
	Check the maximum frequency setting (F03).→ Specify the F03 data in accordance with the output frequency.

Clin Overvoltage [33]

The DC intermediate circuit voltage was over the detection level of overvoltage. Phenomena

Possible Causes	Check and Measures
 The power supply voltage exceeded the inverter's mode range. 	Measure the input voltage.→ Decrease the voltage to within the specified range.
(2) A surge current entered the input power supply.	In the same power line, if a phase-advancing capacitor is turned ON/OFF or a thyristor converter is activated, a surge (momentary large increase in the voltage or current) may be caused in the input power. → Install a DC reactor.
(3) The deceleration time was too short for the moment of inertia of the load.	Recalculate the deceleration torque based on the moment of inertia of the load and the deceleration time. → Increase the deceleration time (F08, F11, F13, and F15).
	 → Enable the anti-regenerative control (H69), or deceleration characteristics (H71).
	 → Set torque limit (F40, F41, E16, E17) to become effective. → Set the rated voltage at base frequency (F05*) to "0" to improve the braking capability.
	→ Consider the use of a braking resistor.
(4) The acceleration time was too short.	 Check if the overvoltage alarm occurs after rapid acceleration. → Increase the acceleration time (F07, E10, E12, and E14). → Select the Curve acceleration/ deceleration (H07). → Consider the use of a braking resistor.
(5) Braking load is too heavy.	 Compare the braking torque of the load with that of the inverter. → Set the rated voltage at base frequency (F05) to "0" to improve the braking capability. → Consider the use of a braking resistor.
(6) Malfunction caused by noise.	 Check if the DC intermediate circuit voltage was below the protective level when the overvoltage alarm occurred. → Implement noise control measures. For details, refer to Appendix A. → Enable the retry function (H04). → Connect a surge absorber to magnetic contactor's coils or other solenoids (if any) causing noise.

[34] PbF Charge circuit fault

Phenomena The magnetic contactor for short-circuiting the charging resistor failed to work.

Possible Causes	Check and Measures
 The control power was not supplied to the magnetic contactor intended for short-circuiting the charging resistor. 	Check that, in normal connection of the main circuit (not a connection via the DC link bus), the connector (CN R) on the power printed circuit board (power PCB) is not inserted to NC. → Insert the connector (CN R) to FAN.
	Check whether you quickly turned the circuit breaker ON and OFF to confirm safety after cabling/wiring.
	→ Wait until the DC intermediate circuit voltage has dropped to a sufficiently low level and then release the current alarm. After that, turn ON the power again. Do not turn the circuit breaker ON and OFF quickly.
	(Turning ON the circuit breaker supplies power to the control circuit to the operation level (lighting the LEDs on the keypad) in a short period. Immediately turning it OFF even retains the control circuit power for a time, while it shuts down the power to the magnetic contactor intended for short-circuiting the charging resistor since the contactor is directly powered from the main power. Under such conditions, the control circuit can issue a turn-on command to the magnetic contactor, but the contactor without power cannot operate normally. This state is regarded as abnormal, causing an alarm.)

6.4 If the "Light Alarm" Indication $(\angle - / / \angle)$ Appears on the LED Monitor

Function codes H81 and H82 specify which alarms should be categorized as "light alarm." Selectable factors (codes) are the codes of light alarm objects shown in Table 6.3-1.

To display the "light alarm" factor and escape from the light alarm state, follow the instructions below.

Check method of light alarm factors

- 1) Press the @ key to enter Programming mode.
- 2) Check the light alarm factor in 5_{-} 3_{-} (Light alarm factor (latest)) under Menu #5 "Maintenance Information" in Programming mode. The light alarm factor is displayed in alarm codes. See Table 6.3-1 for code details.
- See Chapter 3 "3.4.5 Reading maintenance information" for the details of screen transition in the "Maintenance Information." It is possible to display the factors of most recent 3 light alarms in 5_{-} 3_{-} ? (Light alarm factor (last)) to 5_{-} 3_{-} ? (Light alarm factor (3rd last)).

Switching the LED monitor from the light alarm to normal display

If it is necessary to return the LED monitor to the normal display state (showing the running status such as reference frequency) temporarily before removing the light alarm factor because it takes a long time to remove the light alarm factor, for example, follow the steps below.

- 1) Press the R key to return the LED monitor to the light alarm indication $(\cancel{L} \cancel{R})$.
- 2) Press ﷺ key in a state of light alarm display (∠ ¬¬∠). Keypad display returns from light alarm display (∠ -¬¬∠) to monitor display (including frequency display) in the ordinary running state. KEYPAD CONTROL LED continues blinking, though.

Release method of light alarms

- 1) See function codes (H81, H82) corresponding to light alarm factors (codes) checked in the Maintenance Information to remove the occurrence factors of light alarms.
- 2) To return the LED monitor from the $L H_L$ display to the normal display state (showing the running status such as reference frequency), press the \Re key in Running mode.

If the light alarm factor(s) has been successfully removed in step 1) above, the KEYPAD CONTROL LED stops blinking and the digital output L-ALM also goes OFF. If any light alarm factor persists (e.g., detecting a DC fan lock), the KEYPAD CONTROL LED continues blinking and the L-ALM remains ON.

6.5 When Codes Other Than Alarm Codes and Light Alarm Indication ($\angle -A \angle$) are Displayed

6.5.1 Abnormal motor operation

[1] The motor does not rotate

Possible Causes	Check and Measures
 No power supplied to the inverter. 	 Check the input voltage and interphase voltage unbalance. → Switch on the molded-case circuit breaker, an earth-leakage circuit breaker (with overcurrent protective function) or a magnetic contactor. → Check for voltage drop, phase loss, poor connections, or poor contacts, and fix them if necessary. → If only the auxiliary control power input is supplied, also supply the main power to the inverter.
(2) No forward/reverse operation command was inputted, or both the commands were inputted simultaneously (external signal operation).	 Check the input status of the forward/reverse command with Menu "I/O Checking" using the keypad. Input a run command. Set either the forward or reverse operation command to OFF. Correct the run command source. Set F02 data to "1." Correct the assignment error of terminals [FWD], [REV]. (E98, E99) Connect the external circuit wires to control circuit terminals [FWD] and [REV] correctly. Make sure that the sink/source slide switch (SW1) on the control printed circuit board (control PCB) is properly configured.
(3) No rotational direction is instructed.(Keypad operation)	 Check the input status of the forward/reverse rotation direction command with Menu "I/O Checking" using the keypad. → Input the rotation direction (F02 = 0), or select the keypad operation with which the rotation direction is fixed (F02 = 2 or 3).
 (4) The inverter could not accept any run commands from the keypad since it was in Programming mode. 	 Check which operation mode the inverter is in, using the keypad. → Shift the operation mode to Running mode and enter a run command.
(5) A run command with higher priority than the one attempted was active, and the run command was stopped.	 Based on the run command block diagram (See Chapter 8 "BLOCK DIAGRAMS FOR CONTROL LOGIC"), check a higher priority run command by function code data check and I/O checking from Menu using the keypad. → Correct any incorrect function code data settings such as link function (Mode selection) (H30) and bus link function (Mode selection) (y98) or cancel the higher priority run command.
(6) No analog frequency command input.	 Check that a reference frequency has been entered correctly, using Menu "I/O Checking" on the keypad. → Connect external circuit wirings of terminals [13], [12], [11], [C1] correctly.
(7) The reference frequency was below the starting or stop frequency.	 Check that a reference frequency has been entered correctly, using "I/O Checking" from the Menu on the keypad. → Set the reference frequency at the same or higher value than that of the starting and stop frequencies (F23 and F25). → Reconsider the starting and stop frequencies (F23 and F25), and if necessary, change them to lower values. → Inspect the external frequency command potentiometers, signal converters, switches, and relay contacts. Replace any ones that are faulty. → Connect external circuit wiring of terminals [13], [12], [11], [C1] correctly.

Possible Causes	Check and Measures
(8) A frequency command with higher priority than the one attempted was active.	Based on the frequency setting block diagram (See Chapter 8 "BLOCK DIAGRAMS FOR CONTROL LOGIC"), check the data by function code data check and I/O checking from Menu using the keypad.
	→ Correct any incorrect function code data (e.g. cancel the higher priority run command).
(9) The upper and lower frequencies for the frequency limiters were set incorrectly.	Check the data of function codes F15 (Frequency limiter (High)) and F16 (Frequency limiter (Low)).
(40)	
(10) The coast-to-stop command was effective.	the input state by using "I/O Checking" from the Menu on the keypad.
	→ Release the coast-to-stop command setting.
(11) Broken wires, incorrect	Check the wiring (Measure the output current).
connection or poor contact with the motor.	➔ Repair the wires to the motor, or replace them.
(12)Overload.	Measure the inverter output current.
	➔ Reduce the load (In winter, the load tends to increase.)
	Check whether any mechanical brake is applied.
	➔ Release the mechanical brake.
(13) Torque generated by the motor was insufficient.	Check that the motor starts running if the value of the torque boost (F09) is increased.
	➔ Increase the value of torque boost (F09).
	Check the data of function codes (F04, F05, H50, H51, H52, and H53). → Change the V/f pattern to match the motor's characteristics
	Charle whether the reference frequency is helew the slip frequency of
	the motor.
	→ Change the reference frequency so that it becomes higher than the slip frequency of the motor.
(14) Wrong connection or poor contact of DC reactor (DCR)	Check the wiring. DC reactor must be used with inverters of FRN0150F2E-4G or above respectively. These inverters cannot run without a DCR.
	→ Connect the DCR correctly. Repair or replace DCR wires.
(15) No speed command is set (Keypad operation).	Check a speed set value of keypad. → Press key to change the speed set value.

<u> </u>	-
Possible Causes	Check and Measures
 The maximum frequency currently specified was too low. 	Check the data of function code F03 (Maximum frequency).→ Correct the F03 data.
(2) The data of frequency limiter (Upper limit) currently specified was too low.	Check the data of function code F15 (Frequency limiter (Upper limit)). → Correct the F15 data.
(3) Speed setting is not changing (Analog setting).	 Check that the reference frequency has been entered correctly, using Menu "I/O Checking" on the keypad. → Increase the reference frequency. → Inspect the external frequency command potentiometers, signal converters, switches, and relay contacts. Replace any ones that are faulty. → Connect external circuit wirings of terminals [13], [12], [11], [C1] correctly.
(4) A frequency command (e.g., multi-frequency or via communications) with higher priority than the one attempted was active and its reference frequency was too low.	 Based on the frequency setting block diagram (See Chapter 8 "BLOCK DIAGRAMS FOR CONTROL LOGIC"), check the inputted frequency command by function code data check and I/O checking from Menu using the keypad. → Correct any incorrect data of function codes (e.g. cancel the higher priority frequency command).
(5) The acceleration time was too long or too short.	 Check the data of acceleration times (F07, E10, E12, E14). → Change the acceleration time to match the load.
(6) Overload.	Measure the inverter output current. → Reduce the load.
	Check whether any mechanical brake is applied.→ Release the mechanical brake.
(7) Function code settings do not agree with the motor characteristics.	 When automatic torque boost and automatic energy-saving operations are performed, confirm that P02, P03, P06, P07, P08 agree with motor constants. → Perform auto-tuning of the inverter for every motor to be used.
(8) The output frequency does not increase due to the current limiter operation.	Make sure that F43 (Current limiter (Mode selection)) is set to "2" and check the data of F44 (Current limiter (Level)). → Change the F44 data correctly. Or, set the F43 data to "0" (Disable) if the current limiter operation is not needed.
	 Decrease the value of torque boost (F09), then run the motor again and check if the speed increases. → If no stall occurs, decrease the F09 data.
	Check the data of function codes (F04, F05, H50, H51, H52, H53, and H66) to ensure that the V/f pattern setting is right. → Match the V/f pattern setting with the motor ratings.
(9) The output frequency does not increase due to the torque limiter operation.	 Check whether the data of torque control levels (F40, F41, E16, E17) are set to appropriate values. Also, check whether torque limit 2/1 switching signal [TL2/TL1] is correct. → Correct the data of F40, F41, E16 and E17 or reset them to the factory defaults. → Set the TL2/TL1 correctly.
(10) Bias and gain incorrectly specified.	 Check the data of the function codes (F18, C50, C32, C34, C37, C39, C42, C44, C55-C72). → Readjust the bias and gain to appropriate values.

[2] The motor rotates, but the speed does not increase
(11) External wirings of terminals [X1]-[X5] are not connected correctly. Or settings are not correct.	 Check that the reference frequency has been entered correctly, using Menu "I/O Checking" on the keypad. → Connect the external circuit wirings of terminals [X1]-[X5] correctly. → Set up the data of E01-E05 correctly. → Set up the data of C05-C19 correctly (Setting of multistep frequency).
(12) Speed set value is not changing. (Keypad operation)	 Check whether it changes by changing the speed command value of keypad. → Press ✓ I ✓ keys to change the speed command value.

[3] The motor runs in the opposite direction to the command

Possible Causes	Check and Measures
(1) Wiring to the motor is incorrect.	 Check the wiring to the motor. → Connect terminals U, V, and W of the inverter to the U, V, and W terminals of the motor, respectively.
 (2) Incorrect connection and settings for run commands and rotation direction commands (FWD and REV). 	 Check the data of function codes (E98 and E99) and the connection. → Correct the data of the function codes and the connection.
(3) A run command (with fixed rotational direction) from the keypad is active, but the rotational direction setting is incorrect.	 Check the data of function code F02 (Operation method). → Change the data of function code F02 to "2: / Keypad operation (forward rotation)" or "3: / Keypad operation (Reverse rotation)".
(4) The rotation direction mode of the motor is opposite to that of the inverter.	 The rotation direction of IEC-compliant motors is opposite to that of non compliant motors. → Switch the FWD/REV signal setting.
(5) The function code data related to the speed command are incorrect.	Check the function code data. See Chapter 8 "BLOCK DIAGRAMS FOR CONTROL LOGIC." → Set correct data.

Possible Causes	Check and Measures
(1) Analog speed setting is fluctuating.	 Check the signals for the frequency command with Menu "I/O Checking" using the keypad. (See Chapter 3 "3.4.4 Checking I/O signal status.") → Increase the filter constants (C33, C38, and C43) for the frequency command.
(2) An external frequency command potentiometer is used for frequency setting.	 Check that there is no noise in the control signal wires from external sources. → Separate the signal wires from the main power wires as far as possible. → Use shielded or twisted wires for control signals.
	 Check whether the external frequency command potentiometer is malfunctioning due to noise from the inverter. → Connect a capacitor to the output terminal of the potentiometer or insert a ferrite core on the signal wire. See Chapter 2 "Fig. 2.2-12 Example of Noise Countermeasures".
(3) Frequency switching or multi-frequency command was enabled.	 Check whether the relay signal for switching the frequency command is chattering. → If the relay contact is defective, replace the relay.
(4) The wiring length between the inverter and the motor is too long.	 Check whether auto-torque boost or auto-energy saving operation is enabled. → Perform auto-tuning of the inverter for every motor to be used. → Disable the automatic control systems by setting F37* to "1" (Constant torque load) and F42* to "0" (V/f control), then check that the motor vibration stops. → Make the output wires as short as possible.
(5) The machinery is hunting due to vibration caused by low rigidity of the load. Or the current is irregularly oscillating due to special motor parameters.	 After disabling all the automatic control systems such as auto torque boost, auto energy saving operation, overload prevention control, current limiter, torque limiter, anti-regenerative control, auto search for idling motor speed, check that the motor vibration disappears. → Disable the functions causing the vibration. → Readjust the output current fluctuation damping gain (H80*). Check that the motor vibration is suppressed if you decrease the value of F26 (Motor sound (Carrier frequency)) or set F27 (Motor sound (Tone)) to "0." → Decrease the carrier frequency (F26) or set the tone to "0" (F27 = 0)

[4] Speed fluctuation or current oscillation (e.g., hunting) occurs during running at constant speed

Possible Causes	Check and Measures
(1) The specified carrier frequency is too low.	 Check the data of motor operation noise (Carrier frequency) (F26) and motor operation noise (Tone) (F27). → Increase the carrier frequency (F26). → Change the setting of F27 to the appropriate value.
 (2) Ambient temperature of inverter is high. (In the selection of carrier frequency automatic reduction function (H98)) 	 Measure the temperature inside the panel where the inverter is mounted. → If it is over 40°C, lower it by improving the ventilation. → Lower the temperature of inverter by reducing the load. In the case of funs/pumps, lower the frequency limiter Upper limit (F15). NB) The release of H98 causes alarms □H I, □H∃, □LU in some cases.
(3) Resonance with the load.	 Check the machinery mounting accuracy or check whether there is resonance with the mounting base. → Sort out the resonance cause by running the motor independently. → Avoid continuous running at the frequency range where the resonance occurs by setting the jump frequency (C01-C04)

[5] Unpleasant noises are emitted from motor or noises fluctuate

[6] Motor is not accelerated or decelerated according to set-up acceleration or deceleration times

Possible Causes	Check and Measures
 The inverter runs the motor with S-curve or curvilinear pattern. 	 Check the data of function code H07 (Curve acceleration/ deceleration). → Set linear acceleration/deceleration. (H07=0) → Shorten the acceleration/deceleration times (F07, F08, E10 through E15).
(2) The current limiting operation prevented the output frequency from increasing (during acceleration).	 Make sure that F43 (Current limiter (Mode selection)) is set to 2, then check that the setting of F44 (Current limiter (Level)) is reasonable. → Readjust the setting of F44 to appropriate value, or disable the function of current limiter with F43. → Increase the acceleration/deceleration times (F07, F08, E10 through E15).
(3) The anti-regenerative control is enabled (during deceleration).	Check the data of function code H69 (Anti-regenerative control (Mode selection)). → Increase the deceleration time (F08, E11, E13, and E15).
(4) Overload.	 → Reduce the load. For fans or pumps, decrease the frequency limiter Upper limit (F15). In winter, the load tends to increase.
(5) Torque generated by the motor was insufficient.	Check that the motor starts running if the value of the torque boost (F09*) is increased. → Increase the value of the torque boost (F09).
(6) An external frequency command potentiometer is used for frequency setting.	 Check that there is no noise in the control signal wires from external sources. → Separate the signal wires from the main power wires as far as possible. → Use shielded or twisted wires for control signals. → Connect a capacitor to the output terminal of the potentiometer or insert a ferrite core on the signal wire. See Chapter 2 "2.2.6 [3] Description of terminal functions (control circuit terminal) [12], [C1]."

Possible Causes	Check and Measures
(7) The output frequency is limited by the torque limiter.	Check whether the data of torque limit levels (F40, F41, E16, E17) are set to appropriate values. Also, check whether torque limit 2/1 switching signal [TL2/TL1] is correct.
	→ Correct the data of F40, F41, E16 and E17 or reset them to the factory defaults.
	→ Set the TL2/TL1 correctly.
	➔ Increase the acceleration/deceleration times (F07, F08, E10 through E15).
(8) The specified acceleration or deceleration time was incorrect.	Check the terminal commands RT1 and RT2 for acceleration/ deceleration times.
	➔ Correct the RT1 and RT2 settings.

[7] The motor does not restart even after the power recovers from a momentary power failure

Possible Causes	Check and Measures
(1) The data of function code F14 is either "0," "1," or "2."	 Check if an undervoltage trip (∠ ∠') occurs. → Change the data of function code F14 (Restart mode after momentary power failure (Mode selection)) to "3," "4," or "5."
(2) The run command remains OFF even after the power has been restored.	 Check the input signal with Menu "I/O Checking" using the keypad. See Chapter 3 "3.4.4 Checking I/O signal status." → Check the power recovery sequence with an external circuit. If necessary, consider the use of a relay that can keep the run command ON.
	 In a 3-wire operation, momentary power failure duration is long so that control circuit power source of inverter is shut off once. Therefore, "select 3-wire operation" signal [HLD] is switched OFF once. → Change the design or the setting so that a run command can be issued again within 2 seconds after the power has been restored.

[8] Motor generates heat abnormally

Possible Causes	Check and Measures
 Excessive torque boost specified. 	Check whether decreasing the torque boost (F09) decreases the output current but does not stall the motor.
	➔ If no stall occurs, decrease the torque boost (F09).
(2) Continuous running in extremely slow speed.	Check the running speed of the inverter.
	 Change the speed setting or replace the motor with a motor exclusively designed for inverters.
(3) Overload.	Measure the inverter output current.
	→ Reduce the load. In the case of fans/pumps, lower the setting value of F15 (Frequency limiter (Upper limit)). In winter, the load tends to increase.

[9] The motor does not run as expected

Check and Measures
Check that function codes are correctly configured and no unnecessary configuration has been done.
→ Configure all the function codes correctly.
 Make a note of function code data currently configured and then initialize all function code data using H03. → After the above process, reconfigure function codes one by one, checking the running status of the motor.

Possible Causes	Check and Measures
(1) The acceleration time was too short.	Check the data of acceleration time (F07, E10, E12, E14, H57, H58). → Extend the acceleration time.
(2) Moment of inertia of load is large.	 Measure the inverter output current. Reduce the moment of inertia of the load. Increase the inverter capacity.
(3) Voltage drop of wiring is large.	 Check the terminal voltage of motor. → Increase the diameter or shorten the distance of wirings between the inverter and motor.
(4) Load torque of load is large.	 Measure the inverter output current. → Reduce the load torque of load. → Increase the inverter capacity.
(5) Torque generated by the motor was insufficient.	 Check whether the inverter can make the motor rotate when torque boost related functions (F09, H51) are increased. → Change the setting of F09, F37, H51. Increase F09, H51.

[10] Motor stalls during acceleration

6.5.2 Problems with inverter settings

[1] Nothing appears on the LED monitor

Possible Causes	Check and Measures
(1) No power (neither main power nor auxiliary control power) is supplied to the inverter.	 Check the input voltage and interphase voltage unbalance. → Switch on the molded-case circuit breaker, the earth-leakage circuit breaker (with overcurrent protective function) or the magnetic contactor. → Check for voltage drop, phase loss, poor connections, or poor contacts and fix them if necessary.
(2) The power for the control PCB did not reach a sufficiently high level.	 Check if the shorting bar has been removed between terminals P1 and P(+) or if there is a poor contact between the shorting bar and those terminals. → Mount a shorting bar or a DC reactor between terminals P1 and P(+). In case of poor contact, tighten the screws.
(3) The keypad was not properly connected to the inverter.	 Check whether the keypad is properly connected to the inverter. → Remove the keypad, put it back, and see whether the problem recurs. → Replace the keypad with another one and check whether the problem recurs.
	 When running the inverter remotely, ensure that the extension cable is securely connected both to the keypad and to the inverter. → Disconnect the cable, reconnect it, and see whether the problem recurs. → Replace the keypad with another one and check whether the problem recurs.

[2] The desired menu is not displayed

Possible Causes	Check and Measures
 The menu display mode is not selected appropriately. 	Check the data of function code E52 (Keypad (Menu display mode)). → Change the E52 data so that the desired menu appears.

[3] Display of under bars (____)

Phenomena Although e key, run forward command [FWD], or key, run reverse command [REV], was pressed, the motor did not rotate and under bars were displayed.

Possible Causes	Check and Measures		
 The voltage of the DC intermediate circuit was low. 	Select 5_1 / from Menu #5 "Maintenance Information" in the program mode of keypad to check the DC intermediate circuit voltage (3-phase 400V: 400VDC or less). → Connect the inverter to a power supply that meets its voltage supply		
	range.		
(2) The main power is not ON, while the auxiliary input power to the control circuit is supplied.	 Check whether the main power is turned ON. → Turn on the main power. Check if the shorting bar has been removed between terminals P1 and P(+) or if there is a poor contact between the shorting bar and those terminals. → Mount a shorting bar or a DC reactor between terminals P1 and P(+). In case of poor contact, tighten the screws. 		
 (3) AC power source is not connected due to the connection of DC power supply, but the detection of main power interruption is activated (H72=1). 	 Check the connection to the main power and check if the H72 data is set to "1" (factory default). → Review the data of H72. 		
(4) Breaks in wiring to the main power input terminals.	 Measure the input voltage. → Repair or replace the main circuit power input wires or input devices (MCCB, MC, etc.). 		

[4] Display of center bars (----)

Phenomena A center bar (----) appeared on the LED monitor.

Possible Causes	Check and Measures
 (1) When PID control had been disabled (J01 = 0), E43 (LED Monitor (Item selection)) is set to 10 or 12. PID control has been disabled (J01 = 0) when the LED monitor had been set to display the PID command or PID feedback amount by pressing the key. 	 Make sure that when you wish to view other monitor items, E43 is not set to "10: PID command" or "12: PID feedback value." → Set E43 to a value other than "10" or "12." Make sure that when you wish to view a PID command or a PID feedback value, J01 (PID control) is not set to "0: Disable." → Set J01 to "1: Enable (Process control normal operation)."
(2) The keypad was poorly connected.	 Prior check: Even when ^(m)/_(m) key is pressed, the display is not switched. Check continuity of the extension cable used in remote operation. → Replace the cable.

[5] \mathcal{L} \mathcal{J} Display of parenthesis

Phenomena *L* J was displayed during speed monitoring by keypad.

Possible Causes	Check and Measures
 The display data overflows the	Check whether the product of the output frequency and the display coefficient (E50) exceeds 99,999.
LED monitor.	→ Correct the E50 data.

Possible Causes	Check and Measures	
 An attempt was made to change function code data that cannot be changed when the inverter is running. 	Check if the inverter is running with Menu "Drive Monitoring" using the keypad and then confirm whether the data of the function codes can be changed when the motor is running by referring to the function code tables. → Stop the motor then change the data of the function codes.	
(2) The data of the function codes is protected.	 Check the data of function code F00 (Data protection). → Change the data of F00 from a data protection state (F00=1 or 3) to a data changeable state (F00=0 or 2). 	
(3) The WE-KP terminal command ("Enable data change with keypad") is not entered, though it has been assigned to a digital input terminal.	Check the data of the function codes (E01-E05, E98, E99), and check the input state by using "I/O Checking" from the Menu on the keypad. → Input a WE-KP command through a digital input terminal.	
(4) The 💮 key was not pressed.	Check whether ﷺ key was pressed after changing the data of the function codes. → Press ﷺ key after changing the data. Check that 5月七日 is displayed on the LED monitor.	
(5) The data of the function codes F02, E01-E05, E98, E99 are not changeable.	Either one of the FWD and REV terminal commands is turned ON. → Turn OFF both FWD and REV.	
(6) The function code(s) to be changed does not appear.	 If Menu #0 "Quick Setup" (☐, F¬, f) is selected, only the particular function codes appear. Call the menu of /, F to /, f by pressing key from the quick setup (☐, F¬, f) state on the Menu to display the intended function code and to change the value. (See Chapter 3 Section 3.4 Table 3.4-1 "Menus Available in Programming Mode" for the details.) 	

[6] Data of function codes cannot be changed

[7] Function code data are not changeable (change from link functions)

Possible Causes	Check and Measures	
 An attempt was made to change function code data that cannot be changed when the inverter is running. 	Check if the inverter is running with Menu "Drive Monitoring" using the keypad and then confirm whether the data of the function codes can be changed when the motor is running by referring to the function code tables.	
	➔ Stop the motor then change the data of the function codes.	
(2) The data of the function code F02 is not changeable.	Either one of the FWD and REV terminal commands is turned ON. → Turn OFF both FWD and REV.	

MAINTENANCE AND INSPECTION

This chapter describes the maintenance and inspection items of the inverter.

Contents

7.1	Inspe	ection Interval	· 7-1
7.2	Daily	/ Inspection ·····	· 7-2
7.3	Peric	odic Inspection	· 7-3
7.3	3.1	Periodic inspection 1Before the inverter is powered ON or after it stops running	• 7-3
7.3	3.2	Periodic inspection 2When the inverter is ON or it is running	• 7-4
7.4	List o	of Periodic Replacement Parts	· 7-5
7.4	4.1	Judgment on service life ·····	• 7-6
[1]	Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment	• 7-7
[2]	Measuring the capacitance of the DC link bus capacitor under ordinary operating conditions	· 7-8
[3]	Early warning of lifetime alarm	· 7-8
7.5	Meas	surement of Electrical Amounts in Main Circuit	· 7-9
7.6	Insul	ation Test	7-10
7.7	Inqui	iries about Product and Guarantee	7-11
7.7	7.1	When making an inquiry	7-11
7.7	7.2	Product warranty	7-11
[1]	Free of charge warranty period and warranty range	7-11
[2]	Exclusion of liability for loss of opportunity, etc.	7-12
[3]	Repair period after production stop, spare parts supply period (holding period)	7-12
[4]	Transfer rights	7-12
[5]	Service contents	7-12
[6]	Applicable scope of service	7-12

Perform daily and periodic inspections to avoid trouble and keep reliable operation of the inverter for a long time. When performing inspections, follow the instructions given in this chapter.

 Before proceeding to the maintenance/inspection jobs, turn OFF the power and wait at least five minutes for inverters FRN0060F2E-4G or below, or at least ten minutes for inverters FRN0075F2E-4G or above. Make sure that the LED monitor / charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).

Electric shock may occur.

- · Maintenance, inspection, and parts replacement should be made only by authorized persons.
- Take off the watch, rings and other metallic objects before starting work.
- Use insulated tools.
- Never modify the inverter.

Electric shock or injuries could occur.

7.1 Inspection Interval

Table 7.1-1 lists the inspection intervals and check items, as a guide.

Table 7.1-1 List of Inspections

Inspection type	Inspection interval	Check items
Daily inspection	Every day	See Section 7.2 .
Periodic inspection	Every year	See Section 7.3 .
Decennial inspection *1 Every 10 years		Replacement of cooling fans *2 Replacement of DC link bus capacitors and close checks

*1 The decennial inspection (except replacement of cooling fans) should be performed only by the persons who have finished the Fuji Electric training course. Contact the sales agent where you purchased the product or your nearest Fuji Electric representative.

*2 For the standard replacement interval of cooling fans, refer to "7.4 List of Periodic Replacement Parts."

Note The replacement intervals are based on the inverter's service life estimated at an ambient temperature of 40°C at 80% of full load. In environments with an ambient temperature above 40°C or a large amount of dust or dirt, the replacement intervals may be shorter.

Standard replacement intervals mentioned above are only a guide for replacement, not a guaranteed service life. Refer to "7.4 List of Periodic Replacement Parts."

7.2 Daily Inspection

Visually inspect the inverter for operation errors from the outside without removing the covers when the inverter is running or the power is ON.

Table 7.2-1 lists daily inspection items.

Check part	Check item	How to inspect	Evaluation criteria	
Environment	 Check the surrounding temperature, humidity, vibration and atmosphere (dust, gas, oil mist, or water drops). 	 Check visually or measure using apparatus. 	1) The usage environment given in Chapter 1, Section 1.3.1 must be satisfied.	
	 Check that tools or other foreign materials or dangerous objects are not left around the equipment. 	2) Visual inspection	 No foreign or dangerous objects are left. 	
External appearance and others	 Check that the bolts securing the wires to the main circuit terminals and control circuit terminals are not loose <u>before turning the power ON.</u> 	1) Retighten <u>before</u> <u>turning the power</u> <u>ON.</u>	 No loose screws. If loose, retighten the screws. 	
	 Check for traces of overheat, discoloration and other defects. 	2) Visual inspection	2), 3) No abnormalities	
	 Check for abnormal noise, odor, or excessive vibration. 	 Auditory, visual, and olfactory inspection 		
Cooling fans	Check for abnormal noise or excessive vibration when the cooling fans are in operation.	Auditory and visual inspections	No abnormalities	
Keypad	Check for alarm indication.	Visual inspection	If any alarm is displayed, refer to Chapter 6.	
Performance	Check that the inverter provides the expected performance (as defined in the standard specifications).	Check the monitor items shown on the keypad.	No abnormalities in the output speed, current and voltage and other running data.	

Table 7.2-1 Daily Inspection List

7.3 Periodic Inspection

7.3.1 Periodic inspection 1--Before the inverter is powered ON or after it stops running

Perform periodic inspections according to the items listed in Table 7.3-1. Before performing periodic inspection 1, shut down the power and then remove the front cover.

Even if the power has been shut down, it takes the time for the DC link bus capacitor to discharge. After the charging lamp is turned OFF, therefore, make sure that the DC link bus voltage has dropped to the safe level (+25 VDC or below) using a multimeter or a similar instrument.

Check part		Check item	How to inspect	Evaluation criteria
Structure such as frame and cover		 Check for: 1) Loose bolts (at clamp sections). 2) Deformation and breakage 3) Discoloration caused by overheat 4) Contamination and accumulation of dust or dirt 	 Retighten. 3), 4) Visual inspection 	1), 2), 3), 4) No abnormalities (If any section is stained, clean it with a soft cloth.)
	Common	 Check that bolts and screws are tight and not missing. Check the devices and insulators for deformation, cracks, breakage and discoloration caused by overheat or deterioration. Check for contamination or accumulation of dust or dirt. 	 Retighten. 3) Visual inspection 	1), 2), 3) No abnormalities (If any section is stained, clean it with a soft cloth.)
cuit	Conductors and wires	 Check conductors for discoloration and distortion caused by overheat. Check the sheath of the wires for cracks and discoloration. 	1), 2) Visual inspection	1), 2) No abnormalities
ain cir	Terminal blocks	Check that the terminal blocks are not damaged.	Visual inspection	No abnormalities
Ma	DC link bus capacitor	 Check for electrolyte leakage, discoloration, cracks and swelling of the casing. Check that the safety valve does not protrude remarkably. 	1), 2) Visual inspection	1), 2) No abnormalities
	Braking resistor	 Check for abnormal odor or cracks in insulators caused by overheat. Check for wire breakage. 	 Olfactory and visual inspection Check the wires visually, or disconnect either one of the wires and measure the conductivity with a multimeter. 	 No abnormalities Within ±10% of the resistance of the braking resistor
Control circuit	Printed circuit board	 Check for loose screws and connectors. Check for odor and discoloration. Check for cracks, breakage, deformation and remarkable rust. Check the capacitors for electrolyte leaks and deformation. 	 Retighten. Olfactory and visual inspection 4) Visual inspection * Judgment on service life using	1), 2), 3), 4) No abnormalities
ing system	Cooling fan	 Check for engagement or abnormal vibration. Check for loose bolts. Check for discoloration caused by overheat. 	 Turn by hand. (Be sure to turn the power OFF beforehand.) Retighten. Visual inspection Judgment on service life using	 Smooth rotation 3) No abnormalities
Coc	Ventilation path	Check the heat sink, intake and exhaust ports for clogging and foreign materials.	Visual inspection	No clogging or accumulation of dust, dirt or foreign materials. Clean it, if any, with a vacuum cleaner.

Table 7.3-1 Periodic Inspection List 1

7.3.2 Periodic inspection 2--When the inverter is ON or it is running

Visually inspect the inverter for operation errors from the outside without removing the covers when the inverter is ON or it is running.

Perform periodic inspections according to the items listed in Table 7.3-2

Check part		Check item	How to inspect	Evaluation criteria
Input voltage		Check that the input voltages of the main and control circuits are correct.	Measure the input voltages using a multimeter or the like.	The standard specifications must be satisfied.
Structure such as chassis and covers		Check for abnormal noise or excessive vibration when the inverter is running.	Visual and auditory inspections	No abnormalities
	Transformer s and reactors	Check for abnormal roaring noise or odor when the inverter is running.	Auditory, visual, and olfactory inspections	No abnormalities
n circuit	Magnetic contactors and relays	Check for chatters when the inverter is running.	Auditory inspection	No abnormalities
Mai	DC link bus capacitor	Measure the capacitance if necessary.	Judgment on service life using "Menu #5 Maintenance Information $(\underline{5}.\underline{\Gamma}.\underline{h}\underline{\Gamma}$)" in Chapter 3, Section 3.4.5.	Capacitance ≥ Initial value x 0.85
Cooling fans		Check for abnormal noise or excessive vibration when the inverter is running.	Visual and auditory inspections	No abnormalities

Table 7.3-2 Periodic Inspection List 2

Additional notes

- (1) The inspection interval (every year) of check items given in Table 7.3-1 and Table 7.3-2 is merely a guide. Make the interval shorter depending on the usage environment.
- (2) Store and organize the inspection results to utilize them as a guide for operation and maintenance of the equipment and service life estimation.
- (3) At the time of an inspection, check the cumulative run times on the keypad to utilize them as a guide for replacement of parts. Refer to "7.4.1 Judgment on service life".
- (4) The inverter has cooling fans inside to ventilate itself for discharging the heat generated by the power converter section. This will accumulate dust or dirt on the heat sink depending on the ambient environment. In a dusty environment, the heat sink requires cleaning in a shorter interval than that specified in periodic inspection. Neglecting cleaning of the heat sink can rise its temperature, activating protective circuits to lead to an abrupt shutdown or causing the temperature rise of the surrounding electronic devices to adversely affect their service life.

7.4 List of Periodic Replacement Parts

Each part of the inverter has its own service life that will vary according to the environmental and operating conditions. It is recommended that the following parts be replaced at the specified intervals.

When the replacement is necessary, consult your Fuji Electric representative.

Table 7.4-1 Replacement Parts

Part name	Standard replacement intervals (See Note below.)
DC link bus capacitor	10 years
Electrolytic capacitors on printed circuit boards	10 years
Cooling fans	10 years
Fuses	10 years

Note. These replacement intervals are based on the inverter's service life estimated at a surrounding temperature of 40°C at 80% of full load. In environments with an ambient temperature above 40°C or a large amount of dust or dirt, the replacement intervals may be shorter.

Notes for periodic replacement of parts

- (1) The replacement intervals listed above are a guide for almost preventing parts from failure if those parts are replaced with new ones at the intervals. They do not guarantee the completely fault-free operation.
- (2) Table 7.4-1 does not apply to unused spare parts being kept in storage.

It applies only when they are stored under the temporary and long-term storage conditions given in Chapter 1 "1.3.2 Storage environment" and energized approximately once a year.

(3) Cooling fans can be replaced by users. As for other parts, only the persons who have finished the Fuji Electric training course can replace them. For the purchase of spare cooling fans and the request for replacement of other parts, contact the sales agent where you purchased the product or your nearest Fuji Electric representative.

7.4.1 Judgment on service life

The inverter has the life prediction function for some parts which measures the discharging time or counts the voltage applied time, etc. The function allows you to monitor the current lifetime state on the LED monitor and judge whether those parts are approaching the end of their service life.

The life prediction function can also issue early warning signals if the life time alarm command *LIFE* is assigned to any of the digital output terminals. Refer to Chapter 3 "3.4.5 Reading maintenance information "Maintenance Information: $5.2h^{2}$ ".

Table 7.4-2 lists the parts whose service life can be predicted and details the life prediction function. The predicted values should be used only as a guide since the actual service life is influenced by the ambient temperature and other usage environments.

Object of life	Prediction function	End-of-life criteria	Prediction	"5: MAINTENANCE"
DC link bus capacitor	Measurement of discharging time Measures the discharging time of the DC link bus capacitor when the main power is shut down and calculates the capacitance.	85% or lower of the initial capacitance at shipment	At periodic inspection (H98: Bit 3 = 0)	<i>5_05</i> (Capacity)
		85% or lower of the reference capacitance under ordinary operating conditions at the user site	During ordinary operation (H98: Bit 3 = 1)	<i>5_05</i> (Capacity)
	ON-time counting Counts the time elapsed when the voltage is applied to the DC link bus capacitor, while correcting it according to the capacitance measured above.	Exceeding 87,600 hours (10 years)	During ordinary operation	$5_2 = 25$ (Elapsed time) $5_2 = 27$ (Time remaining before the end of life)
Electrolytic capacitors on printed circuit boards	Counts the time elapsed when the voltage is applied to the capacitors, while correcting it according to the surrounding temperature.	Exceeding 87,600 hours (10 years)	During ordinary operation	<i>5_06</i> (Cumulative run time)
Cooling fans	Counts the run time of the cooling fans.	Exceeding 87,600 hours (10 years)	During ordinary operation	<i>5_07</i> (Cumulative run time)

Table 7.4-2 Lif	e Prediction
-----------------	--------------

The service life of the DC link bus capacitor can be judged by the "<u>Measurement of discharging time of the DC link</u> <u>bus capacitor</u>" or "<u>ON-time counting of DC link bus capacitor</u>."

Measurement of discharging time of the DC link bus capacitor

The discharging time of the DC link bus capacitor depends largely on the inverter's internal load conditions, e.g. options attached or ON/OFF status of digital I/O signals. If actual load conditions are so different from the ones at which the initial/reference capacitance is measured that the measurement result falls out of the accuracy level required, then the inverter does not measure.

When the inverter is connected with a converter or with another inverter via DC common connection, it does not performs any measurement.

- The capacitance measuring conditions at shipment are drastically restricted, e.g., all input terminals being OFF in order to stabilize the load and measure the capacitance accurately. Those conditions are, therefore, different from the actual operating conditions in almost all cases. If the actual operating conditions are the same as those at shipment, shutting down the inverter power automatically measures the discharging time; however, if they are different, no automatic measurement is performed. To perform it, put those conditions back to the factory default ones and shut down the inverter. Refer to 7.4.1 [1] Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment on page 7-7.
- To measure the capacitance of the DC link bus capacitor *under ordinary operating conditions* when the power is turned OFF, it is necessary to set up the load conditions for ordinary operation and measure the reference capacitance (initial setting) when the inverter is introduced. For the reference capacitance setup procedure, see
 [2] on page7-8 Performing the setup procedure automatically detects and saves the measuring conditions of the DC link bus capacitor.

Setting bit 3 of H98 data at "0" restores the inverter to the measurement in comparison with the initial capacitance measured at shipment.

When the inverter uses an auxiliary control power input, the load conditions widely differ so that the discharging time cannot be accurately measured. In this case, measuring of the discharging time can be disabled with the function code H98 (Bit 4 = 0) for preventing unintended measuring.

ON-time counting of DC link bus capacitor

In a machine system where the inverter main power is rarely shut down, the inverter does not measure the discharging time. For this case, the ON-time counting is provided. The ON-time counting result can be represented as "elapsed time" (5_25) and "time remaining before the end of life" (5_27) as shown in the "DC link bus capacitor" section in Table 7.4-2.

[1] Measuring the capacitance of DC link bus capacitor in comparison with initial one at shipment

The measuring procedure given below measures the capacitance of DC link bus capacitor <u>in comparison with initial</u> <u>one at shipment</u> when the power is turned OFF. The measuring result can be displayed on the keypad as a ratio (%) to the initial capacitance.

----- Capacitance measuring procedure -----

- 1) To ensure validity in the comparative measurement, put the condition of the inverter back to the state at factory shipment.
 - Remove the option card (if already in use) from the inverter.
 - In case another inverter is connected via the DC link bus to the P(+) and N(-) terminals of the main circuit, disconnect the wires. It is not required to disconnect the DC reactor (optional), if any.
 - Disconnect power wires for the auxiliary input to the control circuit (R0, T0).
 - Mount the keypad.
 - Turn OFF all the digital input signals fed to terminals [FWD], [REV], and [X1] through [X5] of the control circuit.
 - If an external speed command potentiometer is connected to terminal [13], disconnect it.
 - If an external apparatus is attached to terminal [PLC], disconnect it.
 - Ensure that transistor outputs [Y1], [Y2], [Y3], and Relay output terminals [Y5A/C], [30A/B/C] will not be turned ON.
 - Disable the RS-485 communications link.

Note If negative logic is specified for the transistor output and relay output signals, they are considered ON when the inverter is not running. Specify positive logic for them.

- 2) Turn ON the main circuit power.
- 3) Confirm that the DC cooling fan is rotating and the inverter is in stopped state. Disable the cooling fan ON/OFF control (H06 = 0).
- 4) Shut down the main circuit power.
- 5) The inverter automatically starts the measurement of the capacitance of the DC link bus capacitor.

Note If "...." does not appear on the LED monitor, the measurement has not started. Check the conditions listed in 1).

- 6) After "...." has disappeared from the LED monitor, turn ON the main circuit power again.
- 7) Select Menu #5 "Maintenance Information" in Programming mode and check the capacitance (%) of the DC link bus capacitor (5_{-} 3_{-}).

[2] Measuring the capacitance of the DC link bus capacitor under ordinary operating conditions

The inverter automatically measures the capacitance of the DC link bus capacitor <u>under ordinary operating</u> <u>conditions</u> when the power is turned OFF. This measurement requires setting up the load conditions for ordinary operation and measuring the reference capacitance when the inverter is introduced to the practical operation, using the setup procedure given below

1) Set bit 3 of function code H98 at "1" (User mode) to enable the user to specify the judgment criteria for the

- service life of the DC link bus capacitor.
- 2) Turn OFF all run commands.
- 3) Make the inverter ready to be turned OFF under ordinary operating conditions.
- 4) Set each of function codes H42 (Capacitance of DC link bus capacitor) and H47 (Initial capacitance of DC link bus capacitor) at "
- 5) Turn OFF the inverter, and the following operations are automatically performed.

The inverter measures the discharging time of the DC link bus capacitor and saves the result in function code H47 (Initial capacitance of DC link bus capacitor).

The conditions under which the measurement has been conducted will be automatically collected and saved.

6) Turn ON the inverter again.

Confirm that H47 (Initial capacitance of DC link bus capacitor) holds right values. Switch to Menu #5 "Maintenance Information" in Programming mode and confirm that the main capacitor capacity is 100% ($5_{-}25$ = 100%).

Note If the measurement has failed, "CDC /" is entered into each of H42 and H47. Remove the cause of the failure and conduct the measurement again.

Hereafter, each time the inverter is turned OFF, it automatically measures the discharging time of the DC link bus capacitor if the above conditions are met. Periodically check the capacitance (%) of the DC link bus capacitor ($\frac{1}{2}\sqrt{2}$) with Menu #5 "Maintenance Information" in Programming mode.

Note The condition given above produces a rather large measurement error. If this mode gives you a lifetime alarm, revert bit 3 of H98 (Main circuit capacitor life judgment selection) to the default setting (Bit 3 = 0) and conduct the measurement under the condition at the time of factory shipment.

[3] Early warning of lifetime alarm

For the components listed in Table 7.4-2, the inverter can issue an early warning of lifetime alarm LIFE at one of the transistor output terminals [Y1],[Y2],[Y3] and Relay output terminals [Y5A/C][30A/B/C] as soon as any one of the levels specified in Table 7.4-2 has been exceeded.

The early warning signal is also turned ON when a lock condition on the internal air circulation DC fan (provided on FRN0176F2E-4G or above) has been detected.

7.5 Measurement of Electrical Amounts in Main Circuit

Because the voltage and current of the power supply (input, primary circuit) of the main circuit of the inverter and those of the motor (output, secondary circuit) contain harmonic components, the readings may vary with the type of the meter. Use meters indicated in Table 7.5-1 when measuring main circuit.

The power factor cannot be measured by a commercially available power-factor meter that measures the phase difference between the voltage and current. To obtain the power factor, measure the power, voltage and current on each of the input and output sides and use the following formula.

Three-phase input

Power factor = $\frac{\text{Electricpower}(W)}{\sqrt{3} \times \text{Voltage}(V) \times \text{Current}(A)} \times 100\%$

ltem	Input (primary) side			Output (secondary) side			DC link bus voltage (P(+)-N(-))		
Waveform	Voltage	Curren							
Name of meter	Ammeter AR, AS, AT	Voltmeter VR, VS, VT	Wattmeter WR, WT	Ammeter AU, AV, AW	Voltmeter VU, VV, VW	Wattmeter WU, WW	DC voltmeter V		
Type of meter	Moving iron type	Rectifier or moving iron type	Digital AC power meter	Digital AC power meter	Digital AC power meter	Digital AC power meter	Moving coil type		
Symbol of meter	₩	\mathbb{W}	_				Â		

Table 7.5-1 Meters for Measurement of Main Circuit

Note It is not recommended that meters other than a digital AC power meter be used for measuring the output voltage or output current since they may cause larger measurement errors or, in the worst case, they may be damaged.



Figure 7.5-1 Connection of Meters

7.6 Insulation Test

Since the inverter has undergone an insulation test before shipment, avoid making a Megger test at the customer's site.

If a Megger test is unavoidable for the main circuit, observe the following instructions; otherwise, the inverter may be damaged.

A withstand voltage test may also damage the inverter if the test procedure is wrong. When the withstand voltage test is necessary, consult your Fuji Electric representative.

(1) Megger test of main circuit

1) Use a 500 VDC Megger and ensure that the main power has been shut off before measurement.

2) If the test voltage leaks to the control circuit due to the wiring, disconnect all the wiring from the control circuit.

3) Connect the main circuit terminals with a common line as shown in Figure 7.6-1.

- 4) The Megger test must be limited to across the common line of the main circuit and the ground ().
- 5) Value of 5 M Ω or more displayed on the Megger indicates a correct state. (The value is measured on the inverter alone.)



Figure 7.6-1 Main Circuit Terminal Connection for Megger Test

(2) Insulation test of control circuit

Do not make a Megger test or withstand voltage test for the control circuit. Use a high resistance range tester for the control circuit.

1) Disconnect all the external wiring from the control circuit terminals.

2) Perform a continuity test to the ground. One M Ω or a larger measurement indicates a correct state.

(3) Insulation test of external main circuit and sequence control circuit

Disconnect all the wiring connected to the inverter so that the test voltage is not applied to the inverter.

7.7 Inquiries about Product and Guarantee

7.7.1 When making an inquiry

Upon breakage of the product, uncertainties, failure or inquiries, inform your Fuji Electric representative of the following information.

- 1) Inverter type. Refer to Chapter 1 "1.1 Acceptance Inspection (Nameplates and Inverter Type)".
- 2) SER No. (serial number of equipment). Refer to Chapter 1 "1.1 Acceptance Inspection (Nameplates and Inverter Type)".
- 3) Function codes and their data that you changed. Refer to Chapter 3 "3.4.2 Checking changed function codes "Data Checking: 2,-EP "".
- 5) Date of purchase
- Inquiries (for example, point and extent of breakage, uncertainties, failure phenomena, and other circumstances)

7.7.2 Product warranty

To all our customers who purchase Fuji Electric products included in this documentation:

Please take the following items into consideration when placing your order.

When requesting an estimate and placing your orders for the products included in these materials, please be aware that any items such as specifications which are not specifically mentioned in the contract, catalog, specifications or other materials will be as mentioned below.

In addition, the products included in these materials are limited in the use they are put to and the place where they can be used, etc., and may require periodic inspection. Please confirm these points with your sales representative or directly with this company.

Furthermore, regarding purchased products and delivered products, we request that you take adequate consideration of the necessity of rapid receiving inspections and of product management and maintenance even before receiving your products.

[1] Free of charge warranty period and warranty range

(1) Free of charge warranty period

- 1) The product warranty period is "1 year from the date of purchase" or 24 months from the manufacturing date imprinted on the name place, whichever date is earlier.
- 2) However, in cases where the use environment, conditions of use, use frequency and times used, etc., have an effect on product life, this warranty period may not apply.
- 3) Furthermore, the warranty period for parts restored by Fuji Electric's Service Department is "6 months from the date that repairs are completed."

(2) Warranty range

- In the event that breakdown occurs during the product's warranty period which is the responsibility of Fuji Electric, Fuji Electric will replace or repair the part of the product that has broken down free of charge at the place where the product was purchased or where it was delivered. However, if the following cases are applicable, the terms of this warranty may not apply.
 - ① The breakdown was caused by inappropriate conditions, environment, handling or use methods, etc. which are not specified in the catalog, operation manual, specifications or other relevant documents.
 - ^② The breakdown was caused by the product other than the purchased or delivered Fuji's product.
 - ③ The breakdown was caused by the product other than Fuji's product, such as the customer's equipment or software design, etc.
 - ④ Concerning the Fuji's programmable products, the breakdown was caused by a program other than a program supplied by this company, or the results from using such a program.
 - © The breakdown was caused by disassembly, modifications or repairs affected by a party other than Fuji Electric.
 - ⑥ The breakdown was caused by improper maintenance or replacement using consumables, etc. specified in the operation manual or catalog, etc.

- ⑦ The breakdown was caused by a science or technical problem that was not foreseen when making practical application of the product at the time it was purchased or delivered.
- In the product was not used in the manner the product was originally intended to be used.
- In the breakdown was caused by a reason which is not this company's responsibility, such as lightning or other disaster.
- 2) Furthermore, the warranty specified herein shall be limited to the purchased or delivered product alone.
- 3) The upper limit for the warranty range shall be as specified in item (1) above and any damages (damage to or loss of machinery or equipment, or lost profits from the same, etc.) consequent to or resulting from breakdown of the purchased or delivered product shall be excluded from coverage by this warranty.

(3) Trouble diagnosis

As a rule, the customer is requested to carry out a preliminary trouble diagnosis. However, at the customer's request, this company or its service network can perform the trouble diagnosis on a chargeable basis. In this case, the customer is asked to assume the burden for charges levied in accordance with this company's fee schedule.

[2] Exclusion of liability for loss of opportunity, etc.

Regardless of whether a breakdown occurs during or after the free of charge warranty period, this company shall not be liable for any loss of opportunity, loss of profits, or damages arising from special circumstances, secondary damages, accident compensation to another company, or damages to products other than this company's products, whether foreseen or not by this company, which this company is not be responsible for causing.

[3] Repair period after production stop, spare parts supply period (holding period)

Concerning models (products) which have gone out of production, this company will perform repairs for a period of 7 years after production stop, counting from the month and year when the production stop occurs. In addition, we will continue to supply the spare parts required for repairs for a period of 7 years, counting from the month and year when the production stop occurs. However, if it is estimated that the life cycle of certain electronic and other parts is short and it will be difficult to procure or produce those parts, there may be cases where it is difficult to provide repairs or supply spare parts even within this 7-year period. For details, please confirm at our company's business office or our service office.

[4] Transfer rights

In the case of standard products which do not include settings or adjustments in an application program, the products shall be transported to and transferred to the customer and this company shall not be responsible for local adjustments or trial operation.

[5] Service contents

The cost of purchased and delivered products does not include the cost of dispatching engineers or service costs. Depending on the request, these can be discussed separately.

[6] Applicable scope of service

Above contents shall be assumed to apply to transactions and use of the country where you purchased the products.

Consult the local supplier or Fuji for details separately.

Chapter 8 BLOCK DIAGRAMS FOR CONTROL LOGIC

This chapter describes the main block diagrams of the control section.

Contents

8.1	Meanings of Symbols Used in the Control Block Diagrams					
8.2	Frequency Setting Section 8-2					
8.3	Operation Command Section ····· 8-5					
8.4	PID Control Section (for Processing) ······ 8-6					
8.5	9-7 PID Control Section (External PID) ······ 8-7					
8.6	Control Section ······	3-8				
8.6	.1 V/f control ······ 8	3-8				
[1] Common	3-8				
[2] V/f Control	3-9				
8.6	.2 Vector Control8-	·10				
[1] Common8-	·10				
[2] Torque limit ······8-	·10				
[3] Speed limit and Over speed protection processing ······8·	-11				
[4] For PMSM8-	·12				
8.7	FM Output Section8-	·14				

The FRENIC-eHVAC is provided with various functions that allow operations to meet the application requirements. Refer to Chapter 5 "FUNCTION CODES" for details of each function code.

Function codes are mutually related and priority order is given depending on the function codes and data thereof.

This chapter shows major internal control block diagrams. Understand the diagrams together with the explanation of each function code to correctly set up each function code.

Note that the internal control block diagrams show only the function codes mutually related. Refer to Chapter 5 "FUNCTION CODES" for function codes operated individually and each function code explanation.

8.1 Meanings of Symbols Used in the Control Block Diagrams

This section explains major codes, with examples, used in the block diagrams from the next item.

Table 8.1-1 Codes and Meanings

Symbol	Meaning	Symbol	Meaning
[FWD], [Y1], etc.	These symbols denote general-purpose input/output terminals of the inverter control circuit terminal blocks.	(F01)	This denotes a function code.
"FWD", "REV", etc.	These symbols denote control signals (input) or state signals (output) allocated to the control circuit terminals.		This indicates a switch controlled by a function code.
	This is low-pass filter. Time constant is changeable based on function code data.		indicate function code data.
SET FREQUENCY	This symbol denotes control command used inside the inverter.	LINK OPERATION SELECTION "LE"	This indicates a switch controlled by an internal function control command. An
(F15)	This indicates upper limit limiter. This limits an upper limit value by function code setting or a constant.		example at left indicates a link operation selection command "LE" allocated to a digital input terminal.
F16	This indicates lower limit limiter. This limits a lower limit value by function code setting or a constant.	A C	This denotes a logical sum (OR) circuit. In the case of the positive logic, when any one of inputs is ON, C=ON, and when all inputs are OFF, C=OFF.
" ₀ "	This is 0 (zero) limiter. This prevents data from becoming minus.	A c	This denotes an NOR (NOR-OR) circuit. In the case of the positive logic, when any one of inputs is OFF, C=ON, and when all inputs are ON, C=OFF.
	This denotes a set frequency given by a current or a voltage. This is a gain analog multiplier for an analog output signal etc., calculated by C=A×B.	A C	This denotes a conjunction (AND) circuit. In the case of the positive logic, only when A=ON and B=ON, C=ON, and C=OFF under other conditions.
$A \xrightarrow{+} C$ $B \xrightarrow{+} C$	This denotes an adder of two signals or amounts, calculated by C=A+B. This becomes a subtracter when B is a minus sign, calculated by C=A-B.	A B	This denotes a logical negation (NOT) circuit. In the case of the positive logic, when A=ON, B=OFF, and when A=OFF, B=ON.



8.2 Frequency Setting Section





Figure 8.2-2 Frequency Setting Section Block Diagram

BLOCK DIAGRAMS FOR CONTROL LOGIC

Chap 8

8-3



Figure 8.2-3 Frequency Setting Section Block Diagram



Qi -π

REV only

t

Hold in rotating direction

N

WD only

Standard keypad

Gors

8.3

Operation/Control

JOG operation possible Self-holding selection state (hold prohibited) "HLD"

Multifunctional keypad (Available soon)

0

FWD/REV

1

PIOH

STOP (RV (RV)

Figure 8.3-1 Operation Command Section Block Diagram

Bit 0

PIOH

Forward run/stop command "FWD" Reverse run/stop command "REV"

Bit 1 Bit 2 Bit 3 Bit 4 Bit 5 Bit 6 Bit 7 Bit 8 Bit 9

RS-485 communications port 1 keypad connection

Host equipment

8-5

: Not assigned. (Outputs the value of the assigned bit.)

"REV"

rocessor *1 "REV"

ON with E99 = 99

ON with E99 = 98

ა የ ს ბ

NO 5FF

OFF OFF N OFF NO E S

NO OFF

OFF OFF OFF OFF

"FWD"

"FWD" scess

ON with E98 = 98 ON with E98 = 99

Fixed to 0 Fixed to 0 Fixed to 0

Trailor priority

Bit 10 Bit 11

1

RS-485 communication port 2 terminal block

Host equipment

Q q

XFIFWD

Bit 12 Bit 13 Bit 14 Bit 15

Field bus card (optional)*2

Host equipment

(RIRE)

RSI



Figure 8.4-1 PID Control Section (For Processing) Block Diagram



Figure 8.5-1 PID Control Section (External PID) Block Diagram

PID Control Section (External PID)

8.5

8.6 Control Section

8.6.1 V/f control

[1] Common





[2] V/f Control



Figure 8.6-2 V/f Control Section Block Diagram

8.6.2 Vector Control

[1] Common



Figure 8.6-3 Vector Control (Common) Section Block Diagram

[2] Torque limit



Figure 8.6-4 Vector Control (Torque limit) Section Block Diagram



[3] Speed limit and Over speed protection processing

Figure 8.6-5 Vector Control (Speed limit (OS processing)) Section Block Diagram

[4] For PMSM



Figure 8.6-6 Vector Control (For PMSM) Section Block Diagram


Figure 8.6-7 Vector Control (For PMSM) Section Block Diagram

8.7 FM Output Section



Figure 8.7-1 FM Output Section Block Diagram

Chapter 9 COMMUNICATION FUNCTIONS

This chapter describes an overview of inverter operation through the RS-485. For details of RS-485 communication, refer to the RS-485 Communication User's Manual.

Contents

9.1 O	verview of RS-485 Communication ·····	
9.1.1	RS-485 common specifications ·····	
9.1.2	Terminal specifications	
[1]	RS-485 communication port 1 (for connecting the keypad)	
[2]	RS-485 communication port 2 (terminal block)	
9.1.3	Connection method	
9.1.4	RS-485 connection devices ·····	
[1]	Converter	
[2]	Requirements for the cable (COM port 1: for RJ-45 connector)	
[3]	Requirements for the cable (COM port 2: for RS-485 connector) ·····	
[4]	Branch adapter for multi-drop	
9.1.5	RS-485 noise suppression ·····	
9.2 FI	RENIC Loader Overview	
9.2.1	Modes·····	
9.2.2	Connection	
9.2.3	Function overview ·····	
[1]	Configuring inverter's function code	
[2]	Multi-monitor ·····	
[3]	Running status monitor	9-11
[4]	Test-running ·····	
[5]	Real-time trace	
[6]	Historical trace	

9.1 Overview of RS-485 Communication

The FRENIC-eHVAC has two RS-485 communication ports at the locations shown below.

- (i) Communication port 1: RJ-45 connector for the keypad (modular jack)
- (ii) Communication port 2: RS-485 terminals (control circuit terminals DX-, DX+)



Using the RS-485 communication ports shown above enables the extended functions listed below.

- Remote operation from a keypad at the remote location (COM port 1) The standard keypad enables remote operation by mounting the keypad on a remote panel and connecting the keypad to RJ-45 connector with an extension cable. (maximum cable length: 20 m)
- Operation by FRENIC Loader (COM ports 1 and 2) It is possible to edit and monitor the function codes by connecting the RJ-45 connector (RS-485 communication) in the inverter and PC and using the inverter support loader (FRENIC Loader, see "9.2 FRENIC Loader Overview").
- Control via host equipment (COM ports 1 and 2)
 Connecting the inverter to the host equipment (upper controller), such as a computer and programmable controller (PLC), enables to control the inverter as a subordinate device.

Besides the communication port 1 (RJ-45 connector) shared with the keypad, the FRENIC-eHVAC has the RS-485 communication port 2 by default.

The protocols for controlling inverters support the Modbus RTU protocol (compliant to the protocol established by Modicon Inc.) that is widely used and the Fuji Electric's general-purpose inverter protocol that is common to Fuji Electric's inverters including conventional series.

- Note Connecting the keypad to the COM port 1 automatically switches to the keypad protocol; there is no need to modify the function code setting.
 - When using FRENIC Loader, which requires a special protocol for handling Loader commands, you need to set up some communication function codes accordingly.

For details, refer to the FRENIC Loader Instruction Manual.

For details of RS-485 communication, refer to the RS-485 Communication User's Manual.

Item	Specifications				
Protocol	FGI-BUS	Modbus RTU	FRENIC Loader	Metasys N2	BACnet
			(support only for standard)		
Compliance	Fuji general-purpose inverter protocol	Modicon Modbus RTU-compliant (only in RTU mode)	Dedicated protocol (Not disclosed)	Jonson control N2 prtocol	ASHRAE/ANSI /ISO-compliant
Connection quantity	Host device: 1, In	verters: Up to 31			
Electrical mode	EIA RS-485				
Connection to RS-485	RJ-45 connector	or terminal block			
Synchronization	Asynchronous				
Communication system	Half-duplex				
Transmission speed (bps)	2400, 4800, 9600	, 19200 and 38400	bps	9600 bps	9600, 19200 and 38400 bps
Max. transmission cable length	500 m (1640 ft)				
Station No.	1 to 31	1 to 247	1 to 255	0 to 255	0 to 127
Message frame format	FGI-BUS	Modbus RTU	FRENIC Loader	Metasys N2	MS/TP frame format
Frame synchronization	Header character detection (SOH)	Detection of no-data time (for 3 characters period)	Header character detection (Start code: 96 _H)	Header character detection (Start code: 3E _H)	Detection of two header characters (preamble) $(0 \times 55, 0 \times FF)$
Frame length	Normal transmission: 16 bytes (fixed) High-speed transmission: 8 or 12 bytes	Variable length	Variable length	Variable length	Variable length
Max. transfer	Write: 1 word	Write: 100 words	Write: 41 words	Write: 1 words	Write: 50 words
data	Read: 1 word	Read: 100 words	Read: 41 words	Read: 1 words	Read: 50 words
Messaging system	Polling/Selecting/Broadcast		Command message	Polling/Selecting	Polling/Selecting /Broadcast
Transmission character format	ASCII	Binary	Binary	ASCII	Binary *Data of character string read: ASCII
Character length	8 or 7 bit Selectable with the function code	8 bits (fixed)	8 bits (fixed)	8 bits (fixed)	8 bits (fixed)
Parity	Even, Odd, or No the function code	ne (selectable by)	Even (fixed)	None	None
Stop bit length	1 or 2 bit Selectable with the function code	Parity none: 2/1 bit Parity: 1 bit Select by parity setting.	1 bit (fixed)	1 bit (fixed)	1 bit (fixed)
Error checking	Sum-check	CRC-16	Sum-check	Sum-check	Header CRC Data CRC

9.1.1 RS-485 common specifications

9.1.2 Terminal specifications

[1] RS-485 communication port 1 (for connecting the keypad)

The port designed for a standard keypad uses an RJ-45 connector having the following pin assignment:

Pin	Signal name	Description
1	Vcc	Power source for the keypad (5 V)
2	GND	Ground signal
3	NC	Not connected
4	DX-	RS-485 signal, low side *2
5	DX+	RS-485 signal, high side *2
6	NC	Not connected
7	GND	Ground signal
8	Vcc	Power source for the keypad (5 V)



* The terminating resistor 112 Ω is built in. Open/close with SW2. * For details about SW6, refer to Chapter 2, "2.2.8 Operating slide switches."

Note The power supply for keypad is available in the RJ-45 connector for RS-485 communication (Pins 1, 2, 7, and 8). When connecting other devices to the RJ-45 connector, take care not to use those pins. Use pins <u>4 and 5 only</u>.

[2] RS-485 communication port 2 (terminal block)

Terminal symbol	Description	Remarks
DX-	RS-485 signal, low side	Built-in terminating resistor: 112 Ω
DX+	RS-485 signal, high side	Open/close with SW6*



* The terminating resistor 112 Ω is built in. Open/close with SW6. * For details about SW6, refer to Chapter 2, "2.4.2 Setting up the slide switches."

9.1.3 Connection method

- · Up to 31 inverters can be connected to one host equipment.
- The protocol is commonly used in the FRENIC series of general-purpose inverters, so programs for similar host equipment can run/stop the inverter. (The parameters modes may differ depending on the equipment.)
- Fixed-length transmission frames facilitate developing communication control programs for hosts.

For details of RS-485 communication, refer to the RS-485 Communication User's Manual.

Multi-drop connection using the RS-485 communication port 1 (for connecting the keypad)

For connecting inverters in multi-drop connection, use the branch adapters for multi-drop connection as shown below.



Figure 9.1-1 Multi-drop Connection for RS-485 Communication Port 1 (Using the RJ-45 Connector)

- Note
 The power supply for keypad is available in the RJ-45 connector for RS-485 communication (COM port 1) (pins 1, 2, 7 and 8). When connecting other devices to the RJ-45 connector, take care not to use those pins. Use pins <u>4 and 5 only</u>. (refer to "9.1.2 Terminal specifications")
 - When selecting additional devices to prevent the damage or malfunction of the control PCB caused by external noises or eliminate the influence of common mode noises, be sure to see "9.1.4 RS-485 connection devices."
 - The maximum wiring length must be 500 m.
 - Use the cables and converters meeting the modes for connecting the RS-485 communication ports. (Refer to "[2] Requirements for the cable (COM port 1: for RJ-45 connector)" in "9.1.4 RS-485 connection devices")

Multi-drop connection using the RS-485 communication port 2 (on the terminal block)



Figure 9.1-2 Multi-drop Connection Diagram (Connecting to the Terminal Block)



Use the cables and converters meeting the modes for connecting the RS-485 communication ports. (Refer to "[3] Requirements for the cable (COM port 2: for RS-485 connector)" in "9.1.4 RS-485 connection devices.")

9.1.4 **RS-485** connection devices

This section describes the devices required for connecting the inverter to a PC having no RS-485 interface or for connecting two or more inverters in multi-drop network.

[1] Converter

In general, PC is not equipped with an RS-485 port. Therefore, an RS-232C-RS-485 or USB-RS-485 converter is required. To use the equipment properly, be sure to use the converter which meets the mode below. Be careful that a converter not recommended may not work properly.

Requirements for recommended converters

Send/receive switching system:	Auto-switching by monitoring the transmission data at PC (RS-232C)
Electric isolation:	Electrically isolated from the RS-485 port
Fail-safe:	Fail-safe facility (*)
Other requirements:	Superior noise immunity

Note: The fail-safe function refers to a feature that ensures the RS-485 receiver's output is at "logic high" even if the RS-485 receiver's input is opened or short-circuited or all the RS-485 drivers are inactive. (Refer to "Figure 9.1-3 Communication Level Conversion".)

Recommended converters

System Sacom Sales Corporation (Japan) : KS-485PTI (RS-232C-RS-485 converter) : USB-485I RJ45-T4P (USB-RS-485 converter)

Send/receive switching system

The RS-485 communication system of the inverter acts in half-duplex mode (2-wire), so the converter must have a send/receive switching function. Generally, the switching system may be either one of the followings.

- (1) Auto-switching by monitoring the transmitted data
- Switching by RS-232C control signal (RTS or DTR) from the computer (2)



RS-232C-RS-485 converter

FRENIC-eHVAC (two-wire system)

Figure 9.1-3 Communication Level Conversion

[2] Requirements for the cable (COM port 1: for RJ-45 connector)

Use a standard 10BASE-T/100BASE-TX LAN cable (US ANSI/TIA/EIA-568A category 5 compliant, straight cable).

Note The power supply for keypad is available in the RJ-45 connector for RS-485 communication (COM port 1) (pins 1, 2, 7 and 8). When connecting other devices to the RJ-45 connector, take care not to use those pins. Use pins <u>4 and 5 only</u>.

[3] Requirements for the cable (COM port 2: for RS-485 connector)

To ensure the reliability of connection, use twisted pair shield cables for long distance transmission AWG 16 to 26.

Recommended LAN cable manufacturer:

FURUKAWA Electric Co., LTD AWM2789 cable for long distance connection Type (Product code): DC23225-2PB

[4] Branch adapter for multi-drop

The RJ-45 connector is used as the communication connector. To use a standard LAN cable for multi-drop connection, use the branch adapter for the RJ-45 connector.

Recommended branch adapter

SK Koki (Japan): MS8-BA-JJJ

9.1.5 RS-485 noise suppression

Depending on the operating environment, the malfunction may occur due to the noise generated by the inverter. Possible measures to prevent such malfunction are: separating the wiring, use of shielded cable, isolating the power supply, and adding an inductance component. The description shown below is an example of adding an inductance.

Refer to the RS-485 Communication User's Manual, Chapter 2, Section 2.2.4 "Precautions for long wiring (between inverter and motor)" for details.

Adding inductance components

Keep the impedance of the signal circuit high against the high-frequency noises by inserting an inductance component, such as by inserting a choke coil in series or passing the signal line through a ferrite core.



Figure 9.1-4 Adding an Inductance Component

9.2 FRENIC Loader Overview

FRENIC Loader is a software tool that supports the operation of the inverter via an RS-485 communication.

This software allows you to edit, set, and manage the inverter function codes, monitor running data, and remotely operate the operation and stop, as well as monitor the running status and alarm history.



With special order-made inverters, FRENIC Loader may not be able to display some function codes normally.

For details, refer to the FRENIC Loader Instruction Manual.

9.2.1 Modes

Item		Modes	Remarks
Nam	е	Inverter support loader (FRENIC Loader)	
Supported inverter		FRENIC-MEGA/Multi/VP/Mini/Ace/GX1/HF/ eHVAC	(Note 1)
Number of connected inverters		USB connection: 1 RS-485 connection: Up to 31	
Recommended cable		Cable (10BASE-T or more) compliant with EIA568 RJ-45 connector	For the RS-485 interface
	CPU	Intel Pentium III 600 MHz or later	(Note 2)
onment	OS	Microsoft Windows XP (32 bit) Microsoft Vista (32 bit) Microsoft 7 (32 bit, 64 bit)	(Note 3)
Jvirc	Memory	RAM area with 512 MB or more	1GB or more is recommended.
g ei	Hard disk	40 MB or more of empty area	
Operatin	COM port	RS-232C (conversion to RS-485 communication is required to connect inverters) or USB	
	Monitor	800 x 600 or higher	XGA (1024x768) 32 bit Color or more monitor is recommended.
n requirements	COM port	COM1 to COM255	PC COM ports assigned to Loader
	Transmission speed	USB connection: Between loader and keypad = fixed at 12 Mbps Between keypad and inverter = fixed at 19200 (bps) RS-485 connection: 38400, 19200, 9600, 4800, 2400 (bps)	19200 bps or more is recommended (Note 4)
issio	Character length	8 bit	Prefixed
nsm	Stop bit length	1 bit	Prefixed
Trai	Parity	Even	Prefixed
	No. of retries	None or 1 to 10	No. of retry times before detecting communication error
	Timeout setting	100 ms, 300 ms, 500 ms, 1.0 s to 1.5 s to 1.9 s, 2.0 to 9.0 s, 10.0 to 60.0 s	Set longer than the "Response interval time y09"

Note 1: The loader model is unavailable which does not support the protocol for loader commands (SX protocol).

Note 2: Use a PC with as high a performance as possible, since some slow PCs may not properly refresh the operation monitoring and test-running windows.

Note 3: Only Microsoft Windows XP service pack 2 (SP2) or later is supported.

Note 4: To connect to the network where there is a FRENIC-Mini inverter, choose 19200 bps or below.

9.2.2 Connection

By connecting a number of inverters to one PC, you can control one inverter at a time or a number of inverters simultaneously. You can also simultaneously monitor a number of inverters on the multi monitor.

For information how to connect a PC to one or more inverters, refer to the RS-485 Communication User's Manual (MEH448).

9.2.3 Function overview

[1] Configuring inverter's function code

You can set, edit, and check the setting of the inverter's function code data.

List and Edit

In List and edit, you can list and edit function codes with function code No., name, set value, set range, and factory default.

You can also list function codes by any of the following groups according to your needs:

- Function code group
- Function codes that have been modified from their factory defaults
- · Result of comparison with the settings of the inverter
- Result of search by function code name
- User-specified function code set

etc.

Function	Change Function code No.	Function code name	Setting value Range of setting	Factory setting value	Data cannot change in o	
E Code group	F00	Data protection	0 to 3	0	Enable	
Fcode	* F01	Frequency command 1	1 : Voltag 💌 0 to 12	0	Disable	
Ecode	* F02	Operation method	0 : Up or Down keys on keypad			
Roode	F03	Maximum frequency 1	1 : Voltage input to Terminal [12] (-10	to +10V DC)		
Hcode	F04	Base frequency 1	2 : Current inputto Terminal [C1] (4 to	20mADC)		
Acode	F05	Rated voltage at base freqency 1	3 : Sum of voltage and current inputs	to terminals (12) and (0	C1 (C1 function)	
- bcode	F06	Maximum output voltage 1	7 : Terminal command LIP (DOMN c	ontrol	<i>y</i>	
- rcode	F07	Acceleration time 1	8 : Up or Down keys on keypad			
Jcode	F08	Deceleration time 1	11 :DI option card			
dcode	F09	Torque boost 1	12 : PG/SY card			
ycode	F10	Electronic thermal overload protec	1 1 to 2	1	Enable	
- Change (Factory	F11	Electronic thermal overload protec	2 30 0 00 · 0 01 to 2000 A	2.30	Enable	
- Lontents of chan	F12	Electronic thermal overload protec	Function code information			
User definition	F14	Restart mode after momentary po	F01: Frequency command 1		^	
User definition	F15	Frequency limiter (High)				
User definition	F16	Frequency limiter (Low)	Establishment range: 0 to 12 0 : Up or Down kows on kowpad			
E Code for commur	F18	Bias (Frequency command 1)	1: Voltage input to Terminal [12]	-10 to +10V DC)		
- S code	F20	DC Braking 1 (Braking starting fre	2 : Current inputto Terminal [C1] (4 to 20mA DC)		
- M code	F21	DC Braking 1 (Braking level)	3 : Sum of voltage and current inputs to terminals [12] and [C1] (C1			
- W code	F22	DC Braking 1 (Braking time)	function)			
- X code	F23	Starting frequency 1	 5 : Voltage input to terminal [C1] (7 : Terminal command UD / DOMA 	V2 function) (-10 to 10	VDC)	
∠ code Comparison result	F24	Starting frequency 1 (Holding time	8 Up or Down keys on keynad	Control		
Search result	F25	Stop frequency	11 :DI option card			
	* F26	Motor sound (Carrier frequency)	12 : PG/SY card			
	F 20	Motor sound (Tone)	L			
	<					

Comparison

You can compare the function code data currently being edited with that saved in a file or stored in the inverter.

To perform a comparison and review the result displayed, click the Comparison tab and then click the Compared with inverter tab or click the Compared with file tab, and specify the file name.

The result of the comparison will be displayed also in the Comparison Result column of the list.

File information

Clicking the File information tab displays the property and comments for identifying the function code editing file.

- (1) Property Shows file name, inverter model, inverter's capacity, date of readout, etc.
- (2) Comment

Displays the comments you have entered. You can write any comments necessary for identifying the file.

[2] Multi-monitor

This feature lists the status of all the inverters that are marked "connected" in the configuration table.

Multi-monitor

Allows you to monitor the status of more than one inverter in a list format.

ч 0.	Equipment name	RS485 address	Inverter model name	Capacity	Operation status	Frequency comman	Out
1	INV1	1	G1S 3phase 200V	0.4	FWD	38.84	38.
2	INV2	2	G1S 3phase 200V	0.4	STOP	9.17	0.0
3							
4							
5							
6							
- 7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
	1	1	1		1		

CSV Save Setting..

[3] Running status monitor

The running status monitor offers four monitor functions: I/O monitor, System monitor, Alarm monitor, and Meter display. You can choose an appropriate monitoring format according to the purpose and situation.

0

I/O monitor

Allows you to monitor the ON/OFF states of the digital input signals to the inverter and the transistor output signals.

System monitor

The inverter's system information (version, type, maintenance information, etc.) can be confirmed.

Operation Status Monitor				E 1
0 monitor System monitor Alarm monitor	Meter display			
ROM Ver. Man control CPU	Existing setup Mode Operation order : Speed order : Parameter set : Motor selectors : Motor output :	Exercise input Voltage reput(2) 0 to -10/dc 1 2 3 11 12 102 102 103 104 105 105		
Maintenance information Accumulated operation time (h) Accumulated time of PC board mounted CAI Accumulated operation (num of ocoling (an (1 Accumulated operation (number of times) Accumulated of electric energy (1,00-1004)	P(10h) 9999 10h) 9999 47227 47h) 0.025	Main capacitors (%) Mar RMS current (A) Highest TMP inside INV (deg C) Highest TMP of heat init (deg C) Accumulated of electric energy data	100.0 2.68 39 34 0.000	

Alarm monitor

The alarm monitor shows the alarm status of the selected inverter. In this window you can check the details of the alarm currently active and related information.



Meter display

Displays analog readouts of the selected inverter (such as output frequency) on analog meters. The example on the right displays the reference frequency and the output frequency.



[4] Test-running

The Test-running feature allows you to test-run the motor in the forward or reverse direction while monitoring the running status of the selected inverter.



*: The table below lists the details of the operation buttons.

Button Functionality		
STOP	Stop the motor.	
FWD	The motor runs in the normal rotation. (depressed state indicates running state.)	
REV	The motor runs in the reverse rotation. (depressed state indicates running state.)	
RESET	Reset all alarm information saved in the selected inverter.	

[5] Real-time trace

When continuously observing the running state of inverters while the sampling time can be selected between 1 ms to 200 ms, up to 4 analog channels and up to 8 digital channels are available (up to 8 channels in total).

(Maximum waveform amount: 15360 sample/channel)

Type of trace

Note



- The station No can not be changed while tracing waveforms real time.
- The detailed waveform can not be changed while tracing waveforms real time.
- · Change the real time trace window to change the size of monitor window.
- The scrolling and cursor moving are unavailable in the waveform monitoring window while tracing waveforms real time.

[6] Historical trace

The sampling time can be selected between 1 ms to 200 ms. When observing the running state of inverters in much finer continuous waveforms than real-time trace, up to 4 analog channels and up to 8 digital channels are available (up to 8 channels in total).

• Amount of saved data: 2 kbyte

(Waveform capturing capability: Max. 500 sample/channel)

Type of trace





The station No can not be changed while tracing waveforms historically.

- · The detailed waveform can not be changed while tracing waveforms historically.
- · Change the historical trace window to change the size of monitor window.

Chapter 10 SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES

This chapter provides information about the inverter output torque characteristics, selection procedure, and equations for calculating the capacities, in order to be able to select optimal motor and inverter models. It also helps to select the braking resistors, inverter mode, and motor drive control.

Contents

10.1	Moto	or Output Torque Characteristics	10-1
10.2	Sele	ction Procedure ······	
10.3	Equa	ations for Selections	
10).3.1	Load torque during constant speed running	10-6
[1]	General equation	
[2]	Obtaining the required force F	10-6
10).3.2	Acceleration and deceleration time calculation	10-8
[1]	Calculation of moment of inertia	10-8
[2]	Calculation of the acceleration time	10-10
[3]	Calculation of the deceleration time	10-11
[4]	Calculating non-linear acceleration/deceleration time	10-11
[5]	Calculating non-linear deceleration time	
10).3.3	Heat energy calculation of braking resistor	10-13
[1]	Calculation of regenerative energy	10-13
10).3.4	Calculating the RMS rating of the motor	
10.4	Sele	cting an Inverter Drive Mode ·····	10-15
10).4.1	Precaution in making the selection	10-15

When selecting a general-purpose inverter, first select a motor and then inverter as follows:

- (1) Key point for selecting a motor: Determine what kind of load machine is to be used, calculate its moment of inertia, and then select the appropriate motor capacity.
- (2) Key point for selecting an inverter: Taking into account the operation requirements (e.g., acceleration time, deceleration time, and frequency in operation) of the load machine to be driven by the motor selected in (1) above, calculate the acceleration/deceleration/braking torque.

This section describes the selection procedure for (1) and (2) above. First, it explains the output torque characteristics obtained by using the motor driven by the inverter (FRENIC-eHVAC).

10.1 Motor Output Torque Characteristics

Figure 10.1-1 and Figure 10.1-2 graph the output torque characteristics of motors versus the output frequency for 50 Hz and 60 Hz base frequencies. The horizontal and vertical axes show the output frequency and output torque (%), respectively. Curves (a) through (f) depend on the running conditions.



Figure 10.1-1 Output Torque Characteristics (Base frequency: 50 Hz)





(1) Continuous allowable driving torque

① Standard motor (Curve (a1) in Figure 10.1-1 and Figure 10.1-2)

Curve (a1) shows the torque characteristic that can be obtained in the range of the inverter continuous rated current, where the standard motor's cooling characteristic is taken into consideration. When the motor runs at the base frequency of 60 Hz, 100 % output torque can be obtained; at 50 Hz, the output torque is somewhat lower than that in commercial power, and it further lowers at lower frequencies. The reduction of the output torque at 50 Hz is due to increased loss by inverter driving, and that at lower frequencies is mainly due to heat generation caused by the decreased ventilation performance of the motor cooling fan.

② Motor exclusively designed for vector control (Curve (a2) in Figure 10.1-1 and Figure 10.1-2)

Curve (a2) shows the torque characteristic that can be obtained in the range of the inverter continuous rated current, where the motor exclusively designed for vector control is connected. In the motor exclusively designed for vector control, the attached forced-cooling fan reduces heat generation from the motor, so that the torque does not drop in the low-speed range, compared to the standard motor.

(2) Maximum driving torque in a short time (Curves (b) in Figure 10.1-1 and Figure 10.1-2)

Curve (b) shows the torque characteristic that can be obtained in the range of the inverter overload capability in a short time (120% for 1 minute), the motor cooling characteristics have little effect on the output torque.

(3) Starting torque (around the output frequency 0 Hz in Figure 10.1-1 and Figure 10.1-2)

The maximum torque in a short time applies to the starting torque as it is.

(4) Braking torque (Curves (d) and (e) in Figure 10.1-1 and Figure 10.1-2)

In braking the motor, kinetic energy is converted to electrical energy and regenerated to the DC link bus capacitor (reservoir capacitor) of the inverter. Discharging this electrical energy to the braking resistor produces a large braking torque as shown in curve (e). If no braking resistor is provided, however, only the motor and inverter losses consume the regenerated braking energy so that the torque becomes smaller as shown in curve (d).

When an optional braking resistor is used, the braking torque is allowable only for a short time. Its time ratings are mainly determined by the braking resistor ratings. This manual and associated catalogs list the allowable values (kW) obtained from the average discharging loss and allowable values (kWs) obtained from the discharging capability that can be discharged at one time.

Note that the torque % value varies according to the inverter capacity.

For braking-related values when the inverter and braking resistor are normally combined, refer to Chapter 11 "11.8 Braking Resistors (DBRs) and Braking Units."

10.2 Selection Procedure

Figure 10.2-1 shows the general selection procedure for optimal inverters. Items numbered (1) through (5) are described on the following pages.

You may easily select inverter capacity if there are no restrictions on acceleration and deceleration times. If "there are any restrictions on acceleration or deceleration time" or "acceleration and deceleration are frequent," then the selection procedure is more complex.



Figure 10.2-1 Selection Procedure

(1) Calculating the load torque during constant speed running

(For detailed calculation, refer to Section 10.3.1.)

It is essential to calculate the load torque during constant speed running for all loads.

First calculate the load torque of the motor during constant speed running and then select a tentative capacity so that the continuous rated torque of the motor during constant speed running becomes higher than the load torque. To perform capacity selection efficiently, it is necessary to match the rated speeds (base speeds) of the motor and load. To do this, select an appropriate reduction-gear (mechanical transmission) ratio and the number of motor poles.

If the acceleration or deceleration time is not restricted, the tentative capacity can apply as a defined capacity.

(2) Calculating the acceleration time (For detailed calculation, refer to Section 10.3.2 [2].)

When there are some specified requirements for the acceleration time, calculate it according to the following procedure:

1) Calculate the moment of inertia for the load and motor

Calculate the moment of inertia for the load, referring to "10.3.2 Acceleration and deceleration time calculation." For the moment of inertia for motors, refer to the related motor catalogs.

2) Calculate the minimum acceleration torque (See Figure 10.2-2)

The acceleration torque is the difference between the motor short-time output torque (base frequency: 60 Hz) explained in "10.1 (2) Maximum driving torque in a short time" and the load torque (τ_L / η_G) during constant speed running calculated in the above (1). Calculate the minimum acceleration torque for the whole range of speed.

3) Calculate the acceleration time

Assign the value calculated above to the equation (Equation 10.3-15) in "10.3.2 Acceleration and deceleration time calculation" to calculate the acceleration time. If the calculated acceleration time is longer than the expected time, select the inverter and motor having one class larger capacity and calculate it again.



Figure 10.2-2 Example Study of Minimum Acceleration Torque

(3) Deceleration time (For detailed calculation, refer to Section 10.3.2 [4].)

To calculate the deceleration time, check the motor deceleration torque characteristics for the whole range of speed in the same way as for the acceleration time.

1) Calculate the moment of inertia for the load and motor

Same as for the acceleration time.

2) Calculate the minimum deceleration torque (See Figure 10.2-3 and Figure 10.2-4)

Same as for the deceleration time.

3) Calculate the deceleration time

Assign the value calculated above to the equation (Equation 10.3-16) to calculate the deceleration time in the same way as for the acceleration time. If the calculated deceleration time is longer than the requested time, select the inverter and motor having one class larger capacity and calculate it again.



(4) Braking resistor rating (For detailed calculation, refer to Section 10.3.3.)

Braking resistor rating is classified into two types according to the braking periodic duty cycle.

1) When the periodic duty cycle is 100 seconds or less:

Calculate the average loss to determine rated values.

2) When the periodic duty cycle exceeds 100 seconds:

The allowable braking energy depends on the maximum regenerative braking capacity. The allowable values are listed in Chapter 11 "11.8 Braking Resistors (DBRs) and Braking Units."

(5) Motor RMS current (For detailed calculation, refer to Section 10.3.4 .)

In metal processing machines and materials handling machines requiring positioning control, highly frequent running for a short time is repeated. In this case, calculate the maximum equivalent RMS current value (effective value of current) not to exceed the allowable value (rated current) for the motor.

10.3 **Equations for Selections**

10.3.1 Load torgue during constant speed running

[1] **General equation**

The frictional force acting on a horizontally moved load must be calculated. Calculation for driving a load along a straight line with the motor is shown below.

Where the force to move a load linearly at constant speed v (m/s) is F (N) and the motor speed for driving this is N_M (r/min), the required motor output torque τ_M (N·m) is as follows:

$$\tau_{\rm M} = \frac{60 \cdot \upsilon}{2 \pi \cdot N_{\rm M}} \cdot \frac{F}{\eta_{\rm G}} \quad (N \cdot m) \tag{Equation 10.3-1}$$

where, η_{G} is Reduction-gear efficiency.

When the inverter brakes the motor, efficiency works inversely, so the required motor torque should be calculated as follows:

$$\tau_{\rm M} = \frac{60 \cdot \upsilon}{2 \pi \cdot N_{\rm M}} \cdot F \cdot \eta_{\rm G} \quad (N \cdot m)$$
 (Equation 10.3-2)

 $(60 \cdot \upsilon) / (2\pi \cdot N_M)$ in the above equation is an equivalent turning radius corresponding to speed υ (m/s) around the motor shaft.

The value F (N) in the above equations depends on the load type.

[2] Obtaining the required force F

Moving a load horizontally

A simplified mechanical configuration is assumed as shown in Figure 10.3-1. If the mass of the carrier table is W_0 (kg), the load is W (kg), and the friction coefficient of the ball screw is µ, then the friction force F (N) is expressed as follows, which is equal to a required force for driving the load:

$$F = (W_0 + W) \bullet g \bullet \mu \quad (N)$$

where, g is the gravity acceleration ($\approx 9.8 \text{ (m/s}^2\text{)}$).

Then, the driving torque around the motor shaft is expressed as follows:

$$\tau_{\rm M} = \frac{60 \cdot \upsilon}{2 \pi \cdot N_{\rm M}} \cdot \frac{(W_0 + W) \cdot g \cdot \mu}{\eta_{\rm G}} \quad (N \cdot m)$$



Figure 10.3-1 Moving a Load Horizontally

(Equation 10.3-3)

(Equation 10.3-4)

hap

10.3 Equations for Selections

Vertical lift load

A simplified mechanical configuration is assumed as shown in Figure 10.3-2. If the mass of the cage is W_0 (kg), the load is W (kg), and the balance weight is W_B (kg), then the forces F (N) required for lifting the load up and down are expressed as follows:

For lifting up

$$F = (W_0 + W - W_B) \cdot g(N)$$

For lifting down

 $F = (W_0 - W - W_B) \cdot g(N)$

(Equation 10.3-6)

(Equation 10.3-5)

Assuming the maximum load is W_{max} , the mass of the balance weight W_B (kg) is generally obtained with the expression $W_B = W_O + W_{max}/2$. Depending on the mass of load W (kg), the values of F (N) may be negative in both cases of lifting up and down, which means the lift is in braking mode. So, be careful in motor and inverter selection. For calculation of the required output torque τ around the motor shaft, apply the expression (Equation 10.3-1) or (Equation 10.3-2) depending on the driving or braking mode of the lift, that is, <u>apply the expression (Equation 10.3-1) if the value of F (N) is positive, and the (Equation 10.3-2) if negative.</u>

Cage W₀ (kg)

Load W (kg) Reduction-gear

Motor

N_M (r/min)

Balance weight W_B (kg)

Figure 10.3-2 Vertical Lift Load

Inclined lift load

Although the mechanical configuration of an inclined lift load is similar to that of a vertical lift load, non negligible friction force in the inclined lift makes the difference; in an inclined lift load, there is a distinct difference between the expression to calculate the lift force F (N) for lifting up and that for lifting down.

If the incline angle is θ , and the friction coefficient is μ , as shown in Figure 10.3-2, the driving force F (N) is expressed as follows:

For lifting up

$$F = ((W_0 + W)(\sin\theta + \mu \cdot \cos\theta) - W_B) \cdot g (N)$$

For lifting down

 $F = ((W_B - (W_0 + W)(sin\theta + \mu \cdot cos\theta)) \cdot g (N)$

The braking mode applies to both lifting up and down as in the vertical lift load. And the calculation of the required output torque τ around the motor shaft is the same as in the vertical lift load; <u>apply the expression (Equation 10.3-1)</u> if the value of F (N) is positive, and the (Equation 10.3-2) if negative.



Figure 10.3-3 Inclined Lift Load

(Equation 10.3-8)

(Equation 10.3-7)

10.3.2 Acceleration and deceleration time calculation

When an object whose moment of inertia is J (kg·m²) rotates at the speed N (r/min), it has the following kinetic energy:

$$\mathsf{E} = \frac{\mathsf{J}}{2} \cdot \left(\frac{2\pi \cdot \mathsf{N}}{60}\right)^2 (\mathsf{J}) \tag{Equation 10.3-9}$$

To accelerate the above rotational object, the kinetic energy will be increased; to decelerate the object, the kinetic energy must be discharged. The torque required for acceleration and deceleration can be expressed as follows:

$$\tau = J \cdot \frac{2\pi}{60} \left(\frac{dN}{dt}\right) \quad (N \cdot m)$$
 (Equation 10.3-10)

This way, the mechanical moment of inertia is an important element in the acceleration and deceleration. First, calculation method of moment of inertia is described, after the calculation methods for the acceleration and deceleration times are explained.

[1] Calculation of moment of inertia

For an object that rotates around the shaft, virtually divide the object into small segments and square the distance from the shaft to each segment. Then, sum the squares of the distances and the masses of the segments to calculate the moment of inertia.

$$J = \sum (W_i \bullet r_i^2) \quad (kg \bullet m^2)$$
(Equation 10.3)

The following describes equations to calculate moment of inertia having different shaped loads or load systems.

(1) Hollow cylinder and solid cylinder

The common shape of a rotating body is hollow cylinder. The moment of inertia J (kg·m²) around the hollow cylinder center axis can be calculated as follows, where the outer and inner diameters are D1 and D2 [m] and total mass is W [kg] in Figure 10.3-4.

$$J = \frac{W \cdot (D_1^2 + D_2^2)}{8} \quad (kg \cdot m^2)$$
 (Equation 10.3-12)

For a similar shape, a solid cylinder, calculate the moment of inertia as D₂ is 0.



Figure 10.3-4 Hollow Cylinder

3-11)

(2) For a general rotating body

Table 10.3-1 lists the calculation equations of moment of inertia of various rotating bodies including the above cylindrical rotating body.

	Mass: W (kg)		Mass: W (kg)
Shape	Moment of inertia: J (kg·m²)	Shape	Moment of inertia: J (kg⋅m²)
Hollow cylinder	$W = \frac{\pi}{4} \cdot (D_1^2 - D_2^2) \cdot L \cdot \rho$		$W = A \cdot B \cdot L \cdot \rho$
	$J = \frac{1}{8} \cdot W \cdot (D_1^2 + D_2^2)$	c axis b axis a axis	$J_a = \frac{1}{12} \cdot W \cdot (L^2 + A^2)$
Sphere	$W = \frac{\pi}{6} \cdot D^3 \cdot \rho$		$J_{b} = \frac{1}{12} \cdot W \cdot (L^{2} + \frac{1}{4} \cdot A^{2})$
	$J = \frac{1}{10} \cdot W \cdot D^2$		$J_{c} \approx W \cdot (L_{0}^{2} + L_{0} \cdot L + \frac{1}{3} \cdot L^{2})$
Cone ↓↓	$W = \frac{\pi}{12} \cdot D^2 \cdot L \cdot \rho$		$W = \frac{\pi}{4} \cdot D^2 \cdot L \cdot \rho$
	$J = \frac{3}{40} \cdot W \cdot D^2$	c axis b axis a axis	$J_a = \frac{1}{12} \cdot W \cdot (L^2 + \frac{3}{4} \cdot D^2)$
Rectangular prism	$W = A \cdot B \cdot L \cdot \rho$		$J_{\rm b} = \frac{1}{3} \cdot W \cdot (L^2 + \frac{3}{16} \cdot D^2)$
	$J = \frac{1}{12} \cdot W \cdot (A^2 + B^2)$		$J_{c} \approx W \cdot (L_{0}^{2} + L_{0} \cdot L + \frac{1}{3} \cdot L^{2})$
Square cone (Pyramid, rectangular base)	$W = \frac{1}{3} \cdot A \cdot B \cdot L \cdot \rho$	c axis b axis	$W = \frac{1}{3} \cdot A \cdot B \cdot L \cdot \rho$
	$J = \frac{1}{20} \cdot W \cdot (A^2 + B^2)$		$J_{b} = \frac{1}{10} \cdot W \cdot (L^{2} + \frac{1}{4} \cdot A^{2})$ $J_{c} \approx W \cdot (L_{0}^{2} + \frac{3}{2} \cdot L_{0} \cdot L + \frac{3}{5} \cdot L^{2})$
Triangular prism	$W = \frac{\sqrt{3}}{4} \cdot A^2 \cdot L \cdot \rho$		2 0
	$J = \frac{1}{3} \cdot W \cdot A^2$	caxis baxis	$W = \frac{\pi}{12} \cdot D^2 \cdot L \cdot \rho$
Tetrahedron with an equilateral triangular base	$W = \frac{\sqrt{3}}{12} \cdot A^2 \cdot L \cdot \rho$		$J_{\rm b} = \frac{1}{10} \cdot W \cdot (L^2 + \frac{3}{8} \cdot D^2)$
A L	$J = \frac{1}{5} \cdot W \cdot A^2$		$J_{c}\approxW\cdot(L_{0}^{2}+\frac{3}{2}\cdotL_{0}\cdotL+\frac{3}{5}\cdotL^{2})$
Main metal density (at 20°0	C) ρ(kg/m ³) Iron: 7860, Co	opper: 8940, Aluminum: 2700	

Table 10.3-1 Moment of Inertia of Various Rotating Bodies

(3) For a load running horizontally

Assume a carrier table driven by a motor as shown in Figure 10.3-1. If the table speed is υ (m/s) when the motor speed is N_M (r/min), then an equivalent distance from the shaft is equal to $60 \cdot \upsilon / (2\pi \cdot N_M)$ (m). The moment of inertia of the table and load to the shaft is calculated as follows:

$$J = (\frac{60 \cdot \upsilon}{2 \pi \cdot N_M})^2 \cdot (W_0 + W) \quad (kg \cdot m^2)$$
(Equation 10.3-13)

(4) For a vertical or inclined lift load

The moment of inertia J ($kg \cdot m^2$) of the loads connected with a rope as shown in Figure 10.3-2 and Figure 10.3-3 is calculated with the following equation using the mass of all moving objects, although the motion directions of those loads are different.

$$J = (\frac{60 \cdot v}{2 \pi \cdot N_{M}})^{2} \cdot (W_{o} + W + W_{B}) \quad (kg \cdot m^{2})$$
(Equation 10.3-14)

[2] Calculation of the acceleration time

Figure 10.3-5 shows a general load model. Assume that a motor drives a load via a reduction-gear with efficiency η_G . The time required to accelerate this load in stop state to a speed of N_M (r/min) is calculated with the following equation:

$$t_{ACC} = \frac{J_1 + J_2/\eta_G}{\tau_M - \tau_L/\eta_G} \cdot \frac{2\pi \cdot (N_M - 0)}{60} \quad (s)$$
(Equation 10.3-15)

where,

- -

- J_1 : Motor shaft moment of inertia (kg·m²)
- J_2 : Load shaft moment of inertia converted to motor shaft (kg·m²)
- τ_{M} : Minimum motor output torque in driving motor (N·m)
- τ_L : Maximum load torque converted to motor shaft (N·m)
- η_G: Reduction-gear efficiency.

As clarified in the above equation, the equivalent moment of inertia becomes (J_1+J_2/η_G) by considering the reduction-gear efficiency.



Figure 10.3-5 Load Model Including Reduction-gear

[3] Calculation of the deceleration time

In a load system shown in Figure 10.3-5, the time needed to stop the motor rotating at a speed of N_M (r/min) is calculated with the following equation:

$$t_{DEC} = \frac{J_1 + J_2 \cdot \eta_G}{\tau_M - \tau_L \cdot \eta_C} \cdot \frac{2\pi \cdot (0 - N_M)}{60}$$
(s) (Equation 10.3-16)

where,

- J_1 : Motor shaft moment of inertia (kg·m²)
- J₂: Load shaft moment of inertia converted to motor shaft (kg \cdot m²)
- τ_{M} : Minimum motor output torque in braking (or decelerating) motor (N·m)
- τ_L : Maximum load torque converted to motor shaft (N·m)
- η_G: Reduction-gear efficiency

In the above equation, generally output torque τ_M is negative and load torque τ_L is positive. So, deceleration time becomes shorter.



For lift applications, calculate the deceleration time using the negative value of τ_L (maximum load torque converted to motor shaft).

[4] Calculating non-linear acceleration/deceleration time

In applications requiring frequent acceleration/deceleration, the inverter can accelerate/decelerate the motor in the shortest time utilizing the maximum torque capability. The inverter in vector control mode can easily perform this type of operation.



Figure 10.3-6 An Example of Driving Characteristics with a Constant Output Range

In this case, the acceleration/deceleration vs. speed curve will form a non-linear figure, and the acceleration / deceleration time cannot be calculated by a single expression.

Generally, the acceleration/deceleration time is obtained by calculating the acceleration/deceleration time of ΔN that is a difference of speed N broken into small parts, and then integrating it to obtain the total acceleration/deceleration time from start to end. Because the smaller ΔN provides higher accuracy, this numerical calculation needs an aid of a computer program.

The following is a guide for the numerical calculation method using a computer program.

Figure 10.3-6 illustrates an example of driving characteristics with a constant output range. In the figure, the range under N_0 is of constant torque characteristics, and the range between N_0 and N_1 is of a constant output with the non-linear acceleration/deceleration characteristics.

The expression (Equation 10.3-17) gives an acceleration time Δt_{ACC} within a ΔN speed increment.

$$\Delta t_{\text{DEC}} = \frac{J_1 + J_2 / \eta_G}{\tau_M - \tau_L / \eta_G} \cdot \frac{2\pi \cdot \Delta N}{60} \quad (s)$$

(Equation 10.3-17)

Before proceeding this calculation, obtain the motor shaft moment of inertia J₁, the load shaft moment of inertia converted to motor shaft J₂, maximum load torque converted to motor shaft τ_L , and the reduction-gear efficiency η_G . Apply the maximum motor output torque τ_M according to an actual speed thread ΔN as follows.

$$[\tau_{M} \text{ in } N \leq N_{0}]$$
 Constant output torque range

$$\tau_{M} = \frac{60 \cdot P_{0}}{2\pi \cdot N_{0}} \quad (N \cdot m)$$
 (Equation 10.3-18)

$$[\tau_{M} \text{ in } N_{0} \leq N \leq N_{1}]$$
 Constant output power range

(The motor output torque is inversely proportional to the motor speed)

$$\tau_{\rm M} = \frac{60 \cdot P_0}{2\pi \cdot N} \quad (N \cdot m) \tag{Equation 10.3-19}$$

If the result obtained by the above calculation does not satisfy the target value, select an inverter with one rank higher capacity.

[5] Calculating non-linear deceleration time

Use the following expression to obtain the non-linear deceleration time as well as for the acceleration time.

$$\Delta t_{\text{DEC}} = \frac{J_1 + J_2 \cdot \eta_G}{\tau_M - \tau_L \cdot \eta_G} \cdot \frac{2\pi \cdot \Delta N}{60} \quad (s)$$
(Equation 10.3-20)

In this expression, both τ_M , and ΔN are generally negative values so that the load torque τ_L serves to assist the deceleration operation. For a lift load, however, the load torque τ_L is a negative value in some modes. In this case, the τ_M , and τ_L will take polarity opposite to each other and the τ_L will actuate to prevent the deceleration operation of the lift.

10.3.3 Heat energy calculation of braking resistor

If the inverter brakes the motor, the kinetic energy of mechanical load is converted to electric energy to be regenerated into the inverter circuit. This regenerative energy is often consumed in so-called braking resistors as heat. The following explains the braking resistor rating.

[1] Calculation of regenerative energy

In the inverter operation, one of the regenerative energy sources is the kinetic energy that is generated when an object with moment of inertia J is rotating.

(1) Kinetic energy of a moving object

When an object with moment of inertia J (kg \cdot m²) rotates at a speed N₂ (r/min), its kinetic energy is as follows:

$$E = \frac{J}{2} \cdot \left(\frac{2\pi \cdot N_2}{60}\right)^2 \text{ (J=Ws)}$$

$$\approx \frac{1}{1824} \cdot J \cdot N_2^2 \text{ (J)}$$
(Equation 10.3-21')

When this object is decelerated to a speed N_1 (r/min), the output energy is as follows:

$$\mathsf{E} = \frac{\mathsf{J}}{2} \cdot \left[\left(\frac{2\pi \cdot \mathsf{N}_2}{60} \right)^2 - \left(\frac{2\pi \cdot \mathsf{N}_1}{60} \right)^2 \right]$$
(J) (Equation 10.3-22)
$$\approx \frac{1}{1824} \cdot \mathsf{J} \cdot \left(\mathsf{N}_2^2 - \mathsf{N}_1^2 \right)$$
(J) (Equation 10.3-22')

The energy regenerated to the inverter as shown in Figure 10.3-5 is calculated from the reduction-gear efficiency η_{G} and motor efficiency η_{M} as follows:

$$E \approx \frac{1}{1824} \bullet \left(J_1 + J_2 \bullet \eta_G \right) \bullet \eta_M \bullet \left(N_2^2 - N_1^2 \right)$$
 (J) (Equation 10.3-23)

(2) Potential energy of a lift

When an object whose mass is W (kg) falls from the height $h_2(m)$ to the height $h_1(m)$, the output energy is as follows:

$$F = W \cdot g \cdot (h_2 - h_1)$$
 (J=Ws) (Equation 10.3-24)

$$g \approx 9.8065 \, (m/s^2)$$

The energy regenerated to the inverter is calculated from the reduction-gear efficiency η_G and motor efficiency η_M as follows:

$$\mathbf{F} = \mathbf{W} \cdot \mathbf{g} \cdot (\mathbf{h}_2 - \mathbf{h}_1) \cdot \mathbf{\eta}_G \cdot \mathbf{\eta}_M (\mathbf{J})$$
 (Equation 10.3-25)

10.3.4 Calculating the RMS rating of the motor

In case of the load which is repeatedly and very frequently driven by a motor, the motor current fluctuates largely and enters the short-time rating range of the motor repeatedly. Therefore, you have to review the allowable thermal rating of the motor. The heat value is assumed to be approximately proportional to the square of the motor current.

If an inverter drives a motor in duty cycles that are much shorter than the thermal time constant of the motor, calculate the "equivalent RMS current" as mentioned below, and select the motor so that this RMS current will not exceed the rated current of the motor.



Figure 10.3-7 Sample of the Repetitive Operation

First, calculate the required torque of each part based on the speed pattern. Then using the torque-current curve of the motor, convert the torque to the motor current. The "equivalent RMS current, leq" can be finally calculated by the following equation:

$$I_{eq} = \sqrt{\frac{I_1^2 \cdot t_1 + I_2^2 \cdot t_2 + I_3^2 \cdot t_3 + I_4^2 \cdot t_4 + I_5^2 \cdot t_5}{t_1 + t_2 + t_3 + t_4 + t_5 + t_6}} \quad (A)$$
(Equation 10.3-26)

The torque-current curve for the dedicated motor is not available for actual calculation. Therefore, calculate the motor current I from the load torque τ_1 using the following equation (Equation 10.3-27). Then, calculate the equivalent current leq:

$$I = \sqrt{\left(\frac{\tau_1}{100} \times I_{t100}\right)^2 + I_{m100}^2} \quad (A)$$
 (Equation 10.3-27)

Where, τ_1 is the load torque (%), I_{t100} is the torque current, and I_{m100} is exciting current.

10.4 Selecting an Inverter Drive Mode

10.4.1 Precaution in making the selection

To use the inverter under the carrier frequency condition changed from the factory default, the output current rating requires derating due to the ambient temperature or carrier frequency. It is, therefore, necessary to select the inverter unit, referring to Figure 10.4-1 through Figure 10.4-2.



Figure 10.4-1 Derating of Output Current Due to Ambient Temperature





Figure 10.4-2 Derating of Output Current Due to Carrier Frequency
Chapter 11 SELECTING PERIPHERAL EQUIPMENT

This chapter describes how to use a range of peripheral equipment and options, FRENIC-eHVAC's configuration with them, and requirements and precautions for selecting wires and crimp terminals.

Contents

11.1	Conf	figuring the FRENIC-eHVAC ······11-1
11.2	Curr	ents Flowing Across the Inverter Terminals11-2
11.3	Molo	ded Case Circuit Breaker (MCCB), Residual-current-operated Protective Device (RCD)/
	Eart	h Leakage Circuit Breaker (ELCB) and Magnetic Contactor (MC) 11-3
11.	3.1	Function overview ·······11-3
11.	3.2	Connection example and criteria for selection of circuit breakers 11-4
11.4	Surg	ge Killers for L-load ······ 11-7
11.5	Arre	sters 11-8
11.6	Surg	e Absorbers ······ 11-9
11.7	Filte	ring Capacitors Suppressing AM Radio Band Noises
11.8	Brak	ing Resistors (DBRs) and Braking Units 11-11
11.	8.1	Selecting a braking resistor 11-11
[1]	Selection procedure 11-11
[2	2]	Notes on selection 11-11
11.	8.2	Braking resistors (DBRs) 11-12
[1]	Standard model 11-12
[2	2]	10%ED model 11-12
11.	8.3	Braking units 11-13
11.	8.4	Specifications 11-14
11.	8.5	External dimensions 11-16
11.9	Pow	er Regenerative PWM Converters, RHC Series ······ 11-18
11.	9.1	Overview
11.	9.2	Specifications 11-19
[1]	Standard specifications 11-19
[2	2]	Common specifications 11-20
11.	9.3	Function specifications 11-21
11.	9.4	Converter configuration 11-25
11.	9.5	External dimensions 11-27
11.10	DC F	Reactors (DCRs) 11-32
11.11	AC F	Reactors (ACRs)······ 11-35
11.12	Surg	e Suppression Unit (SSU)······ 11-37

11.13 Output Circuit Filters (OFLs) 11-3
11.14 Zero-phase Reactors for Reducing Radio Noise (ACLs) 11-4
11.15 External Cooling Fan Attachments 11-4
11.16 External Frequency Command Potentiometer 11-4
11.17 Extension Cable for Remote Operation 11-4
11.18 Frequency Meters 11-4
11.19 Options for communication and operation overview 11-4
11.19.1 Mounting adapter (for communication option card)
11.19.2 Communication option cards (required mounting adapter required) 11-4
11.19.3 Terminal block type options 11-4
11.19.4 Option keypad 11-4
11.20 DeviceNet communications card (OPC-DEV) 11-4
11.20.1 DeviceNet specifications 11-4
11.21 CC-Link communications card (OPC-CCL) 11-4
11.21.1 CC-Link specifications 11-4
11.22 Analog interface card (OPC-AIO) ······ 11-4
11.23 RTD Card (OPC-PT) 11-5
11.24 LonWorks Card (OPC-LNW) ······ 11-5
11.25 Relay Output Card (OPC-F2-RY)······ 11-5
11.26 Simple keypad with USB port (TP-E1U) 11-5-
11.27 Multi functional keypad (TP-A1) ······ 11-5
11.28 FRENIC Visual Customizer 11-5
11.28.1 Overview
11.28.2 Specifications 11-5
11.28.3 Functions 11-5
11.28.4 Main Window ······ 11-5

11.1 Configuring the FRENIC-eHVAC

This section lists the names and features of peripheral equipment and options for the FRENIC-eHVAC as well as a configuration example.



Figure 11.1-1 Quick Overview of Options

Chap 11 SELECTING PERIPHERAL EQUIPMENT

11.2 Currents Flowing Across the Inverter Terminals

Table 11.2-1 summarizes average (effective) electric currents flowing across the terminals of each inverter model for ease of reference when selecting peripheral equipment and options for each inverter--including supplied power voltage and applicable motor rating.

	Neminal	Neminal		50Hz, 400V			60Hz, 440V		Braking
Power supply	applied		Input RMS	current (A)	DC link	Input RMS	current (A)	DC link	resistor
voltage	motor	Inverter type	DC reacto	ors (DCRs)	bus	DC reacto	ors (DCRs)	bus	circuit
0	(kW)		w/ DCR	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	(A)				
	0.75	FRN0002F2E-4G	1.5	2.7	1.8	1.4	2.7	1.7	0.8
	1.1	FRN0003F2E-4G	2.1	3.9	2.6	1.9	3.9	2.3	1.1
	2.2	FRN0005F2E-4G	4.2	7.3	5.1	3.8	7.1	4.7	1.8
	3.0	FRN0006F2E-4G	5.8	11.3	7.1	5.3	10.2	6.5	1.8
	5.5	FRN0011F2E-4G	10.1	16.8	12.4	9.1	15.7	11.1	2.1
	7.5	FRN0018F2E-4G	14.4	23.2	17.7	13.0	21.0	16.0	3.2
	11	FRN0023F2E-4G	21.1	33.0	25.9	19.0	29.8	23.3	3.1
	15	FRN0031F2E-4G	28.8	43.8	35.3	26.0	39.5	31.9	4.5
	18.5	FRN0038F2E-4G	35.5	52.3	43.5	32.0	47.1	39.2	5.7
	22	FRN0045F2E-4G	42.2	60.6	51.7	38.0	54.6	46.6	7.2
Three-phase	30	FRN0060F2E-4G	57.0	77.9	69.9	51.4	70.2	63.0	7.7
400V/440V	37	FRN0075F2E-4G	68.5	94.3	83.9	61.8	85.0	75.7	10
	45	FRN0091F2E-4G	83.2	114	102	75.0	103	91.9	12
	55	FRN0112F2E-4G	102	140	125	91.9	126	113	15
	75	FRN0150F2E-4G	138	-	169	124	-	152	19
	90	FRN0176F2E-4G	164	-	201	148	-	181	24
	110	FRN0210F2E-4G	201	-	246	181	-	222	31
	132	FRN0253F2E-4G	238	-	292	214	-	263	35
	160	FRN0304F2E-4G	286	-	350	258	-	315	42
	200	FRN0377F2E-4G	357	-	437	321	-	394	50
	220	FRN0415F2E-4G	390	-	478	351	-	430	62
	280	FRN0520F2E-4G	500	-	613	450	-	552	71

Table 11.2-1 Currents Flowing across the Inverter Terminals

 Inverter efficiency is calculated using values suitable for each inverter model. The input route mean square current is calculated based on a power supply capacity of 500 kVA (or 10 times as large as the inverter's capacity when the inverter's capacity exceeds 50 kVA), and a power supply reactance of 5%.

• The input RMS current listed in the above table will vary in inverse proportion to the power supply voltage, such as 480 VAC.

• The braking current is always constant, independent of braking resistor specifications, including standard and 10%ED models.

11.3 Molded Case Circuit Breaker (MCCB), Residual-current-operated Protective Device (RCD)/Earth Leakage Circuit Breaker (ELCB) and Magnetic Contactor (MC)

11.3.1 Function overview

MCCBs and RCDs/ELCBs*

* With overcurrent protection

Molded Case Circuit Breakers (MCCBs) are designed to protect the power circuits between the power supply and inverter's main circuit terminals ([L1/R], [L2/S] and [L3/T]) from overload or short-circuit, which in turn prevents secondary accidents caused by the broken inverter.

Residual-Current-Operated Protective Devices (RCDs)/Earth Leakage Circuit Breakers (ELCBs) function in the same way as MCCBs.

Built-in overcurrent/overload protective functions protect the inverter itself from failures related to its input/output lines.

Magnetic contactor

An MC can be used at both the power input and output sides of the inverter. At each side, the MC works as described below. Use it as necessary. When inserted in the output circuit of the inverter, the MC can also switch the motor drive power supply between the inverter output and commercial power lines.

At the power supply side

Insert an MC in the power supply side of the inverter in order to:

- (1) Forcibly cut off the inverter from the power supply (generally, commercial/factory power lines) with the protective function built into the inverter, or with the external signal input.
- (2) Stop the inverter operation in an emergency when the inverter cannot interpret the stop command due to internal/external circuit failures.
- (3) Cut off the inverter from the power supply when the MCCB inserted in the power supply side cannot cut it off for maintenance or inspection purpose. For the purpose only, it is recommended that you use an MC capable of turning the MC ON/OFF manually.



Avoid frequent ON/OFF operation of the magnetic contactor (MC) in the input (primary) circuit; otherwise, the inverter failure may result.

The frequency of the MC's ON/OFF should not be more than once per 30 minutes. To assure 10-year or longer service life of the inverter, it should not be more than once per hour.

If frequent start/stop of the motor is required, use FWD/REV terminal signals or the www keys on the inverter's keypad.

At the output side

Insert an MC in the power output side of the inverter in order to:

- (1) Prevent externally turned-around current from being applied to the inverter power output terminals ([U], [V], and [W]) unexpectedly. An MC should be used, for example, when a circuit that switches the motor driving power supply between the inverter output and commercial power lines is connected to the inverter.
 - Tip If a magnetic contactor (MC) is inserted in the inverter's output (secondary) circuit for switching the motor to a commercial power or for any other purposes, it should be switched on and off when both the inverter and motor are completely stopped. This prevents the contact point from getting rough due to a switching arc of the MC. The MC should not be equipped with any main circuit surge killer (Fuji SZ-ZM□, etc.).

Applying a commercial power to the inverter's output circuit breaks the inverter. To avoid it, interlock the MC on the motor's commercial power line with the one in the inverter output circuit so that they are not switched ON at the same time.

- (2) Drive more than one motor selectively by a single inverter.
- (3) Selectively cut off the motor whose thermal overload relay or equivalent devices have been activated.

Driving the motor using commercial power lines

MCs can also be used to switch the power supply of the motor driven by the inverter to a commercial power supply. Select the MC so as to satisfy the rated currents listed in Table 11.2-1, which are the most critical RMS currents for using the inverter (Refer to Table 11.3-1). For switching the motor drive source between the inverter output and commercial power lines, use the MC of class AC3 specified by JIS C8325 in the commercial line side.

11.3.2 Connection example and criteria for selection of circuit breakers

Figure 11.3-1 shows a connection example for MCCB or RCD/ELCB (with overcurrent protection) and MC in the inverter input circuit. Table 11.3-1 lists the rated current for the MCCB and corresponding inverter models. Table 11.3-2 lists the applicable grades of RCD/ELCB sensitivity.

Insert an MCCB or RCD/ELCB (with overcurrent protection) recommended for each inverter for its input circuits. Do not use an MCCB or RCD/ELCB of a higher rating than that recommended. **Doing so could result in a fire.**





Molded case circuit breaker or residual-current-operated protective device/ earth leakage circuit breaker

Magnetic contactor



Figure 11.3-1 External Views of MCCB or RCD/ELCB and MC and Connection Example

	Nominal		MCCB, RCD	/ELCB rated	Mag	netic contactor (MC)
Power supply	applied	Invertor type	curre	nt (A)	Input	circuit	Output
Power supply voltage	motor	inverter type	DC reacto	rs (DCRs)	DC reacto	rs (DCRs)	circuit
	(KVV)		w/ DCR	w/o DCR	w/ DCR	w/o DCR	onour
	0.75	FRN0002F2E-4G	5	5			
	1.1	FRN0003F2E-4G	5	10			
	2.2	FRN0005F2E-4G	10	15	SC 05	SC-05	SC 05
	3.0	FRN0006F2E-4G	10	15	30-03		30-03
	5.5	FRN0011F2E-4G	15	30			
	7.5	FRN0018F2E-4G	20	40		SC-4-0	
	11	FRN0023F2E-4G	30	50	SC-4-0	SC-4-0 SC N4	
	15	FRN0031F2E-4G	40	60	SC-5-1	30-111	SC-5-1
	18.5	FRN0038F2E-4G	40	75	SC N1	SC-N2	SC NI
	22	FRN0045F2E-4G	50	100	30-111	SC-N2S	30-111
Three-phase	30	FRN0060F2E-4G	75	105	SC-N2	SC-N3	SC-N2
400 V	37	FRN0075F2E-4G	100	125	SC-N2S		SC-N2S
	45	FRN0091F2E-4G	100	150		50-114	SC-N3
	55	FRN0112F2E-4G	125	200	30-113	SC-N5	SC-N4
	75	FRN0150F2E-4G	175		SC-N4		SC-N5
	90	FRN0176F2E-4G	200		SC-N7		SC-N7
	110	FRN0210F2E-4G	250				
	132	FRN0253F2E-4G	300		5C-INO		5C-No
	160	FRN0304F2E-4G	350	-	SC-N11	-	SC-N11
	200	FRN0377F2E-4G	500		60 N/10		
	220	FRN0415F2E-4G	500		5C-N12		SC-N12
	280	FRN0520F2E-4G	600		SC-N14		SC-N14

 Table 11.3-1
 Rated Current of Molded Case Circuit Breaker (MCCB), Residual-Current-Operated Protective Device (RCD)/ Earth Leakage Circuit Breaker (ELCB) and Magnetic Contactor (MC)

- Install the MCCB or RCD/ELCB at the input side of the inverter. They cannot be installed at the output side of the inverter.
- The above table lists the rated current of MCCBs and RCD/ELCBs to be used in the power control panel with an
 internal temperature of lower than 50 °C (122 °F). The rated current is factored by a correction coefficient of
 0.85 as the RCDs'/MCCBs' and ELCBs' original rated current is specified when using them in a surrounding
 temperature of 40 °C (104 °F) or lower. Select an MCCB and/or RCD/ELCB suitable for the actual short-circuit
 breaking capacity needed for your power systems.
- For the selection of the MC type, it is assumed that the 600 V HIV (allowable surrounding temperature: 75 °C (167 °F)) wires for the power input/output of the inverter are used. If an MC type for another class of wires is selected, the wire size suitable for the terminal size of both the inverter and the MC type should be taken into account.
- Use ELCBs with overcurrent protection.
- To protect your power systems from secondary accidents caused by the broken inverter, use an MCCB and/or RCD/ELCB with the rated current listed in the above table. Do not use an MCCB or RCD/ELCB with a rating higher than that listed.

Table 11.3-2 lists the relationship between the rated leakage current sensitivity of RCDs/ELCBs (with overcurrent protection) and wiring length of the inverter output circuits. Note that the sensitivity levels listed in the table are estimated values based on the results obtained by the test setup in the Fuji laboratory where each inverter drives a single motor.

Table 11.3-2	Rated Current Sensitivity of Residual-Current-Operated Protective Device (RCD)/ Earth Leakage
	Circuit Breakers (ELCBs)

	Nominal applied			Wiring length and	current sensitivity		
Voltage class Three-phase 400 V class	motor (kŴ)	10m (33ft)	30m (98ft)	50m (164ft)	100m (328ft)	200m (656ft)	300m (984ft)
	0.75						
	1.1						
	2.2						
	3.0	30mA					
	5.5						
	7.5						
	11						
	15						
	18.5						
	22						
	30		100mA				
Three-phase	37				200mA		
400 V class	45						
	55					500mA	
	75						
	90						1000mA
	110						
	132						
	160						
	200						
	220						
	250						
	280						

· Values listed above were obtained using Fuji ELCB EG or SG series applied to the test setup.

• The rated current of applicable motor rating indicates values for Fuji standard motor (4 poles, 50 Hz and 200 V three-phase).

• The leakage current is calculated based on neutral grounding for 400 V class Y-connection power lines.

• Values listed above are calculated based on the static capacitance to the earth when the 600 V class of vinyl-insulated IV wires are used in a wiring through metal conduit pipes.

• Wiring length is the total length of wiring between the inverter and motor. If more than one motor is to be connected to a single inverter, the wiring length should be the total length of wiring between the inverter and motors.

11.4 Surge Killers for L-load

A surge killer absorbs surge voltage induced by L-load of an electro magnetic switch or solenoid valve. Use of a surge killer is effective in preventing the electronic equipment, including inverters, from damage or malfunctioning caused by such surges.

Install a surge killer near the power coil of the surge source. Connected to the inverter's power source side, as shown in Figure 11.4-1, a surge killer absorbs the surge voltage, preventing the electronic equipment, from damage or malfunctioning. (Available rated capacity of nominal applied motors is 3.0 kW or less.)

Refer to the catalog "Fuji Surge Killers/Absorbers (HS118: Japanese edition only)" for details. These products are available from Fuji Electric Technica Co., Ltd.

* Do not use the surge killer in the inverter secondary (output) line.





Figure 11.4-1 Dimensions of Surge Killer and Connection Example

11.5 Arresters

An arrester suppresses surge currents induced by lightning invaded from the power supply lines. Use of the grounding wire that is used commonly for electric equipment in the panel, combined with the arrester, is effective in preventing electronic equipment from damage or malfunctioning caused by such surges.

Applicable arrester models are CN5132 for three-phase 200V class series, and CN5134 for three-phase 400V class series. (CN523 series with 20 kA of discharging capability is also available.) Figure 11.5-1 shows their external dimensions and connection examples. Refer to the catalog "Fuji Surge Killers/Absorbers (HS165a: Japanese edition only)" for details. These products are available from Fuji Electric Technica Co., Ltd.



• Tree-phase (AC240/440V)



- *1: Keep the wiring length as short as possible.
- *2: The models with a built-in arrestor separator (CN5212-FK and CN5232-FK) are not required when the short-circuit current of the circuit is 250 VAC, 10kA or less.

(N-phase terminal is only for CN5234 and CN5234-K.)



Figure 11.5-1 Arrester Dimensions and Connection Examples

11.6 Surge Absorbers

A surge absorber absorbs surges or noises generated by a magnetic contactor (MC) or solenoid valve in the power system to effectively protect electronic equipment in the panel from malfunctions or breakdown. Installed parallel to a coil of an MC, solenoid valve, or L load, a surge absorber absorbs the surge voltage.

Applicable surge absorber models are the S2-A-O and S1-B-O. Figure 11.6-1 shows their external dimensions.

These products are available from Fuji Electric Technica Co., Ltd.



Type: S2-A-O (for magnetic contactor)



Type: S1-B-O (for mini-control relay or timer)



Unit: mm (inch)

Available from Fuji Electric Technica Co., Ltd.

Figure 11.6-1 Surge Absorber Dimensions

11.7 Filtering Capacitors Suppressing AM Radio Band Noises

These capacitors are effective to suppress AM radio band (less than 1 MHz) noises. Using them with Zero-phase reactors upgrades capability.

Applicable models are NFM25M315KPD1 for 200 V class series inverters and NFM60M315KPD for 400 V class. Use one of them regardless of the inverter capacity. Figure 11.7-1 shows their external dimensions. These products are available from Fuji Electric Technica Co., Ltd.

* Do not use the filtering capacitor in the inverter secondary (output) line.



Figure 11.7-1 Filtering Capacitors Dimensions

11.8 Braking Resistors (DBRs) and Braking Units

11.8.1 Selecting a braking resistor

[1] Selection procedure

Depending on the cyclic period, the following requirements must be satisfied.

- (1) If the cyclic period is 100 s or less: [Requirement 1] and [Requirement 3]
- (2) If the cyclic period exceeds 100 s: [Requirement 1] and [Requirement 2]
 - [Requirement 1] : The maximum braking torque should not exceed the values listed in the tables in "11.8.4 Specifications". To use the maximum braking torque exceeding the values in those tables, select the braking resistor whose capacity is one class larger.
 - [Requirement 2] : The discharge energy for a single braking action should not exceed the discharging capability (kWs) listed in the tables. For calculation details, refer to Chapter 10 "10.3.3 Heat energy calculation of braking resistor."
 - [Requirement 3] : The average loss that is calculated by dividing the discharge energy by the cyclic period must not exceed the average allowable loss (kW) listed in the tables in "11.8.4 Specifications".

[2] Notes on selection

The braking time T_1 , cyclic period T_0 , and duty cycle %ED are converted under deceleration braking conditions based on the rated torque as shown in Figure 11.8-1. However, it is not necessary to consider these values in the selection of braking resistor capacity.



11.8.2 Braking resistors (DBRs)

A braking resistor converts regenerative energy generated from the deceleration of the motor to heat. Use of a braking resistor results in improved deceleration performance of the inverter.

[1] Standard model

The standard model of a braking resistor integrates a facility that detects the temperature on the heat sink of the resistor and outputs a digital ON/OFF signal if the temperature exceeds the specified level (as an overheating warning signal). To ensure that the signal is recognized at one of the digital input terminals of the FRENIC-eHVAC, assign the external alarm THR to any of terminals [X1] to [X5], [FWD] and [REV]. Connect the assigned terminals to terminals [1] and [2] of the braking resistor. Upon detection of the warning signal (preset detection level: 150° C), the inverter simultaneously transfers to Alarm mode, displays alarm $\frac{1}{2}\frac{1}{2}\frac{1}{2}$ on the LED monitor and shuts down its power output.



Figure 11.8-2 Braking Resistor (Standard Model) and Connection Example

[2] 10%ED model

The 10%ED braking resistors do not support overheating detection or warning output, so an electronic thermal overload relay needs to be set up using function codes F50 and F51 to protect the braking resistor from overheating.



Figure 11.8-3 Braking Resistor (10%ED Model) and Connection Example

For the specifications and external dimensions of the braking units, refer to "11.8.4 Specifications" and 11.8.5 External dimensions".

11.8.3 Braking units

Add a braking unit to the braking resistor to upgrade the braking capability of inverters with the following models. FRN0075F2E-4G to FRN0520F2E-4G.

FRN0060F2E-4G or the lower models of inverters have built-in IGBTs for the braking resistor.



Figure 11.8-4 Braking Unit

	<u> </u>		D 1 '	1.1
able 11.8-1	Generated	Loss in	Braking	Unit

Model	Generated loss (W)	Min. connection resistance (Ω)
BU37-4C	35	12
BU55-4C	40	7.5
BU90-4C	50	4.7
BU132-4C	60	3.0
BU220-4C	80	1.9

* 10%ED

For the specifications and external dimensions of the braking units, refer to "11.8.4 Specifications" and 11.8.5 External dimensions".

11.8.4 Specifications

			-												
Power	Nominal	nal ed Inverter type)		Selecting Options						Maximum braking torque		Continuous braking (100% braking torque)		Repetitive braking (each cycle is 100 s or less)	
supply voltage	applied motor (kW)		Braking units		Braking resistor				50Hz	60Hz	Discharging capability	Braking time	Average allowable loss	Duty cycle	
			Model	Q'ty	Model	Q'ty	Resistance (Ω)		(N∙m)	(N∙m)	(kWs)	(s)	(kW)	(%ED)	
	0.75	FRN0002F2E-4G				1	200		5.05	4.17	9	24	0.044	12	
	1.1	FRN0003F2E-4G			DB0.75-4	1	200		7.33	6.06	17	30	0.068	12	
	2.2	FRN0005F2E-4G				1 160		14.7	12.1	34	30	0.075	7		
	3.0	FRN0006F2E-4G			DD2.2-4		100		20.1	16.5	33	22	0.077	5	
	5.5	FRN0011F2E-4G			DB3.7-4	1	130		36.2	30.0	37	13	0.093	3.5	
	7.5	FRN0018F2E-4G	-		DB5.5-4	1	80	100	49.6	41.0	55	15	0.138	3.5	
	11	FRN0023F2E-4G			DB7.5-4	1	60		72.0	59.7	38	7	0.188	3.5	
	15	FRN0031F2E-4G			DB11-4	1	40		98.1	81.4	55	7	0.275	3.5	
	18.5	FRN0038F2E-4G			DB15-4	1	34.4		121	100	75	8	0.375	4	
	22	FRN0045F2E-4G			DB18.5-4	1	27		144	119	93	8	0.463	4	
Three-	30	FRN0060F2E-4G			DB22-4	1	22		195	162	88	6	0.55	3.5	
phase 400V	37	FRN0075F2E-4G	BU27 4C	1	DB30-4C	1	15		180	150	150	10	1.50	10	
400 V	45	FRN0091F2E-4G	B037-4C	-	DB37-4C	1	12		219	182	185	10	1.85	10	
	55	FRN0112F2E-4G	BU55-4C	1	DB45-4C	1	10		269	223	225	10	2.25	10	
	75	FRN0150F2E-4G	B033-4C	-	DB55-4C	1	7.5		365	303	275	10	2.75	10	
	90	FRN0176F2E-4G	BU00 4C	1	DB75-4C	1	6.5		439	364	375	10	3.75	10	
	110	FRN0210F2E-4G	B090-4C	1	DD110.40	4	47	75	534	444	450	10	4.50	10	
	132	FRN0253F2E-4G	DU1400.40	4	DBT10-4C	1	4.7		641	533	550	10	5.50	10	
	160	FRN0304F2E-4G	BU132-4C		DB132-4C	1	3.9	1	777	646	660	10	6.60	10	
	200	FRN0377F2E-4G	1 1		DB160-4C	1	3.2	1	971	807	800	10	8.00	10	
	220	FRN0415F2E-4G	BU220-4C	1	DB200-4C	1	2.6	1	1068	888	1000	10	10.0	10	
	280	FRN0520F2E-4G	1		DB220-4C	1	2.2	1	1360	1130	1100	10	11.0	10	

Table 11.8-2 Braking Unit and Braking Resistor (Standard Model)

Power	Nominal		Selecting Options					Maximum braking torque		Continuous braking (100% braking torque)		Repetitive braking (each cycle is 100 s or less)		
supply voltage	motor	Inverter type	Braking units		Braking resistor			50Hz	60Hz	Discharging capability	Braking time	Average allowable loss	Duty cycle	
	(kW)		Model	Q'ty	Model	Q'ty	Resistance (Ω)		(N·m)	(N∙m)	(kWs)	(s)	(kW)	(%ED)
	0.75	FRN0002F2E-4G			DB0 75 4C	1	200		5.05	4.17	50	133	0.075	20
	1.1	FRN0003F2E-4G			000.75-40	'	200		7.33	6.06	50	90	0.075	13
	2.2	FRN0005F2E-4G			DB2 2.4C	4	160		14.7	12.1	55	50	0.11	10
	3.0	FRN0006F2E-4G			DB2.2-40	'	100		20.1	16.5	55	36	0.11	7
Three-	5.5	FRN0011F2E-4G			DB3.7-4C	1	130		36.2	30.0	140	50	0.185	7
phase	7.5	FRN0018F2E-4G	-		DB5.5-4C	1	80	100	49.6	41.0	55	15	0.275	10
400 V	11	FRN0023F2E-4G			DB7.5-4C	1	60		72.0	59.7	37	7	0.375	10
	15	FRN0031F2E-4G			DB11-4C	1	40		98.1	81.4	55	7	0.55	10
	18.5	FRN0038F2E-4G	-		DB15-4C	1	34.4		121	100	75	7	0.75	7
	22	FRN0045F2E-4G			DD22 40	1	22		144	119	93	7	0.925	7
	30	FRN0060F2E-4G			0022-40		22		195	162	110	7	1.1	7

Table 11.8-3 Braking Resistors (10% ED Models)

* The 10%ED braking resistor does not support overheating detection or warning output, so an electronic thermal overload relay needs to be set up using function codes F50 and F51 to protect the braking resistor from overheating.

11.8.5 External dimensions

Braking resistors, standard models







Power supply Type Figure Dimensions mm (inch)						mm (inch)	Mass	
voltage	туре	Figure	w	W1	н	H1	D	kg (lb)
	DB0.75-2	А	68 (2.7)		310 (12.2)	295 (11.6)	67 (2.6)	1.3 (2.9)
	DB2.2-2	А	80 (3.2)	_	345 (13.6)	332 (13.1)	94 (3.7)	2.0 (4.4)
	DB3.7-2	А	80 (3.2)		345 (13.6)	332 (13.1)	94 (3.7)	2.0 (4.4)
	DB5.5-2	В	146 (5.7)	90 (3.5)	450 (17.7)	430 (16.9)	67.5 (2.7)	4.5 (9.9)
	DB7.5-2	В	160 (6.3)	90 (3.5)	390 (15.4)	370 (14.6)	90 (3.5)	5.0 (11)
	DB11-2	с	142 (5.6)	74 (2.9)	430 (16.9)	415 (16.3)	160 (6.3)	6.9 (15)
200 V	DB15-2	С	142 (5.6)	74 (2.9)	430 (16.9)	415 (16.3)	160 (6.3)	6.9 (15)
series	DB18.5-2	С	142 (5.6)	74 (2.9)	510 (20.1)	495 (19.5)	160 (6.3)	8.7 (19)
	DB22-2	С	142 (5.6)	74 (2.9)	510 (20.1)	495 (19.5)	160 (6.3)	8.7 (19)
	DB30-2C	D					140 (5.5)	10 (22)
	DB37-2C	D	400 (15.7)	368 (14.5)	660 (26.0)	628 (24.7)		13 (29)
	DB45-2C						240 (9.4)	18 (40)
	DB55-2C	D	405 (15.9)		750 (29.5)	718 (28.3)		22 (49)
	DB75-2C	-	450 (17.7)	420 (16.5)	202 (11 1)	240 (0.4)	440 (17.2)	35 (77)
	DB110-2C		550 (21.7)	520 (20.5)	203 (11.1)	240 (9.4)	440 (17.3)	32 (71)
	DB0.75-4		68 (2.7)		310 (12.2)	295 (11.6)	67 (2.6)	1.3 (2.9)
	DB2.2-4	А	68 (2.7)	_	470 (18.5)	455 (17.9)	67 (2.6)	2.0 (4.4)
	DB3.7-4		68 (2.7)		470 (18.5)	455 (17.9)	67 (2.6)	1.7 (3.7)
	DB5.5-4		146 (5.8)	74 (2.9)	470 (18.5)	455 (17.9)	67 (2.6)	4.5 (9.9)
400 V series	DB7.5-4	В	146 (5.8)	74 (2.9)	510 (20.1)	495 (19.5)	67 (2.6)	5.0 (11)
	DB11-4	С	142 (5.6)	74 (2.9)	430 (16.9)	415 (16.3)	160 (6.3)	6.9 (15)
	DB15-4	С	142 (5.6)	74 (2.9)	430 (16.9)	415 (16.3)	160 (6.3)	6.9 (15)
	DB18.5-4	С	142 (5.6)	74 (2.9)	510 (20.1)	495 (19.5)	160 (6.3)	8.7 (19)
400 V	DB22-4	С	142 (5.6)	74 (2.9)	510 (20.1)	495 (19.5)	160 (6.3)	8.7 (19)
series	DB30-4C	D					140 (5.5)	5.0 (11)
	DB37-4C	D	420 (16.5)	388 (15.3)	660 (26.0)	628 (24.7)		14 (31)
	DB45-4C						240 (9.4)	19 (42)
	DB55-4C	U	425 (16.7)		750 (29.5)	718 (28.3)		21 (46)
	DB75-4C		550 (21 7)	520 (20 5)				26 (57)
	DB110-4C		550 (21.7)	520 (20.5)				30 (66)
	DB132-4C	-	650 (25.6)	620 (24.4)	202 (11 1)	240 (0 4)	440 (17.2)	41 (90)
	DB160-4C	E	750 (20 5)	720 (29 2)	203 (11.1)	240 (9.4)	440 (17.3)	57 (126)
	DB200-4C		100 (29.5)	120 (20.3)				43 (95)
	DB220-4C *		600 (23.6)	570 (22.4)				74 (163)

*: DB220-4C should be used in pairs. The dimension above is for one unit.



Braking resistors, 10% ED models

Braking units



ower	Tuno	Figure		[mm	(inch)	Mass	
oltage	туре	Figure	W	W1	н	H1	H2	D	kg (lb)
	BU37-2C	А	150 (5.9)	100 (3.9)	240 (9.5)	225 (8.9)	010 (0.0)		4 (8.8)
00 V eries	BU55-2C	Б	230 (9.1)	130 (5.1)	240 (9.5)	225 (8.9)	210 (8.3)	160 (6.3)	6 (13)
	BU90-2C	Б	250 (9.8)	150 (5.9)	370 (14.6)	355 (14.0)	mm (inch) Max H2 D kg 9) 210 (8.3) 160 4 (8) 0) 340 (13.4) 9 (2) 9 (2) 9 (2) 4) 250 (9.8) 160 5.5 0) 340 (13.4) 9 (2) 160 5.5 0) 340 (13.4) 13 9 (2) 13	9 (20)	
	BU37-4C		150 (5.9)	100 (3.9)	280 (11.0)	265 (10.4)	250 (9.8)	160 (6.3)	4 (8.8)
	BU55-4C		000 (0 1)						5 5 (12)
00 V eries	BU90-4C	В	230 (9.1)	130 (5.1)					0.0 (12)
	BU132-4C		050 (0.0)	150 (5.0)	370 (14.6)	355 (14.0)	340 (13.4)		9 (20)
	BU220-4C		250 (9.8)	150 (5.9)	450 (17.7)	435 (17.1)	420 (16.5)		13 (29)

Fan units for braking units

Using this option improves the duty cycle [%ED] from 10%ED to 30%ED.





Unit: mm (inch)

Braking unit + Fan unit

ş

_



[Braking unit + Fan unit]

Power	Time		Dimensions												
voltage	Туре	W2	W3	W4	H2	H3	H4	D2	D3	D4					
000.14	BU37-2C+BU-F	150 (5.9)	105	7.5 (0.3)	240 (0.5)		270 (10 6)	400		~ ~					
200 V series	BU55-2C+BU-F	230 (9.1)	135	47.5 (1.9)	240 (9.5)	(12)	270 (10.6)	(6.3)	(0.05)	(2.5)					
	BU90-2C+BU-F	250 (9.8)	(0.0)	57.5 (2.3)	370 (14.6)	(1.2)	400 (15.8)	(0.0)	(0.00)	(2.0)					
	BU37-4C+BU-F	150 (5.9)		7.5 (0.3)											
400.14	BU55-4C+BU-F	220 (0 1)	135	475 (10)	280 (11.0)	20	310 (12.2)	160	12	64					
400 V series	BU90-4C+BU-F	230 (9.1)	(5.3)	47.5 (1.9)		(1.2)		(6.3)	(0.05)	(2.5)					
	BU132-4C+BU-F	250 (0.9)	ľ	57 5 (2 2)	370 (14.6)		400 (15.8)	ľ	Ì	ì					
	BU220-4C+BU-F	250 (9.6)		57.5 (2.5)	450 (17.7)		480 (18.9)								

11.9 Power Regenerative PWM Converters, RHC Series

11.9.1 Overview

- Possible to reduce power supply facility capacity
 Its power-factor control realizes the same phase current
 as the power-supply phase-voltage. The equipment, thus,
 can be operated with the power-factor of almost "1."
 This makes it possible to reduce the power transformer
 capacity and downsize the other devices, compared with
 those required without the converter.
- Upgraded braking performance Regenerated energy occurring at highly frequent accelerating and decelerating operation and elevating machine operation is entirely returned to power supply side.

Thus, energy saving during regenerative operation is possible.

As the current waveform is sinusoidal during regenerative operation, no troubles are caused to the power supply system.

Rated continuous regeneration :100%Rated regeneration for 1 min150%

150% (CT use) 120% (VT use)

- Enhanced maintenance/protective functions
- Failure can be easily analyzed with the trace back function (option).
- (1) The past 10 alarms can be displayed with the 7-segment LEDs.

This helps you analyze the alarm causes and take countermeasures.

- (2) When momentary power failure occurs, the converter shuts out the gate to enable continuous operation after recovery.
- (3) The converter can issue warning signals like overload, heat sink overheating, or the end of service life prior to converter tripping.
- Enhanced network support

The converter can be connected to MICREX-SX, F series and CC-Link master devices (using option). The RS-485 interface is provided as standard.



If an old inverter (FRENIC5000VG7, FRENIC5000G11/P11, etc.) combined with RHC series is replaced by FRENIC-eHVAC, it might be necessary to change wires of the auxiliary power circuit. Refer to the operation manual of RHC series for details.



Comparison of Input Current Waveforms



(With PWM converter)





11.9.2 Specifications

[1] Standard specifications

200 V class series

		Item	Standard specifications												
	une		200 V cla	ass series											
			7.5	11	15	18.5	22	30	37	45	55	75	90		
	Aj (ł	pplicable inverter capacity kW)	7.5	11	15	18.5	22	30	37	45	55	75	90		
ode	ц	Continuous capacity (kW)	8.8	13	18	22	26	36	44	53	65	88	103		
E	đ	Overload rating	150% of	continuous	s rating for	1 minute						•	•		
б	Ō	Voltage 200 V	320 to 3	55 VDC (Va	ariable with										
	Re	equired power supply (kVA)	9.5	14	19	24	29	38	47	57	70	93	111		
	Ca	arrier frequency	15 kHz (1	15 kHz (typical)											
	Applicable inverter capacity (kW)		11	15	18.5	22	30	37	45	55	75	90	110		
de	Ħ	Continuous capacity (kW)	13	18	22	26	36	44	53	65	88	103	126		
Ĕ	Į	Overload rating	120% of	continuous	s rating for	1 minute			•				•		
5	õ	Voltage 200 V	320 to 38	55 VDC (Va	ariable with	input pow	er voltage) (*1)							
	Required power supply (kVA		14	19	24	29	38	47	57	70	93	111	136		
	C	arrier frequency	10 kHz (1	typical)								6 kHz (ty	pical)		
put	Ni VC	umber of phases, bltage, frequency	Three-ph 200 to 22	nase three 20 V 50 Ha	lines, z, 220 to 23	10 V 50 H:	z (*2), 200	to 230 V	60 Hz						
느업	V	oltage/frequency fluctuation	on Voltage: –15 to +10%, Frequency: ±5%, Voltage unbalance: 2% or less (*3)												

400 V class series

	Item		Standard specifications																					
т.	una		400	V cla	ss ser	ies																		
	ype		7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	500	630
	Ap (H	oplicable inverter capacity (W)	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	500	630
bde	ŧ	Continuous capacity (kW)	8.8	13	18	22	26	36	44	53	65	88	103	126	150	182	227	247	314	353	400	448	560	705
Ĕ	ntp(Overload rating	150%	% of c	ontin	Jous	rating	for 1	min															
5	õ	Voltage 200 V	640	to 71() V (\	′ariab	le wit	h inpu	it pow	er vo	Itage) (*1)												
[Re	equired power supply (kVA)	9.5	14	19	24	29	38	47	57	70	93	111	136	161	196	244	267	341	383	433	488	610	762
	Ca	arrier frequency	15 k	Hz (ty	pical)	1						10 ki	Hz (ty	, (pical)								6 kHz (typical)		
	Aj (H	pplicable inverter capacity (W)	11	15	18.5	22	30	37	45	55	75	90	110	132	160	200	220	280	315	355	400	500		
ge	Ħ	Continuous capacity (kW)	13	18	22	26	36	44	53	65	88	103	126	150	182	227	247	314	353	400	448	560		
Ĕ	Itp	Overload rating	120% of continuous rating for 1 min																					
5	õ	Voltage 200 V	640	to 71() V (V	'ariab	le wit	h inpu	it pow	/er vo	Itage) (*1)												
	R	equired power supply (kVA)	14	19	24	29	38	47	57	70	93	111	136	161	196	244	267	341	383	433	488	610		
	Ca	arrier frequency	10 k	Hz (ty	/pical])						6 kH	z (typ	ical)										
wer	Νι vo	umber of phases, Itage, frequency	Thre 380	e-pha to 44	aseth DV 5	ree lir 0 Hz,	nes, 380 1	to 460) V 60	Hz ('	[•] 4)													
- 8	Vo	oltage/frequency fluctuation	Volta	age: -	-15 to	+10%	∕₀, Fre	equen	cy: ±	5%, ۱	∕oltaç	ge unt	palan	ce: 2%	6 or le	ess (*	3)							

(*1) When the power supply voltage is 200/400 V, 220/440 V, or 230/460 V, the output voltage is approximate 320/640 VDC, 343/686 VDC, 355/710 VDC, respectively.

- (*2) The 220 to 230 V/50 Hz models are available on request.
- (*3) Voltage unbalance (%) = (Max. voltage (V) Min. voltage (V)) / Three-phase average voltage (V) x 67

(*4) When the power supply voltage is 380 to 398 V/50 Hz and 380 to 430 V/60 Hz, tap-switching is required in the converter.

	Item	Specifications
	Control method	AVR constant control with DC ACR minor
	Running/Stopping	Starts rectification when the converter is powered ON after connection. Starts boosting when it receives a run signal (terminals [RUN] and [CM] short-circuited or a run command via the communications link). After that, the converter is ready to run.
_	Running status signal	Running, power running, regenerative operation, ready-to-run, alarm output (for any alarm), etc.
Contro	CT/VT switching	Switching between CT and VT modes. CT: 150% of overload rating for 1 min VT: 120% of overload rating for 1 min
	Carrier frequency	Fixed to high carrier frequency
	Input power factor	0.99 or above
	Restart after momentary power failure	Stops the gates (boosting) when the voltage level reaches the undervoltage level if a momentary power failure occurs, and the converter can automatically restart after the power recovers.
	Power limiting control	Controls the power not to exceed the preset limit value.
	Alarm display (Protective functions)	AC fuse blown, AC overvoltage, AC undervoltage, AC overcurrent, AC input current error, input phase loss, synchronous power supply frequency error, DC fuse blown, DC overvoltage, DC undervoltage, charge circuit fault, heat sink overheat, external alarm, converter internal overheat, overload, memory error, keypad communications error, CPU error, network device error, operation procedure error, A/D converter error, optical network error, IPM error
ation	Alarm history	Saves and displays the most recent 10 alarms. Saves and displays the detailed information of the trip cause for the previous alarm.
India	Monitor	Displays input power, input current in RMS, input voltage in RMS, DC link bus voltage and power supply frequency.
	Load factor	Allows the user to measure the load factor with the keypad.
	Language	Allows the user to check and modify function codes in any of the three languagesJapanese, English or Chinese.
	Charging lamp	Lights when the DC link bus capacitor is charged

[2] Common specifications

11.9.3 Function specifications

Terminal functions

Classifi -cation	Symbol	Name	Functions									
uit	L1/R, L2/S, L3/T	Main circuit power inputs	Connects with the three-phase input power lines through a dedicated reactor.									
circ	P(+), N(-)	Converter outputs	Connects with the power input terminals P(+) and N(-) on an inverter.									
ain.	e	Grounding	Grounding terminal for the converter's chassis (or enclosure).									
Ma	R0, T0	Auxiliary power input for the control circuit	For the backup of the control circuit power supply, connect the power lines same as that of the main power input.									
ltage ection	R1, S1, T1	Synchronous power input for voltage detection	Voltage detection terminals for the internal control of the converter. Connect with the power supply side of the dedicated reactor or filter.									
det Vo	R2, T2	Inputs for control monitoring	Detection terminal for AC fuse blown.									
	[RUN]	Run command	Short-circuiting terminals [RUN] and [CM] runs the converter; opening them stops the converter.									
le	[RST]	Reset alarm command	When the converter stops due to an alarm, removing the alarm factor and short-circuiting the terminals [RST] and [CM] cancels the protective function, restarting the converter.									
Input signa	[X1]	General-purpose transistor input	 Enable external alarm trip <i>THR</i> Cancel current limiter <i>LMT-CCL</i> 73 answerback <i>73ANS</i> Switch current limiter <i>I-LIM</i> Option DI <i>OPT-DI</i> 									
	[CM]	Digital input common	Common terminal for digital input signals.									
[F	[PLC]	PLC signal power	connects to PLC output signal power supply. (Rated voltage: 24 VDC (2 77 VDC)									
	[30A/B/C]	Alarm relay output (for any alarm)	Outputs a signal when the protective function is activated to stop the converter. (Contact: [1C], Terminals [30A] and [30C] are closed: Signal ON) (Contact rating: 250 VAC, max. 50 mA)									
;] [] []	[Y1], [Y2], [Y3], [Y11] to [Y18]	General-purpose transistor output	0: Converter running <i>RUN</i> 1: Converter ready to run <i>RDY</i>									
	[CME]	Digital output common	2: Power supply current limiting IL									
Output signal	[Y5A/C]	Relay output	 3: Lifetime alarm <i>LIFE</i> 4: Heat sink overheat early warning <i>PRE-OH</i> 5: Overload early warning <i>PRE-OL</i> 6: Power running <i>DRV</i> 7: Regenerating <i>REG</i> 8: Current limiting early warning <i>CUR</i> 9: Restarting after momentary power failure <i>U-RES</i> 10: Synchronizing power supply frequency <i>SY-HZ</i> 11: Alarm content 1 <i>AL1</i> 12: Alarm content 2 <i>AL2</i> 13: Alarm content 4 <i>AL4</i> 14: Option DO <i>OPT-DO</i> * Mounting the OPC-VG7-DIOA option makes 8 points of DO extended functions available. (DI functions are not available.) 									
	[A01], [A04], [A05]	General-purpose analog output	 0: Input power <i>PWR</i> 1: Input current in RMS <i>I-AC</i> 2: Input voltage in RMS <i>V-AC</i> 3: DC link bus voltage <i>V-DC</i> 4: Power supply frequency <i>FREQ</i> 5: +10 V test <i>P10</i> 6: -10 V test <i>N10</i> * Mounting the OPC-VG7-AIO option makes 2 points of AO extended functions available. (AI functions are not available.) 									
		Charging resistor input										
	[73A], [73C]	relay outputs	Control output for the input relay of the external charging resistor (73).									

Item		Specifications							
General communicati specifications	on	Monitoring the running information, running status and function code data, and controlling (selecting) the terminals [RUN], [RST] and [X1]. * Writing to function codes is not possible.							
RS-485 (standard)		Communicating with a PC or PLC. (The converter supports the Fuji general-purpose inverter protocol and Modbus RTU protocol.)							
T-Link (option)		Mounting the OPC-VG7-TL option enables communication with a T-Link module of MICREX-F or MICREX-SX via a T-Link network.							
SX-bus (option)		Mounting the OPC-VG7-SX option enables communication with a MICREX-SX via an SX bus network.							
CC-Link (option)		Mounting the OPC-VG7-CCL option enables communication with a CC-Link master.							
Traceback (option)	Hardware	Mounting the OPC-RHC-TR option enables tracing back of the running status data of the converter. WPS-LD-TR software is required.							
	Software	Installing the WPS-RHC-TR software enables collecting of traceback data on the PC.							

Communications specifications

Function settings

Function code	Name
F00	Data protection
F01	High frequency filter selection
F02	Restart mode after momentary power failure (Mode selection)
F03	Current rating switching
F04	LED monitor, item selection
F05	LCD monitor, item selection
F06	LCD monitor, language selection
F07	LCD monitor, contrast control
F08	Carrier frequency
E01	Terminal [X1] function
E02 to E13	Terminal [Y1], [Y2], [Y3,], [Y5], [Y11] to [Y18] function
E14	I/O function normal open/closed
E15	RHC overload early warning level
E16	Cooling fan ON/OFF control
E17	Under current limiting (Hysteresis width)
E18 to E20	A01, A04 and A05, function selection
E21 to E23	A01, A04 and A05, gain setting
F24 to F26	A01, A04 and A05, bias setting
E27	A01, A04 and A05, filter setting
 S01	Operation method
S02, S03	Power supply current limiting (driving/braking)
H01	Station address
H02	Communications error processing
H03	Timer
H04	Baud rate
H05	Data length
H06	Parity bits
H07	Stop bits
H08	No-response error detection time
H09	Response interval
H10	Protocol selection
H11	TL transmission format
H12	Parallel system
H13	Number of slave stations in parallel system
H14	Clear alarm data
H15. H16	Power supply current limiter (driving 1/2)
H17, H18	Power supply current limiter (braking 1/2)
H19, H20	Current limiting early warning (level/timer)
M09	Power supply frequency
M10	Input power
M11	Input current in RMS
M12	Input voltage in RMS
M13	Run command
M14	Running status
M15	Output terminals [V1] to [V18]
ini io	

Protective functions

Item	LED monitor displays:	Description	Remarks
AC fuse blown	REF	Stops the converter output if the AC fuse (R-/T-phase only) is blown.	
AC overvoltage	ROLI	Stops the converter output upon detection of an AC overvoltage condition.	
AC undervoltage	RLU	Stops the converter output upon detection of an AC undervoltage condition.	
AC overcurrent	ADE	Stops the converter output if the peak value of the input current exceeds the overcurrent level.	
AC input current error	ACE	Stops the converter output upon detection of the excessive deviation of the AC reactor from the AC input.	
Input phase loss	LPU	Stops the converter output upon detection of an input phase loss.	
Synchronous power frequency error	FrE	After the MC for charging circuit (73) is turned on, the converter checks the power frequency. If it detects a power frequency error, this function stops the converter output. An error during converter running (e.g., momentary power failure) triggers no alarm.	
DC fuse blown	dEF	Stops the converter output if the DC fuse (P side) is blown.	18.5 kW or above
DC overvoltage	dOU	Stops the converter output upon detection of a DC overvoltage condition. If a power failure continues for a long time and the control power source is shut down, this alarm is automatically reset.	200 V class series: 400 V ±3 V 400 V class series: 800 V ±5 V
DC undervoltage	dlu	Stops the converter output upon detection of a DC undervoltage condition. If a power failure continues for a long time and the control power source is shut down, this alarm is automatically reset.	200 V class series: Stops at 185 V, restarts at 208 V. 400 V class series: Stops at 371 V, restarts at 417 V.
Charging circuit fault	<i>P6F</i>	Stops the converter output upon detection of a charging circuit fault, provided that the answerback signal from 73 is enabled.	Condition: 73ANS (Answerback from 73) is assigned to terminal [X1].
Heat sink overheat	DH I	Stops the converter output upon detection of a heat sink overheat.	
External alarm	OHZ	Stops the converter output upon receipt of an external signal <i>THR</i> .	Condition: <i>THR</i> (Enable external alarm trip) is assigned to terminal [X1].
Converter internal overheat	DH3	Stops the converter output upon detection of an internal overheat of the converter.	
Converter overload	OLU	Stops the converter output with the inverse-time characteristics due to the input current.	Activate at 105%, 150% for 1 min
Memory error	Er 1	Stops the converter output if a data writing error or any other memory error occurs (when the checksums of the EEPROM and RAM do not match).	
Keypad communications error	Er-2'	Displays " $\mathcal{E}_{\mathcal{T}}\mathcal{Z}$ " upon detection of a wire break in initial communication with the keypad. This does not affect the converter operation.	
CPU error	Er 3	Activated if a CPU error occurs.	
Network device error	Er-4	Stops the converter output if a fatal error (including no power supply connection) occurs in the master unit in the network.	Applies to T-Link, SX-bus, and CC-Link devices.
Operation procedure error	Er-6	Stops the converter output upon detection of an error in the operation procedure.	
A/D converter error	E-8	Stops the converter output upon detection of a failure in the A/D converter circuit.	
Optical network error	Егь	Stops the converter output upon detection of an optical cable break or a fatal error in the optical option.	
IPM error	175	Activated when the IPM's self-diagnosis function works due to an overcurrent or overheat.	15 kW or below

	Item	Required structure, environment and standards	Remarks
	Structure	Mounting in a panel or mounting for external cooling	
	Enclosure	IP00	
ure	Cooling system	Forced air cooling	
nct	Installation	Vertical installation	
Str	Coating color	Munsell 5Y3/0.5, eggshell (Same color as our inverter FRENIC 5000VG7S series.)	
	Maintainability	Structure designed for easy parts replacement	
	Site location	Shall be free from corrosive gases, flammable gases, dusts, and direct sunlight. Indoor use only.	
	Surrounding temperature	-10 to 50°C	
nt	Relative humidity	5 to 95% RH (No condensation)	
onme	Altitude	3,000 m max. (For use in an altitude between 1,001 m to 3,000 m, the output current should be derated.)	
Envir	Vibration	2 to 9 Hz: Amplitude = 3 mm, 9 to 20 Hz: 9.8 m/s ² , 20 to 55 Hz: 2 m/s ² (9 to 55 Hz: 2 m/s ² for 90 kW or above), 55 to 200 Hz: 1 m/s ²	
	Storage temperature	-20 to 55°C	
	Storage humidity	5 to 95% RH	

Required structure and environment

11.9.4 Converter configuration

List of configurators

CT mode

	Nominal	PWM	MC for char	nina	MC for poy	ver			Charging box	(*1)			Boostir	ng	Filtering resist	or	Filtering	3	Filtering		MC for filtering
owe	applied metor	converter	circui	t	supp	ly l			Charging resis	stor	Fuse		reacto	r	T intering resist		reactor		capacit	or	circuit
<u>т</u> 20	(k₩)	type	(73)	Q'ty	(52)	Qʻty	(CU)	Qʻty	(R0)	Qʻty	(F)	Qʻty	(Lr)	Qʻty	(Rf)	Qʻty	(Lf)	Q'ty	(Cf)	Qʻty	(6F) Q'ty
	7.5	RHC7.5-2C	SC-5-1	1			CU7.5-2C	1	(80W 7.5Ω)	(3)	(CR2LS-50/UL)	(2)	LR2-7.5C	1	GRZG80 0.42 Ω	3	LFC2-7.5C	1	CF2-7.5C	1	
	11	RHC11-2C	SC-N1	1			CU11-2C	1	(HF5C5504)		(CR2LS-75/UL)	(2)	LR2-15C	1	GRZG150 0.2 Ω	3	LFC2-15C	1	CF2-15C	1	
s	15	RHC15-2C	SC-N2	1			CU15-2C	1			(CR2LS-100/UL)	(2)									
erie	18.5	RHC18.5-2C	SC-N3	1			CU18.5-2C	1	(GRZG120 2 Q)	(3)			LR2-22C	1	GRZG200 0.13 Q	3	LFC2-22C	1	CF2-22C	1	
ŝŝ	22	RHC22-2C					CU22-2C	1			(CR2L-150/UL)	(2)									
clas	30	RHC30-2C	SC-N4	1			CU30-2C	1			(CR2L-200/UL)	(2)	LR2-37C	1	GRZG400 0.1Ω	3	LFC2-37C	1	CF2-37C	1	
Š	37	RHC37-2C	SC-N5	1			CU45-2C	1			(CR2L-260/UL)	(2)									
20	45	RHC45-2C	SC-N7	1									LR2-55C	1			LFC2-55C	1	CF2-55C	1	
	55	RHC55-2C	SC-N8	1			CU55-2C	1			(CR2L-400/UL)	(2)									
	75	RHC75-2C	SC-N11	1			CU75-2C	1					LR2-75C	1			LFC2-75C	1	CF2-75C	1	
	90	RHC90-2C					CU90-2C	1	(GRZG400 1 Q)	(3)	(A50P600-4)	(2)	LR2-110C	1	GRZG400 0.12 Q	6	LFC2-110C	1	CF2-110C	1	
															(2 pcs in parallel)						
	7.5	RHC7.5-4C	SC-05	1			CU7.5-4C	1	(TK50B 30 Q J)	(3)	(CR6L-30/UL)	(2)	LR4-7.5C	1	GRZG80 1.74 Ω	3	LFC4-7.5C	1	CF4-7.5C	1	
	11	RHC11-4C	SC-4-0	1			CU15-4C	1	(HF5B0416)		(CR6L-50/UL)	(2)	LR4-15C	1	GRZG150 0.79 Ω	3	LFC4-15C	1	CF4-15C	1	
	15	RHC15-4C	SC-5-1	1																	
	18.5	RHC18.5-4C	SC-N1	1			CU18.5-4C	1	(80W 7.5Ω)	(3)			LR4-22C	1	GRZG200 0.53 Q	3	LFC4-22C	1	CF4-22C	1	
	22	RHC22-4C					CU22-4C	1	(HF5C0416)		(CR6L-75/UL)	(2)									
	30	RHC30-4C	SC-N2	1			CU30-4C	1			(CR6L-100/UL)	(2)	LR4-37C	1	GRZG400 0.38 Ω	3	LFC4-37C	1	CF4-37C	1	
	37	RHC37-4C	SC-N2S	1			CU45-4C	1			(CR6L-150/UL)	(2)									
	45	RHC45-4C	SC-N3	1									LR4-55C	1	GRZG400 0.26 Q	3	LFC4-55C	1	CF4-55C	1	
ies	55	RHC55-4C	SC-N4	1			CU55-4C	1			(CR6L-200/UL)	(2)									
ser	75	RHC75-4C	SC-N5	1			CU75-4C	1					LR4-75C	1	GRZG400 0.38Ω	3	LFC4-75C	1	CF4-75C	1	
ass	90	RHC90-4C	SC-N7	1			CU90-4C	1			(CR6L-300/UL)	(2)	LR4-110C	1	GRZG400 0.53 Q	6	LFC4-110C	1	CF4-110C	1	
Ğ	110	RHC110-4C	SC-N8	1			CU110-4C	1	(GRZG120 2 Q)	(3)					(2 pcs in parallel)						
6	132	RHC132-4C					CU132-4C	1			(A50P400-4)	(2)	LR4-160C	1	RF4-160C	1	LFC4-160C	1	CF4-160C	1	
4	160	RHC160-4C	SC-N11	1			CU160-4C	1			(A50P600-4)	(2)								\square	
	200	RHC200-4C	SC-N12	1			CU200-4C	1	(GRZG400 1 Ω)	(3)			LR4-220C	1	RF4-220C	1	LFC4-220C	1	CF4-220C	1	
	220	RHC220-4C					CU220-4C	1			(A70QS800-4)	(2)									
	280	RHC280-4C	SC-N3	1	SC-N14	1			GRZG400 1 Q	6	A70QS800-4	2	LR4-280C	1	RF4-280C	1	LFC4-280C	1	CF4-280C	1	SC-N4 1
	315	RHC315-4C							(2 pcs in parallel)		A70P1600-4TA	2	LR4-315C	1	RF4-315C	1	LFC4-315C	1	CF4-315C	1	
	355	RHC355-4C											LR4-355C	1	RF4-355C	1	LFC4-355C	1	CF4-355C	1	
	400	RHC400-4C			SC-N16	1							LR4-400C	1	RF4-400C	1	LFC4-400C	1	CF4-400C	1	
	500	RHC500-4C			SC-N11	3							LR4-500C	1	RF4-500C	1	LFC4-500C	1	CF4-500C	1(*2)	SC-N4 ^(*3) 1
	630	RHC630-4C			SC-N12	3					A70P2000-4	2	LR4-630C	1	RF4-630C	1	LFC4-630C	1	CF4-630C	1(*2)	SC-N7 ^(*4) 1
V	/T mc	ndo –		_						_								_		_	

VT mode

	Nominal	PWM	MC		MC				Charging box	((*1)			Boostir	ıg	Filtering social		Filterin	g	Filterin	g	MC 1	or
(Iddr	applied motor	converter	circui	ging it	suppl	yer y			Charging resis	stor	Fuse		reacto	r	Filtering resist	lor	reacto	r	capacit	or	circu	ng uit
<u>с</u> 3	(KW)	type	(73)	Qʻty	(52)	Qʻly	(CU)	Q'ty	(R0)	Qʻty	(F)	Q'ty	(Lr)	Q'ty	(Rf)	Q'ty	(Lf)	Qʻty	(Cf)	Qʻty	(6F)	Q'ty
	11	RHC7.5-2C	SC-N1	1			CU7.5-2C	1	(80W 7.5Ω)	(3)	(CR2LS-50/UL)	(2)	LR2-15C	1	GRZG150 0.2 Ω	3	LFC2-15C	1	CF2-15C	1		
	15	RHC11-2C	SC-N2	1			CU11-2C	1	(HF5C5504)		(CR2LS-75/UL)	(2)										
s	18.5	RHC15-2C	SC-N3	1			CU15-2C	1			(CR2LS-100/UL)	(2)	LR2-22C	1	GRZG200 0.13 Q	3	LFC2-22C	1	CF2-22C	1		
erie	22	RHC18.5-2C					CU18.5-2C	1	(GRZG1202Ω)	(3)												
ss	30	RHC22-2C	SC-N4	1			CU22-2C	1			(CR2L-150/UL)	(2)	LR2-37C	1	GRZG400 0.1 Ω	3	LFC2-37C	1	CF2-37C	1		
clas	37	RHC30-2C	SC-N5	1			CU30-2C	1			(CR2L-200/UL)	(2)										
>	45	RHC37-2C	SC-N7	1			CU45-2C	1			(CR2L-260/UL)	(2)	LR2-55C	1			LFC2-55C	1	CF2-55C	1		
00	55	RHC45-2C	SC-N8	1																		
	75	RHC55-2C	SC-N11	1			CU55-2C	1			(CR2L-400/UL)	(2)	LR2-75C	1			LFC2-75C	1	CF2-75C	1		
	90	RHC75-2C					CU75-2C	1					LR2-110C	1	GRZG400 0.12 Q	6	LFC2-110C	1	CF2-110C	1		
	110	RHC90-2C	SC-N12	1			CU90-2C	1	(GRZG400 1Ω)	(3)	(A50P600-4)	(2)			(2 pcs in parallel)							
	11	RHC7.5-4C	SC-4-0	1			CU7.5-4C	1	(TK50B 30 Q J)	(3)	(CR6L-30/UL)	(2)	LR4-15C	1	GRZG150 0.79 Q	3	LFC4-15C	1	CF4-15C	1		
	15	RHC11-4C	SC-5-1	1			CU15-4C	1	(HF5B0416)		(CR6L-50/UL)	(2)										
	18.5	RHC15-4C	SC-N1	1									LR4-22C	1	GRZG200 0.53 Q	3	LFC4-22C	1	CF4-22C	1		
	22	RHC18.5-4C					CU18.5-4C	1	(80W 7.5Ω)	(3)												
	30	RHC22-4C	SC-N2	1			CU22-4C	1	(HF5C5504)		(CR6L-75/UL)	(2)	LR4-37C	1	GRZG400 0.38Ω	3	LFC4-37C	1	CF4-37C	1		
	37	RHC30-4C	SC-N2S	1			CU30-4C	1			(CR6L-100/UL)	(2)										
6	45	RHC37-4C	SC-N3	1			CU45-4C	1]		(CR6L-150/UL)	(2)	LR4-55C	1	GRZG400 0.26Ω	3	LFC4-55C	1	CF4-55C	1		
erie	55	RHC45-4C	SC-N4	1																		
s se	75	RHC55-4C	SC-N5	1			CU55-4C	1]		(CR6L-200/UL)	(2)	LR4-75C	1	GRZG400 0.38 Q	3	LFC4-75C	1	CF4-75C	1		
las	90	RHC75-4C	SC-N7	1			CU75-4C	1					LR4-110C	1	GRZG400 0.53 Ω	6	LFC4-110C	1	CF4-110C	1		
>	1 10	RHC90-4C	SC-N8	1			CU90-4C	1			(CR6L-300/UL)	(2)			(2 pcs in parallel)							
00	132	RHC110-4C					CU110-4C	1	(GRZG1202Ω)	(3)			LR4-160C	1	RF4-160C	1	LFC4-160C	1	CF4-160C	1		
~	160	RHC132-4C	SC-N11	1			CU132-4C	1			(A50P400-4)	(2)										
	200	RHC160-4C	SC-N12	1			CU160-4C	1			(A50P600-4)	(2)	LR4-220C	1	RF4-220C	1	LFC4-220C	1	CF4-220C	1		
	220	RHC200-4C					CU200-4C	1	(GRZG400 1Ω)	(3)												
	280	RHC220-4C	SC-N14	1			CU220-4C	1			(A70QS800-4)	(2)	LR4-280C	1	RF4-280C	1	LFC4-280C	1	CF4-280C	1		
	315	RHC280-4C	SC-N3	1	SC-N14	1			GRZG400 1 Ω	6	A70Q\$800-4	2	LR4-315C	1	RF4-315C	1	LFC4-315C	1	CF4-315C	1	SC-N4	1
	355	RHC315-4C							(2 pcs in parallel)		A70P1600-4TA	2	LR4-355C	1	RF4-355C	1	LFC4-355C	1	CF4-355C	1		
	400	RHC355-4C	1		SC-N16	1							LR4-400C	1	RF4-400C	1	LFC4-400C	1	CF4-400C	1		
	500	RHC400-4C			SC-N11	3							LR4-500C	1	RF4-500C	1	LFC4-500C	1	CF4-500C	1(*2)	SC-N4/SF	1

(*1) The charging box (CU) contains a combination of a charging resistor (R0) and a fuse (F). If no CU is used, it is necessary to prepare the charging resistor (R0) and fuse (F) at your end.

The filtering capacitor consists of two pieces of capacitors. For an order of quantity "1," two pieces of capacitors are to be delivered. (*2)

(*4) If the carrier frequency is lowered or OPC-VG7-SIR is applied, use SC-N4/SF for (*3) and SC-N8 for (*4) because the losses increases. (*3)

Basic connection diagrams

- RHC7.5-2C to RHC90-2C (Applicable inverters: Three-phase 200 V • class series, 7.5 to 90 kW)
- RHC7.5-4C to RHC220-4C (Applicable inverters: Three-phase 400 class series, 7.5 to 220 kW)



- (*1) For the 400 V class power supply, connect a stepdown transformer to limit the voltage of the sequence circuit to 220 V or below.
- Be sure to connect the auxiliary power input terminals R0 and T0 of the PWM converter to the main power input lines via B (NC) contacts of magnetic contactors of the charging circuit (73 or MC).

If 73 uses SC-05, SC-4-0, or SC-5-1, connect an auxiliary contact unit to the MC's B contact or 73.

- (*3) Be sure to connect the auxiliary power input terminals R0 and T0 of the inverter to the main power input lines via B (NC) contacts of magnetic contactors of the charging circuit (73 or MC). For 200 V class series of inverters with a capacity of 37 kW or above and 400 V class series with a capacity of 75 kW or above, connect the fan power input terminals R1 and T1 of the inverter to the main power input lines without going through the MC's B (NC) contacts or 73.
- (*4) Construct a sequence in which a run command is given to the inverter after the PWM converter becomes ready to run.
- (*5) Assign the external alarm THR to any of terminals [X1] to [X5] on the inverter.
- RHC280-4C to RHC400-4C (Applicable inverters: Three-phase 400 V. 280 to 400 kW)



- 220 V or below
- (*2) Be sure to connect the auxiliary power input terminals R0 and T0 of the PWM converter and the inverter to the main power input terminals to and to or the PVWM magnetic contactors of the power supply circuit (52). Connect the fan power input terminals R1 and T1 of the inverter to the main power input lines without going through the B (NC) contacts of 52, since the
- (*3) inverter's AC fans are supplied with power from these terminals. Construct a sequence in which a run command is given to the inverter after
- (*4) the PWM converter becomes ready to run. Set the timer 52T to 1.
- (*5) Assign the external alarm **THR** to any of terminals [X1] to [X5] on the inverter. (*6)

- RHC7.5-2C to RHC90-2C (Applicable inverters: Three-phase 200 V) class series. 7.5 to 90 kW) RHC7.5-4C to RHC220-4C (Applicable inverters: Three-phase 400
- V class series, 7.5 to 220 kW)



- (*1) For the 400 V class power supply, connect a stepdown transformer to limit the voltage of the sequence circuit to 220 V or below.
- (*2) Be sure to connect the auxiliary power input terminals R0 and T0 of the PWM converter to the main power input lines via B (NC) contacts of magnetic contactors of the charging circuit (73 or MC). If 73 uses SC-05, SC-4-0, or SC-5-1, connect an auxiliary contact unit to the
- MC's B contact or 73. Be sure to connect the auxiliary power input terminals R0 and T0 of the inverter to the main power input lines via B (NC) contacts of magnetic contactors of the charging circuit (73 or MC). For 200 V class series of inverters with a capacity of 37 kW or above and 400 V class series with a
- capacity of 75 kW or above, connect the fan power input terminals R1 and T1 of the inverter to the main power input lines without going through the MC's B (NC) contacts or 73.
- Construct a sequence in which a run command is given to the inverter after (*4) the PWM converter becomes ready to run.
- (*5) Assign the external alarm THR to any of terminals [X1] to [X5] on the inverter.
- . RHC400-4C in VT mode (Applicable inverters: Three-phase 400 V. 400 kW)
- RHC500-4C and RHC630-4C (Applicable inverters: Three-phase 400 V. 500 and 630 kW)



- Connect a stepdown transformer to limit the voltage of the sequence circuit to (*1) 220 V or below.
- Be sure to connect the auxiliary power input terminals R0 and T0 of the PWM converter and the inverter to the main power input lines via B (NC) contacts of (*2) magnetic contactors of the power supply circuit (52). Connect the fan power input terminals R1 and T1 of the inverter to the main
- (*3) power input lines without going through the B (NC) contacts of 73 or 52, since the inverter's AC fans are supplied with power from these terminals.
- Construct a sequence in which a run command is given to the inverter after the PWM converter becomes ready to run. (*4)
- (*5) Set the timer 52T to 1.
- Assign the external alarm *THR* to any of terminals [X1] to [X5] on the inverter. Wiring for terminals L1/R, L2/S, L3/T, R2, T2, R1, S1, and T1 should match (*6) (*7) with the phase sequence.

11.9.5 External dimensions

PWM converter









- DV	M convertor type	Figure				Di	mensior	าร		mm	(inch)	Mass
FV	www.conventer.type	Figure	W	W1	н	H1	D	D1	n	В	С	kg (lb)
	RHC7.5-2C	A	250	226	380	358	245	125	2	10	10	12.5
	RHC11-2C	1	(9.8)	(8.9)	(15.0)	(14.1)	(9.7)	(4.9)	(0.08)	(0.39)	(0.39)	(28)
	RHC15-2C	1										
	RHC18.5-2C	в	340	240	480	460	255	145	2	10	10	24
	RHC22-2C	1 -	(13.4)	(9.5)	(18.9)	(18.1)	(10.0)	(5.7)	(0.08)	(0.39)	(0.39)	(53)
200 V	RHC30-2C	В	340 (13.4)	240 (9.5)	550 (21.7)	530 (20.9)	255 (10.0)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	29 (64)
senes	RHC37-2C	В	375 (14.8)	275 (10.8)	615 (24.2)	595 (23.4)	270 (10.6)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	36 (79)
	RHC45-2C	В	375 (14.8)	275 (10.8)	740 (29.1)	720 (28.4)	270 (10.6)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	42 (93)
	RHC55-2C	В	375 (14.8)	275 (10.8)	740 (29.1)	720 (28.4)	270 (10.6)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	44 (97)
	RHC75-2C	С	530 (20.9)	430 (16.9)	750 (29.5)	720 (28.4)	285 (11.2)	145 (5.7)	2 (0.08)	15 (0.59)	15 (0.59)	70 (154)
	RHC90-2C	С	680 (26.8)	580 (22.8)	880 (34.7)	850 (33.5)	360 (14.2)	220 (8.7)	3 (0.12)	15 (0.59)	15 (0.59)	115 (254)
	RHC7.5-4C	A	250	226	380	358	245	125	2	10	10	8
	RHC11-4C	1	(9.8)	(8.9)	(15.0)	(14.1)	(9.7)	(4.9)	(0.08)	(0.39)	(0.39)	(18)
	RHC15-4C	1										
	RHC18.5-4C	В	340	240	480	460	255	145	2	10	10	24
	RHC22-4C	1	(13.4)	(9.5)	(18.9)	(18.1)	(10.0)	(5.7)	(0.08)	(0.39)	(0.39)	(53)
	RHC30-4C	В	340 (13.4)	240 (9.5)	550 (21.7)	530 (20.9)	255 (10.0)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	29 (64)
	RHC37-4C	В	375 (14.8)	275 (10.8)	550 (21.7)	530 (20.9)	270 (10.6)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	34 (75)
	RHC45-4C	В	375	275	675	655	270	145	2	10	10	38
	RHC55-4C		(14.8)	(10.8)	(26.6)	(25.8)	(10.6)	(5.7)	(0.08)	(0.39)	(0.39)	(84)
	RHC75-4C	В	375 (14.8)	275 (10.8)	740 (29.1)	720 (28.4)	270 (10.6)	145 (5.7)	2 (0.08)	10 (0.39)	10 (0.39)	48 (106)
400 V	RHC90-4C	С	530	430	740	710	315	145	2	15	15	70
series	RHC110-4C	1	(20.9)	(16.9)	(29.1)	(28.0)	(12.4)	(5.7)	(0.08)	(0.59)	(0.59)	(154)
	RHC132-4C	С	530	430	1000	970	360	220	2	15	15	100
	RHC160-4C	1	(20.9)	(16.9)	(39.4)	(38.2)	(14.2)	(8.7)	(0.08)	(0.59)	(0.59)	(220)
	RHC200-4C	С	680	580	1000	970	360	220	3	15	15	140
	RHC220-4C	1	(26.8)	(22.8)	(39.4)	(38.2)	(14.2)	(8.7)	(0.12)	(0.59)	(0.59)	(309)
	RHC280-4C	с	680	580	1400	1370	450	285	3	15	15	320
	RHC315-4C	1	(26.8)	(22.8)	(55.1)	(53.9)	(17.7)	(11.2)	(0.12)	(0.59)	(0.59)	(705)
	RHC355-4C	С	880	780	1400	1370	450	285	4	15	15	410
	RHC400-4C	1	(34.7)	(30.7)	(55.1)	(53.9)	(17.7)	(11.2)	(0.16)	(0.59)	(0.59)	(904)
	RHC500-4C	D	999	900	1550	1520	500	313.2	4	15	15	525
	RHC630-4C	1	(39.3)	(35.4)	(61.0)	(59.8)	(19.7)	(12.3)	(0.16)	(0.59)	(0.59)	(1157)

Boosting reactor





Figure B





Roor	ting reactor type	Figuro			[Dimensio	ns		m	m (inch)	Mass
6008	sting reactor type	Figure	W	W1	Н	D	D1	D2	K	М	kg (lb)
	LR2-7.5C	A	180 (7.1)	75 (3.0)	205 (8.1)	105 (4.1)	85 (3.4)	95 (3.7)	7 (0.28)	M5	12 (26)
200 V series	LR2-15C	В	195 (7.7)	75 (3.0)	215 (8.5)	131 (5.2)	110 (4.3)	130 (5.1)	7 (0.28)	M8	18 (40)
	LR2-22C	С	240 (9.5)	80 (3.2)	340 (13.4)	215 (8.5)	180 (7.1)	145 (5.7)	10 (0.39)	M8	33 (73)
200 V series	LR2-37C	С	285 (11.2)	95 (3.7)	420 (16.5)	240 (9.5)	205 (8.1)	150 (5.9)	12 (0.47)	M10	50 (110)
	LR2-55C	С	285 (11.2)	95 (3.7)	420 (16.5)	250 (9.8)	215 (8.5)	160 (6.3)	12 (0.47)	M12	58 (128)
	LR2-75C	С	330 (13.0)	110 (4.3)	440 (17.3)	255 (10.0)	220 (8.7)	165 (6.5)	12 (0.47)	M12	70 (154)
	LR2-110C	С	345 (13.6)	115 (4.5)	500 (19.7)	280 (11.0)	245 (9.7)	185 (7.3)	12 (0.47)	M12	100 (220)
	LR4-7.5C	В	180 (7.1)	75 (3.0)	205 (8.1)	105 (4.1)	85 (3.4)	90 (3.5)	7 (0.28)	M4	12 (26)
	LR4-15C	A	195 (7.7)	75 (3.0)	215 (8.5)	131 (5.2)	110 (4.3)	120 (4.7)	7 (0.28)	M5	18 (40)
	LR4-22C	С	240 (9.5)	80 (3.2)	340 (13.4)	215 (8.5)	180 (7.1)	120 (4.7)	10 (0.39)	M6	33 (73)
	LR4-37C	С	285 (11.2)	95 (3.7)	405 (15.9)	240 (9.5)	205 (8.1)	130 (5.1)	12 (0.47)	M8	50 (110)
	LR4-55C	С	285 (11.2)	95 (3.7)	415 (16.3)	250 (9.8)	215 (8.5)	145 (5.7)	12 (0.47)	M10	58 (128)
	LR4-75C	С	330 (13.0)	110 (4.3)	440 (17.3)	255 (10.0)	220 (8.7)	150 (5.9)	12 (0.47)	M10	70 (154)
	LR4-110C	С	345 (13.6)	115 (4.5)	490 (19.3)	280 (11.0)	245 (9.7)	170 (6.7)	12 (0.47)	M12	100 (220)
400 V	LR4-160C	С	380 (15.0)	125 (4.9)	550 (21.7)	300 (11.8)	260 (10.2)	185 (7.3)	15 (0.59)	M12	140 (309)
series	LR4-220C	С	450 (17.7)	150 (5.9)	620 (24.4)	330 (13.0)	290 (11.4)	230 (9.1)	15 (0.59)	M12	200 (441)
	LR4-280C	С	480 (18.9)	160 (6.3)	740 (29.1)	330 (13.0)	290 (11.4)	240 (9.5)	15 (0.59)	M16	250 (551)
	LR4-315C	С	480 (18.9)	160 (6.3)	760 (29.9)	340 (13.4)	300 (11.8)	250 (9.8)	15 (0.59)	M16	270 (595)
	LR4-355C	С	480 (18.9)	160 (6.3)	830 (32.7)	355 (14.0)	315 (12.4)	255 (10.0)	15 (0.59)	M16	310 (683)
	LR4-400C	С	480 (18.9)	160 (6.3)	890 (35.0)	380 (15.0)	330 (13.0)	260 (10.2)	19 (0.75)	M16	340 (750)
	LR4-500C	С	525 (20.7)	175 (6.9)	960 (37.8)	410 (16.1)	360 (14.2)	290 (11.4)	19 (0.75)	M16	420 (926)
	LR4-630	D	600	200	640	440	390	285	19	_	450

Filtering reactor



Filter	ing register type	Figure			D	imensior	ıs		m	m (inch)	Mass
Filler	ing reactor type	Figure	W	W1	Н	D	D1	D2	К	М	kg (lb)
	LFC2-7.5C	В	125 (4.9)	40 (1.6)	100 (3.9)	85 (3.4)	67 (2.6)	85 (3.4)	6 (0.24)	M5	2.2 (4.9)
	LFC2-15C	В	125 (4.9)	40 (1.6)	100 (3.9)	93 (3.7)	75 (3.0)	90 (3.5)	6 (0.24)	M8	2.5 (5.5)
	LFC2-22C	В	125 (4.9)	40 (1.6)	100 (3.9)	93 (3.7)	75 (3.0)	105 (4.1)	6 (0.24)	M8	3.0 (6.6)
200 V series	LFC2-37C	В	150 (5.9)	60 (2.4)	115 (4.5)	103 (4.1)	85 (3.4)	125 (4.9)	6 (0.24)	M10	5.0 (11)
	LFC2-55C	В	175 (6.9)	60 (2.4)	145 (5.7)	110 (4.3)	90 (3.5)	140 (5.5)	6 (0.24)	M12	8.0 (18)
	LFC2-75C	В	195 (7.7)	80 (3.2)	200 (7.9)	120 (4.7)	100 (3.9)	150 (5.9)	7 (0.28)	M12	13 (29)
	LFC2-110C	С	255 (10.0)	85 (3.4)	230 (9.1)	118 (4.7)	95 (3.7)	165 (6.5)	7 (0.28)	M12	20 (44)
	LFC4-7.5C	Α	125 (4.9)	40 (1.6)	100 (3.9)	85 (3.4)	67 (2.6)	75 (3.0)	6 (0.24)	M4	2.2 (4.9)
	LFC4-15C	A	125 (4.9)	40 (1.6)	100 (3.9)	93 (3.7)	75 (3.0)	90 (3.5)	6 (0.24)	M5	2.5 (5.5)
	LFC4-22C	Α	125 (4.9)	40 (1.6)	100 (3.9)	93 (3.7)	75 (3.0)	95 (3.7)	6 (0.24)	M6	3.0 (6.6)
	LFC4-37C	В	150 (5.9)	60 (2.4)	115 (4.5)	103 (4.1)	90 (3.5)	110 (4.3)	6 (0.24)	M8	5.0 (11)
	LFC4-55C	В	175 (6.9)	60 (2.4)	145 (5.7)	110 (4.3)	90 (3.5)	120 (4.7)	6 (0.24)	M10	8.0 (18)
	LFC4-75C	В	195 (7.7)	80 (3.2)	200 (7.9)	113 (4.5)	93 (3.7)	130 (5.1)	7 (0.28)	M10	12 (26)
	LFC4-110C	С	255 (10.0)	85 (3.4)	220 (8.7)	113 (4.5)	90 (3.5)	145 (5.7)	7 (0.28)	M12	19 (42)
400 V series	LFC4-160C	С	255 (10.0)	85 (3.4)	245 (9.7)	137 (5.4)	110 (4.3)	150 (5.9)	10 (0.39)	M12	22 (49)
	LFC4-220C	D	300 (11.8)	100 (3.9)	320 (12.6)	210 (8.3)	180 (7.1)	170 (6.7)	10 (0.39)	M12	35 (77)
	LFC4-280C	D	330 (13.0)	110 (4.3)	330 (13.0)	230 (9.1)	195 (7.7)	195 (7.7)	12 (0.47)	M16	43 (95)
	LFC4-315C	D	315 (12.4)	105 (4.1)	365 (14.4)	230 (9.1)	195 (7.7)	200 (7.9)	12 (0.47)	M16	48 (106)
	LFC4-355C	D	315 (12.4)	105 (4.1)	395 (15.6)	235 (9.3)	200 (7.9)	210 (8.3)	12 (0.47)	M16	53 (117)
	LFC4-400C	D	345 (13.6)	115 (4.5)	420 (16.5)	235 (9.3)	200 (7.9)	235 (9.3)	12 (0.47)	M16	60 (132)
	LFC4-500C	D	345 (13.6)	115 (4.5)	480 (18.9)	240 (9.5)	205 (8.1)	240 (9.5)	12 (0.47)	M16	72 (159)
	LFC4-630C	E	435 (17.1)	145 (5.7)	550 (21.7)	295 (11.6)	255 (10.0)	200 (7.9)	15 (0.59)	-	175 (386)

Filtering capacitor



						Dir	nensio	ns		mm	(inch)	Mass
Filteri	ng capacitor type	Figure	W	W1	н	H1	D	D1	E	F	1	kg (lb)
	CF2-7.5C	A	165 (6.5)	150 (5.9)	185 (7.3)	-	70 (2.8)	40 (1.6)	30 (1.2)	7 (0.28)	M5	1.9 (4.2)
	CF2-15C	A	205 (8.1)	173 (6.8)	245 (9.7)	-	70 (2.8)	40 (1.6)	30 (1.2)	(0.28)	M5	3.5 (7.7)
	CF2-22C	A	280 (11.0)	265 (10.4)	260 (10.2)	-	90 (3.5)	55 (2.2)	80 (3.2)	7 (0.28)	M5	6.0 (13.0)
200 V series	CF2-37C	A	280 (11.0)	265 (10.4)	290 (11.4)	-	90 (3.5)	55 (2.2)	80 (3.2)	7 (0.28)	M5	7.0 (15.0)
	CF2-55C	A	280 (11.0)	265 (10.4)	340 (13.4)	-	90 (3.5)	55 (2.2)	80 (3.2)	(0.28)	M8	8.5 (19.0)
	CF2-75C	A	280 (11.0)	265 (10.4)	290 (11.4)	-	90 (3.5)	55 (2.2)	80 (3.2)	(0.28)	M6	7.0 (15.0)
	CF2-110C	A	280 (11.0)	265 (10.4)	340 (13.4)	-	90 (3.5)	55 (2.2)	80 (3.2)	7 (0.28)	M8	8.5 (19.0)
	CF4-7.5C	A	165 (6.5)	150 (5.9)	135 (5.3)	-	70 (2.8)	40 (1.6)	30 (1.2)	7 (0.28)	M5	1.3 (2.9)
	CF4-15C	A	165 (6.5)	150 (5.9)	215 (8.5)	-	70 (2.8)	40 (1.6)	30 (1.2)	(0.28)	M5	2.3 (5.1)
	CF4-22C	A	205 (8.1)	190 (7.5)	185 (7.3)	-	70 (2.8)	40 (1.6)	30 (1.2)	(0.28)	M5	2.5 (5.5)
	CF4-37C	A	205 (8.1)	190 (7.5)	205 (8.1)	-	70 (2.8)	40 (1.6)	30 (1.2)	7 (0.28)	M5	2.9 (6.4)
	CF4-55C	A	205 (8.1)	190 (7.5)	245 (9.7)	-	70 (2.8)	40 (1.6)	30 (1.2)	7 (0.28)	M5	3.5 (7.7)
	CF4-75C	A	205 (8.1)	190 (7.5)	205 (8.1)	-	70 (2.8)	40 (1.6)	30 (1.2)	7 (0.28)	M5	2.9 (6.4)
400.14	CF4-110C	A	205 (8.1)	190 (7.5)	245 (9.7)	-	70 (2.8)	40 (1.6)	30 (1.2)	(0.28)	M5	3.5 (7.7)
400 V series	CF4-160C	A	280 (11.0)	265 (10.4)	260 (10.2)	-	90 (3.5)	55 (2.2)	80 (3.2)	(0.28)	M6	6.0 (13.0)
	CF4-220C	В	435 (17.1)	400 (15.8)	310 (12.2)	125 (4.9)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	13.0 (29.0)
	CF4-280C	в	435 (17.1)	400 (15.8)	350 (13.8)	165 (6.5)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	15.0 (33.0)
	CF4-315C	в	435 (17.1)	400 (15.8)	460 (18.1)	275 (10.8)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	20.0 (44.0)
	CF4-355C	в	435 (17.1)	400 (15.8)	520 (20.5)	335 (13.2)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	23.0 (51.0)
	CF4-400C	в	435 (17.1)	400 (15.8)	610 (24.0)	425 (16.7)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	27.0 (60)
	CF4-500C	в	435 (17.1)	400 (15.8)	310 (12.2)	125 (4.9)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	13.0 (29.0)
	CF4-630C	в	435 (17.1)	400 (15.8)	460 (18.1)	275 (10.8)	100 (3.9)	-	80 (3.2)	15 × 20 * (0.59 × 0.79)	M12	20.0 (44.0)

* Elongate hole

Note

- Mount vertically. Do not lower onto its side and mount.
- All mounting feet must be secured to the cabinet floor, etc. Figure A: 2 mounting feet locations, Figure B: 4 mounting feet locations

Damage may occur due to vibrations or impact.

Filtering resistor



Filto	ring register type	Figuro				Dir	mensio	ns		mm	n (inch)	Mass	O'ty
Fille	ning resistor type	Figure	W	W1	W2	H1	H2	D	D1	D2	С	kg (lb)	Quy
	GRZG80 0.42Ω	A	167 (6.6)	148 (5.8)	115 (4.5)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	0.19 (0.4)	3
	GRZG150 0.2Ω	A	247 (9.7)	228 (9.0)	195 (7.7)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	0.19 (0.4)	3
200 V series	GRZG200 0.13Ω	А	306 (12.1)	287 (11.3)	254 (10.0)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	0.35 (0.8)	3
	GRZG400 0.1Ω	А	411 (16.2)	385 (15.2)	330 (13.0)	40 (1.6)	39 (1.5)	47 (1.9)	40 (1.6)	9.5 (0.37)	5.5 (0.22)	0.85 (1.9)	3
	GRZG400 0.12Ω	А	411 (16.2)	385 (15.2)	330 (13.0)	40 (1.6)	39 (1.5)	47 (1.9)	40 (1.6)	9.5 (0.37)	5.5 (0.22)	0.85 (1.9)	3
	GRZG80 1.74Ω	А	167 (6.6)	148 (5.8)	115 (4.5)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	0.19 (0.4)	3
	GRZG150 0.79Ω	A	247 (9.7)	228 (9.0)	195 (7.7)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	0.19 (0.4)	3
	GRZG200 0.53Ω	A	306 (12.1)	287 (11.3)	254 (10.0)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	0.35 (0.8)	3
	GRZG400 0.38Ω	А	411 (16.2)	385 (15.2)	330 (13.0)	40 (1.6)	39 (1.5)	47 (1.9)	40 (1.6)	9.5 (0.37)	5.5 (0.22)	0.85 (1.9)	3
	GRZG400 0.26Ω	A	411 (16.2)	385 (15.2)	330 (13.0)	40 (1.6)	39 (1.5)	47 (1.9)	40 (1.6)	9.5 (0.37)	5.5 (0.22)	0.85 (1.9)	3
	GRZG400 0.53Ω	А	411 (16.2)	385 (15.2)	330 (13.0)	40 (1.6)	39 (1.5)	47 (1.9)	40 (1.6)	9.5 (0.37)	5.5 (0.22)	0.85 (1.9)	6
400 V series	RF4-160C	в	400 (15.8)	370 (14.6)	-	240 (9.5)	55 (2.2)	470 (18.5)	460 (18.1)	320 (12.6)	-	22 (49)	1
	RF4-220C	1										25 (55)	1
	RF4-280C	с	655 (25.8)	625 (24.6)	-	240 (9.5)	55 (2.2)	470 (18.5)	460 (18.1)	320 (12.6)	-	31 (68.3)	1
	RF4-315C]										35 (77.2)	1
	RF4-355C]										36 (79.4)	1
	RF4-400C											38 (83.8)	1
	RF4-500C	1										41 (90)	1
	RF4-630C	с	655 (25.8)	625 (24.6)	-	440 (17.3)	55 (2.2)	530 (20.9)	520 (20.5)	320 (12.6)	-	70 (154)	1

Charging box

The charging box contains a combination of a charging resistor and a fuse, which is essential in the configuration of the RHC-C series of PWM converters. Using this charging box eases mounting and wiring jobs.

Capacity range

200 V class series: 7.5 to 90 kW (10 to 150 HP) in 10 types,

400 V class series: 7.5 to 220 kW (10 to 450 HP) in 14 types, Total 24 types

As for 400 V class series with a capacity of 280 to 400 kW (500 to 800 HP), the charging resistor and the fuse are separately provided as before.





Chap 11 SELECTING PERIPHERAL EQUIPMENT

Charging resistor



80W 7.50 (HF5C5504)



		Dimensions mm (inch)									
Charging resistor type	Figure	W	W1	W2	H1	H2	D	D1	D2	C	g (lb)
GRZG120 2Ω	A	217 (8.5)	198 (7.8)	165 (6.5)	22 (0.87)	32 (1.3)	33 (1.3)	26 (1.0)	6 (0.24)	5.5 (0.22)	250 (0.6)
GRZG400 1Ω	A	411 (16.2)	385 (15.2)	330 (13.0)	40 (1.6)	39 (1.5)	47 (1.9)	40 (1.6)	9.5 (0.37)	5.5 (0.22)	850 (1.9)
TK50B 30ΩJ (HF5B0416)	В	-	-	-	-	-	-	-	-	-	150 (0.3)
80W 7.5Ω (HF5C5504)	С	-	-	-	-	-	-	-	-	-	-

Fuse

1 (0.04)



Generated loss

In CT mode

PWM c	converter	Boosti	ng reactor	Filtering	g reactor	Filtering re	sistor	
Туре	Generated loss (W)	Туре	Generated loss (W)	Туре	Generated loss (W)	Туре	Q'ty	Generated loss (W)
RHC7.5-2C	400	LR2-7.5C	95	LFC2-7.5C	10	GRZG80 0.42Ω	3	16
RHC11-2C	500	1.02-150	150	1502-150	10	OP70150.0.2O	2	10
RHC15-2C	650	LRZ 100	150	LF02 100	19	GR2G150 0.2 S2	3	40
RHC18.5-2C	700	1 02-220	230	1502-220	26	CP7C200.0.13O	2	68
RHC22-2C	800	LN2 220	230		20	GRZ G200 0.13 32	<u> </u>	00
RHC30-2C	1000	L R2-37C	330	LEC2-37C	32			107
RHC37-2C	1350		0000		02	_		107
RHC45-2C	1500	LR2-55C	450	LEC2-55C	43	GRZG400 0.1 Ω	3	240
RHC55-2C	1750		100		10			
RHC75-2C	2050	LR2-75C	520	LFC2-75C	74			137
RHC90-2C	2450	LR2-110C	720	LR2-110C	115	GRZG400 0.12 Ω Two in parallel	6	374
RHC7.5-4C	400	LR4-7.5C	90	LFC4-7.5C	9	GRZG80 1.74Ω	3	15
RHC11-4C	500	LR4-15C	160	LFC4-15C	20	GRZG150 0.79Ω	3	48
RHC15-4C	600						_	
RHC18.5-4C	650	LR4-22C	230	LFC4-22C	22	GRZG200 0.53 Ω	3	70
RHC22-4C	900							
RHC30-4C	1200	LR4-37C	350	LFC4-37C	36	GRZG400 0.38Ω	3	86
RHC37-4C	1000							
RHC45-4C	1800	LR4-55C	490	LFC4-55C	43	GRZG400 0.26 Ω	3	130
RHC00-4C	2000	1.04-750	520		70	0070400.0.290	2	110
RHC75-4C	2100	LR4-750	520		/0	GRZG400 0.36 SZ	<u> </u>	112
RHC30 40	2000	LR4-110C	710	LFC4-110C	90	GRZG400 0.53Ω	6	405
PHC132-4C	3500					Two in parallel		
RHC160-4C	4150	LR4-160C	1000	LFC4-160C	160	RF4-160C	1	568
RHC200-4C	5100							
RHC220-4C	5600	LR4-220C	1240	LFC4-220C	200	RF4-220C	1	751
RHC280-4C	7100	LR4-280C	1430	LEC4-280C	220	BF4-280C	1	1027
RHC315-4C	8000	LR4-315C	1660	LFC4-315C	260	RF4-315C	1	1154
RHC355-4C	8900	LR4-355C	1910	LFC4-355C	300	RF4-355C	1	1286
RHC400-4C	10100	LR4-400C	2160	LFC4-400C	350	RF4-400C	1	1454

In VT mode

PWM	converter	Boost	ing reactor	Filterir	ng reactor	Filterin	g res	istor
Туре	Generated loss (W)	Туре	Generated loss (W)	Туре	Generated loss (W)	Туре	Q'ty	Generated loss (W)
RHC7.5-2C	450	1 02 150	150	1 500 150	10	CB7C150.0.20	2	40
RHC11-2C	550	LK2-15C	150	LFC2-15C	19	GRZG150 0.202	3	40
RHC15-2C	650	LR2-22C	230	LEC 2-22C	26	GP7G200.0.130	3	68
RHC18.5-2C	750	LK2-220	230	LI 02-220	20	GRZG200 0.1312	3	08
RHC22-2C	850	L R 2-37C	330	LEC 2-37C	32			107
RHC30-2C	1200	LIN2-370	550	LI 02-370	52			107
RHC37-2C	1500	LR2-55C	450	LEC2-55C	43	GRZG400 0.1Ω	3	240
RHC45-2C	1600	EIX2-330	450	EI 02-330	45			240
RHC55-2C	2100	LR2-75C	520	LFC2-75C	74			137
RHC75-2C	2300	LR2-110C	720	LEC2-110C	115	GRZG400 0.12Ω	6	374
RHC90-2C	2650	ERZ-1100	720	LI 02-1100	113	(2 parts in parallel)	0	574
RHC7.5-4C	400	LR4-15C	160	LEC4-15C	20	GR7G150.0.790	З	48
RHC11-4C	500	EIGH 180	100	EI 04 100	20	0120100 0.1022	0	40
RHC15-4C	600	LR4-22C	230	LEC4-22C	22	GR7G200.0.530	З	70
RHC18.5-4C	600		200	21 0 1 220		01120200 0.0001	Ŭ	10
RHC22-4C	950	LR4-37C	350	LEC4-37C	36	GR7G400.0.380	3	86
RHC30-4C	1200		550	EI 04 510	50	01120400 0.0032	9	00
RHC37-4C	1450	LR4-55C	490	LEC4-55C	43	GR7G400.0.260	3	130
RHC45-4C	1750	EICH 000	100	21 0 1 000	10	011201000.2011	Ŭ	100
RHC55-4C	2250	LR4-75C	520	LFC4-75C	78	GRZG400 0.38Ω	3	112
RHC75-4C	1950	LR4-110C	710	LEC4-110C	90	GRZG400 0.53Ω	6	405
RHC90-4C	2400	EICH HIGG	110	21011100	00	(2 parts in parallel)	v	100
RHC110-4C	2900	LR4-160C	1000	LEC4-160C	160	RF4-160C	1	568
RHC132-4C	3250	EICH 1000	1000	21 0 1 1000	100		·	000
RHC160-4C	4100	LR4-220C	1240	LEC4-220C	200	RF4-220C	1	751
RHC200-4C	4400	EIGH EEGO	1210	21 0 1 2200	200	14112200	·	101
RHC220-4C	5600	LR4-280C	1430	LFC4-280C	220	RF4-280C	1	1027
RHC280-4C	6250	LR4-315C	1660	LFC4-315C	260	RF4-315C	1	1154
RHC315-4C	7000	LR4-355C	1910	LFC4-355C	300	RF4-355C	1	1286
RHC355-4C	8050	LR4-400C	2160	LFC4-400C	350	RF4-400C	1	1454
RHC400-4C	8950	LR4-500C	2470	LFC4-500C	450	RF4-500C	1	1821

Note: Generated losses listed in the above tables are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200 V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The capacity of the power supply used is the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).

11.10 DC Reactors (DCRs)

A DCR is mainly used for power supply matching and for input power factor correction (for reducing harmonic components).

For power supply matching

- Use a DCR when the capacity of a power supply transformer exceeds 500 kVA and is 10 times or more the
 rated inverter capacity. In this case, the percent reactance of the power supply decreases, and harmonic
 components and their peak value increase. These factors may break rectifiers or capacitors in the converter
 section of inverter, or decrease the capacitance of the capacitor (which can shorten the inverter's service life).
- Also use a DCR when there are thyristor-driven loads or when phase-advancing capacitors are being turned ON/OFF.
- Use a DCR when the interphase voltage unbalance ratio of the inverter power supply exceeds 2%.

Interphasevoltageunbalance(%) =
$$\frac{\text{Max.voltage(V)} - \text{Min.voltage(V)}}{\text{Three-phaseaveragevoltage(V)}} \times 67$$

■ For input power factor correction (for suppressing harmonics)

Generally a capacitor is used to improve the power factor of the load, however, it cannot be used in a system that includes an inverter. Using a DCR increases the reactance of inverter's power supply so as to decrease harmonic components on the power supply lines and improve the power factor of inverter. Using a DCR improves the input power factor to approximately 86% to 95%.

- At the time of shipping, a jumper bar is connected across terminals P1 and P (+) on the terminal block. Remove the jumper bar when connecting a DCR.
 - If a DCR is not going to be used, do not remove the jumper bar.
 - Please select in the capacity of the applicable motor selection of DC reactor.



Figure 11.10-1 External View of a DC Reactor (DCR) and Connection Example

Power supply voltage	Nominal applied motor (kW)	Nominal applied motor (HP)	DC reactor type	Rated current (A)	Inductance (mH)	Generated loss (W)
	0.75	1	DCR4-0.75	2.5	30	2.5
	1.1 1.5	1 1/2 2	DCR4-1.5	4.0	16	4.8
	2.2	3	DCR4-2.2	5.5	12	6.8
	3.0	4		0.0	7.0	0.1
	3.7	5	DCR4-3.7	9.0	7.0	0.1
	5.5	7.5	DCR4-5.5	13	4	10
	7.5	10	DCR4-7.5	18	3.5	15
	11	15	DCR4-11	25	2.2	21
	15	20	DCR4-15	34	1.8	28
	18.5	25	DCR4-18.5	41	1.4	29
	22	30	DCR4-22A	49	1.2	35
Three-phase	30	40	DCR4-30B	71	0.86	35
400 V	37	50	DCR4-37B/DCR4-37C	88/88	0.70/0.483	40/63
	45	60	DCR4-45B/DCR4-45C	107/107	0.58/0.4	44/69
	55	75	DCR4-55B/DCR4-55C	131/131	0.47/0.324	55/78
	75	100	DCR4-75C	178	0.23	97
	90	125	DCR4-90C	214	0.2	111
	110	150	DCR4-110C	261	0.166	122
	132	200	DCR4-132C	313	0.148	159
	160	250	DCR4-160C	380	0.122	185
	200	300	DCR4-200C	475	0.098	218
	220	350	DCR4-220C	524	0.087	231
	250	400	DCR4-250C	589	0.077	249
	280	450	DCR4-280C	649	0.069	270

Table 11.10-1 DC Reactors (DCRs)

Note: Generated losses listed in the above tables are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The capacity of the power supply used is the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).
- An AC reactor (ACR) is not connected.



Table 11.10-2 DC Reactors (DCRs) External Dimensions

Power supply voltage	DC reactor						Dim	ensions	s mm			Mass
voltage	type	Figure	W	W1	D	D1	D2	н	H1	Mounting hole	Terminal hole	kg
	DCR4-0.4	А	66	56	90	72	15	94	-	M4 (5.2×8)	M4	1.0
	DCR4-0.75	А	66	56	90	72	20	94	-	M4 (5.2×8)	M4	1.4
	DCR4-1.5	Α	66	56	90	72	20	94	-	M4 (5.2×8)	M4	1.6
	DCR4-2.2	А	86	71	100	80	15	110	-	M5 (6×9)	M4	2.0
	DCR4-3.7	А	86	71	100	80	20	110	-	M5 (6×9)	M4	2.6
	DCR4-5.5	А	86	71	100	80	20	110	-	M5 (6×9)	M4	2.6
	DCR4-7.5	Α	111	95	100	80	24	130	-	M6 (7×11)	M5	4.2
	DCR4-11	А	111	95	100	80	24	130	-	M6 (7×11)	M5	4.3
	DCR4-15	А	146	124	120	96	15	168	-	M6 (7×11)	M5	5.9
	DCR4-18.5	Α	146	124	120	96	25	171	-	M6 (7×11)	M6	7.2
	DCR4-22A	А	146	124	120	96	25	171	-	M6 (7×11)	M6	7.2
	DCR4-30B	В	152	90	157	115	100	130	190	M6 (ø8)	M8	13
	DCR4-37B	В	171	110	150	110	100	150	200	M6 (ø8)	M8	15
Three-phase	DCR4-37C	D	210	185	101	81	105	125	-	M6 (7×13)	M8	7.4
400V	DCR4-45B	В	171	110	165	125	110	150	210	M6 (ø8)	M8	18
	DCR4-45C	D	210	185	106	86	120	125	-	M6 (7×13)	M8	8.4
	DCR4-55B	В	171	110	170	130	110	150	210	M6 (ø8)	M8	20
	DCR4-55	D	255	225	96	76	120	145	-	M6 (7×13)	M10	11
	DCR4-75C	D	255	225	106	86	125	145	-	M6 (7×13)	M10	13
	DCR4-90C	D	255	225	116	96	140	145	-	M6 (7×13)	M12	15
	DCR4-110C	D	300	265	116	90	175	155	-	M8 (10×18)	M12	19
	DCR4-132C	D	300	265	126	100	180	160	-	M8 (10×18)	M12	22
	DCR4-160C	D	350	310	131	103	180	190	-	M10 (12×22)	M12	26
	DCR4-200C	D	350	310	141	113	185	190	-	M10 (12×22)	M12	30
	DCR4-220C	D	350	310	146	118	200	190	-	M10 (12×22)	M12	33
	DCR4-250C	D	350	310	161	133	210	190	-	M10 (12×22)	M12	35
	DCR4-280C	D	350	310	161	133	210	190	-	M10 (12×22)	M16	37
	DCR4-315C	D	400	345	146	118	200	225	-	M10 (12×22)	M16	40
11.11 AC Reactors (ACRs)

Use an ACR when the converter part of the inverter should supply very stable DC power, for example, in DC link bus operation (shared PN operation). Generally, ACRs are used for correction of voltage waveform and power factor or for power supply matching, but not for suppressing harmonic components in the power lines. For suppressing harmonic components, use a DCR. Please select in the capacity of the applicable motor selection of AC reactor.



Figure 11.11-1 External View of AC Reactor (ACR) and Connection Example

	Nominal	Nominal			Reactance	(mΩ/phase)		
Power supply	applied	applied motor	AC reactor type	Rated		60H-	Coil resistance	Generated
voltage	(kW)	(HP)		current (A)	SUHZ	0002	(11152)	1055 (11)
	0.75	1	ACR4-0.75A	2.5	1920	2300	-	10
	1.1	1-1/2		27	1160	1200		11
	1.5	2	ACK4-1.5A	3.7	1100	1390	-	11
	2.2	3	ACR4-2.2A	5.5	851	1020	-	14
	3.0	4	ACB4 2 7A	0	512	615	_	17
	3.7	5	AOI(4-3.7A	5	512	015	-	17
	5.5	7.5	ACR4-5.5A	13	349	418	-	22
	7.5	10	ACR4-7.5A	18	256	307	-	27
	11	15	ACR4-11A	24	183	219	-	40
	15	20	ACR4-15A	30	139	167	-	46
	18.5	25	ACR4-18.5A	39	114	137	-	57
_	22	30	ACR4-22A	45	95.8	115	-	62
I hree-phase	30	40	ACR4-37	100	41.7	50	2.73	38.9
400 V	37	50	ACR4-37	100	41.7	50	2.73	55.7
	45	60	ACR4-55	135	30.8	37	1.61	50.2
	55	75	ACR4-55	135	30.8	37	1.61	70.7
	75	100	ACR4-75 *	160	25.8	31	1.16	65.3
	90	125	ACR4-110	250	16.7	20	0.523	42.2
	110	150	ACR4-110	250	16.7	20	0.523	60.3
	132	200	ACR4-132 *	270	20.8	25	0.741	119
	160	250						56.4
	200	300	ACR4-220	561	10	12	0.236	90.4
	220	350						107
	250	400	ACP4 280	825	6 67	Q	0 1 4 4	96.4
	280	450	ACR4-280	825	6.67	ð	0.144	108

Table 11.11-1 AC Reactor (ACR)

* Cool this reactor using a fan with 3 m/s or more WV (Wind Velocity).

Note: Generated losses listed in the above table are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The capacity of the power supply used is the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).





Figure C



Table 11.11-2 AC Reactors (ACRs) External Dimensions

Power			Dimensions mm (inch)						Mass		
supply voltage	oply DC reactor type age		W	W1	D	D1	D2	G	н	Terminal hole	kg (lb)
	ACR4-0.75A		120	40	90	65	106	M5 (6×10)	85	M4	1.1
	ACR4-1.5A		125	40	100	75	106	M5 (6×10)	85	M4	1.9
	ACR4-2.2A		125	40	100	75	106	M5 (6×10)	95	M4	2.2
	ACR4-3.7A		125	40	100	75	106	M5 (6×10)	95	M4	2.4
	ACR4-5.5A		125	40	115	90	106	M5 (6×10)	95	M5	3.1
	ACR4-7.5A	В	125	40	115	90	106	M5 (6×10)	95	M5	3.7
	ACR4-11A		180	60	110	85	106	M6 (7×11)	115	M6	4.3
	ACR4-15A		180	60	110	85	106	M6 (7×11)	137	M6	5.4
Three-phase	ACR4-18.5A		180	60	110	85	106	M6 (7×11)	137	M6	5.7
400 V	ACR4-22A		180	60	110	85	106	M6 (7×11)	137	M6	5.9
	ACR4-37		190	60	120	90	172	M6 (7×11)	190	M8	12
	ACR4-55		190	60	120	90	200	M6 (7×11)	190	M10	14
	ACR4-75		190	60	126	90	157	M6 (7×10)	190	M10	16
	ACR4-110		250	100	136	105	202	M8 (9.5×18)	245	M12	24
	ACR4-132	С	250	100	146	115	207	M8 (10×16)	250	M12	32
	ACR4-220		320	120	150	110	240	M8 (12×20)	300	M12	40
	ACR4-280		380	130	150	110	260	M8 (12×20)	300	M12	52
	ACR4-355		380	130	150	110	260	M8 (12×20)	300	M12	52

11.12 Surge Suppression Unit (SSU)



If the drive wire for the motor is long, an extremely low surge voltage (micro surge) occurs at the wire end connected to the motor. Surge voltage causes motor degradation, insulation breakdown, or increased noises. The surge suppression unit (SSU) suppresses the surge voltage. It features the connectivity for all inverter capacities and easy wiring work.



Dimensions

• 50 m spec: SSU 50TA-NS

• 100 m spec: SSU 100TA-NS



Effects of surge suppression units (voltage waveform between motors)

1500

1200

1000

750

500

250

-250

Voltage (V)

- Motor/inverter capacity: 3.7 kW
- Running status: No-load
- Wiring length: 50 m
- Power supply voltage: Three-phase 400 V





(151%

- Motor/inverter capacity: 75 kW
- Running status: No-load
- Wiring length: 100 m
- Power supply voltage: Three-phase 400 V



Basic specifications

Item	Specifica	ations
Туре	SSU 50TA-NS	SSU 100TA-NS
Applicable wiring length	Up to 50 m (164 ft)	Up to 100 m (328 ft)
Power supply voltage	200 V and 400 V classes; PW	/M converter is applicable.
Inverter capacity	Up to 75 kW (90 kW or larger re	equires customized service.)
Output frequency	Up to 40	00 Hz
Carrier frequency	Up to 15 kHz (Cannot	be used at 16 kHz.)
Enclosure	IP20	0
Installation environment	Ambient temperature: -20 to +40°C, re vibration: 0.7 G or less, Ir	elative humidity: 85% RH or below, nstallation: horizontally
Dielectric strength voltage	2500 VAC	, 1 min

11.13 Output Circuit Filters (OFLs)

Insert an OFL in the inverter power output circuit to:

- Suppress the surge voltage at motor terminals This protects the motor from insulation damage caused by the application of high voltage surge currents from the 400 V class series of inverters.
- Suppress leakage current from the output lines This reduces the leakage current from long power feed lines. (The maximum wiring length must be 400 m.)
- Minimize radiation and induction noise from the output lines An OFL effectively suppresses noise from long lines such as wiring at plants.





Figure 11.13-1 External View of Output Circuit Filter (OFL) and Connection Example

Table 11.13-1	Output Circuit Filter (OFL)

Power supply voltage	Nominal applied motor (kW)	Filter type	Rated current (A)	Generated loss (kW)
	0.75 1.1	OFL-1.5-4A	3.7	105
	2.2 3.0	OFL-3.7-4A	9	210
	5.5 7.5	OFL-7.5-4A	18	190
	<u>11</u> 15	OFL-15-4A	30	320
	18.5	OFL-22-4A	45	350
	30	OFL-30-4A	60	570
Three-phase	37	OFL-37-4A	75	610
400 V	45	OFL-45-4A	91	810
	55	OFL-55-4A	112	910
	75	OFL-75-4A	150	1200
	90	OFL-90-4A	176	1360
	110	OFL-110-4A	210	1410
	132	OFL-132-4A	253	1800
	160	OFL-160-4A	304	2210
	200	OFL-200-4A	377	2520
	220	OFL-220-4A	415	2590
	250		520	3570
	280	01 L-200-4A	520	5570

OFL-DDD-4A

<u>OFL-000-4A</u>

Filter (for 22 kW or below)





Reactor (for 30 kW or above)



Figure D

Figure C





Resistor and Capacitor (for 30 kW or above)

Figure F



For filters OFL-30-4A and greater, a reactor, resistor, and capacitor should be installed separately. (Those parts are not included in the mass of a filter. If ordered with the filter type, the filter is shipped in combination with a reactor, resistor, and capacitor.)



	Dimensions mm (inch)										
Filter type	Figure	А	В	С	D	Е	F	G	Grounding screw H	Terminal screw J	Mounting screw K
OFL-0.4-4A			175	195		95					
OFL-1.5-4A		220	(6.9)	(7.7)	200	(3.7)			M4	M4	M5
OFL-3.7-4A	Α	(8.7)	225 (8.9)	220 (8.7)	(7.9)	115 (4.5)					
OFL-7.5-4A		290 (11.4)	290 (11.4)	230 (9.1)	260 (10.2)	160 (6.3)	-	—	M5	M5	M6
OFL-15-4A	Р	330	275 (10.8)	310 (12.2)	300	145 (5.7)			Me	Me	Me
OFL-22-4A	в	(13.0)	300 (11.8)	330 (13.0)	(11.8)	170 (6.7)			Olvi	Olvi	IVIO
OFL-30-4A	C/F	210 (8.3)	175 (6.9)	210 (8.3)	70 (2.8)	140 (5.5)	90 (3.5)			6 4 (0 25)	8 (0 31)
OFL-37-4A	U/F	220	190 (7.5)	220 (8.7)	75 (3)	150 (5.9)	95 (3.7)	160		0.4 (0.25)	0 (0.31)
OFL-45-4A		(8.7)	195 (7.7)	265 (10.4)	70 (2.8)	155 (6.1)	140 (5.5)	(6.3)		8 4 (0.33)	10 (0 39)
OFL-55-4A		260	200 (7.9)	275 (10.8)	85	160 (6.3)	150			0.4 (0.00)	.5 (0.03)
OFL-75-4A		(10.2)	210	10 290 (3.3	(3.3)	170	(0.0)				
OFL-90-4A			(8.3)	(11.4)	((6.7)	155 (6.1)		_	10.5 (0.41)	
OFL-110-4A	D/F	200	230 (9.1)	330 (13.0)	100	190 (7.5)	170	233 (9.2)			12 (0.47)
OFL-132-4A	Dn	(11.8)	240	340	(3.9)	200	(0.7)				
OFL-160-4A		,	(9.4)	(13.4)	()	(7.9)	180 (7.1)				
OFL-200-4A		320 (12.6)	270 (10.6)	350 (13.8)	105 (4.1)	220 (8.7)	190			13 (0.51)	
OFL-220-4A		340 (13.4)	300	390 (15.4)	115	250	(7.5)	333 (13.1)			15 (0.59)
OFL-280-4A		350 (13.8)	(11.8)	430 (16.9)	(4.5)	(9.8)	200 (7.9)				
OFL-315-4A			275 (10.8)	450 (17.7)		230 (9.1)	170 (6.7)				
OFL-355-4A			290 (11.4)	480 (18.9)		245 (9.6)	175 (6.9)	333 (13.1)			
OFL-400-4A	E/G	440 (17.3)	295 (11.6)	510 (20.1)	150 (5.9)	240 (9.4)	175 (6.9)		-	15 (0.59)	15 (0.59)
OFL-450-4A			325 (12.8)	470 (18.5)		270 (10.6)	195 (7.7)	_			
OFL-500-4A			335 (13.2)	500 (19.7)		280 (11.0)	210 (8.3)				

Note: The OFL-DD-4A models have no restrictions on carrier frequency.

400 V class series

11.14 Zero-phase Reactors for Reducing Radio Noise (ACLs)

An ACL is used to reduce radio frequency noise emitted from the inverter output lines. Pass the total of four wires--three inverter output wires and a grounding wire through the ACL in the same passing direction four times. If shielded wires are used, pass them through the ACL with their shields four times. Be sure to use wires with a heat resistance of $75^{\circ}C$ ($167^{\circ}F$) or above.

The ACL absorbs high-frequency noise components and emits them as heat into the air so that the amount of heat generation can be large. If it happens, lower the carrier frequency, upgrade the heat-resistance rank of wires, increase the number of the ACLs to decrease the number of turns per ACL, replace the ACLs with higher type ones, or take any other measures.

The wire size is determined depending upon the ACL size (I.D.) and installation requirements. Refer to Table 11.14-1.



Figure 11.14-1 Dimensions of Zero-phase Reactor for Reducing Radio Noise (ACL) and Connection Example

	Installation r	equirements	Wire size	Wire size	
ACL type	Q'ty	Number of turns (mm ²)		(AWG)	
	1	4	5.5 or below	10 or below	
ACL-40B	2	2	14 or below	6 or below	
	4	1	38 or below	1 or below	
	1	4	14 or below	6 or below	
ACL-74B	2	2	60 or below	1/0 or below	
	4	1	250 or below	500 or below	

Table 11.14-1 Zero-phase Reactors for Reducing Radio Noise (ACL)

11.15 External Cooling Fan Attachments

An external cooling fan attachment for the FRENIC-eHVAC allows to mount the cooling fin outside the panel, which enhances cooling efficiency while making the panel smaller. It can release from the panel approximately 70% of the inverter's generated loss. The inverter of FRN0045F2E-4G and FRN0060F2E-4G only be applied to.



Panel processing diagram

Unit: mm (inch)

Option type	Applicable inverter type
	FRN0045F2E-4G
PB-F1-30	FRN0060F2E-4G

11.16 External Frequency Command Potentiometer

An external frequency command potentiometer may be used to set the drive frequency. Connect the potentiometer to control signal terminals [11] through [13] of the inverter as shown in Figure 11.16-1.

Type: RJ-13 (BA-2 B-characteristics, 1 k Ω)



Type: WAR3W-1kΩ (3W B-characteristics)



Dial plate type: 40P

Unit: mm (inch)



Note: The dial plate and knob must be ordered separately. Available from Fuji Electric Technica Co., Ltd.



Figure 11.16-1 External Frequency Command Potentiometer Dimensions and Connection Example

11.17 Extension Cable for Remote Operation

The extension cable connects the inverter with the keypad (standard or multi-function) or USB-RS-485 converter to enable remote operation of the inverter. The cable is a straight type with RJ-45 jacks and its length is selectable from 5, 3, and 1 m.



Table 11.17-1 Extension Cable Length for Remote Operation

Туре	Length m (ft)
CB-5S	5 (16)
CB-3S	3 (9.8)
CB-1S	1 (3.3)

11.18 Frequency Meters

Connect a frequency meter to the analog signal output terminals [FM1], [FM2] (for China only) and [11] of the inverter to measure the frequency component selected by function code F31 (FM1), F35(FM2). Figure 11.8-1 shows the dimensions of the frequency meter and a connection example.

Type : TRM-45 (DC10V, 1mA)

This model has two types of calibration: "0 to 60/120 Hz" and "60/120/240 Hz."



Unit: mm (inch)

Available from Fuji Electric Technica Co., Ltd.











Panel cutout size 2-ø4 (ø0.16)



Type : FMN-80 (10VDC, 1mA)





Unit: inch (mm) Available from Fuji Electric Technica Co., Ltd.



Figure 11.18-1 Frequency Meter Dimensions and Connection Example

11.19 Options for communication and operation overview

In FRENIC-eHVAC it is possible to install one communication card and one terminal block type option card. A mounting adapter is required to install the communication card to the inverter.

11.19.1 Mounting adapter (for communication option card)

This adapter is required for mounting the communication option card to FRENIC-eHVAC.

Table 11.19-1

Туре	Option Name	Functions
OPC-E2-ADP1	Option card mounting adapter for small-size inverter.	FRN0002F2E-4G to FRN0038F2E-4G.
OPC-E2-ADP2	Option card mounting adapter for mid-size inverter.	FRN0045F2E-4G and FRN0060F2E-4G
OPC-E2-ADP3	Option card mounting adapter for large-size inverter.	FRN0075F2E-4G or above.

11.19.2 Communication option cards (required mounting adapter required)

Table 11.19-2

Туре	Option Name	Functions	Refer
OPC-DEV	DeviceNet communications card	This card enables the FRENIC-eHVAC to interface with DeviceNet and the FRENIC-eHVAC can be operated as a DeviceNet slave.	Section 11.20
OPC-CCL	CC-Link communications card	This card enables the FRENIC-eHVAC to interface with CC-Link and the FRENIC-eHVAC can be operated as a CC-Link slave.	Section 11.21
OPC-AIO	Analog I/O interface card	This card enables the FRENIC-eHVAC to input analog set-points to the inverter and output analog monitors.	Section 11.22
OPC-PT	RTD card	This card enables the FRENIC-eHVAC to input RDT.	Section 11.23
OPC-LNW	LonWorks card	This card enables the FRENIC-eHVAC to interface with LonWorks and the FRENIC-eHVAC can be operated as a LonWorks slave.	Section 11.24
OPC-PDP3	PROFIBUS-DP communications card	This card enables the FRENIC-eHVAC to interface with PROFIBUS DP and the FRENIC-eHVAC can be operated as a PROFIBUS DP slave.	Comming soon.

11.19.3 Terminal block type options

Table 11.19-3

Туре	Option Name	Functions	Refer
OPC-F2-RY	Relay output card	This card provides three relay output (1A relay).	Section 11.25

11.19.4 Option keypad

Tab	le	11	.1	9-4	1

Туре	Option Name	Functions	Refer
TP-E1U	Keypad with USB port.	The operation keypad adopted large-sized 7 segments LED to improve the visibility.	Section 11.26
		Allows to connect a computer directly with a commercial USB cable (mini B) to be able to use FRENIC Loader software. Additional converter is not required.	
		TP-E1U cannot be directly mounted on FRENIC-eHVAC. It can be connected only through a cable.	
TP-A1	Multi-functional keypad	The operation keypad adopted LCD(Liquid Crystal Display) with a back light.	Section 11.27
		The keypad corresponds to multi-languages.	
		TP-A1-E2C cannot be directly mounted on FRENIC-eHVAC. It can be connected only through a cable.	

11.20 DeviceNet communications card (OPC-DEV)

The DeviceNet communications card is used to connect the FRENIC-eHVAC series to a DeviceNet master via DeviceNet. Mounting the communications card on the FRENIC-eHVAC enables the user to control the FRENIC-eHVAC as a slave unit by configuring and monitoring run and frequency commands and accessing inverter's function codes from the DeviceNet master.

Note: Two or more communication cards cannot be mounted simultaneously. And this card requires a mounting adapter; refer to Section 11.19.

11.20.1 DeviceNet specifications

Item	Specifications				
Number of nodes connectable	Max. 64 (including the master)				
MAC ID	0 to 63				
Insulation	500 VDC (photocoupler ins	sulation)			
Transmission rate	500, 250, or 125 kbps				
	Transmission rate	500 kbps	250 kbps	125 kbps	
Maximum cable length	Trunk line length	100 m (328 ft)	250 m (820 ft)	500m (1600 ft)	
(When using thick cables)	Drop line length	6 m (20 ft)			
	Total length of drop lines	39 m (128 ft)	78 m (256 ft)	156 m (512 ft)	
Messages supported	 I/O Message (Poll, Change of State) Explicit Message 				
Vendor ID	319 (Registered name: Fuji Electric Group)				
Device type	AC drive (code: 2)				
Product code	9219				
Applicable device profile	AC Drive				
Number of input/output bytes	Max. 8 bytes for each of input and output. Depending on the format selected. Refer to Instruction manual of OPC-DEV.				
Applicable DeviceNet Specifications	CIP Specifications Volume 1, Edition 2.2 Japanese version and Volume 3, Edition 1.1 Japanese version				
Node type	Group 2 only server (noncompliant with UCMM)				
Network power consumption	80 mA, 24 VDC (Note) The network power is supplied by an external power source.				

Table 11.20-1

For the items not contained in the table above, the DeviceNet Specifications apply.

11.21 CC-Link communications card (OPC-CCL)

CC-Link (Control & Communication Link) is an FA open field network system.

The CC-Link communications card connects the inverter to a CC-Link master via CC-Link using a dedicated cable. It supports the transmission speed of 156 kbps to 10 Mbps and the total length of 100 to 1,200 m so that it can be used in wide range of systems requiring a high-speed or long-distance transmission, enabling a flexible system configuration.

Note: Two or more communication cards cannot be mounted simultaneously. And this card requires a mounting adapter; refer to Section 11.19.

11.21.1 CC-Link specifications

	Table	11.21-1
--	-------	---------

Item	Specifications				
Applicable controller	Mitsubishi Ele	Mitsubishi Electric sequencer, etc. (CC-Link master)			
Transmission system	CC-Link version 1.10 and 2.0 (Broadcast polling system)				
Number of inverters connectable	Max. 42 units (one station occupied/unit)				
Number of stations occupied	CC-Link version 1.10: 1 station occupied CC-Link version 2.0: 1 station occupied (Selectable from among 2x, 4x and 8x settings)				
Transmission speed (Baud rate)	10 Mbps/5 Mbps/2.5 Mbps/625 kbps/156 kbps				
Maximum cable length	10 Mbps	5 Mbps	2.5 Mbps	625 kbps	156 kbps
(When using the CC-Link dedicated cable)	100 m (328 ft)	150 m (492 ft)	200 m (656 ft)	600 m (2000 ft)	1200 m (3900 ft)
Insulation	500 VDC (photocoupler insulation)				
Station type	Remote device station				
Remote device type	Inverter (0x20)				

For items not contained in the above table, the CC-Link specifications apply.

11.22 Analog interface card (OPC-AIO)

The analog interface card has the terminals listed below. Mounting this interface card on the FRENIC-eHVAC enables analog input and analog output to/from the inverter.

- One analog voltage input point (0 to ± 10 V)
- One analog current input point (4 to 20 mA)
- One analog voltage output point (0 to ± 10 V)
- One analog current output point (4 to 20 mA)

Applicable ROM version

This interface card is applicable to inverters with a ROM version 0300 or later.

Table 11.22-1 Te	rminal functions
------------------	------------------

Classifi- cations	Symbol	Name	Functions	Remarks
	[P10]	Power supply for the potentiometer	Power supply for frequency command potentiometer (Variable resistor: 1 to $5 \text{ k}\Omega$) (10 VDC, 10 mA DC max.)	
og input	[32]	Analog voltage input	 Used as analog voltage input from external equipment. 0 to ±10 VDC/0 to ±100% (0 to ±5 VDC/0 to ±100%) One of the following signals can be assigned to this terminal. Auxiliary frequency command PID command, PID feedback value Ratio setting Torque limiter level, Torque bias amount Torque command, Torque current command Speed limit value of FWD, Speed limit value of REV Analog input monitor Resolution: 1/3000 	Input impedance: 22kΩ Max. input: ±15 VDC
Analo	[C2]	Analog current input	 Used as analog current input from external equipment. 4 to 20 mA DC/0 to 100% One of the following signals can be assigned to this terminal. Auxiliary frequency command PID command, PID feedback value Ratio setting Torque limiter level, Torque bias amount Torque command, Torque current command Speed limit value of FWD, Speed limit value of REV Analog input monitor Resolution: 1/3000 	Input impedance: 250Ω Max. input: 30 mA DC
	[31]	Analog common	Reference terminal for [P10], [32], [C2].	Equipotent with the inverter's terminal [11]

Classifi- cations	Symbol	Name	Functions	Remarks
O O [Ao+] Analog voltage output (+)		Analog voltage output (+)	 Outputs the monitor signal of analog DC voltage (0 to ±10 VDC). One of the following signals can be issued from this terminal. Output frequency Output current, Output voltage, Output torque Load factor, Input power PID feedback value Actual speed / Estimated speed DC link bus voltage Universal AO Motor output Analog output test PID command, PID output Position deviation in master follower operation Heat sink temperature PG feedback value Customizable logic output signal 1 to 4 Resolution: 1/3000 * Capable of driving up to two analog voltmeters with 10 kΩ impedance. 	
log outpu	[Ao-]	Analog voltage output (-)	Reference terminal for [Ao+].	Equipotent with the inverter's terminal [11]
Anal	[CS+]	Analog current output (+)	 Outputs the monitor signal of analog DC current (4 to 20 mA DC) One of the following signals can be issued from this terminal. Output frequency Output current, Output voltage, Output torque Load factor, Input power PID feedback value Actual speed / Estimated speed DC link bus voltage Universal AO Motor output Analog output test PID command, PID output Position deviation in master-follower operation Heat sink temperature PG feedback value Customizable logic output signal 1 to 4 	Isolated from terminals [31], [Ao-], and [11]
	[CS-]	Analog current output (-)	* Input impedance of the external device: Max. 500Ω	

Table 11.22-1Terminal functions (cont.)



Table 11.22-2 Connection example

11.23 RTD Card (OPC-PT)

The RTD card (OPC-PT) makes it possible to connect up to two resistance temperature detectors (RTDs) to the FRENIC-eHVAC and digitalize temperatures. The following five types of RTDs can be connected: JPt100, Pt100, Ni100, Pt1000, and Ni1000.

The mounting of this card requires a mounting adapter. For details, refer to the Instruction Manual, which will be provided with the card.

Specifications

Item	Specifications			
Number of input channels	2 channels			
Types of RTDs connectable	JPt100, Pt100, Ni100, Pt1000, and Ni1000 (3-wire type) * The types of RTDs are set with function codes.			
RTD excitation current	JPt100, Pt100, and Ni100: 1 mA Pt1000 and Ni1000: 0.5 mA * Selected by switching.			
Measurement temperature range	-20 to +100°C (-4 to +212°F, 253 to 373 K)			
Resolution	0.01°C (0.01°F, 0.01 K)			
Accuracy	±0.3% FS (inverter ambient temperature: at 23°C (at 73.4°F, 296 K)) ±0.7% FS (inverter all temperature specification range) * RTD errors are not included.			
Sampling period	Max. 700 ms/2 channels			
Input filter time *1	Hardware (time constant): max. 50 ms Digital filter time: 0.0 to 100.0 s (Can be set in 0.1-s increments (default value: 1.0 s))			
Insulation method	Between the sensor input terminal and the internal logic	Photo-coupler insulation		
	Between sensor input terminals and CM, 11, CMY	Transformer insulation		
	Between sensor terminals	None		
Error detection	Possible to detect sensor disconnection/short-circuiting and incorrect switching settings. *2			

*1 Input filtering time does not affect the display.

*2 Make sure that sensor selection settings (o10 and o15) are the same as the sensors in use. Do not perform wiring across channels, or otherwise error detection may not be possible. In addition, the error display will indicate "-30°C."

11.24 LonWorks Card (OPC-LNW)

The LonWorks card (OPC-LNW) is an interface card that connects the FRENIC-eHVAC to peripheral devices (e.g., the master) through the LonWorks. The use of this communications card makes it possible to make run command and frequency settings or monitor them through the master equipment connected through the LonWorks, change settings of function codes required for the operation of the system and confirm the changes. Furthermore, the card allows data exchange with the peripheral devices.

The mounting of this card requires a mounting adapter. For details, refer to the Instruction Manual, which will be provided with the card.

LonWorks specifications

Item	Specifications
Communications baud rate	78 kbps
Profile	LonMark 3.3
	Variable Speed Motor Drive functional Profile Ver. 1.1
Communications topology	Free topology
Network variable (NV)	62 variables (node objects: 3, VSD objects: 59)
Communications IC	Smart transceiver (FT3120-E4S40)
Communications transceiver	TP/FT-10 (free topology)
Communications protocol	LonTalk protocol
Configuration property (CP)	24

11.25 Relay Output Card (OPC-F2-RY)

This card adds three relay output points to the FRENIC-eHVAC. Therefore, with the standard five output points of the FRENIC-eHVAC and the three output points of this card will make a total of eight output points. These points are available for pump control. For details, refer to Chapter 5 "5.3.7 [5] Pump control".

11.26 Simple keypad with USB port (TP-E1U)

Using the keypad in combination with FRENIC Loader enables a variety of data about the inverter unit to be saved in the keypad memory, allowing you to check the information in any place.

TP-E1U cannot be directly mounted on FRENIC-eHVAC. It can be connected only through a cable.



Features

- The keypad can be directly connected to a computer through a commercial USB cable (mini B) without using (1) a converter. The computer can be connected online with the inverter.
- With the FRENIC Loader, the inverter can support thefollowing functions (1) to (4). (2)
 - 1) Editing, comparing, and copying the function code data
 - 2) Real-time operation monitor
 - 3) Trouble history (indicating the latest four troubles)
 - 4) Maintenance information

Data can be transferred from the USB port of the keypad directly to the computer (FRENIC Loader) at the site of production. Periodical collection of life information can be carried out efficiently

Dimensions

(0.67))

(53.8 (2.1))

15.24



11.27 Multi functional keypad (TP-A1)

Replacing the standard keypad with the multi-function keypad enables setting and checking of function code data, and monitoring of the inverter running status, on the LCD monitor.

TP-A1 cannot be directly mounted on FRENIC-eHVAC. It can be connected only through a cable.

Specifications

Items	Specifications	Remarks
Dimensions	Refer to the figures below	
Mass	120g	
Available languages	Japanese, English, Chinese	It is due to correspond to user-customized language.
Copy function	Possible to memorize or copy three function data sets.	
Applicable inverter	FRENIC-HVAC/AQUA series FRENIC-eHVAC series	Do not connect to FVR-E11S series otherwise Keypad or inverter may be damaged.
Number of connection	One inverter to one Multi-function keypad	
Connection cable	Conformed to ANSI/TIA/EIA568A Category 5 (For 10BASE-T/100BASE-TX straight connection)	Extension cable (CB-5S)
Extension cable length	20m or less	
Connector	RJ-45 connector	

External view, dimension

(53.8 (2.1))

(0.6)





11.28 FRENIC Visual Customizer

11.28.1 Overview

FRENIC Visual Customizaer is a inverter support software which can provide the visual customizing environment for FRENIC-eHVAC.

Customers can modify their inverter easily with this software by themselves.

11.28.2 Specifications

Item		Specifications	Remarks
Name of software		FRENIC Visual Customizer	
No.	of supported inverters	For USB connection: Only one inverter	
		For RS-485 connection: Up to 31 inverters	
_		USB : USB cable (mini B connecter)	
Recommended cable		RS-485 : Shielded twisted pair cable for long distance transmission	
٦t		Microsoft Windows XP(SP3 or later)	
ner	OS *	Microsoft Windows Vista	***
onr		Microsoft Windows 7	
vir	Memory	512MB or more RAM	2GB or more is recommended
er	Hard disk	35MB or more free space	
tinç	COM port	RS-232C or LISB	Conversion to RS-485 communications required
era;			to connect inverters
Ope	Monitor resolution	800 × 600 or higher	SXGA(1280 × 1024) / 32-bit color is recommended
	COM port **	COM1 to COM255	PC COM ports assigned to Loader
nts		USB connection : Fixed at 12 Mbps	
me	Transmission rates **	RS-485 connection :	38400bps or more is recommended.
uire		38400, <u>19200</u> , 9600, 4800 and 2400 bps	
edr	Character length	8 bits	Prefixed
L L	Stop bit length	1 bit	Prefixed
sio	Parity	Even	Prefixed
nsmis	No. of retries **	None or <u>1</u> to 10	No. of retry times before detecting communications error
Tra	Timeout setting **	100ms, 300ms, 500ms, 1.0s to <u>1.5s</u> to 1.9s, 2.0 to 9.0s, 10.0 to 60.0s	This setting should be longer than the response interval time specified by the function code H39.

* Use on the PC downgraded to Windows XP from Windows7 or Windows Vista is not recommended.

** Bolded, underlined values are factory defaults.

***Only support 32bit version of Windows XP, Windows Vista. Support both 32bit and 64bit version of Windows 7.

11.28.3 Functions

This software can provide functions below.

Function	Overview
Customizable function editing	Draws functions and sends them to the inverter using a graphical editing tool.
Real-time trace	Displays the customizable function operation status with a waveform in real time.
Communication settings	Specifies settings for communicating with the inverter.

11.28.4 Main Window

The following window appears when the software is started.



Clear log

Clear log of Message window.



Chapter 12 SPECIFICATIONS

This chapter describes the output ratings, input power, basic functions and other specifications of the FRENIC-eHVAC standard and EMC Filter Built-in model.

Contents

12.1	Stand	dard Model······	2-1
12	.1.1	Inverters for general load ······12	2-1
12.2	Com	mon Specifications	2-4

12.1 Standard Model

12.1.1 Inverters for general load

Standard-model, Three-phase 400 V class series (0.75 kW to 15 kW)

	Item				Specif	cations					
Ту	pe (FRNF2E-4G)	0002	0003	0005	0006 * 9	0011 * 9	0018	0018 0023 0031			
Nominal applied motor (kW) (Output rating) *1		0.75	1.1	2.2	3.0	5.5	7.5	11	15		
sbu	Rated capacity (kVA) *2	1.3	2.5	3.8	4.8	8.4	13	17	23		
ratir	Rated voltage (V) *3	Three-phas	e 380 to 480	V (with AVR	function)						
tput	Rated current (A) *4	1.8	3.4	5.0	6.3	11.1	17.5	23	31		
no	Overload capability	120%-1 mir	ı								
	Main power supply	Three-phas	e 380 to 480	V, 50/60 Hz							
er	Voltage/frequency variations	Voltage: +1 Frequency:	0 to -15% (In +5 to -5%	iterphase vol	tage unbalar	nce: 2% or le	ss) * 5 ,				
out pow	Rated input current (w/o DCR) (A) *6	2.7	3.9	7.3	11.3	16.8	23.2	33.0	43.8		
dul	(with DCR) (A) *6	1.5	2.1	4.2	5.8	10.1	14.4	21.1	28.8		
	Required capacity (with DCR) (kVA) * 7	1.1	1.5	3.0	4.1	7.0	10	15	20		
	Torque (%) *8	53%	68%	48%	29%	27%	15%				
aking	DC braking	Braking starting frequency: 0.0 to 60.0 Hz, Braking time: 0.0 to 30.0 s, Braking level: 0 to 80%									
B	Braking transistor	Built-in as standard									
	Braking resistor	Separately mounted option									
EMC filter		Compliant with EMC Directives,Compliant with EMC DirectiveEmission: Category C2. Immunity: 2nd Env.Emission: Category C3. Imm(EN61800-3:2004+A1:2012)2nd Env.(EN61800-3:2004+A1:2012)Env.					ectives, Immunity: 012)				
DC	reactor (DCR)	Separately mounted option									
Applicable safety standards		IEC/EN61800-5-1: 2007									
En	closure (IEC60529)	IP20, UL op	en type								
Сс	oling method	Natural	cooling			Fan c	ooling				
Weight / Mass (kg) [lbs]		1.5	1.8	2.3	2.3	2.4	6.5	6.5	11.2		

*1 Fuji 4-pole standard motor. At the selection of the inverter rating, consider not only the rating capacity (kW) is enough but also inverter output current is larger than selected the motor's nominal current.

*2 Rated capacity is calculated by assuming the output rated voltage as 440 V.

- *3 Output voltage cannot exceed the power supply voltage.
- *4 When the carrier frequency (F26) is set to below value or higher, the inverter is sure to be necessary to derate its nominal current.

Type 0002 to 0011 : 8 kHz, type 0018 to 0045 : 10 kHz, type 0060 to 0150 : 6 kHz, type 0176 to 0520 : 4 kHz

*5 Voltageunbalance(%) = $\frac{Max.voltage(V) - Min.voltage(V)}{Three phaseaveragevoltage(V)} \times 67$ (IEC 61800-3)

If the unbalance ratio is 2% to 3%, use an optional AC reactor (ACR).

- *6 The value is calculated assuming that the inverter is connected with a power supply with the capacity of 500 kVA (or 10 times the inverter capacity if the inverter capacity exceeds 50 kVA) and %X is 5%. Be sure to use the DCR when applicable motor capacity is 75 kW or above.
- *7 This specification applies when a DC reactor (DCR) is used.
- *8 Average braking torque for the motor running alone. (It varies with the efficiency of the motor.)
- *9 Type 0006 and 0011: allowable ambient temperature 40 °C (+104 °F) or less. The rated output current is decreased 1% for every 1 °C (1.8 °F) when ambient temperature is +40 °C (+104 °F) or more.

	Item			r	Specifi	cations						
Ту	be (FRNF2E-4G)	0038	0045	0060	0075	0091	0112	0150	0176			
No (kV	minal applied motor V) (Output rating) * 1	18.5	22	30	37	45	55	75	90			
ings	Rated capacity (kVA) *2	28	34	45	57	69	85	114	134			
Output rat	Rated voltage (V) *3	Three-phas	e 380 to 480	V (with AVR	function)							
	Rated current (A) *4	38	45	60	75	91	112	150	176			
	Overload capability	120%-1 mir	1									
ver	Main power supply	Three-phas	e 380 to 480) V, 50/60 Hz					Threephase 380 to 440V, 50Hz Threephase 380 to 480V, 60Hz *10			
Input pov	Voltage/frequency variations	Voltage: +1 Frequency:	Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less) *8, Frequency: +5 to -5%									
	Rated input current (w/o DCR) (A) *5	52.3	60.6	77.9	94.3	114	140	-	-			
	(with DCR) (A) *5	35.5	42.2	57.0	68.5	83.2	102	138	164			
	Required capacity (with DCR) (kVA) * 6	25	30	40	48	58	71	96	114			
	Torque (%) *7		15% 7% to 12%									
aking	DC braking	Braking sta Braking leve	rting frequen el: 0 to 80%	cy: 0.0 to 60 of nominal cu	.0 Hz, Brakin urrent	g time: 0.0 to	o 30.0 s,					
В	Braking transistor	Built-in as standard Separately mounted option										
	Braking resistor	Separately mounted option										
ΕN	1C filter	Compliant with EMC Directives, Emission: Category C3. Immunity: 2nd Env. (EN61800-3:2004+A1:2012)										
DC reactor (DCR)			ę	Separately m	ounted optio	n		Standard	accessory			
Applicable safety standards		IEC/EN618	00-5-1: 2007	,								
En	closure (IEC60529)	IP2	0, UL open t	уре		IP0	0, UL open t	уре				
Co	oling method				Fan c	ooling						
Weight / Mass (kg) [lbs]		11.2	10.5	11.2	26	27	31	33	40			

Standard-model, Three-phase 400 V class series (38 kW to 176 kW)

*1 Fuji 4-pole standard motor. At the selection of the inverter rating, consider not only the rating capacity (kW) is enough but also inverter output current is larger than selected the motor's nominal current.

*2 Rated capacity is calculated assuming the rated output voltage as 440 V.

*3 Output voltage cannot exceed the power supply voltage.

*4 When the carrier frequency (F26) is set to below value or higher, the inverter is sure to be necessary to derate its nominal current.

Type 0002 to 0011 : 8 kHz, type 0018 to 0045 : 10 kHz, type 0060 to 0150 : 6 kHz, type 0176 to 0520 : 4 kHz

- *5 The value is calculated assuming that the inverter is connected with a power supply with the capacity of 500 kVA (or 10 times the inverter capacity if the inverter capacity exceeds 50 kVA) and %X is 5%. Be sure to use the DCR when applicable motor capacity is 75 kW or above.
- *6 This specification applies when a DC reactor (DCR) is used.
- *7 Average braking torque for the motor running alone. (It varies with the efficiency of the motor.)
- *8 Voltageunbalance(%) = $\frac{Max.voltage(V) Min.voltage(V)}{Three phaseaveragevoltage(V)} \times 67$ (IEC 61800-3)

If the unbalance ratio is 2% to 3%, use an optional AC reactor (ACR).

*10 The 400 V class series with type 0176 or above is equipped with a set of switching connectors (male) which should be configured according to the power source voltage and frequency.

Standard-model, Three-phase 400 V class series (90 kW to 280 kW)

	Item	Specifications							
Ту	pe (FRNF2E-4G)	4G) 0210 0253 0304 0377 0415 0520							
Nc (k\	ominal applied motor W) (Output rating) * 1	110	132	160	200	220	280		
ings	Rated capacity (kVA) * 2	160	192	231	287	316	396		
it rat	Rated voltage (V) *3	Three-phas	e 380 to 480	V (with AVR	function)				
utpu	Rated current (A) *4	210	253	304	377	415	520		
0	Overload capability	120%-1 mir	ı						
Main power supply Three-phase 380 to 440V, 50Hz Three-phase 380 to 480V, 60Hz *10)				
ower	Voltage/frequency variations	Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less) *8, Frequency: +5 to -5%							
nput po	Rated input current (w/o DCR) (A) *5	-	-	-	-	-	-		
_	(with DCR) (A) *5	201	238	286	357	390	500		
	Required capacity (with DCR) (kVA) * 6	140	165	199	248	271	347		
	Torque (%) *7	7% to 12%							
aking	DC braking	Braking starting frequency: 0.0 to 60.0 Hz, Braking time: 0.0 to 30.0 s, Braking level: 0 to 80% of nominal current							
ä	Braking transistor	Separately mounted option							
	Braking resistor	Separately mounted option							
ΕN	IC filter	Compliant with EMC Directives, Emission: Category C3. Immunity: 2nd Env. (EN61800-3:2004+A1:2012)							
DC	C reactor (DCR)	Standard accessory							
Ap sta	plicable safety andards	IEC/EN61800-5-1: 2007							
En	closure (IEC60529)	IP00, UL open type							
Сс	oling method			Fan c	ooling				
W	eight / Mass (kg) [lbs]	62	63	95	96	130	140		

*1 Fuji 4-pole standard motor. At the selection of the inverter rating, consider not only the rating capacity (kW) is enough but also inverter output current is larger than selected the motor's nominal current.

*2 Rated capacity is calculated assuming the rated output voltage as 440 V.

*3 Output voltage cannot exceed the power supply voltage.

*4 When the carrier frequency (F26) is set to below value or higher, the inverter is sure to be necessary to derate its nominal current.

Type 0002 to 0011 : 8 kHz, type 0018 to 0045 : 10 kHz, type 0060 to 0150 : 6 kHz, type 0176 to 0520 : 4 kHz

- *5 The value is calculated assuming that the inverter is connected with a power supply with the capacity of 500 kVA (or 10 times the inverter capacity if the inverter capacity exceeds 50 kVA) and %X is 5%. Be sure to use the DCR when applicable motor capacity is 75 kW or above.
- *6 This specification applies when a DC reactor (DCR) is used.
- *7 Average braking torque for the motor running alone. (It varies with the efficiency of the motor.)
- Max.voltage(V)-Min.voltage(V) ×67 (IEC 61800-3) Voltageunbalance(%) = Three phaseaveragevoltage(V) *8

If the unbalance ratio is 2% to 3%, use an optional AC reactor (ACR).

*10 The 400 V class series with type 0176 or above is equipped with a set of switching connectors (male) which should be configured according to the power source voltage and frequency.

Item		Item	Explanation	Remarks
		Maximum frequency	25 to 120 Hz variable (V/f control mode, Magnetic pole position sensorless vector control mode)	
		Base frequency	25 to 120 Hz variable	
		Starting frequency	0.1 to 60.0 Hz variable	
			Three phase 400 V class	
	Setting range		FRN0002F2E-4G to FRN0045F2E-4G:	
			0.75 to 16 kHz variable	
			FRN0060F2E-4G to FRN0160F2E-4G:	
		Carrier frequency	0.75 to 10 kHz variable	
t		Carner inequency	C 75 to 6 kHz variable	
ntpu				
Õ			Note: The carrier frequency may automatically lower depending upon the ambient temperature or the output current to protect the inverter. (The automatic lowering function can be disabled.)	
	Out	tput frequency	 Analog setting: ±0.2% of maximum frequency (at 25±10 °C) (77±18 °F) 	
	acc	curacy (Stability)	 Keypad setting: ±0.01% of maximum frequency (at -10 to +50 °C) (14 to 122 °F) 	
	Fro	auency setting	Analog setting: 0.05% of maximum frequency	
	res	olution	• Keypad setting: 0.01 Hz (99.99 Hz or less), 0.1 Hz (100.0 to 120 Hz)	
	_		Link setting: 0.005% of maximum frequency or 0.01 Hz (fixed)	
	Spe	eed control range	1: 10 (Minimum speed : Nominal speed, 6P, 180 to 1800 r/min)	PM-SVC
	Spe	eed control	 Analog setting: ±0.5% of base frequency or below (at 25 ±10 °C) (77±18 °F) Digital patting: ±0.5% of base frequency or below (10 to ±50 °C) (14 to 122 °E) 	PM-SVC
	acc	Julicey	 Digital Setting. ±0.5% of base nequency of below (-10 to +50° C) (14 to 122° F) 	
	Cor	ntrol method	V/I control Victor control without magnetic pole position sensor	VF PM-SVC
			Possible to set output voltage at base frequency and at maximum output	1 11 0 1 0
	Voltage/frequency characteristics		frequency (160 to 500 V).	
			 Non-linear V/f setting (2 points): Free voltage (0 to 500 V) and frequency (0 to 120 Hz) can be set. 	
	Torque boost		Auto torque boost (For constant torque load)	
			 Manual torque boost: Torque boost value can be set between 0.0 and 20.0% 	
			 Select application load with the function code. (Variable torque load or constant torque load) 	
	Starting torque		Three phase 400 V class : 50% or higher	
	Start/stop operation		Keypad: Start and stop with and a keypad (Standard keypad) Start and stop with and a stop with and keypad (Rev and keypad)	
			External signals (digital inputs):	
_			Forward (Reverse) rotation, stop command (capable of 3-wire operation),	
ntro				
ပိ			Operation via built-in RS-485 or field bus (option) communications	
			Switching operation command: Remote/local switching, link switching	
			Keypad: Settable with \odot and \odot keys	
			External volume: Available to be set with external frequency command	
			potentiometer. (1 to 5 k Ω 1/2 W)	
			Analog input : 0 to ± 10 VDC (± 5 VDC)/ 0 to $\pm 100\%$ (terminal [12]),	Analog input
			0 to +10 VDC (+5 VDC)/ 0 to +100% (terminal [12])	between DC+1 to +5V
	F		4 to 20 mADC/ 0 to $\pm 100\%$ (terminal [C1])	is available
	re	equency setting	: 0 to 20 mADC/ 0 to +100% (terminal [C1])	with analog
			0 to 20 mADC/ 0 to ±100% (terminal [C1])	function.
			: 0 to +10 VDC (+5 VDC)/ 0 to +100% (terminal [V2]), 0 to +10 VDC (+5 VDC)/ 0 to ±100% (terminal IV2])	
			UP/DOWN operation: Frequency can be increased or decreased while the digital input signal is ON.	<u> </u>
			Multistep frequency: Selectable from 16 different frequencies (step 0 to 15)	<u> </u>
				l

12.2 Common Specifications

	Item	Explanation	Remarks
		Pattern operation mode: Automatically run in accordance with the previously configured running time, rotation direction, acceleration/deceleration and reference frequency. Maximum allowable settings are 7 stages.	
		Link operation: Can be specified via built-in RS-485 or field bus communications. (Option)	
		Switching frequency setting source : Two of frequency settings source can be switched with an external signal (digital input). Remote/local switching, Link switching	
	Frequency setting	Auxiliary frequency setting: Inputs at terminals [12], [C1] or [V2] can be added to the main setting as auxiliary frequency settings.	
		Inverse operation : Switchable from "0 to +10 VDC/0 to 100%" to "+10 to 0 VDC/0 to 100%" by external command. (terminals [12], [V2])	
		 Switchable from "0 to -10 VDC/0 to -100%" to "-10 to 0 VDC/0 to -100%" by external command.(terminal [12]) Switchable from "4 to +20 mADC/0 to 100%" to "+20 to 4 mADC/0 to 100%" by external command.(terminal [C1]) Switchable from "0 to +20 mADC/0 to 100%" to "+20 to 0 mADC/0 to 100%" by external command (terminal [C1]) 	
		Pulse train input (standard): Pulse input = Terminal [X5], Rotational direction = Another input terminal except [X5]. Complementary output: Max. 100 kHz, Open collector output: Max. 30 kHz	
		Setting range: From 0.00 to 3600 s	
	Acceleration/ deceleration time	Switching: The four types of acceleration/deceleration time can be set or selected individually (switchable during operation).	
ntrol		Acceleration/deceleration pattern: Linear acceleration/deceleration, S-shape acceleration/deceleration (weak, free (set by function codes)), curvilinear acceleration/deceleration	
Co		Deceleration mode (coast-to-stop): Shut-off of the run command makes the motor coast to a stop.	
		Deceleration time for forcible stop: Deceleration stop by the forcible stop (<i>STOP</i>). S-curve will be canceled during "Force to Stop".	
	Frequency limiter (Upper limit and lower limit frequencies)	 Specifies the upper and lower limits in Hz. Selectable for the operation performed when the reference frequency drops below the lower limit specified by related function code. 	
	Bias for frequency/PID command	Bias of set frequency and PID command can be independently set (setting range: 0 to $\pm 100\%$).	
		Gain: Set in the range from 0 to 200%	
	Analog input	Offset: Setting in the range from -5.0 to +5.0% Eilter: Setting in the range from 0.00 s to 5.00 s	
		 Filter. Setting in the range from 0.00 s to 5.00 s Select from ± or + 	
	Jump frequency	Three operation points and their common jump width (0.0 to 30.0 Hz) can be set.	
		 Trip at power failure: The inverter trips immediately after power failure. Trip at power recovery: Coast-to-stop at power failure and trip at power recovery. Deceleration stop: Deceleration stop at power failure, and trip after stoppage. Continue to run: Operation is continued using the load inertia energy. 	
	Auto-restart after momentary power failure	 Start at the frequency selected before momentary power failure): Coast-to-stop at power failure and start after power recovery at the frequency selected before momentary stop. 	
		 Start at starting frequency: Coast-to-stop at power failure and start at the starting frequency after power recovery. Start at the searched frequency: 	
		Coast-to-stop at power failure and start at the searched frequency after power recovery.	
	Hardware current limiter	Limits the current by hardware to prevent an overcurrent trip caused by fast load variation or momentary power failure, which cannot be covered by the software current limiter. This limiter can be canceled.	

	Item	Explanation	Remarks	
	Software current limiter	Automatically reduces the frequency so that the output current becomes lower than the preset operation level. This limiter can be canceled.		
	Operation by commercial power supply	With commercial power selection command, the inverter outputs 50/60 Hz (<i>SW50</i> , <i>SW60</i>). The inverter has the commercial power supply selection sequence.		
	Torque limiter	Control output torque so that output torque is preset limiting value or less. Switchable between 1st and 2nd torque limit values.		
	PID control	 PID processor for process control Normal operation/inverse operation PID command: Keypad, analog input (from terminals [12], [C1] and [V2]), Multi-step setting(Selectable from 3 points), RS-485 communication PID feedback value (from terminals [12], [C1] and [V2]) Alarm output (absolute value alarm, deviation alarm) Slow flowrate stop function Anti-reset wind-up function PID output limiter Integration reset/hold 		
	Auto-reset	The auto-reset function that makes the inverter automatically attempt to reset the tripped state and restart without issuing an alarm output (for any alarm) even if any protective function subject to reset is activated. The allowable maximum number of reset times for the inverter to automatically attempt to escape the tripped state is 20.		
	Auto search for idling motor speed	The inverter automatically searches for the idling motor speed to start to drive without stopping. (Motor constants must be needed tuning: Auto-tuning (offline))		
Control	Automatic deceleration	 If the DC link bus voltage or calculated torque exceeds the automatic deceleration level during deceleration, the inverter automatically prolongs the deceleration time to avoid overvoltage trip. (It is possible to select forcible deceleration actuated when the deceleration time becomes three times longer.) If the calculated torque exceeds automatic deceleration level during constant speed operation the inverter avoids overvoltage trip by increasing the frequency. 		
	Deceleration characteristic (improved braking capacity)	The motor loss is increased during deceleration to reduce the regenerative energy in the inverter to avoid overvoltage trip.	cancelled at PM-SVC	
	Auto energy saving operation	The output voltage is controlled to minimize the total power loss of the motor and the inverter at a constant speed.	Exclusive high efficiency control at PM-SVC	
	Overload prevention control	If the ambient temperature or internal IGBT junction temperature is almost near the overheat level due to overload, the inverter drops its output frequency automatically in order to escape overload situation.		
	Auto-tuning (off-line)	Measures the motor parameters while the motor is stopped or running, for setting up motor parameters. Tuning mode to only identify %R1 and %X. Tuning mode to identify the parameters for PM motor.		
	Cooling fan ON/OFF control	Detects inverter internal temperature and stops cooling fan when the temperature is low. Fan control signal can be output to an external device.		
	Universal DI	The status of external digital signal connected with the universal digital input terminal is transferred to the host controller.		
	Universal DO	Digital command signal from the host controller is output to the universal digital output terminal.		
	Universal AO	The analog command signal from the host controller is output to the analog output terminal.		
	Speed control Selectable among the two set of the auto speed regulator (ASR) parameters. (The PG option card is required.)			

	Item	Explanation	Remarks
	DC braking	When the run command turns OFF and the motor speed fall below the preset DC braking starting speed, the inverter starts to inject DC current into the motor in order to stop the motor. When the run command turns ON, the inverter starts to inject DC current into the motor in order to pre-excite.	
	Rotation direction control	Select either of reverse or forward rotation prevention.	
Control	Dew condensation prevention	When the motor is stopped, current is automatically supplied to the motor to keep the motor warm and avoid condensation.	
	Customizable logic interface	 The digital logic circuits and analog arithmetic circuits can be chosen and connected with digital/analog input/output signals. Logic circuit: (Digital) AND, OR, XOR, flip-flops, rising/falling edge detection, counters, etc. (Analog) Addition, subtraction, multiplication, division, limiter, absolute value, sign inversion addition, comparison, highest selection, lowest selection, average value, measure conversion . Multifunctional timer: On-delay, off-delay, pulse train, etc. Setting range: 0.0 to 9990 s Input/output signal: Terminal input/output(Digital and Analog), logic circuit output, inverter command/monitor data Others: The 200 steps are available. Output/input of each step can be connected. 	
	 Applicable functions for Constant temperature difference control Presumed terminal pressure control 	The specific functions which are suitable for each application field are realized by customizable logics.	
	Pump number control	 Possible to operate a water system with optimal power by controlling a number of pumps. Inverter-driven fixed system Maximum number of units in control: 4 One pump driven by inverter at variable speed (fixed), up to three pumps driven by commercial power (fixed), and one auxiliary pump (driven by commercial power) (fixed) Inverter-driven circulation system Maximum number of units in control: 3 One pump driven by inverter at variable speed (circulation), up to two pumps driven by commercial power (circulation) (the relay output interface card (optional) is required in the case of the circulation operation of three pumps), and one auxiliary pump (driven by commercial power) (fixed) Communications link system Maximum number of units in control: 4 Up to four pumps driven by inverter at variable speed (all units under inverter variable speed control) (Each pump requires an inverter.) 	
	Password function	Possible to hide the display of data or prevent setting changes caused by unintended control (possible to set in two levels).	
	Data initialization	Selectable from "Factory default value" and "User initial value".	
	External PID Control	 PID processor for process control Normal operation/inverse operation PID command: Keypad, analog input (from terminals [12], [C1] and [V2]), Multi-step setting(Selectable from 3 points), RS-485 communication PID feedback value (from terminals [12], [C1] and [V2]) Alarm output (absolute value alarm, deviation alarm) PID feedback error detection Sensor input quantity scaling function PID output limiter Integral reset/hold function Anti recet windup function 	
	Fire mode	Continues operation without alarm by retry.	

	Item	Explanation					
	Display	Detachable with 7 segments LEDs (4 digits) , 7 keys(PRG/RESET, FUNC/DATA, UP, DOWN, RUN, STOP, SHIFT) and 6LED indicator (KEYPAD CONTROL, Hz, A, kW, \times 10, RUN)	Back cover for keypad panel is not provided.				
Indicate	Running/stopping	 Speed monitor (reference frequency, output frequency, motor speed, load shaft speed, line speed, and speed indication with percent), Output current in RMS[A], Output voltage in RMS[V], Calculated torque [%], Input power [kW], PID command value, PID feedback value, PID output, Load factor [%], Motor output [kW] Analog input monitor, input watt-hour, external PID1 command value (final), external PID1 feedback amount, external PID1 output, and manual external PID1 command value (final). 					
	Life early warning	 The life early warning of the main circuit capacitors, capacitors on the PCBs and the cooling fan can be displayed. An external output is issued in a transistor output signal. Outputs the warning when the maintenance time or the number of start times has exceeded the preset. Ambient temperature: 40 °C (104 °F) Load factor: Inverter rated current 80% 					
	Maintenance monitor	Displays DC link bus voltage, Max. Output current in RMS, Input watt-hour, Input watt-hour data, Temperature (inside the inverter and heat sink, maximum value of heat sink), Capacitance of the DC link bus capacitor, Lifetime of DC link bus capacitor (elapsed hours and remaining hours), Cumulative run time (power-ON time counter of the inverter, electrolytic capacitors on the printed circuit boards, cooling fan and each motor), Remaining time before the next motor maintenance, Remaining startup times before the next maintenance, Number of startups (of each motor), Light alarm factors (Latest to 3rd last), Contents and numbers of RS-485 communications errors, Option error factors , Number of option errors, ROM version of the inverter, Keypad and Option port.					
	I/O check	Displays the I/O signal states of control circuit terminals using the segment ON/OFF of the 7-segment LED monitor or hexadecimal format. (digital and analog signals)					
	Locked by password	Limits to change or display in function code.					
	Trip mode	Displays the cause of trip by codes.					
	Light-alarm	Shows the light-alarm display $L - R_L$.					
	Running or trip mode	 Trip history: Saves and displays the cause of the last four trips (with a code). Saves and displays the detailed operation status data of the last four trips. 					
PC-Loader	Inverter loader	 Personal computer software tool that supports the operation of the inverter via an RS-485 communications link. Setting of function code: Manage the function codes (list, edit, comparison, multi-monitor). Editing customizable logic: Customizable logic editor. Running status monitor: I/O monitor, system monitor, alarm monitor, etc. Test-running: Remotely run or stop the inverter. Real-time trace: The real-time trace monitors(minimum sampling time : 20 to 200 ms) up to 4 analog readouts and up to 8 digital ON/OFF signals to display the running status of a selected inverter in real-time waveforms. Historical trace: The historical trace monitors the running status of a selected inverter in greater detail with more contiguous waveforms than in the real-time trace. Sampling time : 1 to 200ms Up to 4 analog and 8 digital readouts (Maximum) (Data store size : 2kB) 					

*Note: The meaning of the described abbreviations are shown as follows. VF V/f Control

PM Magnetic Pole Position Sensorless Vector Control

When the protective function is activated so that the LED monitor shows alarm codes, refer to Chapter 6 "TROUBLESHOOTING."

EXTERNAL DIMENSIONS

This chapter describes the external dimensions of the inverter.

Contents

13.1 Standard Model······13-1
13.1 Standard Model

FRN0002F2E-4G



Figure 13.1-1

(Unit

FRN0003F2E-4G









Figure 13.1-2

FRN0005F2E-4G, FRN0006F2E-4G, FRN0011F2E-4G



■ FRN0018F2E-4G, FRN0023F2E-4G



Figure 13.1-4

■ FRN0031F2E-4G, FRN0038F2E-4G

– <u>Ma</u>

32



(Unit: mm)

Figure 13.1-5

- A

30

FRN0045F2E-4G, FRN0060F2E-4G

The figure given in the lower right-hand corner of each set of drawings shows the dimension of panel cutting required for external cooling. To employ external cooling for inverters FRN0045F2E-4G and FRN0060F2E-4G, the optional mounting adapter for external cooling is necessary. For the external dimensions of the mounting adapter, refer to Chapter 11, Section 11.15.





FRN0075F2E-4G, FRN0091F2E-4G





FRN0112F2E-4G



Figure 13.1-8

FRN0150F2E-4G





(Unit: mm)

Chap 13 EXTERNAL DIMENSIONS

FRN0176F2E-4G



Figure 13.1-10

■ FRN0210F2E-4G, FRN0253F2E-4G



Figure 13.1-11

■ FRN0304F2E-4G, FRN0377F2E-4G



Figure 13.1-2



(Unit: mm)

13-13

Figure 13.1-3



APPENDICES

Contents

Appendix A	Trouble-free Use of Inverters (Notes on electrical noise)1
A.1	Effect of inverters on other devices1
[1]	Effect on AM radios ······1
[2]	Effect on telephones ·······1
[3]	Effect on proximity switches1
[4]	Effect on pressure sensors ······1
[5]	Effect on position detectors (pulse encoders) 1
A.2	Noise2
[1]	Inverter noise2
[2]	Types of noise3
A.3	Measures ······5
[1]	Noise prevention prior to installation5
[2]	Implementation of noise prevention measures5
[3]	Noise prevention examples8
Appendix B	Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage (General-purpose inverter)······ 12
B.1	Application to general-purpose inverters
[1]	Guideline for suppressing harmonics in home electric and general-purpose appliances
[2]	Guideline for suppressing harmonics by customers receiving high voltage or special high voltage
B.2	Compliance to the harmonic suppression for customers receiving high voltage or special high voltage
[1]	Calculation of equivalent capacity (Pi) 13
[2]	Calculation of harmonic current 14
[3]	Examples of calculation 16
Appendix C	Effect on Insulation of General-purpose Motors Driven with 400 V Class Inverters 17
C.1	Generating mechanism of surge voltages 17
C.2	Effect of surge voltages 18
C.3	Countermeasures against surge voltages 19
[1]	Using a surge suppressor unit, SSU (Patent pending) 19

[2]	Suppressing surge voltages 19
[3]	Using motors with enhanced insulation 19
C.4	Regarding existing equipment
[1]	In case of a motor being driven with 400 V class inverter 20
[2]	In case of an existing motor driven using a newly installed 400 V class inverter $\cdots\cdots$ 20
Appendix D	Inverter Generating Loss 21
Appendix E	Conversion from SI Units 22
E.1	Conversion of units 22
E.2	Calculation formulas 23
Appendix F	Allowable Current of Insulated Wires 24
Appendix G	Conformity with Standards 26
G.1	Compliance with European Standards ($\boldsymbol{\zeta} \boldsymbol{\epsilon}$)
[1]	Compliance with EMC standards 26
[2]	Compliance with the low voltage directive in the EU 29
G.2	Compliance with UL Standards and Canadian Standards (cUL certification) (c(t) us ustree)
Appendix H	Compliance with Management Methods for Controlling Pollution Caused by Electronic Information Products Regulation (China RoHS)

Appendix A Trouble-free Use of Inverters (Notes on electrical noise)

Excerpt from technical material of the Japan Electrical Manufacturers' Association (JEMA) (April 1994)

A.1 Effect of inverters on other devices

Inverters have been and are rapidly expanding its application fields. This paper describes the effect that inverters have on electronic devices already installed or on devices installed in the same system as inverters, as well as introducing noise prevention measures. (Refer to "A.3 [3] Noise prevention examples" for details.)

[1] Effect on AM radios

<u>Phenomena</u>	If an inverter operates, AM radios may pick up noise radiated from the inverter. (An inverter has almost no effect on FM radios or television sets.)
Probable cause	The noise radiated from the inverter may be received by a radio.
<u>Measure</u>	Inserting a noise filter on the power supply side of the inverter is effective.

[2] Effect on telephones

Phenomena	If an inverter operates, nearby telephones may pick up noise radiated from the inverter in conversation so that it may be difficult to hear.
Probable cause	A high-frequency leakage current radiated from the inverter and motors enters shielded telephone cables, causing noise.
<u>Measure</u>	It is effective to commonly connect the grounding terminals of the motors and return the common grounding line to the grounding terminal of the inverter.

[3] Effect on proximity switches

Phenomena	If an inverter operates, proximity switches (capacitance-type) may malfunction.
Probable cause	The capacitance-type proximity switches may provide inferior noise immunity.
<u>Measure</u>	It is effective to connect a filter to the input terminals of the inverter or change the power supply treatment of the proximity switches. The proximity switches can be replaced with superior noise immunity types such as magnetic types.

[4] Effect on pressure sensors

Phenomena	If an inverter operates, pressure sensors may malfunction.
Probable cause	Noise may penetrate through a grounding wire into the signal line.
Measure	It is effective to install a noise filter on the power supply side of the inverter or to change the wiring.

[5] Effect on position detectors (pulse encoders)

<u>Phenomena</u> If an inverter operates, pulse encoders may produce erroneous pulses that shift the stop position of a machine.

- <u>Probable cause</u> Erroneous pulses are liable to occur when the signal lines of the PG and power lines are bundled together.
- <u>Measure</u> The influence of induction noise and radiated noise can be reduced by separating the PG signal lines and power lines. Providing noise filters at the input and output terminals is also an effective measure.

A.2 Noise

This section gives a summary of noises generated in inverters and their effects on devices subject to noise.

[1] Inverter noise

Figure A-1 shows an outline of the inverter configuration. The inverter converts AC to DC (rectification) in a converter unit, and converts DC to AC (inversion) with 3-phase variable voltage and variable frequency. The conversion (inversion) is performed by PWM implemented by switching six transistors (IGBT: Insulated Gate Bipolar Transistor, etc), and is used for variable speed motor control.

Switching noise is generated by high-speed on/off switching of the six transistors. Noise current (i) is emitted and at each high-speed on/off switching, the noise current flows through stray capacitance (C) of the inverter, cable and motor to the ground. The amount of the noise current is expressed as follows:

 $i = C \cdot dv/dt$

It is related to the stray capacitance (C) and dv/dt (switching speed of the transistors). Further, this noise current is related to the carrier frequency since the noise current flows each time the transistors are switched on or off.

In addition to the main circuit of the inverter, the DC-to-DC switching power regulator (DC/DC converter), which is the power source for the control circuit of the inverter, may be a noise source in the same principles as stated above.

The frequency band of this noise is less than approximately 30 to 40 MHz. Therefore, the noise will affect devices such as AM radios using low frequency band, but will not virtually affect FM radios and television sets using higher frequency than this frequency band.



Figure A-1 Outline of Inverter Configuration

[2] Types of noise

Noise generated in an inverter is propagated through the main circuit wiring to the power supply and the motor so as to affect a wide range of applications from the power supply transformer to the motor. The various propagation routes are shown in Figure A-2. According to those routes, noises are roughly classified into three types--conducted noise, induction noise, and radiated noise.



Figure A-2 Noise Propagation Routes

(1) Conducted noise

The noise that has occurred in the inverter and propagates through a conductor to influence peripheral equipment is called conducted noise. Some conducted noise will propagate through the main circuit (1). If the ground wires are connected to a common ground, conducted noise will propagate through route (2). As shown in route (3), some conducted noise will propagate through signal lines or shielded wires.



Figure A-3 Conducted Noise

(2) Induction noise

When wires or signal lines of peripheral devices are brought close to the wires on the input and output sides of the inverter through which noise current is flowing, noise will be induced into those wires and signal lines of the devices by electromagnetic induction (Figure A-4) or electrostatic induction (Figure A-5). This is called "induction noise" (4).



Figure A-4 Electromagnetic Induced Noise



Figure A-5 Electrostatic Induced Noise

(3) Radiated noise

Noise generated in an inverter may be radiated through the air from wires (that act as antennas) at the input and output sides of the inverter so as to affect peripheral devices. This noise is called "radiated noise" as shown below as (5). Not only wires but motor frames or control system panels containing inverters may also act as antennas.



Figure A-6 Radiated Noise

A.3 Measures

As the noise prevention is strengthened, the more effective it is. However, with the use of appropriate measures, noise problems may be resolved easily. It is necessary to implement economical noise prevention according to the noise level and the equipment conditions.

[1] Noise prevention prior to installation

Before installing an inverter in your control panel or installing an inverter panel, you need to consider noise prevention. Once noise problems occur, it will cost additional materials and time for solving them.

Noise prevention prior to installation includes:

- (1) Separate the main circuit from the control circuit.
- (2) Accommodate the main circuit wiring in a metal pipe (conduit pipe).
- (3) Use shielded wire or twisted shielded wire in the control circuit.
- (4) Perform reliable grounding work and wiring.

These noise prevention measures can avoid most noise problems.

[2] Implementation of noise prevention measures

There are two types of noise prevention measures--one for noise propagation routes and the other for noise receiving sides (that are affected by noise).

The basic measures for reducing the effect of noise at the receiving side include: Separating the main circuit wiring from the control circuit wiring, avoiding noise effect.

Measures on the noise-affected side are:

- (1) Lower the noise level for example by installing a noise filter.
- (2) Suppress the noise level for example by using a metal wiring pipe or metal control panel.
- (3) Block the noise propagation route for example by using an insulation transformer for power source.

Table A-1 lists the noise prevention measures, their goals, and propagation routes.

Table A-1 Noise Prevention Mea	asures
--------------------------------	--------

			Goal of noise prevention measures			Conduction route		
	Noise prevention method	Make it more difficult to receive noise	Cutoff noise conduction	Confine noise	Reduce noise level	Conducted noise	Induction noise	Radiated noise
	Separate main circuit from control circuit	Y					Y	
	Minimize wiring distance	Υ			Y		Y	Y
	Avoid parallel and bundled wiring	Υ					Y	
Wiring and installation	Use appropriate grounding	Y			Y		Y	Y
	Use shielded wire and twisted shielded wire	Y					Y	Y
	Use shielded cable in main circuit			Υ				Y
	Use metal conduit pipe			Υ			Y	Y
Control papel	Appropriate arrangement of devices in panel	Y					Y	Y
	Metal control panel			Υ			Y	Y
Anti-noise devices	Line filter	Y			Y	Y		Y
	Insulation transformer		Y			Y		Y
Maaaumaa taluan an	Use a passive capacitor for control circuit	Y					Y	Y
noise-affected side	Use ferrite core for control circuit	Y					Y	Y
	Line filter	Y				Y		
Other	Separate power supply systems	Y	Y			Y		
Other	Lower the carrier frequency				Y	Y	Y	Y

In the table, a column marked with Y shows a measure expected to produce an effect depending on the conditions. An empty column shows an ineffective measure.

What follows is noise prevention measures for the inverter drive configuration.

(1) Wiring and grounding

As shown in Figure A-7, separate the main circuit wiring from control circuit wiring as far as possible regardless of being located inside or outside the system control panel containing an inverter. Use shielded wires and twisted shielded wires that will block out extraneous noises, and minimize the wiring distance. Also avoid bundled wiring of the main circuit and control circuit or parallel wiring.



Figure A-7 Separate Wiring

For the main circuit wiring, use a metal conduit pipe and connect its wires to the ground to prevent noise propagation (refer to Figure A-8).

The shield (braided wire) of a shielded wire should be securely connected to the base (common) side of the signal line at only one point to avoid the loop formation resulting from a multi-point connection (refer to Figure A-9).

The grounding is effective not only to reduce the risk of electrical shocks due to leakage current, but also to block noise penetration and radiation. Corresponding to the main circuit voltage, the grounding work should be Class D (300 VAC or less, grounding resistance: 100Ω or less) and Class C (300 to 600 VAC, grounding resistance: 10Ω or less). Each ground wire is to be provided with its own ground or separately wired to a grounding point.



Figure A-8 Grounding of Metal Conduit Pipe

Figure A-9 Treatment of Braided Wire of Shielded Wire

(2) Control panel

The system control panel containing an inverter is generally made of metal, which can shield noise radiated from the inverter itself.

When installing other electronic devices such as a programmable logic controller in the same control panel, be careful with the layout of each device. If necessary, arrange shield plates between the inverter and peripheral devices.

(3) Anti-noise devices

To reduce the noise propagated through the electrical circuits and the noise radiated from the main circuit wiring to the air, a line filter and power supply transformer should be used (refer to Figure A-10).

Line filters are classified into simple-type filters including capacitive filters to be connected in parallel to a power line and inductive filters to be connected in series to a power line and authentic filters (LC filters) to address radio noise restrictions. They are used selectively used to meet the target noise reduction effect. Power transformers include generally used insulation transformers, shield transformers and noise-cut transformers, which have different effects to block propagation of noise.



Figure A-10 Various Filters and their Connection

(4) Noise prevention measures at the receiving side

It is important to strengthen the noise immunity of those electronic devices installed in the same control panel as the inverter or located near an inverter. Line filters and shielded or twisted shielded wires are used to block the penetration of noise in the signal lines of these devices. The following treatments are also implemented.

- 1) Lower the circuit impedance by connecting capacitors or resistors to the input and output terminals of the signal circuit in parallel.
- Increase the circuit impedance for noise by inserting choke coils in series in the signal circuit or passing signal lines through ferrite core beads. It is also effective to widen the signal base lines (0 V line) or grounding lines.

(5) Other

The level of generating/propagating noise will change with the carrier frequency of the inverter. The higher the carrier frequency, the higher the noise level.

In an inverter whose carrier frequency can be changed, lowering the carrier frequency can reduce the generation of electrical noise and result in a good balance with the audible noise of the motor under driving conditions.

[3] Noise prevention examples

Table A-2 lists examples of the measures to prevent noise generated by a running inverter.

Table A-2	Examples of Noise Prevention Measures

No.	Target	Phenomena	Measure		
	aevice			Notes	
1	AM radio	Noise enters the AM radio broadcast (500-1500kHz) when the inverter is operated. Power source AM radio <possible cause=""> Radiated noise from the power source and output wiring of inverted was received by the AM radio.</possible>	 Install an LC filter at the power supply side of the inverter. (In some cases, a capacitive filter may be used as a simple method.) Install a metal conduit wiring between the motor and inverter. Power source	 The radiated noise of the wiring can be reduced. Reduce the conducted noise to the power source or apply shielded wiring. Note: Sufficient improvement may not be expected in narrow regions such as between mountains. 	
2	AM radio	Noise enters the AM radio broadcast (500 to 1500kHz) when the inverter is operated. Pole transformar Radio <possible cause=""> Radiated noise from the power line of inverter's power source was received by the AM radio.</possible>	 Install inductive filters at the input and output sides of the inverter. Short Short Short distance distance filter (zero-phase reactor) The number of turns of the zero-phase reactor (or ferrite ring) should be as large as possible. Minimize the distance between the inverter and the inductive filter (within 1 m). When further improvement is necessary, install LC filters. 	1) The radiated noise of the wiring can be reduced.	

No.	Target device	Phenomena	Measure		
				Notes	
3	Telephone (in a common private residence at a distance of 40 m)	When driving a ventilation fan with an inverter, noise enters a telephone in a private residence at a distance of 40 m. Pole transformer transformer transformer transformer transformer transformer transformer to the shielded ground of the telephone cable on the way back via the ground of the pole transformer to cause noise by electrostatic induction.	 1) Connect the ground terminals of the motors in a common connection. Return to the inverter panel, and insert a 1 µF capacitor between the input terminal of the inverter and ground. Image: the inverter and ground terminal of the inverter and ground. 	 The effect of the inductive filter and LC filter may not be expected because of sound frequency component. In the case of a V-connection power supply transformer in a 200V system, it is necessary to connect capacitors as shown in the following figure, because of different potentials to ground. 	
4	Photo- electric relay	A photoelectric relay malfunctioned when the inverter runs the motor. [The inverter and motor are installed in the same place (for overhead traveling)] $\qquad \qquad $	 1) As a temporary measure, Insert a 0.1 µF capacitor between the 0 V terminal of the power supply circuit in the detection unit of the overhead photoelectric relay and a frame of the overhead panel. 24V Photoelectric relay 24V Photoelectric relay 2) As a permanent measure, move the 24 V power supply from the ground to the overhead unit so that signals are sent to the ground side with relay contacts in the ceiling part. 	 Separate the wiring (30 cm or more). When separation is impossible, signals can be received and sent with dry contacts etc. Do not wire low-current signal lines and power lines in parallel. 	

Table A-2 Examples of Noise Prevention Measures (C	ontinued)
--	-----------

No.	Target	Phenomena	Measure	
	device			Notes
5	Photo- electric relay	A photoelectric relay malfunctioned when the inverter was operated.	1) Insert a 0.1 μ F capacitor between the output common terminal of the amplifier of the photoelectric relay and the frame.	1) If a low-current circuit at the malfunctioning side is observed, the measures may be simple and economical.
6	Proximity switch (capacitanc e type)	A proximity switch malfunctioned. Power source Power Power Power Proximity switch <possible cause=""> The electrostatic capacitive proximity switch has a low noise immunity, and is vulnerable to circuit conducted noise and radiated noise.</possible>	 Install an LC filter at the output side of the inverter. Install a capacitive filter at the input side of the inverter. Ground the 0 V (common) line of the DC power supply of the proximity switch through a capacitor to the box body of the machine. Power Unverter Un	 Noise generated in the inverter can be reduced. The switch is superseded by a proximity switch of superior noise immunity (such as a magnetic type).
7	Pressure sensor	A pressure sensor malfunctioned. Power source DC 244 Pressure sensor Box body <possible cause=""> Noise enters from the box body via the shielded wire to cause malfunctioning of the pressure sensor.</possible>	 Install an LC filter on the input side of the inverter. Connect the shield of the shielded wire of the pressure sensor to the 0 V line (common) of the pressure sensor, changing the original connection. Power	 The shielded parts of shield wires for sensor signals are connected to a common point in the system. Conducted noise from the inverter can be reduced.

Table A-2	Examples of Noise Prevention Measures	(Continued)
-----------	---------------------------------------	-------------

No	Target	Phonomona	Moosuro	
NO.	device	Flienomena	Measure	Notes
8	Position detector (pulse encoder)	Erroneous-pulse outputs from a pulse converter caused a shift in the stop position of a crane.	 Install an LC filter and a capacitive filter at the input side of the inverter. Install an LC filter at the output side of the inverter. Install an LC filter at the output side of the inverter. 	 This is an example of a measure where the power line and signal line cannot be separated. Induction noise and radiated noise at the output side of the inverter can be reduced.
9	Program mable logic controller (PLC)	The PLC program sometimes malfunctions. PowerN PowerPLCSignal sourcePLCSignal sourceSource <possible cause=""> Power sources of the inverter and PLC are in the same system so that noise enters PLC via the power source.</possible>	 Install a capacitive filter and an LC filter on the input side of the inverter. Install an LC filter on the output side of the inverter. Lower the carrier frequency of the inverter. Power Power Inverter LC filter M LC filter LC filter	 Total conducted noise and induction noise in the electric line can be reduced.

Table A-2	Examples of Noise Prevention Measures	(Continued)
-----------	---------------------------------------	-------------

Appendix B Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage (General-purpose inverter)

Agency of Natural Resource and Energy of Japan published the following two guidelines for suppressing harmonic noise in September 30, 1994.

- (1) "Guideline to reduce harmonic emissions caused by electrical and electronic equipment for household and general use"
- (2) "Guideline of harmonics reduction for consumers with high or ultra-high voltage power receiving facilities"

Assuming that electronic devices generating high harmonics will be increasing, these guidelines are to establish regulations for preventing high frequency noise interference on devices sharing the power source. These guidelines should be applied to all devices that are used on the commercial power lines and generate harmonic current. This section gives a description limited to general-purpose inverters.

B.1 Application to general-purpose inverters

[1] Guideline for suppressing harmonics in home electric and general-purpose appliances

As of January 2004, the "Guideline to reduce harmonic emissions caused by electrical and electronic equipment for household and general use" (established September 1994) put into effect by the Ministry of Economy, Trade and Industry no longer applied to general-purpose inverters (input current of 20A or less). For consumers who do not apply to the "Guideline to the control of harmonics by consumers of high or special high voltage power supply", it is recommended that the "DC reactors" indicated in catalogues and user's manual be connected to inverters as before.

[2] Guideline for suppressing harmonics by customers receiving high voltage or special high voltage

Unlike other guidelines, this guideline is not applied to the equipment itself such as a general-purpose inverter, but is applied to each large-scale electric power consumer for total amount of harmonics. Regulation is applied to each power consumer rather than direct regulation of harmonic current generating equipment such as the "general-purpose inverter". Calculation of the amount of generated harmonic current is necessary on individual equipment.

(1) Scope of regulation

In principle, the guideline applies to the customers that meet the following two conditions:

- The customer receives high voltage or special high voltage.
- The "equivalent capacity" of the converter load exceeds the standard value for the receiving voltage (50 kVA at a receiving voltage of 6.6 kV).

"B.2 [1] Calculation of equivalent capacity (Pi)" gives you some supplemental information with regard to estimation for the equivalent capacity of an inverter according to the guideline.

(2) Regulation

The level (calculated value) of the harmonic current that flows from the customer's receiving point out to the system is subjected to the regulation. The regulation value is proportional to the contract demand. The regulation values specified in the guideline are shown in Table B-1.

"B.2 Compliance to the harmonic suppression for customers receiving high voltage or special high voltage" gives you some supplemental information with regard to estimation for the equivalent capacity of the inverter for compliance to "Japanese guideline for suppressing harmonics by customers receiving high voltage or special high voltage."

Receiving voltage	5th	7th	11th	13th	17th	19th	23rd	Over 25th
6.6 kV	3.5	2.5	1.6	1.3	1.0	0.90	0.76	0.70
22 kV	1.8	1.3	0.82	0.69	0.53	0.47	0.39	0.36

Table B-1 Upper Limits of Harmonic Outflow Current per kW of Contract Demand (mA/kW)

(3) When the regulation applied

The guideline has been applied.

The estimation for "Voltage distortion factor" required as the indispensable conditions when entering into the consumer's contract of electric power is already expired.

B.2 Compliance to the harmonic suppression for customers receiving high voltage or special high voltage

When calculating the required matters related to inverters according to the guideline, follow the terms listed below. The following descriptions are based on "Technical document for suppressing harmonics" (JEAG 9702-1995) published by the Japan Electrical Manufacturer's Association (JEMA).

[1] Calculation of equivalent capacity (Pi)

The equivalent capacity (Pi) may be calculated using the equation of (input rated capacity) x (conversion factor). However, catalogs of conventional inverters do not contain input rated capacities, so a description of the input rated capacity is shown below:

(1) "Inverter rated capacity" corresponding to "Pi"

- In the guideline, the conversion factor of a 6-pulse converter is used as reference conversion factor 1. It is, therefore, necessary to express the rated input capacity of inverters in a value including harmonic component current equivalent to conversion factor 1.
- In particular, calculate the input fundamental current I₁ from the kW rating and efficiency of the motor and the efficiency of the inverter as loads and then calculate:

Input rated capacity= $\sqrt{3} \times$ (power voltage) × I₁ × 1.0228/1000 (kVA).

Then, calculate the input rated capacity as shown below: where 1.0228 is the 6-pulse converter's value of (effective current)/ (fundamental current).

- When a general-purpose motor or inverter motor is used, the appropriate value shown in Table B-2 can be used. Select a value based on the kW rating of the motor used, irrespective of the inverter type.
 - Note The input rated capacity shown above is for the dedicated use in the equation to calculate capacity of the inverters, following the guideline. Note that the capacity cannot be applied to the reference for selection of the equipment or wires to be used in the inverter input circuits.
- For selection of capacity for the peripheral equipment, refer to the catalogs or technical documents issued from their manufacturers.

Applicable (k)	motor rating N)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22
Pi (kVA)	400 V	0.97	1.95	2.81	4.61	6.77	9.07	13.1	17.6	21.8	25.9

Table B-2 "Input Rated Capacities" of General-purpose Inverters Determined by the Applicable Motor Ratings

Applicable (k)	motor rating N)	30	37	45	55	75	90	110	132	160	200
Pi (kVA)	400 V	34.7	42.8	52.1	63.7	87.2	104	127	153	183	229

Applicable (k)	motor rating W)	220	250	280
Pi (kVA) 400 V		252	286	319

(2) Values of "Ki (conversion factor)"

Depending on whether an optional ACR (AC reactor) or DCR (DC reactor) is used, apply the appropriate conversion factor specified in the appendix to the guideline. The values of the conversion factor are listed in Table B-3.

Table B-3	"Conversion Factors Ki"	" for General-r	ourpose Inverters	Determined by	/ Reactors
	001101310111 401013 14				

Circuit category	Ci	rcuit type	Conversion factor Ki	Main applications
3	Three-phase bridge (Capacitor smoothing)	w/o a reactor	K31=3.4	General-purpose inverter
		w/- a reactor (ACR)	K32=1.8	Elevator
		w/- a reactor (DCR)	K33=1.8	Cold air refrigerating machine
		w/- reactors (ACR and DCR)	K34=1.4	Other equipment in general



Some models are equipped with a reactor as a standard accessory.

Calculation of harmonic current [2]

Value of "input fundamental current" (1)

- · When you calculate the amount of harmonics according to Table 2 in Appendix of the Guideline, you have to previously know the input fundamental current.
- Apply the appropriate value shown in Table B-4 based on the kW rating of the motor, irrespective of the inverter type or whether a reactor is used.



If the input voltage is different, calculate the input fundamental current in inverse proportion to the voltage.

Table B-4 "Input Fundamental Currents" of General-purpose Inverters Determined by the Applicable Motor Ratings

licable motor rating	g (kW)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22
ut fundamental current (A)	400 V	1.37	2.75	3.96	6.50	9.55	12.8	18.5	24.9	30.7	36.6
6.6 kV converted value (mA)		83	167	240	394	579	776	1121	1509	1860	2220
licable motor rating	g (kW)	30	37	45	55	75	90	110	132	160	200
ut fundamental 4 current (A)	400 V	49.0	60.4	73.5	89.9	123	147	179	216	258	323
6.6 kV converted value (mA)		2970	73.5	4450	5450	7450	8910	10850	13090	15640	19580
current (A) 4 kV converted value licable motor rating ut fundamental current (A) 4	400 V e (mA) g (kW) 400 V	1.37 83 30 49.0	2.75 167 37 60.4	3.96 240 45 73.5	6.50 394 55 89.9	9.55 579 75 123	12.8 776 90 147	18.5 1121 110 179	24.9 1509 132 216	30.7 1860 160 258	3 22 2 3

Applicable motor rat	ting (kW)	220	250	280
Input fundamental current (A)	400 V	355	403	450
6.6 kV converted va	lue (mA)	21500	24400	27300

100%

Calculation of harmonic current (2)

Usually, calculate the harmonic current according to the Sub-table 3 "Three-phase bridge rectifier with the smoothing capacitor" in Table 2 of the Guideline's Appendix. Table B-5 lists the contents of the Sub-table 3.

Table B-5 Generated Harmonic Current (%), 3-phase Bridge Rectifier (Capacitor Smoothing)

Degree	5th	7th	11th	13th	17th	19th	23rd	25th
w/o a reactor	65	41	8.5	7.7	4.3	3.1	2.6	1.8
w/- a reactor (ACR)	38	14.5	7.4	3.4	3.2	1.9	1.7	1.3
w/- a reactor (DCR)	30	13	8.4	5.0	4.7	3.2	3.0	2.2
w/- reactors (ACR and DCR)	28	9.1	7.2	4.1	3.2	2.4	1.6	1.4

ACR: 3%

DCR: Accumulated energy equal to 0.08 to 0.15 ms (100% load conversion)

Smoothing capacitor: Accumulated energy equal to 15 to 30 ms (100% load conversion)

Load:

Generated thharmonic urrent(%) nthharmoniccurrent(A)=Fundament¤t(A)×

Appendix-14

100

Calculate the harmonic current of each degree using the following equation:

(3) Maximum availability factor

- For a load like elevators, which provides intermittent operation, or a load with a sufficient designed motor rating, reduce the current by multiplying the equation by the "maximum availability factor" of the load.
- According to the Appendix to Guideline, "Maximum availability factor of equipment refers to the ratio of the maximum capacity of the operating equipment to the total capacity of the harmonic generation equipment. Capacity of the operating equipment shall be an average value over 30 minutes."
- In general, the maximum availability factor is calculated according to this definition, but the standard values shown in Table B-6 are recommended for inverters for building equipment.

Table B-6 Availability Factors of Inverters, etc. for Building Equipment (Standard Values)

Equipment type	Inverter capacity category	Single inverter availability		
Air conditioning overcom	200 kW or less	0.55		
Air conditioning system	Over 200 kW	0.60		
Sanitary pump	-	0.30		
Elevator	-	0.25		
Refrigerator, freezer	50 kW or less	0.60		
UPS (6-pulse)	200kVA	0.60		

Correction coefficient according to contract demand level

Since the total availability factor decreases if the scale of a building increases, the calculation of reduced harmonics with the correction coefficient β defined in Table B-7 is permitted.

Contract demand (kW)	Correction coefficient β		
300	1.00		
500	0.90		
1,000	0.85		
2,000	0.80		

Note: If the contract demand is between two specified values listed in Table B-7, calculate the value by interpolation.

Note: The correction coefficient β is to be determined as a matter of consultation between the customer and electric power company for the customers receiving the electric power over 2000 kW or from the special high voltage lines.

(4) Degree of harmonics to be calculated

The higher the degree of harmonics, the lower the current flows. This is the property of harmonics generated by inverters so that the inverters are covered by "The case not causing a special hazard" of the term 3.(3) in the above Appendix for the 9th or higher degrees of the harmonics.

Therefore, "It is sufficient that the 5th and 7th harmonic currents should be calculated."

[3] Examples of calculation

(1) Equivalent capacity

Example of loads	Input capacity and No. of inverters	Conversion factor	Equivalent capacity	
[Example (1)] 400 V, 3.7 kW,10 units w/- AC/DC reactor	4.61 kVA × 10 units	K32=1.4	4.61×10×1.4=64.54 kVA	
[Example (2)] 400 V, 1.5 kW, 15 units w/- AC reactor	2.93 kVA × 15 units	K34=1.8	2.93×15×1.8= 79.11 kVA	
	Refer to Table B-2.	Refer to Table B-3.		

(2) Harmonic current for every harmonic order

Example 1: 400 V, 3.7 kW, 10 units (w/- AC reactor), maximum availability factor: 0.55

6.6kV side fundamental current (mA)	Harmonic current onto 6.6 kV lines (mA)							
394 × 10= 3940	5th (38%)	7th (14.5%)	11th (7.4%)	13th (3.4%)	17th (3.2%)	19th (1.9%)	23th (1.7%)	25th (1.3%)
3940 × 0.55= 2167	823.5	314.2						
Refer to Table B-4 and Table B-6.				Refer to 1	able B-5.			

Example 2: 400 V, 3.7 kW, 15 units (w/- AC/DC reactor), maximum availability factor: 0.55

6.6kV side fundamental current (mA)	Harmonic current onto 6.6 kV lines (mA)							
394 × 15= 5910 5910 × 0.55= 3250.5	5th (28%)	7th (9.1%)	11th (7.2%)	13th (4.1%)	17th (3.2%)	19th (2.4%)	23th (1.6%)	25th (1.4%)
	910.1	295.8						
Refer to Table B-4 and Table B-6.				Refer to 7	Table B-5.			

Appendix C Effect on Insulation of General-purpose Motors Driven with 400 V Class Inverters

Excerpt from technical material of the Japan Electrical Manufacturers' Association (JEMA) (March 1995)

Preface

When an inverter drives a motor, surge voltages generated by switching the inverter elements are superimposed on the inverter output voltage and applied to the motor terminals. If the surge voltages are too high they may have an effect on the motor insulation and some cases have resulted in damage.

For preventing such cases this document describes the generating mechanism of the surge voltages and countermeasures against them.

Refer to "A.2 [1] Inverter noise" for details of the principle of inverter operation.

C.1 Generating mechanism of surge voltages

As the inverter rectifies a commercial power source voltage and smoothes into a DC voltage, the magnitude E of the DC voltage becomes about $\sqrt{2}$ times that of the source voltage (about 620 V in case of an input voltage of 440 VAC). The peak value of the output voltage is usually close to this DC voltage value.

But, as there exists inductance (L) and stray capacitance (C) in wiring between the inverter and the motor, the voltage variation due to switching the inverter elements causes a surge voltage originating in LC resonance and results in the addition of high voltage to the motor terminals. (Refer to Figure C-1)

This voltage sometimes reaches up to about twice that of the inverter DC voltage (620 V \times 2 = approximately 1,200 V) depending on a switching speed of the inverter elements and wiring conditions.



Figure C-1 Voltage Waveform of Individual Portions

A measured example in Figure C-2 illustrates the relation of a peak value of the motor terminal voltage with a wiring length between the inverter and the motor.

From this it can be confirmed that the peak value of the motor terminal voltage ascends as the wiring length increases and becomes saturated at about twice the inverter DC voltage.

The shorter a pulse rise time becomes, the higher the motor terminal voltage rises even in the case of a short wiring length.



Figure C-2 Measured Example of Wiring Length and Peak Value of Motor Terminal Voltage

C.2 Effect of surge voltages

The surge voltages originated in LC resonance of wiring may be applied to the motor terminals and depending on their magnitude sometimes cause damage to the motor insulation.

When the motor is driven with a 200 V class inverter, the dielectric strength of the insulation is no problem even the peak value at the motor terminal voltage increases twice due to the surge voltages (the DC voltage is only about 300 V).

But in case of a 400 V class inverter, the DC voltage is approximately 600 V and depending on the wiring length, the surge voltages may greatly increase and sometimes result in damage to the insulation.

C.3 Countermeasures against surge voltages

When driving a motor with a 400 V class inverter, the following are countermeasures against damage to the motor insulation by the surge voltages.

Using a surge suppressor unit, SSU (Patent pending) [1]

The surge suppressor unit (SSU) is a newly structured unit using circuits based on the impedance-matching theory of a transmission line. Just connecting the SSU to the surge suppressor cable of the existing equipment can greatly reduce the surge voltage that results in a motor dielectric breakdown.



For 50 m of wiring length: SSU 50TA-NS



For 100 m of wiring length: SSU 100TA-NS

[2] Suppressing surge voltages

There are two ways for suppressing the surge voltages, one is to reduce the voltage rise time and another is to reduce the voltage peak value.

Output reactor (1)

If wiring length is relatively short, the surge voltages can be suppressed by reducing the voltage rise time (dv/dt) with the installation of an AC reactor on the output side of the inverter. Refer to Figure C-3 (1).

However, if the wiring length becomes long, suppressing the peak voltage due to surge voltage may be difficult.

(2) Output filter

Installing a filter on the output side of the inverter allows the peak value of the motor terminal voltage to be reduced. Refer to Figure C-3 (2).



Figure C-3 Method to Suppress Surge Voltage

Tip

If the wiring length between the inverter and the motor is comparatively long, the crest value of the surge voltage can be suppressed by connecting a surge suppressor unit (SSU) to the motor terminal. For details, refer to Chapter 11 "11.12 Surge Suppression Unit (SSU)."

[3] Using motors with enhanced insulation

Enhanced insulation of a motor winding allows its surge withstanding to be improved.

C.4 Regarding existing equipment

[1] In case of a motor being driven with 400 V class inverter

A survey over the last five years on motor insulation damage due to the surge voltages originating from switching of inverter elements shows that the damage incidence is 0.013% under the surge voltage condition of over 1,100 V and most of the damage occurs several months after commissioning the inverter. Therefore there seems to be little probability of occurrence of motor insulation damage after a lapse of several months of commissioning.

[2] In case of an existing motor driven using a newly installed 400 V class inverter

We recommend suppressing the surge voltages with the methods shown in "C.3 Countermeasures against surge voltages".
Appendix D Inverter Generating Loss

The table below lists the inverter generating loss.

Power	la contante est	Carrier frequency (F	unctional code:F26)
system	Inverter type	Factory shipment value	Maximum set value
	FRN0002F2E-4G	32	56
	FRN0003F2E-4G	50	93
	FRN0005F2E-4G	69	120
	FRN0006F2E-4G	98	Note 2
	FRN0011F2E-4G	155	Note 2
	FRN0018F2E-4G	220	370
	FRN0023F2E-4G	330	510
	FRN0031F2E-4G	390	630
	FRN0038F2E-4G	410	750
	FRN0045F2E-4G	510	870
3-phase	FRN0060F2E-4G	710	1000
400 V	FRN0075F2E-4G	1000	1250
	FRN0091F2E-4G	1200	1550
	FRN0112F2E-4G	1300	1700
	FRN0150F2E-4G	1850	2300
	FRN0176F2E-4G	1950	2250
	FRN0210F2E-4G	2250	2550
	FRN0253F2E-4G	2700	3050
	FRN0304F2E-4G	3050	3400
	FRN0377F2E-4G	3900	4350
	FRN0415F2E-4G	4250	4750
	FRN0520F2E-4G	5500	6100

Note 1: The maximum set value (max. carrier) differs depending on specification. For details please refer to Chapter 5 "FUNCTION CODES" F26.

Note 2: When the inverters of FRN0006F2E-□ and FRN0011F2E-□ are operated at maximum carrier, reduce output to 60% of rated current. At that setting, generated losses will be at same level as the factory shipment value.

Unit: W

Appendix E Conversion from SI Units

All expressions given in Chapter 10 "SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES" are based on SI units (The International System of Units). This section explains how to convert expressions to other units.

E.1 **Conversion of units**

(1) Force

- 1 [kgf] ≈ 9.8 [N]
- 1 [N] ≈ 0.102 [kgf]

(2) Torque

- 1 [kgf•m] ≈ 9.8 [N•m]
- 1 [N•m] ≈ 0.102 [kgf•m]

(3) Power (energy)

• 1 [kgf•m] ≈ 9.8 [N•m] = 9.8 [J] = 9.8 [W•s]

(4) Power

- 1 [kgf•m/s] ≈ 9.8 [N•m/s] = 9.8 [J/s] = 9.8 [W]
- 1 $[N \cdot m/s] \approx 1 [J/s] = 1 [W] \approx 0.102 [kgf \cdot m/s]$

(5) Rotation speed

• 1 [min⁻¹] =
$$\frac{2\pi}{60}$$
 [rad/s] ≈ 0.1047 [rad/s]

• 1[rad/s] =
$$\frac{60}{2\pi}$$
 [min⁻¹] \approx 9.549[min⁻¹]

(6) Inertia constant

- $J [kg \cdot m^2]$: moment of inertia
- GD2 [kg•m²]: flywheel effect
- $GD^2 = 4J$

$$J = \frac{GD^2}{4}$$

(7) Pressure, stress

- 1 [mmAq] ≈ 9.8 [Pa] ≈9.8 [N/m²]
- 1 [Pa] ≈ 1 [N/m2] ≈ 0.102 [mmAq]
- 1 [bar] ≈ 100000 [Pa] ≈ 1.02 [kg•cm2]
- 1 [kg•cm²] ≈ 98000 [Pa] ≈ 980 [mbar]
- 1 barometric pressure
 - = 1013 [mbar] = 760 [mmHg]
 - = 101300 [Pa] ≈ 1.033 [kg/cm²]

E.2 Calculation formulas

(1) Torque, power, rotation speed

- $P[W] \approx \frac{2\pi}{60} \cdot N[min^{-1}] \cdot \tau[N \cdot m]$
- $P[W] \approx 1.026 \cdot N[min^{-1}] \cdot T[kgf \cdot m]$

•
$$\tau$$
 [N·m] \approx 9.55 · $\frac{P[W]}{N[min^{-1}]}$

• T [kgf·m]
$$\approx 0.974 \cdot \frac{P[W]}{N[min^{-1}]}$$

(2) Kinetic energy

•
$$E[J] \approx \frac{1}{1824} \cdot J[kg \cdot m^2] \cdot N^2[(min^{-1})^2]$$

• $E[J] \approx \frac{1}{730} \cdot GD^2[kg \cdot m^2] \cdot N^2[(min^{-1})^2]$

(3) Linear motion load torque

[Driving mode]

•
$$\tau [N \cdot m] \approx 0.159 \cdot \frac{V [m/min]}{N_{M} [min^{-1}] \cdot \eta_{G}} \cdot F[N]$$

•
$$T [kgf \cdot m] \approx 0.159 \cdot \frac{V [m/min]}{N_M [min^{-1}] \cdot \eta_G} \cdot F [kgf]$$

[Braking mode]

•
$$\tau$$
 [N·m] \approx 0.159· $\frac{V$ [m/min]}{N_{M} [min⁻¹]/ η_{G} ·F [N]

•
$$T [kgf \cdot m] \approx 0.159 \cdot \frac{V [m/min]}{N_{M} [min^{-1}]/\eta_{G}} \cdot F [kgf]$$

(4) Acceleration torque

[Driving mode]

•
$$\tau[N \cdot m] \approx \frac{J[kg \cdot m^2]}{9.55} \cdot \frac{\Delta N[min^{-1}]}{\Delta t[s] \cdot \eta_G}$$

• T [kgf·m]
$$\approx \frac{\text{GD}^2 [\text{kg·m}^2]}{375} \cdot \frac{\Delta \text{N}[\text{min}^{-1}]}{\Delta t [\text{s}] \cdot \eta_{\text{G}}}$$

[Braking mode]

•
$$\tau$$
 [N·m] $\approx \frac{J[kg \cdot m^2]}{9.55} \cdot \frac{\Delta N[min^{-1}] \cdot \eta_G}{\Delta t [s]}$

•
$$T [kgf \cdot m] \approx \frac{GD^2 [kg \cdot m^2]}{375} \cdot \frac{\Delta N [min^{-1}] \cdot \eta_G}{\Delta t [s]}$$

(5) Acceleration time

•
$$t_{ACC}[s] \approx \frac{J_1 + J_2/\eta_G [kg \cdot m^2]}{\tau_M - \tau_L/\eta_G [N \cdot m]} \cdot \frac{\Delta N[min^{-1}]}{9.55}$$

•
$$t_{ACC}[s] \approx \frac{GD_1^2 + GD_2^2/\eta_G[kg \cdot m^2]}{T_M - T_L/\eta_G[kgf \cdot m]} \cdot \frac{\Delta N[min^{-1}]}{375}$$

(6) Deceleration time

•
$$t_{\text{DEC}}[s] \approx \frac{J_1 + J_2 \cdot \eta_G [\text{kg} \cdot \text{m}^2]}{\tau_M - \tau_L \cdot \eta_G [\text{N} \cdot \text{m}]} \cdot \frac{\Delta N[\text{min}^{-1}]}{9.55}$$

•
$$t_{\text{DEC}}[s] \approx \frac{GD_1^2 + GD_2^2 \cdot \eta_G [\text{kg} \cdot \text{m}^2]}{T_M - T_L \cdot \eta_G [\text{kgf} \cdot \text{m}]} \cdot \frac{\Delta N[\text{min}^{-1}]}{375}$$

Appendix F Allowable Current of Insulated Wires

The tables below list the allowable current of IV wires, HIV wires, and 600 V cross-linked polyethylene insulated wires.

	Allowable current		Wiring in free air				(up t	Wiring in o three wires	wire duct in the same	duct)
Wire size	Reference value	35 °C	40 °C	45 °C	50 °C	55 °C	35 °C	40 °C	45 °C	50 °C
(mm²)	(30°C or less)	(lox0.91)	(lox0.82)	(lox0.71)	(lox0.58)	(lox0.40)	(lox0.63)	(lox0.57)	(lox0.49)	(lox0.40)
	lo (A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)
2.0	27	24	22	19	15	11	17	15	13	10
3.5	37	33	30	26	21	15	23	21	18	14
5.5	49	44	40	34	28	20	30	27	24	19
8.0	61	55	50	43	35	25	38	34	29	24
14	88	80	72	62	51	36	55	50	43	35
22	115	104	94	81	66	47	72	65	56	46
38	162	147	132	115	93	66	102	92	79	64
60	217	197	177	154	125	88	136	123	106	86
100	298	271	244	211	172	122	187	169	146	119
150	395	359	323	280	229	161	248	225	193	158
200	469	426	384	332	272	192	295	267	229	187
250	556	505	455	394	322	227	350	316	272	222
325	650	591	533	461	377	266	409	370	318	260
400	745	677	610	528	432	305	469	424	365	298
500	842	766	690	597	488	345	530	479	412	336
2 × 100	497	452	407	352	288	203	313	283	243	198
2 × 150	658	598	539	467	381	269	414	375	322	263
2 × 200	782	711	641	555	453	320	492	445	383	312
2 × 250	927	843	760	658	537	380	584	528	454	370
2 × 325	1083	985	888	768	628	444	682	617	530	433
2 × 400	1242	1130	1018	881	720	509	782	707	608	496
2 × 500	1403	1276	1150	996	813	575	883	799	687	561

■ IV wire (Maximum allowable temperature: 60 °C (140 °F))

Table F-1 (a) Allowable Current of Insulated Wires

■ HIV wire (Maximum allowable temperature: 75°C (167°F))

Table F-1 (b)	Allowable Current of Insulated Wires

	Allowable current	Wiring in free air			Wiring in wire duct (up to three wires in the same duct)			duct)		
Wire size	Reference value	35 °C	40 °C	45 °C	50 °C	55 °C	35 °C	40 °C	45 °C	50 °C
(mm²)	(30°C or less)	(lox0.91)	(lox0.82)	(lox0.71)	(lox0.58)	(lox0.40)	(lox0.63)	(lox0.57)	(lox0.49)	(lox0.40)
	lo (A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)
2.0	32	31	29	27	24	22	21	20	18	17
3.5	45	42	39	37	33	30	29	27	25	23
5.5	59	56	52	49	44	40	39	36	34	30
8.0	74	70	65	61	55	50	48	45	42	38
14	107	101	95	88	80	72	70	66	61	55
22	140	132	124	115	104	94	92	86	80	72
38	197	186	174	162	147	132	129	121	113	102
60	264	249	234	217	197	177	173	162	151	136
100	363	342	321	298	271	244	238	223	208	187
150	481	454	426	395	359	323	316	296	276	248
200	572	539	506	469	426	384	375	351	328	295
250	678	639	600	556	505	455	444	417	389	350
325	793	747	702	650	591	533	520	487	455	409
400	908	856	804	745	677	610	596	558	521	469
500	1027	968	909	842	766	690	673	631	589	530
2 × 100	606	571	536	497	452	407	397	372	347	313
2 × 150	802	756	710	658	598	539	526	493	460	414
2 × 200	954	899	844	782	711	641	625	586	547	492
2 × 250	1130	1066	1001	927	843	760	741	695	648	584
2 × 325	1321	1245	1169	1083	985	888	866	812	758	682
2 × 400	1515	1428	1341	1242	1130	1018	993	931	869	782
2 × 500	1711	1613	1515	1403	1276	1150	1122	1052	982	883

■ 600 V crosslinkable polyethylene insulated wire (Maximum allowable temperature: 90 °C (194 °F))

	Allowable current	Wiring in free air			Wiring in wire duct (up to three wires in the same duct)			duct)		
Wire size	Reference value	35 °C	40 °C	45 °C	50 °C	55 °C	35 °C	40 °C	45 °C	50 °C
(mm²)	(30°C or less)	(lox0.91)	(lo×0.82)	(lox0.71)	(lo×0.58)	(lo×0.40)	(lo×0.63)	(lo×0.57)	(lox0.49)	(lox0.40)
	lo (A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)	(A)
2.0	38	36	34	32	31	29	25	24	22	21
3.5	52	49	47	45	42	39	34	33	31	29
5.5	69	66	63	59	56	52	46	44	41	39
8.0	86	82	78	74	70	65	57	54	51	48
14	124	118	113	107	101	95	82	79	74	70
22	162	155	148	140	132	124	108	103	97	92
38	228	218	208	197	186	174	152	145	137	129
60	305	292	279	264	249	234	203	195	184	173
100	420	402	384	363	342	321	280	268	253	238
150	556	533	509	481	454	426	371	355	335	316
200	661	633	605	572	539	506	440	422	398	375
250	783	750	717	678	639	600	522	500	472	444
325	916	877	838	793	747	702	611	585	552	520
400	1050	1005	961	908	856	804	700	670	633	596
500	1187	1136	1086	1027	968	909	791	757	715	673
2 × 100	700	670	641	606	571	536	467	447	422	397
2 × 150	927	888	848	802	756	710	618	592	559	526
2 × 200	1102	1055	1008	954	899	844	735	703	664	625
2 × 250	1307	1251	1195	1130	1066	1001	871	834	787	741
2 × 325	1527	1462	1397	1321	1245	1169	1018	974	920	866
2 × 400	1751	1676	1602	1515	1428	1341	1167	1117	1055	993
2 × 500	1978	1894	1809	1711	1613	1515	1318	1262	1192	1122

Table F-1 (c) Allowable Current of Insulated Wires

Appendix G Conformity with Standards

G.1 Compliance with European Standards ($\zeta \in$)

The CE marking on Fuji products indicates that they comply with the essential requirements of the Electromagnetic Compatibility (EMC) Directive 2004/108/EC, Low Voltage Directive 2006/95/EC, and Machinery Directive 2006/42/EC which are issued by the Council of the European Communities.

			Standards
	IEC/EN61800-3	: 2	2004/A1 : 2012
	Immunity	: \$	Second environment (Industrial)
	Emission	: -	Type of FRN0011F2E-4 \Box or below : Category C2
EMC Directives		((Radiated emission : With Ferritecore at the input wiring)
		-	Type of FRN0018F2E-4 \Box or above : Category C3
	IEC/EN61326-3-1	: 2	2008
Low Voltage Directive	IEC/EN61800-5-1	: 2	2007

Table G-1	Conformity with	Standards
	1	

CAUTION

The EMC filter built-in type of the FRENIC-eHVAC inverters is categorized as "Category C3" of the EN61800-3. It is not designed for use in a domestic environment. It may interfere with the operations of home appliances or office equipment due to noise emitted from it.

[1] Compliance with EMC standards

The CE marking on inverters does not ensure that the entire equipment including our CE-marked products is compliant with the EMC Directive. Therefore, CE marking for the equipment shall be the responsibility of the equipment manufacturer. For this reason, Fuji's CE mark is indicated under the condition that the product shall be used within equipment meeting all requirements for the relevant Directives. Instrumentation of such equipment shall be the responsibility of the equipment manufacturer.

Generally, machinery or equipment includes not only our products but other devices as well. Manufacturers, therefore, shall design the whole system to be compliant with the relevant Directives.

Mount inverters in accordance with the installation procedure given below. To ensure the compliance, it is recommended to mount the inverters in a metal panel.



Our EMC compliance test is performed under the following conditions.

Wiring length (of the shielded cable) between the inverter (EMC filter built-in type) and motor: 10m

Note To use Fuji inverters in combination with a PWM converter, the basic type of inverters having no built-in EMC filter should be used. Use of an EMC filter built-in type may increase heat of capacitors in the inverter, resulting in damage. In addition, the effect of the EMC filter can no longer be expected.

Recommended installation procedure

To make the machinery or equipment fully compliant with the EMC Directive, certified technicians should wire the motor and inverter in strict accordance with the procedure described below.

In case of EMC filter built-in type inverter

- (1) Mount the inverter and the filter on a grounded panel or metal plate. Use shielded wires for the motor cable and route the cable as short as possible. Firmly clamp the shields to the metal plate to ground them. Further, connect the shielding layers electrically to the grounding terminal of the motor.
- (2) For connection to inverter's control terminals and for connection of the RS-485 communication signal cable, use shielded wires. As with the motor connections, clamp the shields firmly to a grounded panel.
- (3) If noise from the inverter exceeds the permissible level, enclose the inverter and its peripherals within a metal panel as shown in Figure G-1.





■ Leakage current of EMC-filter built-in type of inverters

An EMC filter uses grounding capacitors for noise suppression which increase leakage current. When using an EMC-filter built-in type of inverters, therefore, check whether there is no problem with electrical systems.

<u>Three-Phase PDS (Power Drive System) with touch currents \geq 3.5 mA AC or \geq 10 mA DC</u>

As the touch current (leakage current) of inverters with EMC-filter is relatively high, it is of essential importance to always assure a reliable connection to Protective Earth (PE).

In Table G-3, for the inverter types whose leakage currents are equal to or exceed the critical value of 3.5 mA AC or 10 mA DC (IEC 61800-5-1), the minimum cross sectional area of the PE-conductor should be:

- 10 mm² (Cu-conductors)
- 16 mm² (Al-conductors)

An electric shock could occur.

Power supply voltage	Inverter type	Leakage current (mA)
	FRN0002F2E-4	2.3 *1)
	FRN0004F2E-4	2.3 *1)
	FRN0006F2E-4	5.5 *1)
	FRN0007F2E-4	5.5 *1)
	FRN0012F2E-4	5.5 *1)
	FRN0022F2E-4	9.6 *1)
	FRN0029F2E-4	9.6 *1)
	FRN0037F2E-4	18.5 *1)
	FRN0044F2E-4	18.5 *1)
	FRN0059F2E-4	4
Three-phase 400 V *1)	FRN0072F2E-4	4
	FRN0085F2E-4	
	FRN0105F2E-4	11
	FRN0139F2E-4	
	FRN0168F2E-4	
	FRN0203F2E-4	
	FRN0290F2E-4	
	FRN0361F2E-4	5
	FRN0415F2E-4	
	FRN0520F2E-4	
	FRN0590F2E-4	

Table G-2 Leakage Current of EMC Filter Built-in Type of Inverters

*1) Calculated based on these measuring conditions: 400 V/ 60 Hz, neutral grounding in Y-connection, interphase voltage unbalance ratio 2%.

[2] Compliance with the low voltage directive in the EU

General-purpose inverters are regulated by the Low Voltage Directive in the EU. Fuji Electric states that all our inverters with CE marking are compliant with the Low Voltage Directive.

Note

If installed according to the guidelines given below, inverters marked with CE are considered as compliant with the Low Voltage Directive 2006/95/EC.

Compliance with European Standards

Adjustable speed electrical power drive systems. Part 5-1: Safety requirements. Electrical, thermal and energy. IEC/EN61800-5-1: 2007

${\mathbin{\rm label{eq:marginal} WARNING}}{\mathbin{\rm label{eq:marginal} A}}$

- 1. The ground terminal 🖨 G should always be connected to the ground. Do not use only a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB)* as the sole method of electric shock protection. Be sure to use ground wires whose size is greater than power supply lines. *With overcurrent protection.
- 2. To prevent the risk of hazardous accidents that could be caused by damage of the inverter, install the specified fuses in the supply side (primary side) according to the following tables.
 Breaking capacity: Min. 10 kA Rated voltage: Min. 500 V

Power supply voltage	Nominal applied motor (kW)	Inverter type	Fuse rating (A)
	0.75	FRN0002F2E-4G	6(IEC60269-2)
	1.1	FRN0003F2E-4G	10(IEC60269-2)
	2.2	FRN0005F2E-4G	15(IEC60269-2)
	3.0	FRN0006F2E-4G	20(IEC60269-2)
	5.5	FRN0011F2E-4G	30(IEC60269-4)
	7.5	FRN0018F2E-4G	80(IEC60269-4)
	11	FRN0023F2E-4G	80(IEC60269-4)
	15	FRN0031F2E-4G	125(IEC60269-4)
	18.5	FRN0038F2E-4G	160(IEC60269-4)
	22	FRN0045F2E-4G	160(IEC60269-4)
Three phase 400 V	30	FRN0060F2E-4G	160(IEC60269-4)
·	37	FRN0075F2E-4G	250(IEC60269-4)
	45	FRN0091F2E-4G	315(IEC60269-4)
	55	FRN0112F2E-4G	315(IEC60269-4)
	75	FRN0150F2E-4G	350(IEC60269-4)
	90	FRN0176F2E-4G	350(IEC60269-4)
	110	FRN0210F2E-4G	350(IEC60269-4)
	132	FRN0253F2E-4G	400(IEC60269-4)
	160	FRN0304F2E-4G	450(IEC60269-4)
	200	FRN0377F2E-4G	500(IEC60269-4)
	220	FRN0415F2E-4G	550(IEC60269-4)
	280	FRN0520F2E-4G	630(IEC60269-4)



 When used with the inverter, a molded case circuit breaker (MCCB), residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) or magnetic contactor (MC) should conform to the EN or IEC standards.

MWARN	IING A
--------------	---------------

4. When you use a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) for protection from electric shock in direct or indirect contact power lines or nodes, be sure to install type B of RCD/ELCB on the input (primary) of the inverter.

Power supply	Nominal applied	Inverter type	MCCB or RCD/ELCB *1 Rated current		
voltage	(kW)	inverter type	W/DCR	W/o DCR	
	0.75	FRN0002F2E-4G	5	5	
	1.1	FRN0003F2E-4G	5	5	
	2.2	FRN0005F2E-4G	5	10	
	3.0	FRN0006F2E-4G	10	15	
	5.5	FRN0011F2E-4G	15	30	
	7.5	FRN0018F2E-4G	20	40	
	11	FRN0023F2E-4G	30	50	
	15	FRN0031F2E-4G	40	60	
	18.5	FRN0038F2E-4G	40	75	
Three phase	22	FRN0045F2E-4G	50	100	
400 V	30	FRN0060F2E-4G	75	125	
	37	FRN0075F2E-4G	100	125	
	45	FRN0091F2E-4G	100	150	
	55	FRN0112F2E-4G	125	200	
	75	FRN0150F2E-4G	175	-	
	90	FRN0176F2E-4G	200	=	
	110	FRN0210F2E-4G	250	=	
	132	FRN0253F2E-4G	300	-	
	160	FRN0304F2E-4G	350	-	
	200	FRN0377F2E-4G	500	-	
	220	FRN0415F2E-4G	500	-	
	280	FRN0520F2E-4G	600	-	

- *1 The frame size and model of the MCCB or RCD/ELCB (with overcurrent protection) will vary, depending on the power transformer capacity. Refer to the related technical documentation for details.
- 5. The inverter should be used in an environment that does not exceed Pollution Degree 2 requirements. If the environment has a Pollution Degree 3 or 4, install the inverter in an enclosure of IP54 or higher.
- 6. Install the inverter, AC or DC reactor, input or output filter in an enclosure with minimum degree of protection of IP2X (Top surface of enclosure shall be minimum IP4X when it can be easily accessed), to prevent human body from touching directly to live parts of these equipment.
- 7. Do not connect any copper wire directly to grounding terminals. Use crimp terminals with tin or equivalent plating to connect them.
- 8. When you use an inverter at an altitude of more than 2000 m, you should apply basic insulation for the control circuits of the inverter. The inverter cannot be used at altitudes of more than 3000 m.



G.2 Compliance with UL Standards and Canadian Standards (cUL certification) (((())) ((())) (())) (()) (())) (()) (())) (()) (()) (()) (())) (()) (())) (()) (())) (()) (()) (())) (()) (()) (())) (()) (()) (())) (()) (())) (()) (()) (())) (()) (()) (())) (()) (())) (()) (()) (()) (())) (()) (()) (()) (())) (()) (()) (()) (()) (()) (()) (()) (()) (())) (()

Originally, the UL standards were established by Underwriters Laboratories, Inc. as private criteria for inspections/investigations pertaining to fire/accident insurance in the USA. Later, these standards were authorized as the official standards to protect operators, service personnel and the general populace from fires and other accidents in the USA.

cUL certification means that UL has given certification for products to clear CSA Standards. cUL certified products are equivalent to those compliant with CSA Standards.

Notes

UL/cUL-listed inverters are subject to the regulations set forth by the UL standards and CSA standards (cUL-listed for Canada) by installation within precautions listed below.



2. Use Cu wire only.

3. Use Class 1 wire only for control circuits.

4. Short circuit rating

For Models FRN0002 to 0038F2E-4G:

"Suitable For Use On A Circuit Of Delivering Not More Than 100,000 rms Symmetrical Amperes, 480 Volts Maximum when protected by Class J or Class CC Fuses."

For Models FRN0045F2E-4G or above:

"Suitable For Use On A Circuit Of Delivering Not More Than 100,000 rms Symmetrical Amperes, 480 Volts Maximum when protected by Class J or Class CC Fuses or a Circuit Breaker Having An Interrupting Rating Not Less Than 100,000 rms Symmetrical Amperes, 480 Volts minimum."

- 5. Field wiring connections must be made by a UL Listed and CSA Certified closed-loop terminal connector sized for the wire gauge involved. Connector must be fixed using the crimp tool specified by the connector manufacturer.
- 6. All circuits with terminals L1/R, L2/S, L3/T, R0, T0, R1, T1 must have a common disconnect and be connected to the same pole of the disconnect if the terminals are connected to the power supply.

Connection diagram of the three phase input type.



			∆CA	UTION					
7. Envi	ronmental Re	equirements							
7.1	Type FRN001	18F2E-4G or abov	/e						
• M T	laximum Suri he ambient te	rounding Air Temp emperature shall t	erature / Maxim be lower than the	um ambient temperature e values in the table below.					
	Open Type 50 deg C								
	Enclosed Type 40 deg C								
• A F	tmosphere or use in poll	ution degree 2 en	vironments (for	Open-Type models).					
7.2	Type FRN001	11F2E-4G or belov	N						
• M T	laximum Suri he surroundii	rounding Air Temp ng air temperature	erature e shall be lower	than the values in the table below.					
		Op FRN0011F	en Type 2E-4G or below	50 deg C					
• A F	tmosphere or use in poll	ution degree 2 en	vironments (for	Open-Type models).	_				
8. UL E UL E	Enclosure Typ Enclosed Typ	be e formats are sho	wn in the table t	pelow.					
	Va	ariation		Enclosed Type1					
	St	tandard		FRNDDDDF2F-4C					
9. Plen UL FRN	other models num rated driv Enclosed Ty 10011F2E-4G	s of above table an ves vpe is Suitable f or below are exc ription of Control (e excluded. or installation i luded.	n a compartment handling condit	tioned air. Models of				
A p ove	ower source rvoltage cate	e for connection egory II such as co	to the Integrate	ed alarm output (30A, 30B, 30C) econdary winding of power transforr	should be limited to mer.				
Cla	assification	Terminal Symbol	Terminal Name	Functional description					
Co	ntact output	[30A/B/C]	Integrated alarm output	When the inverter stops with an alarm, the relay contact (1C).	output is generated on				
	Contact capacitance: AC250 V 0.3A cosφ=1, DC30 V 0.5 A								

- All models rated 380-480 V input voltage ratings shall be connected to TN-C system power source, i.e. 3-phase, 4-wire, wye (480Y/277V), so that the phase-to-ground rated system voltage is limited to 300V maximum.
- 12. Install UL certified fuses or circuit breaker between the power supply and the inverter, referring to the table below.

	Nominal applied motor	Inverter type	Class J or CC fuse size(A) *4	Circuit breaker trip size (A) *5	Required torque lb-in (N • m)			Wire size AWG (mm ²)									
Power supply voltage					Main terminal	Inverter's grounding	Aux. control power supply	Aux. Fan power supply	Main terminal Cu Wire						۸		
									L1/R,L2/S,L3/T			ι	U, V, W			ldns Je	liddns
									60°C Cu wire	75°C Cu wire	Remarks	60°C Cu wire	75°C Cu wire	Remarks	Inverter's grounding	Aux. control powe	Aux. fan power
se 400 V	0.75	FRN0002F2E-4G	6	-	10.6 (1.2)	15.9 (1.8)		10.6 (1.2)	-				14		14		
	1.1	FRN0003F2E-4G	10							14	14				(2.1)		
	2.2	FRN0005F2E-4G	15							(2.1)		(2.1)		12			
	3.0	FRN0006F2E-4G	20								10 (5.3) 8 (8.4)			-	(3.3)	-	_
	7.5	FRN0011F2E-4G	40		27 (3.0)	27 (3.0)				10			12		10 (5.3)		
	11	ERN0023E2E-4G	60							(5.3)			(3.3)		9		
	45		70							(8.4)			(5.3)		(8.4)		
	18.5	FRN0031F2E-4G	90	75	51.3 (5.8)	51.3 (5.8)	10.6 (1.2)		6			8	8	- *3			
	22	FRN0045F2E-4G	100	100					(13.3)) 6 (13.3)	<u> </u>	(8.4) 6	(8.4)		6 (13.3)	14 (2.1) *1 *2	
	30	FRN0060F2E-4G	125						(21.2)	4	*3	(13.3)	6				
	37	FRN0075F2F-4G	175	125	119.4 (13.5)	9.4 3.5) 119.4 (13.5) 8.9 (7)			2	3		3	(13.3)				
	<u> </u>								(33.6)	(26.7)		(26.7)	(21.2)				
-pha	45	FRN0091F2E-4G	200	150					_	2 (33.6)	*2 *3	(33.6)	3 (26.7)	*2 *3			
Three	55	FRN0112F2E-4G	250	200 175						1/0			2 (33.6)		4		
	75	FRN0150F2E-4G	200]					(53.5)			1/0 (53.5)		(21.2)		
	90	FRN0176F2E-4G	300	200	238.9 (27)					2/0 (67.4)			3/0				14 (2.1) *1 *2
	110	FRN0210F2E-4G								4/0			1/0x2		3		
	132	FRN0253F2E-4G								1/0x2			2/0x2		(20.7)		
	160	FRN0304F2E-4G			424.7 (48)	238.9 (27)				(33.5x2) 3/0x2			(07.4x2) 3/0x2		2		
	200	FRN0377F2E-4G								(85x2) 4/0x2			(85x2) 250x2		(33.6)		
	220	FRN0415F2E-4G								(107.2x2) 250x2			(127x2) 300x2		1/0 (53.5)		
	280	FRN0520F2E-4G								(127x2) 400x2 (202x2)			(152x2) 400x2		2/0		

Note: Control circuit terminals M2 tightening torque: 1.7 lb-in (0.19 N·m) ±10% Recommended wire size: AWG26 to 18 (0.14 to 1 mm²) M3 tightening torque: 4.4 to 5.3 lb-in (0.5 to 0.6 N·m), recommended wire size: AWG26 to 16 (0.14 to 1.5 mm²)

- *1 No terminal end treatment is required for connection.
- *2 Use 75°C (167°F) Cu wire only.
- *3 The wire size of UL Open Type and Enclosed Type are common. Please contact us if UL Open Type exclusive wire is necessary.
- *4 6 rms Amperes for aux. control power supply. There is no aux. control power supply in FRN0018F2E-4G or below.
- *5 5 rms Amperes for aux. control power supply. There is no aux. control power supply in FRN0018F2E-4G or below.

Appendix H Compliance with Management Methods for Controlling Pollution Caused by Electronic Information Products Regulation (China RoHS)

This inverter contains hazardous substances specified by the Management Methods for Controlling Pollution Caused by Electronic Information Products Regulation (China RoHS). Act appropriately at the time of disposing of the inverter.

		Hazardous substances or elements									
Capacity range	Part	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ether (PBDE)				
	IGBT module	×	0	0	0	0	0				
	Printed circuit board	×	0	0	0	0	0				
	Plastic case	×	0	0	0	0	0				
FRN0011 to	Cooling fin	×	0	0	0	0	0				
0060F2E-4G	Cooling fan	×	0	0	0	0	0				
	Sheet metal/Screw	×	0	0	0	0	0				
	Electrolytic capacitor	×	0	0	0	0	0				
	Diode module	×	0	0	0	0	0				
	IGBT module	×	0	0	0	0	0				
	Diode module	×	0	0	0	0	0				
	Printed circuit board	×	0	0	0	0	0				
	Plastic case	×	0	0	0	0	0				
FRN0075 to	Cooling fin	×	0	0	0	0	0				
0520F2E-4G	Cooling fan	×	0	0	0	0	0				
	Sheet metal/Screw	×	0	0	0	0	0				
	Copper bar	×	0	0	0	0	0				
	Wires and wiring	×	0	0	0	0	0				
	Electrolytic capacitor	×	0	0	0	0	0				

 Table H-1
 Names and contents of hazardous substances or elements

○ : Indicates that the toxic and hazardous substances contained in all the homogeneous materials of the part are less than the limits set by SJ/T 11363-2006.

× : Indicates that the toxic and hazardous substances contained in at least one type of homogeneous material of the part is in excess of the limits set by SJ/T 11363-2006.

Expiration period of environmental protection:

The specification sheet specifies that an expiration period of environmental protection is 10 years if the product operates normally in an appropriate environment with no leakage of the above toxic hazardous substances.

FRENIC-eHVAC

User's Manual

First Edition, June 2015

Fuji Electric Co., Ltd.

The purpose of this User's manual is to provide accurate information on handling, setting up and operation of the FRENIC-eHVAC series of inverters. Please feel free to send your comments regarding any errors or omissions you may have found, or any suggestions you may have for generally improving this manual.

In no event will Fuji Electric Co., Ltd. be liable for any direct or indirect damages resulting from the application of the information in this manual.







CSE-Uniserve has sales & engineering offices in 4 locations across Australia – Sydney, Melbourne, Perth & Brisbane.

INDUSTRIAL & MINING ENQUIRIES Tel: 1800 987 616 Email: industrial@cse-uniserve.com.au GENERATION, TRANSMISSION & DISTRIBUTION ENQUIRIES Tel: 03 9245 1700 Email: energy@cse-uniserve.com.au



